# भारतीय रेल Indian Railways

पटियाला रेलइंजन कारख़ाना, पटियाला

# PATIALA LOCOMOTIVE WORKS, PATIALA



LOCO TESTING & DISPATCH REPORT OF IGBT BASED wAg9hc ELECTRIC LOCOMOTIVE

LOCO NO.: 42014

TYPE: WAG9HC

Rail way shed: nfR/ml dd

ProPulsion system: alstom

Date of Dispatch: 27.01.2025

लोको निर्माण रिकार्ड



# पटियाला रेलइंजन कारख़ाना, पटियाला PATIALA LOCOMOTIVE WORKS, PATIALA

LOCO NO.: 42014

RAILWAY/SHED: NFR/MLDD

**DOD: Jan-2025** 

#### **INDEX**

SN	PARA	ACTIVITIES	PAGE NO.		
Testing & Commissioning (ECS)					
1.	1.0	Continuity Test of the cables			
	1.1	Continuity Test of Traction Circuit Cables			
	1.2	Continuity Test of Auxiliary Circuit Cables	1-4		
	1.3	Continuity Test of Battery Circuit Cables			
	1.4	Continuity Test of Screened Control Circuit Cables			
2.	2.0	Low Tension test			
	2.1	Measurement of resistor in OHMS ( $\Omega$ )	5-6		
	2.2	Check Points			
	2.3	Low Tension Test Battery Circuits (without control electronics)			
3	3.0	Downloading of Software			
	3.1	Check Points			
	3.2	Download Software	7-10		
	3.3	Analogue Signal Checking			
	3.4	Functional test in simulation mode			
4	4.0	Sensor test & convertor test			
	4.1	Test wiring Transformer Circuits – Polarity Test			
	4.2	Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)			
	4.3	Primary Voltage Transformer			
	4.4	Minimum voltage relay (Pos. 86)	11-16		
	4.5	Maximum current relay (Pos. 78)	77.70		
	4.6	Test current sensors			
	4.7	Test DC Link Voltage Sensors (Pos 15.6/*)			
	4.8	Verification of Converter Protection Circuits (Hardware limits)			
	4.9	Sequence of BUR contactors			
5.	5.0	Commissioning with High Voltage			
	5.1	Check List			
	5.2	Safety test main circuit breaker			
	5.3 5.3.1	Auxiliary Converter Commissioning			
	5.3.1 5.3.2	Running test of 3 ph. auxiliary equipments			
	5.3.2 5.3.3	Performance of Auxiliary Converters Performance of BURs when one BUR goes out	16-25		
	5.3.3 5.4	Auxiliary circuit 415/110	10-25		
	5.4 5.5	Hotel Load Circuit			
	5.6	Traction Converter Commissioning			
	5.7	Test protective shutdown SR			
	5.8	Test Harmonic Filter			
	5.9	Test important components of the locomotive			
6.	6.0	Running Trial of the locomotive	25-26		
7.	7.0	Final Check List to be verified at the time of Loco dispatch	27		
8.	8.0	Status of RDSO modifications	28		
9.	1-10	Pneumatic Test Parameters	29 - 32		
10.		Loco Check Sheet(LAS)	33		
11.	-	Component History (LAS,ECS,ABS)	34-36		
12.	-	Component History & Testing Parameter (Bogie Shop)	37 - 38		
13	-	Warranty Conditions as per Tenders	39 -41		

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 42014 - 6411.0 Continuity Test of the cables

Type of Locomotive: WAP-7/WAG-9HC

Page: 1 of 27

1.1 Continuity Test of Traction Circuit Cables

As per cable list given in Para 1.3 of document no. 3 EHX 410 124, check the continuity with continuity tester and megger each cable to be connected between following equipment with 1000V megger.

From	То	Continuity (OK/Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Filter Cubicle	Transformer	ok	100 ΜΩ	550ma
Filter Cubicle	Terminal Box of Harmonic Filter Resistor (Roof)	oK	100 ΜΩ	booma
Filter Cubicle	Earthing Choke	OK	100 ΜΩ	bsom1.
Earthing Choke	Earth Return Brushes	OK	100 ΜΩ	600MA
Transformer	Power Converter 1	øK	100 ΜΩ	ssoma
Transformer	Power Converter 2	OK	100 ΜΩ	800mn
Power Converter 1	TM1, TM2, TM3	ok	100 ΜΩ	700m1
Power Converter 2	TM4, TM5, TM6	oK	100 ΜΩ	<b>bsom</b> ()
Earth .	Power Converter 1	ok	100 MΩ	700m()
Earth	Power Converter 2	OK	100 ΜΩ ·	800mn

#### 1.2 Continuity Test of Auxiliary Circuit Cables

As per cable list given in Para 1.4 of document no. 3 EHX 410 124, check the continuity with continuity meter and megger each cable to be connected between following equipment with the help of 1000V megger.

Signature of the JE/SSE/Harness

Signature of the JE/SSE/Loco Cabling

Effective Date: Feb 2022

# PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

**Locomotive No.:** 

Type of Locomotive: WAP-7/WAG-9HC

Page: 2 of 27

(Ref: WI/ECS/10)

From	То	Continuity(OK/ Not OK)	Prescribed Megger Value (min)	Measured Megger Value
		OL	100 ΜΩ	900 Mr
Transformer	BUR1	on	100 MΩ	booms
Transformer	BUR2 BUR3	oh_	100 MΩ	TOOM
Transformer		8K	100 ΜΩ	Gooma
Earth	BUR1 BUR2	oh	100 ΜΩ	com
Earth		on	100 ΜΩ	600 m/c
Earth	BUR3	on	100 MΩ	700 mm
BUR1	HB1	Sh.	100 ΜΩ	TOD MA
BUR2	HB2		100 ΜΩ	GODMA
HB1	HB2 <sup>e<sup>e</sup></sup>	01/4	100 ΜΩ	
HB1	TM Blower 1	5h	100 ΜΩ	ROOMA
HB1	TM Scavenge Blower 1	oh		600 m/
HB1	Oil Cooling Unit 1	oh	100 ΜΩ	400 m
HB1	Compressor 1	oh	100 ΜΩ	900 m
HB1	TFP Oil Pump 1	Ohi	100 MΩ	600 m
HB1	Converter Coolant Pump 1	oh	100 MΩ	700 m
HB1	MR Blower 1	oh	100 ΜΩ	800 m/
HB1	MR Scavenge Blower 1	٥'n	100 MΩ	GOD MY
HB1	Cab1	on_	100 MΩ	GOOM
Cab1	Cab Heater 1	6/L	100 MΩ	700 m
HB2	TM Blower 2	ole_	100 ΜΩ	800 mr
HB2	TM Scavenge Blower 2 •	or	100 ΜΩ	600 m/
HB2	Oil Cooling Unit 2	Ole_	100 ΜΩ	Jeo MI
HB2	Compressor 2	OL	100 ΜΩ	600 m
HB2	TFP Øil Pump 2	الع	100 MΩ	-100 M
HB2	Converter Coolant Pump 2		100 ΜΩ	900m
HB2 ,	MR Blower 2	oh	100 MΩ	GOD MA
HB2	MR Scavenge Blower 2	OK	100 ΜΩ	JUD PM
HB2	Cab2	ok	100 ΜΩ	800 m
Cab2	Cab Heater 2	OK	100 MΩ	600 m/

(Ref: WI/ECS/10) Effective Date: Feb 2022

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 420/4

Type of Locomotive: WAP-7/WAG-9HC

Page: 3 of 27

1.3 Continuity Test of Battery Circuit Cables

Check continuity of following cables as per Para 2.3 of document no. 3 EHX 610 299

From	То	Condition	Continuity (OK/Not OK)
Battery (wire no 2093)	Circuit breakers 110- 2, 112.1-1, 310.4-1	By opening and closing MCB 112	Ok .
MCB 110	Connector 50.X7-1	By opening and closing MCB 110	Ok
Battery (Wire no. 2052)	Connector 50.X7-2		08
SB2 (Wire no 2050)	Connector 50.X7-3		øk

Close the MCB 112, 110, 112.1, and 310.4 and measure the resistance of battery wires 2093, 2052, 2050 with respect to the loco earth.	Prescribed value $> 0.5 \ M\Omega$	Measured Value 7 MΩ
Measure the resistance between 2093 & 2052, 2093 & 2050, 2052 & 2050	Prescribed value: > 50 MΩ	Measured  Value  70 MΩ

Commission the indoor lighting of the locomotive as per Sheet No 7A & 7B.

#### 1.4 Continuity Test of Screened Control Circuit Cables

Check the continuity and isolation of the screen cable of the following circuits with the help of sheet no. mentioned against each as per document no. 3 EHX 610 299.

Screened control circuit cables for	Corresponding Sheet Nos.	Continuity & isolation (OK/Not OK)
Battery voltage measurement	04B	615
Memotel circuit of cab1 &2	10A	<u> </u>
Memotel speed sensor	10A	0/1
Primary voltage detection	01A, 12A	0 19
Brake controller cab-1 & 2	06F, 06G	014

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

# <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC

Page : 4 of 27

Master controller cab-1 &2	08C, 08D	olc
TE/BE meter bogie-1 & 2	08E, 08F	60
Terminal fault indication cab-1 & 2	09F	01.
Brake pipe pressure actual BE electric	06H	GC
Primary current sensors	12B, 12F	0(5
Harmonic filter current sensors	12B, 12F	
Auxiliary current sensors	12B, 12F	<i>o</i> (s
Oil circuit transformer bogie 1	12E, 12I	Ok
Magnetization current	12C, 12G	019
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-1	12D	ok
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-2	12D	· ok
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-3	12D	ok
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-4	12H	ok
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-5	12H	ok
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-6	12H	9/1
Train Bus cab 1 & 2 (Wire U13A& U13B to earthing resistance=	13A	Ok
10KΩ±±10%) UIC line	13B	ol <sub>a</sub>
Connection FEG1-Box TB	13A · · · ·	ok ok

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

## Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 42914 2.0 Low Tension test

Type of Locomotive: WAP-7/WAG-9HC

Page: 5 of 27

2.1 Measurement of resistor in OHMS ( $\Omega$ )

Measure the resistances of the load resistors for primary voltage transformer, load resistors for primary current transformer and Resistor harmonic filter as per Para 3.2 of the document no. 3 EHX 610 279.

Name of the resistor	Prescribed value	Measured value
Load resistor for primary voltage	$3.9$ K $\Omega \pm 10\%$	3.982
transformer (Pos. 74.2).	1Ω ± 10%	12
Resister to maximum current relay.  Load resistor for primary current	3.3 Ω ± 10%	3.312
transformer (Pos. 6.11).  Resistance harmonic filter (Pos 8.3). Variation allowed ± 10%	WAP7	WAP7
Between wire 5 & 6	.0.2 Ω	0.252
Between wire 6 & 7	0.2 Ω	0.22
Between wire 5 & 7	0.4 Ω	0.41
For train bus, line U13A to earthing.	10 kΩ± 10%	10.0KJ
For train bus, line U13B to earthing.	$10 \text{ k}\Omega \pm 10\%$	99982
Insulation resistance of High Voltage Cable from the top of the roof to the earth (by1000 V megger).	200 ΜΩ	300MN
Resistance measurement earth return brushes Pos. 10/1.	≤0.3 Ω	· 0.2&A
Resistance measurement earth return brushes Pos. 10/2.	≤0.3 Ω	0.280
Resistance measurement earth return brushes Pos. 10/3.	≤0.3 Ω	0-291
Resistance measurement earth return brushes Pos. 10/4.	≤0.3 Ω	0.201
Earthing resistance (earth fault detection) Harmonic Filter –I; Pos. 8.61.	2.2 kΩ± 10%	2.282
Earthing resistance (earth fault detection) Harmonic Filter –II; Pos 8.62.	2.7 kΩ± 10%	2.7K2
Earthing resistance (earth fault detection) Aux. Converter; Pos. 90.3.	3.9 k <b>Ω</b> ± 10%	3.982
Earthing resistance (earth fault detection) 415/110V; Pos. 90.41	1.8 k <b>Ω</b> ± 10%	1.8KZ
Earthing resistance (earth fault detection) control circuit; Pos. 90.7.	390 <b>Ω</b> ± 10%	3902
Earthing resistance (earth fault detection) Hotel load; Pos. 37.1(in case of WAP5).	3.3 k <b>Ω</b> ± 10%	MA
Resistance for headlight dimmer; Pos. 332.3.	10 <b>Ω</b> ± 10%	10.52

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 1/2014

Type of Locomotive: WAP-7/WAG-9HC

Page: 6 of 27

Make sure that the earthing brush device don't make direct contact with the axle housing, earth connection must go by brushes.

#### 2.2 Check Points

Items to be checked	Remarks
Check whether all the earthing connection in roof and machine room as mentioned in sheet no. 22A is done properly or not.  These earthing connections must be flexible and should be	cheled ole
marked yellow & green  Check whether all the earthing connection between loco body and bogie is done properly or not. These cables must be flexible having correct length and cross section	checked ok

# 2.3 Low Tension Test Battery Circuits (without control electronics)

These tests are done with the help of the special type test loop boxes as per procedure given in Para 3.6 of the document no. 3 EHX 610 279

Para 3.6 of the document no. 3 EHX 6.  Name of the test	Schematic used.	Remarks
Test 24V supply	Sheet 04F and other linked sheets	Checked of
Test 48V supply	Sheet 04F & sheets of group 09	Fan supply to be checked.
Test traction control	Sheets of Group 08.	ok
Test power supply bus stations.	Sheets of Group 09.	Fan supply to be checked.
Test control main apparatus	Sheets of Group 05.	als .
Test earth fault detection battery circuit by making artificial earth fault to test the earth fault detection	Sheet 04C	ok
Test control Pneumatic devices	Sheets of Group 06	ok
Test lighting control	Sheets of Group 07	o c
Pretest speedometer	Sheets of Group 10	Ob
Pretest vigilance control and fire system	Sheets of Group 11	ok
Power supply train bus	Sheets of Group 13	Ole

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 42014 Downloading of Software Type of Locomotive: WAP-7/WAG-9HC

Page: 7 of 27

	Yes/No
3.1 Check Points.	
Check that all the cards are physically present in the bus stations and all the plugs are connected.	Ye)
Check that all the fibre optic cables are correctly connected to the bus stations.	yes
Make sure that <b>control electronics off relay</b> is not energized i.e. disconnect Sub-D 411.LG and loco is set up in simulation mode.	Ye)
Check that battery power is on and all the MCBs (Pos. 127.*) in SB1 &SB2 are on	Yes

3.2 Download Software

The software of Traction converter, Auxiliary converter and VCU should be done by commissioning engineer of the firm in presence of supervisor. Correct software version of the

propulsion equipment to be ensured and noted:

propulsion equipment to be ensured and noted:	20
Traction converter-1 software version:	28
Traction converter 2 software version:	<del>2&amp;</del>
Auxiliary converter-1 software version:	520
Auxiliary converter-2 software version:	4,0
Auxiliary converter-3 software version:	400
Vehicle control unit -1 software version:	1600
Vehicle control unit -2 software version:	1603

3.3 Analogue Signal Checking

Check for the following analogue signals with the help of diagnostic tool connected with loco.

Description	Signal name	Prescribed value	Measured Value
Brake pipe pressure	FLG2;0101XPrAutoBkLn	100% (= 5 Kg/cm2)	OK
Actual BE electric	FLG2; AMSB_0201- Wpn BEdem	100% (= 10V)	SX
TE/BE at 'o' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 9% and 11 %	10 1,
TE/BE at 'TE maximal' position from both cab	FLG1; AMSB_0101- Xang Trans	Between 99 % and 101 %	100,
TE/BE at 'TE minimal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 20 % and 25 %	24

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC

Page : 8 of 27

	g	·	
TE/BE at 'BE maximal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 99% and 101%	(001,
TE/BE at 'BE Minimal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 20% and 25%	25),
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>1/3 HBB2; AMS_0101- LT/BDEM>1/3	Between 42 and 44%	444,
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>2/3 HBB2; AMS_0101- LT/BDEM>2/3	Between 72 and 74%	74,
Both temperature sensor of TM1	SLG1; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature $0^{\circ}$ C to $40^{\circ}$ C	16°C
Both temperature sensor of TM2	SLG1; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	15°C
Both temperature sensor of TM3	SLG1; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	16°C
Both temperature sensor of TM4	SLG2; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	15.50
Both temperature sensor of TM5	SLG2; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	, , , , , , , , , , , , , , , , , , , ,
Both temperature sensor of TM6	SLG2; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	15°C

Effective Date: Feb 2022

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC

Page : 9 of 27

#### 3.4 Functional test in simulation mode

Conduct the following functional tests in simulation mode as per Para 5.5 of document no.3EHX 610 281. through the Diagnostic tool/laptop:

Test Function	Result desired in sequence	Result obtained
Emergency shutdown through emergency stop switch 244	VCB must open. Panto must lower.	checked on
Shut Down through cab activation switch to OFF position	VCB must open. Panto must lower.	checkedok
Converter and filter contactor operation with both Power Converters during Start Up.	FB contactor 8.41 is closed.  By moving reverser handle:  Converter pre-charging contactor 12.3 must close after few seconds.  Converter contactor 12.4 must close.  Converter re-charging contactor 12.3 must opens.  By increasing TE/BE throttle:  FB contactor 8.41 must open.  FB contactor 8.2 must close.  FB contactor 8.1 must close.	checked of
Converter and filter contactor operation with both Power Converters during Shut Down.	Bring TE/BE to O. Bring the cab activation key to "O" VCB must open. Panto must lower. Converter contactor 12.4 must open. FB contactor 8.1 must open. FB contactors 8.41 must close. FB contactor 8.2 must remain closed.	

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC Page: 10 of 27

	·	
isolating any bogie 🦽	Isolate any one bogie through bogie cut out switch. Wait for self-test of the loco.  • Check that FB contactor 8.1 is open.  • Check that FB contactor 8.2 is open.  After raising panto, closing VCB, and setting TE/BE  • FB contactor 8.1 closes.  • FB contactor 8.2 remains open.	checked ok
Test earth fault detection battery circuit positive & negative	By connecting wire 2050 to earth, create earth fault negative potential.  • message for earth fault  • By connecting wire 2095 to earth, create earth fault positive potential.  • message for earth fault	Checkel ex
Test fire system. Create a smoke in the machine room near the FDU. Watch for activation of alarm.	When smoke sensor-1 gets activated then  • Alarm triggers and fault message priority 2 appears on screen.  When both smoke sensor 1+2 gets activated then  • A fault message priority 1 appears on screen and lamp LSF1 glow.  • Start/Running interlock occurs and TE/BE becomes to 0.	checkel ek
Time, date & loco number	Ensure correct date time and Loco number	ok

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

#### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 48014

Type of Locomotive: WAP-7/WAG-9HC

Page: 11 of 27

# Sensor Test and Converter Test

4.1 Test wiring main Transformer Circuits

Apply  $198V_p/140V_{RMS}$  to the primary winding of the transformer (at 1u; wire no. 2 at surge arrestor and at 1v; wire no. 100 at earthing choke). Measure the output voltage and compare

the phase of the following of the transformers.

Output Winding nos.	Description of winding.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
2U <sub>1</sub> & 2V <sub>1</sub>	For line converter bogie 1 bétween cable 801A- 804A	10.05V <sub>p</sub> and same polarity	10.0400	OK.
2U <sub>4</sub> & 2V <sub>4</sub>	For line converter bogie 1 between cable 811A- 814A	10.05V <sub>p</sub> and same polarity	10.05-18	<b>3</b> x
2U <sub>2</sub> & 2V <sub>2</sub>	For line converter bogie 2 between cable 801B- 804B	10.05V <sub>p</sub> and same polarity	10.0400	PK
2U <sub>3</sub> & 2V <sub>3</sub>	For line converter bogie 2 between cable 811B- 814B	10.05V <sub>p</sub> and same polarity	10.0440	er,
2U <sub>B</sub> & 2V <sub>B</sub>	For aux. converter 1 between cable 1103- 1117 (in HB1) For Aux converter 2 between cable 1103- 1117 (in HB2)	7.9V <sub>p</sub> , 5.6V <sub>RMS</sub> and same polarity.	7.82P 5-642ms	<b>૭</b> ૫
2U <sub>F</sub> & 2V <sub>F</sub>	For harmonic filter between cable 4-12 (in FB)	9.12V <sub>p</sub> , 6.45V <sub>RMS</sub> and same polarity.	8.44 VRMS	Dц

## 4.2 Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)

Apply  $141V_p$  /  $100V_{RMS}$  to input of the auxiliary transformer at cable no 1203 –1117 and measure the output at

Description of wire no.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
Cable no. 1218 - 1200	58.7V <sub>p</sub> , 41.5V <sub>RMS</sub> and opposite polarity.	58.611 41.502mg)	26
Cable no. 1218 – 6500	15.5V <sub>p</sub> , 11.0V <sub>RMS</sub> and opposite polarity.	15-511	31

(Ref: WI/ECS/10)

Effective Date: Feb 2022

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC

Page: 12 of 27

#### **Primary Voltage Transformer**

Apply  $250V_{eff}/350V_p$  by variac to roof wire 1 and any wire 0 and measure the magnitude and polarity of the output of the primary voltage transformer for both bogies as per the procedure specified and suggested by the traction converter manufacturer. Primary voltage measurement converters (Pos. 224.1/\*) & catenary voltmeter (Pos. 74/\*)

This test is to be done for each converter.

Activate cab in driving mode and supply  $200V_{RMS}$  through variac to wire no 1501 and 1502. Monitor the following parameters through Diagnostic tool and in catenary voltmeter.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	25kV	250%	25 KV	930 X
SLG2 G 87-XUPrim	25 kV	250%	25 KV	950 X

Decrease the supply voltage below 140  $V_{\text{RMS}}$ . VCB must open at this voltage. In this case the readings in Diagnostic Tool and catenary voltmeter will be as follows.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	17kV	170% .	12/sv	170 X
SLG2 G 87-XUPrim	17 kV	170%	12 1ew	170 X

Reactivate VCB to on by increasing this voltage to 175% (17.5 kV).

Increase the supply to 240  $V_{RMS}$  through variac. VCB must open at this voltage, In this case the readings in diagnostic tool and catenary voltmeter will be as follows:

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	30kV	300%	30 bV	30m x.
SLG2 G 87-XUPrim	30 kV	300%	30 KV	200 X

Reactivate VCB to on by decreasing this voltage to 290% (29 kV).

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC

Page: 13 of 27

#### 4.4 Minimum voltage relay (Pos. 86)

Functionality test:	ted to approx 68%
Minimum voltage relay (Pos. 86) must be adjus	Wes/No)
Activate loco in cooling mode. Check Power supply of 48V to	Wieshild
minimum voltage relay Disconnect primary voltage	ļ
transformer (wire no. 1511 and 1512) from load resistor (POS.	
74.3) and connect variac to wire no. 1501 and 1502. Supply	· .
200V <sub>RMS</sub> through variac. In this case; <i>Minimum voltage relay</i>	
(Pos. 86) picks up	
	(1600/140)
Try to activate the cab in driving mode:	(Yes/No)
Contactor 218 do not close; the control	
electronics is not be working.	<u> </u>
Turn off the variac :	Wes/No)
Contactor 218 closes; the control electronics is be	
working Tech Harden Valtage Protection	
Test Under Voltage Protectio	<del>।।,</del>
	166-1010
Activate the cab in cooling mode; Raise panto;	U(Yes/No)
Supply 200V <sub>RMS</sub> through variac to wire no. 1501	
& 1502; Close the VCB; Interrupt the supply	,
voltage	
The VCB goes off after 2 second time delay.	
	(Yes/No)
Again supply 200V <sub>RMS</sub> through variac to wire no.	<i>y</i> . <i>z</i> =, ,
1501 & 1502; Decrease the supply voltage below	
140V <sub>RMS</sub> ± 4V;	
Fine tune the minimum voltage relay so that VCB opens.	
	·
4.5 Maximum current relay (Pos. 78)	
Disconnect wire 1521 & 1522 of primary current transform	mer; Connect variac to wire 1521
&1522 (including the resistor at Pos. 6.11); Put loco in simular	tion for driving mode; Open R <sub>3</sub> – R <sub>4</sub>

Disconnect wire 1521 & 1522 of primary current transformer; Connect variac to wire 1521 & 1522 (including the resistor at Pos. 6.11); Put loco in simulation for driving mode; Open R<sub>3</sub> – R<sub>4</sub> on contact 136.3; Close VCB; supply 3.6A<sub>RMS</sub> at the open wire 1521; Tune the drum of the maximum current relay Pos. 78 for correct over current value;

VCB opens with Priority 1 fault message on display.

Keep contact R<sub>3</sub> – R<sub>4</sub> of 136.3 closed; Close VCB; Tune the resistor 78.1 for the current of 7.0A<sub>RMS</sub> /9.9A<sub>p</sub> at the open wire 1521;

VCB opens with Priority 1 fault message on display.

DOC.NO. /LOC/U (Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC

Page : 14 of 27

4.6 Test current sensors	- the took	Prescribed value	Set/Measured
Name of the sensor	Description of the test		value
Primary return current sensor (Test-1,Pos.6.2/1 & 6.2/2)	Activate cab in driving mode supply 10A. Measure the current through diagnostic tool or measuring print.	(Variation allowed is ± 10%)	
	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		
Primary return current sensor (Test-2, Pos.6.2/1 & 6.2/2)	Supply 297mA <sub>DC</sub> to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		2-99mg
Auxiliary winding current sensor (Pos. 42.3/1 & 42.3/2)	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AC/1or 2 pin no. 7(+) & 8(-)		
	Supply 333mA <sub>DC</sub> to the test winding of sensor through connector 415.AC/1 or 2 pin no. 7(+) & 8(-)		338ma
Harmonic filter current sensors (Pos.8.5/1 &8.5/2)	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AE/10 2 pin no. 7(+) & 8(-)	r	
	Supply 342mA <sub>DC</sub> to the test winding of sensor through connector 415.AE/10 2 pin no. 7(+) & 8(-)	r	3 46mo
Hotel load current sensors (Pos. 33/1 &	Switch on hotel load. Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415:AG/1or 2 pin no. 7(+) 8(-)	<b> </b>	NA
33/2)	Supply 1242mA <sub>DC</sub> to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)	NA	MA

DOC.NO.F/ECO/V (Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 48014

Type of Locomotive: WAP-7/WAG-9HC

Page: 15 of 27

4.7 Test DC Link Voltage Sensors (Pos 15.6/\*)

This test is to be done by the commissioning engineer of the firm if required.

# 4.8 Verification of Converter Protection Circuits (Hardware limits) -

This test is to be done as per para 6.17 of the document no. 3EHX 610 282 for both the converters.

Protection circuits	Limit on which shutdown should take place	Measured limit	
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 1	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 18.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=	ok
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 2	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 8.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=	01
Fibre optic failure in Power Converter1	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	ok	
Fibre optic failure in Power Converter2	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	. OK	

#### 4.9 Sequence of BUR contactors

The sequence of operation of BUR contactors for 'ALL BUR OK' BUR 1 out BUR 2 out and BUR 3 out condition has to be verified by putting the Loco in driving mode (VCB should not be closed) and isolating the BURs one by one. In these condition following will be the contactor sequence.

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	Close	Open	Close	Open	Close	Open	Close	Close	Open
BUR1 off	Close	Open	Close	Close	Open	Close	Open	Open	Close
BUR2 off	Open	Open	Close	Close	Close	Close	Open	Open	Close
BUR3 off	Open	Close	Open	• Close	Close	Close	Open	Open	Close

PATIALA LOCOMOTIVE WORKS, PATIALA

(Ref: WI/ECS/10)

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC Page: 16 of 27

Monitored contactor sequence

Officored contra			F2/2	52/4	52/5	52.4/1	52,4/2	52.5/1	52.5/2
Status	52/1	52/2	52/3	52/4				62 1 0	
AI BUR OK	Perse	den	clase	open	Close	open	COOSE	Close	colen
BUR1 off	Tone	colm	Clase	Clase	den	Clare.	open	pen_	Clare
BUR2 off	Den	pen	Clase	Clase	Clase	Care	com	Al-	111/11/11
BUR3 off	often	clese	den	Clase	(60)2	(Upse	pen	den	Clase

#### Commissioning with High Voltage

#### 5.1 Check List

Items to be checked	Yes/No
	<del> </del>
Fibre optic cables connected correctly.	Yes
No rubbish in machine room, on the roof, under the loco.	yes.
All the electronic Sub-D and connectors connected	Y 03
All the MCBs of the HB1 & HB2 open.	Yen
All the three fuses 40/* of the auxiliary converters	408
The fuse of the 415/110V auxiliary circuit (in HB1) open.	Y8
Roof to roof earthing and roof to cab earthing done	40
Fixing, connection and earthing in the surge arrestor done correctly.	408
Connection in all the traction motors done correctly.	40
All the bogie body connection and earthing connection done correctly.	40
Pulse generator (Pos. 94.1) connection done correctly.	408
All the oil cocks of the gate valve of the transformer in open condition.	408
All covers on Aux & Power converters, Filter block, HB1, HB2 fitted	Yes
KABA key interlocking system.	19

#### 5.2 Safety test main circuit breaker

Prepare to switch off the catenary supply during the first charging of the locomotive in case of any unexpected behavior of the electrical component of the loco. Charge the loco for the first time by closing BLDJ switch. The VCB will trip after certain time as no oil/coolant pumps are running yet.

Perform the following safety test of main circuit breaker through both the cabs of the locomotive.

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

# Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC Page: 17 of 27

Name of the test	Description of the test	Expected result	Monitored result
Emergency stop in cooling mode	Raise panto in cooling mode. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	checked or
Emergency stop in driving mode	Raise panto in driving mode in. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	Checkedok
Under voltage protection in cooling mode	Raise panto in cooling mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open.	checkedok
Under voltage protection in driving mode	Raise panto in driving mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open with diagnostic message that catenary voltage out of limits	Checkedok
Shut down in cooling mode.	Raise panto in cooling mode. Close the VCB. Bring the BL- key in O position.	VCB must open. Panto must lower.	Chapedok
Shutdown in driving mode	Raise panto in driving mode. Close the VCB. Bring the BL-key in O position.	VCB must open. Panto must lower.	Checkedol
Interlocking pantograph- VCB in cooling mode	Raise panto in cooling mode. Close the VCB.  Lower the pantograph by ZPT	VCB must open.	Cheekedok
Interlocking pantograph- VCB in driving mode	Raise panto in driving mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	Cheeked ole

DOC.NO.F/EGG/V (Ref: WI/ECS/10)

Effective Date: Feb 2022

# PATIALA LOCOMOTIVE WORKS, PATIALA

#### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC

Page: 18 of 27

## 5.3 Auxiliary Converter Commissioning

Switch on the high voltage supply and set up the loco in driving mode. Raise the panto. Close the VCB. Check that there is no earth fault in the auxiliary circuit, Switch off the VCB. Lower the panto. Create the earth fault in auxiliary circuit by making connection between wire no 1117(in HB2 cubicle) and earth. After 3 minutes a diagnostic message will come that "Earth fault auxiliary circuit."

5.3.1 Running test of 3 ph. auxiliary equipments

Switch on the 3 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured continuous phase current	Measured starting phase current
Oil pump transformer 1	9.8 amps	9.1	12.0
Oil pump transformer 2	9.8 amps	9.0	12.0
Coolant pump converter 1	19.6 amps	. 5.1	7,6
Coolant pump converter 2	19.6 amps	5.0	7:2
Oil cooling blower unit 1	40.0 amps	40.1	81,0
Oil cooling blower unit 2	40.0 amps	40.2	620
Traction motor blower 1	34.0 amps	22.6	56.5.
Traction motor blower 2	34.0 amps	23.0	57.0
Sc. Blower to Traction motor blower 1	6.0 amps	3,6	8,6
Sc. Blower to Traction motor blower 1	6.0 amps	3,4	8.0
Compressor 1	25 amps at 0 kg/ cm <sup>2</sup> 40 amps at 10 kg/ cm <sup>2</sup>	23.5	50.1
Compressor 2	25 amps at 0 kg/ cm <sup>2</sup> 40 amps at 10 kg/ cm <sup>2</sup>	20.0	45:0

Effective Date: Feb 2022

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC

Page: 19 of 27

(Ref: WI/ECS/10)

5.3.2 Performance of Auxiliary Converters

Measure the performance of the auxiliary converters through software and record it. BUR1 (Condition: Switch off all the load of BUR 1)- to be filled by commissioning engineer

Description of the signal	Prescribed value	Monitored value	Value under Limit (Yes/No)
Input voltage to BUR1	75% (10%=125V)	100/2	Yey
	60% (10%=100V)	636V	Yay
DC link current of BUR1	0% (10%=50A)	1 Ann	4.0
	Input voltage to BUR1  DC link voltage of BUR1	value	value   value   value

BUR2 (Condition: Switch off all the load of BUR 2, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value by the firm	Monitored value	Value under Limit (Yes/No)
BUR2 7303-XUUN	Input voltage to BUR2	75% (10%=125V)	10034	Yes
BUR2 7303-XUUZL	DC link voltage of BUR2	60% (10%=100V)	637V	Yey
BUR2 7303-XUIZ 1	DC link current of BUR2	1% (10%=50A)*	7 Anh	10,
BUR2 7303-XUILG	Current battery charger of BUR2	3% (10%=100A)*	21 Amb	163
BUR2 7303-XUIB1	Current battery of BUR2	1.5%(10%=100A)*	11 Amb	Yey
BUR2 7303 -XUUB	Voltage battery of BUR2	110%(10%=10V)	1104.	Y9

<sup>\*</sup> Readings are dependent upon charging condition of the battery.

BUR3 (Condition: Switch off all the load of BUR 3, Battery Charger on) to be filled by

commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed set value by the firm	Monitored value	Value under limit (Yes/No)
BUR3 7303-XUUN	Input voltage to BUR3	75% (10%=125V	10040	7cy .
BUR3 7303- XUUZ1	DC link voltage of BUR3	60% (10%=100V)	6374	Yes
BUR3 7303-XUIZ 1	DC link current of BUR3	1% (10%=50A)*	7 Amp	Yey
BUR3 7303-XUILG.	Current battery charger of BUR 3	3% (10%=100A)*	21 Amg	6
BUR3 7303-XUIB1	Current battery of BUR 3	1.5%(10%=100A)*	1) Amp	Tey
BUR3 7303-XUUB	Voltage battery of BUR 3	110%(10%=10V)	110~	G

Readings are dependent upon charging condition of the battery.

DOC.NO.F/EU (Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC Page: 20 of 27

5.3.3 Performance of BURs when one BUR goes out

When any one BUR goes out then rest of the two BURs should take the load of all the

	Loads on BUR1	Loads in BUR2	Loads in BUR3
All BURs OK	Oil Cooling unit 1&2	TM blower1&2, TFP oil pump 1&2, SR coolant pump 1&2.	Compressor 1&2, Battery ( charger and TM Scavenger blower 1&2
BUR 1 out	1 A A A A A A A A A A A A A A A A A A A	Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2,TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 2 out	Oil Cooling unit 1&2, TM blower 1&2, TM Scavenger blower 1&2	<u></u> `	Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 3 out	Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.	

5.4 Auxiliary circuit 415/110

For checking earth fault detection, make a connection between wire no. 1218 and vehicle body. On switching on VCB, Earth fault relay 89.5 must pick up and after 3 minutes a message will come in the Diagnostic display that Earth Fault 415/110V Circuit

Switch on the 1 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured phase current	Measured starting current
Machine room blower 1	15.0 amps*	4.4	20.1
Machine room blower 2	15.0 amps*	4-7	. 21.3
Sc. Blower to MR blower 1	1.3 amps	1.8	5-6
Sc. Blower to MR blower 2	1.3 amps	1.9	6.0
Ventilator cab heater 1	1.1 amps	1.8	2.1
Ventilator cab heater 2	1.1 amps	1.8	2.1
Cab heater 1	4.8 amps	5~0	5-1
Cab heater 2	4.8 amps	5.0	5-,

<sup>\*</sup> For indigenous MR blowers.

Effective Date: Feb 2022

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

#### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC

Page: 21 of 27

# 5.5 Hotel load circuit (Not applicable for WAG-9HC)

For WAP-7 locomotive with Hotel load converter refer to Annexure-HLC

#### 5.6 Traction Converter Commissioning

## This test is carried out in association with Firm.

Traction converter commissioning is being done one at a time. For testing Converter 1, switch off the traction converter 2 by switch bogie cut out switch 154. For testing Converter 2, switch off the traction converter 2 by switch bogie cut out switch 154. Isolate the harmonic filter also by switch 160. Start up the loco by one converter. Follow the functionality tests.

For Converter 1  Results desired Result obtained				
Test Function	Results desired	Kesuit optained		
Measurement of charging and pre-charging and charging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chee kedok		
Measurement of discharging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	CheekeLok		
Earth fault detection on positive potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheekelok		
Earth fault detection on negative potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	checkestak		
Earth fault detection on AC part of the traction circuit of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	anedicedok		
Pulsing of line converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	checkelok		
Pulsing of drive converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked on		

Effective Date: Feb 2022

DOC:140'1 /FCC'01 (Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC Page: 22 of 27

For Converter 2	**************************************	Result obtained
Test Function	Results desired in sequence	Nesuit obtaines
charging and pre- charging and charging	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	checked ok
Measurement of discharging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	checkedok
positive potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeredok
Earth fault detection on negative potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/v	Checked ok
Earth fault detection on AC part of the traction circuit of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	checked ole
Pulsing of line converter of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheekedek
Pulsing of drive converter of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheated or

Effective Date: Feb 2022

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC

Page: 23 of 27

## 5.7 Test protective shutdown SR

Test Function	Results desired in sequence	Result obtained
	·	
Measurement of protective shutdown by Converter 1 electronics.	Start up the loco with both the converter. Raise panto. Close VCB.  Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 1Check that converter 1 electronics produces a protective shut down.  • VCB goes off  • Priority 1 fault mesg. on DDU appears  Disturbance in Converter 1	checked ok
Measurement of protective shutdown by Converter 2 electronics.	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 2. Check that converter 2 electronics produces a protective shu down.  • VCB goes off • Priority 1 fault mesg. on diagnostic display appears  Disturbance in Converter 2	

#### 5.8 Test Harmonic Filter

Switch on the filter by switch 160

Test Function	Results desired in sequence	Result obtained
Measurement of filter currents	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Apply a small value of TE/BE by moving the throttle.  • FB contactor 8.41 must open.	checked or

DOC.NO.F/ECS/UI (Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

# <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC

Page: 24 of 27

and the second		
	FB contactor 8.2 must close. FB contactor 8.1 must close Check the filter current in diagnostic laptop Bring the TE/BE throttle to O Switch off the VCB FB contactor 8.1 must open. FB discharging contactor 8.41 must close Check the filter current in diagnostic laptop Make a connection between wire no. 12 and vehicle body. Start up the loco. Close VCB. Earth fault relay 89.6 must pick up. Diagnostic message comes that Earth fault in harmonic filter circuit	Checked ok
Test traction motor speed sensors for both bogie in both cabs	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/PLW	ala

#### 5.9 Test important components of the locomotive

Items to be tested	Description of the test	Monitored value/remarks	
Speedometer	VCU converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	checked uk	
Time delay module of MR blower	The time after which the starting capacitor for MR blower should go off the circuit should be set to 10-12 seconds	checkelok	
Ni-Cd battery voltage	At full charge, the battery voltage should be 110V DC.	checked old	
Flasher light	From both cab flasher light should blink at least 65 times in one minute.	checkedole	
Head light	Head light should glow from both cabs by operating ZLPRD. Dimmer operation of headlight should also occur by operating the switch ZLPRD.	cheekelisk	

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC Page : 25 of 27

	the state of the s	_ <del></del>
Marker light	Both front and tail marker light should glow from both the cabs	checked ok
Cab Light	Cab light should glow in both the cabs by operating the switch ZLC	checked ok
Spot lights	Both Drivers and Asst. Drivers Spot light should glow in both cabs by operating ZLDD	cheeked ok
Instrument lights	Instrument light should glow from both cab by operating the switch ZLI	Charles 61
Illuminated Push button	All illuminated push buttons should glow during the operation	cheaced on
Contact pressure of the high rating contactors	The contact pressure of FB contactors (8.1, 8.2) is to be measured  Criteria:  The minimum contact pressure is 54 to 66  Newton.	For contactor 8.1: For contactor 8.2:
Crew Fan	All crew fans should work properly when VCB of the loco is switched on. The airflow from each cab fan is to be measured.  Criteria:  The minimum flow of air of cab fan should be 25 m <sup>3</sup> /minute	Cab 1 LHS: Cab 1 RHS: Cab 2 LHS: Cab 2 RHS:

#### 6.0 Running Trial of the locomotive

SN	Description of the items to be seen during trail run	Action which should take place	Remarks
1	Cab activation in driving mode	No fault message should appear on the diagnostic panel of the loco.	Cheere
,	Loco charging	Loco to be charged and all auxiliaries should run.  No fault message to appear on the diagnostic panel of the loco. Raise MR pressure to 10 Kg/cm <sup>2</sup> , BP to 5 Kg/cm <sup>2</sup> , FP to 6 Kg/cm <sup>2</sup> .	Checica
3.	Check function of Emergency push stop.	This switch is active only in activated cab. By pushing this switch VCB should open & pantograph should be lowered.	Checker
4.	Check function of BPCS.	<ul> <li>Beyond 5 kmph, press BPCS, the speed of loco should be constant.</li> <li>BPCS action should be cancelled by moving TE/BE throttle, by dropping BP below 4.75 Kg/cm<sup>2</sup>, by pressing BPCS again.</li> </ul>	charke ok
5.	Check train parting operation of the Locomotive.	Operate the emergency cock to drop the BP Pressure LSAF should glow.	(Checked

}

(Ref: WI/ECS/10)

checked ok

checkedor

Checkedor

cneckedol

checkelor

MA

# Effective Date: Feb 2022 PATIALA LOCOMOTIVE WORKS, PATIALA

switch then

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 49014

Check vigilance

locomotive

operation of the

Type of Locomotive: WAP-7/WAG-9HC

Set the speed more than 1.5 kmph and ensure that brakes are released i.e. BC < 1 Kg/cm<sup>2</sup>.

For 60 seconds do not press vigilance foot switch or sanding foots switch or TE/BE throttle or BPVG

Buzzer should start buzzing.LSVW should glow continuously.

Do not acknowledge the alarm through BPVG or vigilance foot switch further for 8 seconds then:-

 Emergency brake should be applied automatically.

VCB should be switched off.
Resetting of this penalty brake is possible only after
32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch.

7. Check start/run interlock
 At low pressure of MR (< 5.6 Kg/cm²).</li>
 With park brake in applied condition.

• With direct loco brake applied (BP< 4.75Kg/cm<sup>2</sup>).

With automatic train brake applied (BP<4.75Kg/cm<sup>2</sup>).
 With emergency cock (BP < 4.75 Kg/cm<sup>2</sup>).

8. Check traction interlock Switch of the brake electronics. The Tractive / Braking effort should ramp down, VCB

should open and BP reduces rapidly.

9. Check regenerative Bring the TE/BE throttle to BE side. Loco speed

braking. should start reducing.

10. Check for BUR In the event of failure of one BUR, rest of the two redundancy test at BURs can take the load of all the auxiliaries. For this

ventilation level 1 & 3 of loco operation switch off one BUR.

Auxiliaries should be catered by rest of two BURs.

Switch off the 2 BURs; loco should trip in this case.

11. Check the power converter by switching converter isolation test should get isolated and traction is possible with another power converter.

Effective Date: Feb 2022

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 42014

Type of Locomotive: WAP-7/WAG-9HC

Page: 27 of 27

# 7.0 Final check list to be verified at the time of Loco dispatch

Condition /Operations of the following items are to be checked:

ŚN	Item	Cab-1	Cab-2	Remarks
1	Head lights	elc	010	
2	Marker Red	6k	ols	
3	Marker White	ok	Ok	
4	Cab Lights	OK	ole	, ,
5	Dr Spot Light	210	619	·
6	Asst Dr Spot Light	ek	elr	checked working ok
7	Flasher Light	Ck	0.19	
8	Instrument Lights	ole	el c	
9	Corridor Light	ok	de	
10	Cab Fans	96	de	
11	Cab Heater/Blowers	210	0.10	
12	All Cab Signal Lamps Panel 'A'	ole	66	

# Status of RDSO modifications

LOCO NO: 42014

Sn	Modification No.	Description	Remarks
1.	RDSO/2008/EL/MS/0357 Rev.'0' Dt 20.02.08	Modification in control circuit of Flasher Light and Head Light of three phase electric locomotives.	Ok/Not Ok
2.	RDSO/2009/EL/MS/0377 Rev.'0' Dt 22.04.09	Modification to voltage sensing circuit in electric locomotives.	Ok/Not Ok
3.	RDSO/2010/EL/MS/0390	Paralleling of interlocks of EP contactors and Relays of three phase locomotives to improve reliability.	Ok/Not Ok
4.	Rev.'0' Dt 31.12.10 RDSO/2011/EL/MS/0399 Rev.'0' Dt 08.08.11	Removal of interlocks of control circuit contactors no. 126 from MCPA circuit.	Ok/Not Ok
5.	RDSO/2011/EL/MS/0400 Rev.'0' Dt 10.08.11	Modification sheet for shifting the termination of \$GKW, 1.8 KV, 70 sq mm cables and 2x2.5 sq mm cables housed in lower portion of HB2 panel and provision of Synthetic resin bonded glass fiber sheet for three phase locomotives.	Ok/Not Ok
6.	RDSO/2011/EL/MS/0401 Rev.'0' Dt 10.08.11	Modification sheet for relaying of cables in HB-2 paner of	Ok/Not Ok
7.	RDSO/2011/EL/MS/0403 Rev.'0' Dt 30.11.11	Auto switching of machine room/corridor lights to avoid draining of hatteries in three phase electric locomotives.	Ok/Not Ok
8.	RDSO/2012/EL/MS/0408 Rev.'0'		Ok/Not Ok
9.	RDSO/2012/EL/MS/0411 Rev.'1' dated 02.11.12	this All of	Ok/Not Ok
10	RDSO/2012/EL/MS/0413 Rev.'1' Dt 25.04.16		Ok/Not Ok
11	RDSO/2012/EL/MS/0419 Rev.'0' Dt 20.12.12		Ok/Not Ok
12			Ok/Not Ok
13	RDSO/2013/EL/MS/0425 Rev.'0' Dt 22.05.13	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Ok/Not Ok
14			Ok/Not Ok
15			Ok/Not Ok
16		Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.	Ok/Not Ok
17	RDSO/2014/EL/MS/0432 Rev. '0' Dt 12.03.14	Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.	Ok/Not Ok
18			Ok/Not Ok
19	RDSO/2017/EL/MS/046 Rev.'0' Dt 07.12.17		Ok/Not Ok
20			Ok/Not Ok

# Status of RDSO modifications

LOCO NO: \_\_\_\_\_

1. RDSO/2008/ELMS/0357 Rev '0' Dt 20.02.08  2. RDSO/2009/ELMS/0357 Rev '0' Dt 22.04.09  3. RDSO/2019/ELMS/0390 Rev '0' Dt 31.12.0  4. RDSO/2011/ELMS/0390 Rev '0' Dt 31.12.0  5. RDSO/2011/ELMS/0401 Rev '0' Dt 0.08.11  5. RDSO/2011/ELMS/0401 Rev '0' Dt 0.08.11  6. RDSO/2011/ELMS/0401 Rev '0' Dt 10.08.11  7. RDSO/2011/ELMS/0403 Rev '0' Dt 10.08.11  7. RDSO/2011/ELMS/0404 Rev '0' Dt 10.08.11  8. RDSO/2011/ELMS/0404 Rev '0' Dt 30.31.11  8. RDSO/2011/ELMS/0404 Rev '0' Dt 30.31.11  8. RDSO/2011/ELMS/0404 Rev '0' Dt 30.11.11  8. RDSO/2012/ELMS/0404 Rev '0' Dt 30.11.11  8. RDSO/2013/ELMS/0401 Rev '0' Dt 20.01.21  9. RDSO/2013/ELMS/0401 Rev '0' Dt 20.01.13  10. RDSO/2013/ELMS/0401 Rev '0' Dt 20.01.13  11. RDSO/2013/ELMS/0402 Rev '0' Dt 20.01.13  12. RDSO/2013/ELMS/0402 Rev '0' Dt 20.01.13  13. RDSO/2013/ELMS/0425 Rev '0' Dt 20.01.13  14. RDSO/2013/ELMS/0425 Rev '0' Dt 20.01.13  15. RDSO/2013/ELMS/0425 Rev '0' Dt 20.01.13  16. RDSO/2013/ELMS/0425 Rev '0' Dt 20.01.13  17. RDSO/2013/ELMS/0425 Rev '0' Dt 20.01.13  18. RDSO/2013/ELMS/0425 Rev '0' Dt 20.01.13  19. RDSO/2013/ELMS/0425 Rev '0' Dt 20.01.13  10. RDSO/2013/ELMS/0425 Rev '0' Dt 20.01.13  10. RDSO/2013/ELMS/0425 Rev '0' Dt 20.01.13  10. RDSO/2013/ELMS/0425 Rev '0' Dt 10.02.01  10. RDSO/2013/ELMS/0425 Rev '0' Dt 10.03.01  11. RDSO/2013/ELMS/0425 Rev '0' Dt 10.03.01  12. RDSO/2013/ELMS/0425 Rev '0' Dt 10.03.01  13. RDSO/2013/ELMS/0425 Rev '0' Dt 10.03.024  14. RDSO/2013/ELMS/0425 Rev '0' Dt 10.03.024  15. RDSO/2013/ELMS/0427 Rev '0' Dt 10.03.024  16. RDSO/2014/ELMS/0430			Description	Remarks
Rev. '0 Dt 20.02.08 three phase electric locomotives.  RDSO/2009/ELMS/0377 Modification to voltage sensing circuit in electric locomotives.  RDSO/2010/ELMS/0390 Paralleling of interlocks of EP contactors and Relays of three phase locomotives to improve reliability.  RDSO/2011/ELMS/0390 Nase locomotives to improve reliability.  RDSO/2011/ELMS/0390 Nase locomotives to improve reliability.  RREW '0' Dt 10.80.81.1 MOdification sheet for shifting the termination of SGKW, 1.8 KV, 70 sq mm cables and 2x.2.5 sq mm cables housed in lower portion of HB2 panel and provision of Synthetic resin bonded glass fiber sheet for three phase locomotives.  Rev. '0' Dt 10.08.11.1 Modification sheet for relaying of cables in HB-2 panel of three phase locomotives.  Rev. '0' Dt 3.0.11.11  RDSO/2011/ELMS/0403 Auto switching of machine room/corridor lights to avoid draining of HB2 panel and provision of Synthetic resin bonded glass fiber sheet for three phase locomotives.  Rev. '0' Dt 3.0.11.11  RDSO/2012/ELMS/0403 Auto switching of machine room/corridor lights to avoid draining of Rev. '0' Dt 3.0.11.11  RDSO/2012/ELMS/0413 Rev. '0' Dt 2.0.12.12  RDSO/2012/ELMS/0413 Rev. '0' Dt 2.0.12.12  RDSO/2012/ELMS/0415 Rev. '0' Dt 2.0.12.13  Rev. '0' Dt 2.0.12.12  RDSO/2013/ELMS/0420 Modification of terminal connection of heater curn biower and Relays of three phase electric locomotives.  Rev. '0' Dt 2.0.12.12  RDSO/2013/ELMS/0420 Modification sheet to avoid simultaneous switching ON of White Rev. '0' Dt 2.0.12.13  RDSO/2013/ELMS/0420 Modification sheet to provide mechanical locking arrangement in Rev. '0' Dt 10.12.13  RDSO/2013/ELMS/0426 Modification sheet for improving illumination of head light in dimmer mode in three phase electric locomotives.  Modification sheet for miproving illumination of head light in dimmer mode in three phase locomotives.  Modification sheet for miproving illumination of over current relay of three phase electric locomotives.  Modification sheet for miproving illumination of over current relay of three phase electric lo	Sn	Modification No.		
Rev. '0' Dt 20.02.08 three phase electric locomotives.  Rev. '0' Dt 22.04.09  RDSO/2009/ELM/S/0390 Paralleling of interlocks of EP contactors and Relays of three phase locomotives to improve reliability.  RDSO/2017/ELM/S/0390 Paralleling of interlocks of EP contactors and Relays of three phase locomotives to improve reliability.  RDSO/2017/ELM/S/0390 Paralleling of interlocks of EP contactors and Relays of three phase locomotives.  Rev. '0' Dt 30.11.11 Mp/PA circuit.  Rev. '0' Dt 10.08.01.1 Mp/PA circuit.  Rev. '0' Dt 10.08.11 Mp/PA circuit.  Rev. '0' Dt 10.11.11 Mp/PA circuit.  Rev. '0' Dt 20.11.12 Mp/PA circuit.  Rev. '0' Dt 20.11.21 Mp/PA circuit.  Rev. '0' Dt 10.11.11 Mp/PA circuit.  Rev. '0' Dt 10.11.13 Mp/PA circuit.  Rev. '0' Dt 10.10.13 Mp/PA circuit.  Rev. '0' Dt 10.10.13 Mp/PA circuit.  Rev. '0' Dt 10.10.13 Mp/PA circuit.  Rev. '0' Dt 10.10.11 Mp/PA circuit.  Rev. '0' Dt 10.10		TROUGODUEL (MC10257	Modification in control circuit of Flasher Light and Head Light of	
2. RDSO/2010/ELM/S/0397 Modification to voltage sensing circuit in electric locomotives.  Rev. '0' Dt 22.04.09  3. RDSO/2010/ELM/S/0399 Paralleling of interlocks of EP contactors and Relays of three phase locomotives to improve reliability.  4. RDSO/2011/ELM/S/0399 Rev. '0' Dt 10.08.011  5. RDSO/2011/ELM/S/0400 MC/PA circuit.  5. RDSO/2011/ELM/S/0400 MC/PA circuit.  6. RDSO/2011/ELM/S/0401 Rev. '0' Dt 10.08.11  7. RDSO/2011/ELM/S/0401 Rev. '0' Dt 10.08.11  8. RDSO/2011/ELM/S/0401 Rev. '0' Dt 10.08.11  8. RDSO/2011/ELM/S/0401 Rev. '0' Dt 30.11.11  8. RDSO/2011/ELM/S/0401 Rev. '0' Dt 30.11.11  8. RDSO/2012/ELM/S/0401 Rev. '0' Dt 30.01.11  8. RDSO/2013/ELM/S/0402 Rev. '0' Dt 10.12.03.14  8. RDSO/2013/ELM/S/0402 Rev. '0' Dt 10.10.2024  8. RDSO/2013/ELM/S/0402 Rev. '0' Dt 10	1.	KDSO/5008/EL/M9/039/	three phase electric locomotives.	Okariot Ok
Rev.'0 http://www.new.new.new.new.new.new.new.new.new.	}	Rev. 0 Dt 20:02:08	·	
Rev.'0 Dt 31-12.10 phase locomotives to improve reliability.  Rev.'0 Dt 31-12.10 phase locomotives to improve reliability.  Rev.'0 Dt 31-12.10 phase locomotives to improve reliability.  Rev.'0 Dt 30-80-11 MS/0399 Rev.'0 Dt 10.08-11 MCPA circuit.  Rev.'0 Dt 10.08-11 MS/0400 Mcdification sheet for shifting the termination of SGKW, 1.8 KV, 70 sq mm cables and 2xc.5 sq mm cables housed in lower portion of HB2 panel and provision of Synthetic resin bonded glass fiber sheet for three phase locomotives.  Rev.'0 Dt 10.08-11 MS/0401 Mcdification sheet for relaying of cables in HB-2 panel of three phase locomotives to switching of machine room/corridor lights to avoid draining of phase locomotives to avoid fire hazards.  Rev.'0 Dt 30.11-11 Mcdification sheet to avoid simultaneous switching ON of White Rev.'1 dated 02.11-12 Mcdification sheet to avoid simultaneous switching ON of White Rev.'1 Dt 25.04-16 Mcdification sheet to avoid simultaneous switching ON of White Rev.'1 Dt 25.04-16 Mcdification sheet to avoid simultaneous switching ON of White Rev.'0 Dt 20.12-12 Modification sheet to provide rubbers and sublainty contactors of three phase locomotives and swilliamy contactors of three phase locomotives.  Rev.'0 Dt 20.12-12 MS/0425 Mcdification sheet to provide rubbers and sublainty contactors of three phase locomotives.  Rev.'0 Dt 20.13-13 Mcdification sheet provide mechanical locking arrangement in Primary Over Current Relay of three phase locomotives.  Rev.'0 Dt 20.13-13 Mcdification sheet to provide rubbers asaling gasket in Master Controller of three phase locomotives.  Rev.'0 Dt 10.12-13 Mcdification sheet to provide rubbers asaling gasket in Master Rev.'0 Dt 10.12-13 Mcdification sheet to provide mechanical locking arrangement in Primary Over Current Relay of three phase electric locomotives.  Rev.'0 Dt 10.12-13 Mcdification sheet to provide mechanical locking arrangement in Indigent Mcdification sheet to provide		77 C 10000 (FL IME /0277	Modification to voltage sensing circuit in electric locomotives.	OLINIO OL
3. RDSO/2017IELIMS/0399 Rev.'0' Dt 31.12.10 Passe locomotives to improve reliability. Rev.'0' Dt 30.8.11 RPSO/2017IELIMS/0399 Removal of interlocks of control circuit contactors no. 126 from MCPA circuit. Rev.'0' Dt 10.08.11 RPSO/2017IELIMS/0400 Rev.'0' Dt 10.08.11 RDSO/2017IELIMS/0401 Rev.'0' Dt 10.08.11 RDSO/2017IELIMS/0401 Rev.'0' Dt 10.08.11 RPSO/2017IELIMS/0401 Rev.'0' Dt 10.08.11 RPSO/2017IELIMS/0403 Rev.'0' Dt 10.08.11 RPSO/2017IELIMS/0403 Rev.'0' Dt 30.11.11 RPSO/2017IELIMS/0408 Rev.'0' Dt 30.11.11 RPSO/2017IELIMS/0408 Rev.'0' Dt 30.11.11 RPSO/2017IELIMS/0409 Rev.'0' Dt 25.04.13 Rev.'1' Dt 25.04.13 Rev.'1' Dt 25.04.13 Rev.'0' Dt 20.12.12 RPSO/2017IELIMS/0404 Rev.'0' Dt 20.13.11 RPSO/2017IELIMS/0404 Rev.'0' Dt 20.11 RPSO/2017IELIMS/0404 Rev.'0' Dt 10.12.12 RPSO/2017IELIMS/0404 Rev.'0' Dt 10.12.13 RPSO/2017IELIMS/0404 Rev.'0' Dt 10.12.13 RPSO/2017IELIMS/0404 Rev.'0' Dt 10.12.13 RPSO/2017IELIMS/0404 Rev.'0' Dt 10.12.10 RPSO/2017IELIMS/0404 Rev.'0' Dt 10.12.03.14 RPSO/2017IELIMS/0404 Rev.'0' Dt 10.12.03.14 RPSO/2017IELIMS/0404 Rev.'0' Dt 10.10.2024 Rev.'0' Dt	2.		Modification to tolage comme	OK/NOLOK
Rev.'0' Dt 30.13.10   Phase locomotives to improve reliability.				
Rev.'0' Dt 30.11.2 (10) phase locomotives to improve reliability.  Rev.'0' Dt 08.8.11 RDSO/2011/EL/MS/0401 Rev.'0' Dt 10.08.11 MODIfication sheet for shifting the termination of SGKW, 1.8 KV, 70 sq mm cables and 2x.2.5 sq mm cables housed in lower portion of HB2 panel and provision of Synthetic resin bonded glass fiber sheet for three phase locomotives.  Rev.'0' Dt 10.08.11 Modification sheet for relaying of cables in HB-2 panel of three phase locomotives and avoid fire hazards.  Rev.'0' Dt 10.08.11 Modification sheet for relaying of cables in HB-2 panel of three phase locomotives and avoid fire hazards.  Rev.'0' Dt 30.11.11 Modification sheet for relaying of cables in HB-2 panel of three phase locomotives and searchly.  Rev.'0' Dt 30.11.11 Modification of terminal connection of heater cum blower assembly.  Rev.'0' Dt 30.11.12 No.050/2012/EL/MS/0401 Modification sheet to avoid simultaneous switching On of White Rev.'1' dated 02.11.12 NO.050/2012/EL/MS/0413 Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives to improve reliability.  Rev.'1' Dt 20.64.16 Modification sheet to provide rubber sealing gasket in Master Controller of three phase locomotives.  Rev.'0' Dt 20.12.12 MS/0425 Rev.'0' Dt 20.12.13 No.050/2013/EL/MS/0425 Rev.'0' Dt 20.12.13 No.050/2013/EL/MS/0425 Rev.'0' Dt 20.13.10.13 No.050/2013/EL/MS/0425 Rev.'0' Dt 18.07.13 No.050/2013/EL/MS/0425 Rev.'0' Dt 18.07.12 No.050/2013/EL/MS/0425 Rev.'0' Dt 18.07.12 No.050/2013/EL/MS/0425 Rev.'0' Dt 18.07.12 No.050/2013/EL/MS/0425 Rev.'0' Dt 18.09.19 No.050/2013/EL/MS/0425 No.050/2013/EL/MS/0425 No.050/2013/EL/MS/0425 No.050/2013/EL/MS/0425 No	3.	RDSO/2010/EL/MS/0390	Paralleling of interlocks of EP contactors and Relays of three	Ok/Not Ok
Rev. Or Dit 0.8.08.11   MCPA circuit.		Rev.'0' Dt 31.12.10	phase locomotives to improve reliability.	-(
Modification sheet for shifting the termination of SCKW, 1.8 KV, 7.0 to 10.08.11	4.	RDSO/2011/EL/MS/0399	Removal of interlocks of control circuit contactors no. 120 nom	Øk/Not Ok
Rev. 0' Dt 10.08.11 70 sq mm cables and 2x2.5 sq mm cables housed in lower putuol of HEZ panel and provision of Synthetic resin bonded glass fiber sheet for three phase locomotives.  Rev. 0' Dt 10.08.11 phase locomotives in HB-2 panel of three phase locomotives.  Rev. 0' Dt 10.08.11 phase locomotives to avoid fire hazards.  Rev. 0' Dt 10.01.11 phase locomotives to avoid fire hazards.  Rev. 0' Dt 10.01.11 phase locomotives to avoid fire hazards.  Rev. 0' Dt 10.01.11 phase locomotives to avoid fire hazards.  Rev. 0' Dt 10.01.11 phase locomotives to avoid fire hazards.  Rev. 0' Dt 10.01.11 phase locomotives to avoid fire hazards.  Rev. 1' dated 02.11.12 phase locomotives and Red marker light in three phase electric locomotives.  Rev. 1' Dt 25.04.16 phase locomotives to locomotives and auxiliary contactors of three phase locomotives to provide rubber sealing gasket in Master Rev. 0' Dt 10.12.13 phase locomotives to provide rubber sealing gasket in Master Rev. 0' Dt 22.01.3/EL/MS/0420 phase locomotives to provide rubber sealing gasket in Master Rev. 0' Dt 12.01.12 phase locomotives.  Rev. 0' Dt 12.01.12 phase locomotives to provide rubber sealing gasket in Master Rev. 0' Dt 12.01.13 phase locomotives.  Rev. 0' Dt 12.01.13 phase locomotives.  Rev. 0' Dt 10.12.13 phase locomotives.  Modification sheet to provide mechanical locking arrangement in Rev. 0' Dt 12.01.13 phase locomotives.  Modification sheet for improving illumination of head light in QMINot Ok Rev. 0' Dt 10.12.13 phase locomotives.  Modification sheet for MCP control in three phase electric locomotives.  Rev. 0' Dt 10.12.13 phase locomotives.  Rev. 0' Dt 12.01.14 phase locomotives.  Rev. 0' Dt 12.01.14 phase locomotives.  Rev. 0' Dt 12.01.14 phase locomotives.  Rev. 0' Dt 12.01.15 phase locomotives.  Rev. 0' Dt 12.01.16 phase locomotives.  Rev. 0' Dt 12.01.17			"- ''. I' FC'D'M 1 8 KM	
6. RDSO/2011/EL/MS/0401 Rev.'0' Dt 10.08.11 7. RDSO/2011/EL/MS/0403 Rev.'0' Dt 30.11.11 8. RDSO/2012/EL/MS/0408 Rev.'0' Dt 30.11.11 8. RDSO/2012/EL/MS/0408 Rev.'0' Dt 30.11.11 Rev.'1' dated 02.11.12 10. RDSO/2012/EL/MS/0411 Rev.'1' dated 02.11.12 11. RDSO/2012/EL/MS/0411 Rev.'1' dated 02.11.12 12. RDSO/2012/EL/MS/0411 Rev.'1' dated 02.11.12 13. RDSO/2012/EL/MS/0411 Rev.'0' Dt 30.11.19 14. RDSO/2013/EL/MS/0410 15. Rev.'0' Dt 20.10.12 16. RDSO/2013/EL/MS/0410 17. RDSO/2013/EL/MS/0420 Rev.'0' Dt 20.10.13 18. RDSO/2013/EL/MS/0420 Rev.'0' Dt 20.10.13 19. RDSO/2013/EL/MS/0420 Rev.'0' Dt 10.01.13 19. RDSO/2013/EL/MS/0428 Rev.'0' Dt 18.07.13 19. RDSO/2013/EL/MS/0428 Rev.'0' Dt 10.10.13.14 19. RDSO/2013/EL/MS/0428 Rev.'0' Dt 10.10.12.13 19. RDSO/2013/EL/MS/0428 Rev.'0' Dt 10.10.12.13 19. RDSO/2013/EL/MS/0428 Rev.'0' Dt 10.10.12.13 19. RDSO/2013/EL/MS/0428 Rev.'0' Dt 10.00 11. RDSO/2013/EL/MS/0429 Rev.'0' Dt 10.00 12. RDSO/2013/EL/MS/0429 Rev.'0' Dt 10.00 18. RDSO/2013/EL/M	5.		Modification sheet for snitting the termination of solicy, as the same applies boused in lower portion	(A) 1. 1. 01.
Sheet for three phase locomotives.   Sheet for three phase locomotives   Modification sheet for relaying of cables in HB-2 panel of three phase locomotives to avoid fire hazards.   Post 10.08.11   Phase locomotives to avoid simultaneous switching ON of White and Red marker light in three phase electric locomotives assembly.   Post 10.02.012/EL/MS/0411   Rev.'1' dated 02.11.12   Phase locomotives to improve reliability.   Post 10.02.012/EL/MS/0415   Phase locomotives to improve reliability.   Post 10.02.012/EL/MS/0425   Phase locomotives to improve reliability.   Post 10.02.012/EL/MS/0425   Phase locomotives.   Post 10.02.013/EL/MS/0425   Phase locomotives.   Post 10.02.013/EL/MS/0425   Phase locomotives.   Post 10.02.013/EL/MS/0426   Phase locomotives.   Post 10.02.013/EL/MS/0427   Phase locomotives.   Post 10.02.013/EL/MS/0432   Phase locomotives.   Post 10.02.013/EL/MS/0432   Phase locomotives.   Post 10.02.013/EL/MS/0432   Phase locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON   Post 10.02.013/EL/MS/0437   Provision of Auxiliary interlock for monitoring of Harmonic filter ON   Provision of Phase Phase electric locomotives.   Provision of Phase Phas	İ	Rev.'0' Dt 10.08.11	70 sq mm cables and 2x2.5 sq fill cables floaded in lower persons and analysis of Synthetic regin handed class fiber	ZOK/NOT OK
6. RDSO/2011/EL/MS/0403   Modification sheet for relaying of cables in HB-2 panel of three phase locomotives to avoid fire hazards.  7. RDSO/2011/EL/MS/0403   Auto switching of machine room/corridor lights to avoid draining of batteries in three phase electric locomotives.  8. RDSO/2012/EL/MS/0408   Rev.'0' Dt 3.0.11.11   Rev.'1' dated 02.11.12   Auto switching of machine room/corridor lights to avoid draining of batteries in three phase electric locomotives.  9. RDSO/2012/EL/MS/0411   Rev.'1' dated 02.11.12   And Red marker light in three phase electric locomotives.  10. RDSO/2012/EL/MS/0419   And Red marker light in three phase electric locomotives.  11. RDSO/2012/EL/MS/0419   And Red marker light in three phase electric locomotives.  12. RDSO/2013/EL/MS/0420   And Red marker light in three phase locomotives.  13. RDSO/2013/EL/MS/0420   And Red marker light in three phase locomotives.  14. RDSO/2013/EL/MS/0420   And Red marker light in three phase locomotives.  15. RDSO/2013/EL/MS/0420   And Red marker light in three phase locomotives.  16. RDSO/2013/EL/MS/0420   And Red marker light in three phase electric locomotives.  17. RDSO/2013/EL/MS/0425   And Red Marker light in three phase electric locomotives.  18. RDSO/2013/EL/MS/0426   And Red Marker light in three phase electric locomotives.  19. RDSO/2013/EL/MS/0427   And Red Marker light in three phase electric locomotives.  10. RDSO/2013/EL/MS/0428   And Red Marker light in three phase electric locomotives.  11. RDSO/2013/EL/MS/0428   And Red Marker light in three phase electric locomotives.  12. RDSO/2013/EL/MS/0428   And Red Marker light in three phase electric locomotives.  13. RDSO/2013/EL/MS/0428   And Red Marker light in three phase electric locomotives.  14. RDSO/2013/EL/MS/0428   And Red Marker light lig			of HB2 panel and provision of Symmetic resim borided glass mass	
Rev.'0 Dt 10,08.11  Phase locomotives to avoid fire hazards.  RDSO/2011/EL/MS/0403 Rev.'0 Dt 30.11.11  RDSO/2012/EL/MS/04040 RDSO/2012/EL/MS/04041  RDSO/2012/EL/MS/04041  RPSO/2012/EL/MS/0413  Rev.'1 dated 02.11.12  RDSO/2012/EL/MS/0413  Rev.'1' Dt 25.04.16  Rev.'0' Dt 10.12.12  RDSO/2012/EL/MS/0419 Rev.'0' Dt 23.01.13  Rev.'0' Dt 23.01.13  Rev.'0' Dt 23.01.13  RDSO/2013/EL/MS/0420 RDSO/2013/EL/MS/0420 RDSO/2013/EL/MS/0420 RDSO/2013/EL/MS/0420 RDSO/2013/EL/MS/0420 RDSO/2013/EL/MS/0420 REV.'0' Dt 23.01.13  RDSO/2013/EL/MS/0426 REV.'0' Dt 12.05.13  RDSO/2013/EL/MS/0427 REV.'0' Dt 12.05.14  RDSO/2013/EL/MS/0427 Rev.'0' Dt 12.05.15  RDSO/2013/EL/MS/0427 Rev.'0' Dt 10.07.13  RDSO/2013/EL/MS/0427 Rev.'0' Dt 10.07.14  RDSO/2013/EL/MS/0427 Rev.'0' Dt 10.07.14  RDSO/2013/EL/MS/0427 Rev.'0' Dt 10.07.14  RDSO/2013/EL/MS/0428 Rev.'0' Dt 10.07.14  RDSO/2013/EL/MS/0429 Rev.'0' Dt 10.07.14  RDSO/2013/EL/MS/0429 Rev.'0' Dt 10.07.14  RDSO/2013/EL/MS/0429 Rev.'0' Dt 10.07.14  RDSO/2013/EL/MS/0430 Rev.'0' Dt 10.07.14  RDSO/2013/EL/MS/0430 Rev.'0' Dt 10.07.14  RDSO/2013/EL/MS/0430 Rev.'0' Dt 10.07.14  RDSO/2013/EL/MS/0430 Rev.'0' Dt 10.07.14  RDSO/2014/EL/MS/0430 Rev.'0' Dt 10.07.15  RDSO/2014/EL/MS/0500 Rev.'0' Dt 10.07.15  RDSO/2014/EL/MS/0500 Re	<u> </u>			200
7. RDSO/2011/ELMS/0403 Auto switching of machine room/corridor lights to avoid draining of batteries in three phase electric locomotives.  Rev. '0' Dt 30.11.11   7. RDSO/2012/ELMS/0408   Rev. '1' dated 02.11.12   7. RDSO/2012/ELMS/0411   7. RDSO/2012/ELMS/0411   7. RDSO/2012/ELMS/0411   7. RDSO/2012/ELMS/0411   7. RDSO/2012/ELMS/0419   7. RDSO/2012/ELMS/0419   7. RDSO/2013/ELMS/0419   7. RDSO/2013/ELMS/0419   7. RDSO/2013/ELMS/0419   7. RDSO/2013/ELMS/0419   7. RDSO/2013/ELMS/0420   7. Rev. '0' Dt 23.01.13   7. Rev. '0' Dt 23.01.13   7. RDSO/2013/ELMS/0420   7. Rev. '0' Dt 23.01.13   7. RDSO/2013/ELMS/0425   7. Rev. '0' Dt 23.01.13   7. RDSO/2013/ELMS/0427   7. Rev. '0' Dt 23.01.13   7. RDSO/2013/ELMS/0427   7. Rev. '0' Dt 23.10.13   7. RDSO/2013/ELMS/0428   7. Rev. '0' Dt 25.09.17   7. RDSO/2013/ELMS/0432   7. Rev. '0' Dt 12.03.14   7. RDSO/2017/ELMS/0432   7. Rev. '0' Dt 13.09.19   7. Rev. '0' Dt 13.09.204   7. RDSO/2017/ELMS/0432   7. Rev. '0' Dt 13.09.204   7. RDSO/2014/ELMS/0430   7. Rev. '0' Dt 13.09.204   7. RDSO/2014/ELMS/0430   7. Rev. '0' Dt 13.09.204   7. RDSO/2024/ELMS/0500   7. Rev. '0' Dt 13.09.204   7. RDSO/2024/ELMS/0500   7. Rev. '0' Dt 13.	6.		Modification sheet for relaying of capies in Fib-2 parior of the	ØK/Not OK
Rev.'0' Dt 30.11.11 batteries in three phase electric locomotives.  RDSO/2012/EL/MS/0408 Modification of terminal connection of heater cum blower assembly.  RDSO/2012/EL/MS/0413 Modification sheet to avoid simultaneous switching ON of White Rev.'1' dated 02.11.12 and Red marker light in three phase electric locomotives.  Rev.'1' Dt 25.04.16 Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives to improve reliability.  Rev.'0' Dt 20.12.12 Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives to improve reliability.  Rev.'0' Dt 20.12.12 Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives to improve reliability.  Rev.'0' Dt 20.12.12 Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives.  Rev.'0' Dt 20.12.12 Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives.  Rev.'0' Dt 20.12.12 Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives.  Rev.'0' Dt 20.12.12 Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives.  Rev.'0' Dt 20.12.12 Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives.  Rev.'0' Dt 20.13/EL/MS/0425 Modification sheet to provide mechanical locking arrangement in QK/Not Ok defined to three phase electric locomotives.  Rev.'0' Dt 10.12.13 Paralleling of interlocks of minimal paralleling of phase electric locomotives.  Rev.'0' Dt 10.12.13 Rev.'0' Dt 12.03.14 Rev.'0' D		Rev.'0' Dt 10.08.11	phase locomotives to avoid life flazards.	ON IN CUE
8. RDSO/2012/EL/MS/0408 Rev.'0' Dt 20.13.12 10. RDSO/2013/EL/MS/0413 Rev.'1' Dt 25.04.16 11. RDSO/2013/EL/MS/0413 Rev.'0' Dt 20.12.12 12. RDSO/2013/EL/MS/0420 Rev.'0' Dt 20.13.13 13. RDSO/2013/EL/MS/0420 Rev.'0' Dt 20.13.13 14. RDSO/2013/EL/MS/0425 Rev.'0' Dt 13.01.31 15. RDSO/2013/EL/MS/0426 Rev.'0' Dt 12.01.31 16. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.01.31 17. RDSO/2013/EL/MS/0428 Rev.'0' Dt 20.30.13 18. RDSO/2013/EL/MS/0429 Rev.'0' Dt 20.30.13 19. RDSO/2013/EL/MS/0425 Rev.'0' Dt 20.30.13 10. RDSO/2013/EL/MS/0425 Rev.'0' Dt 23.01.31 10. RDSO/2013/EL/MS/0425 Rev.'0' Dt 23.01.32 Rev.'0' Dt 23.01.31 11. RDSO/2013/EL/MS/0426 Rev.'0' Dt 13.07.32 12. RDSO/2013/EL/MS/0426 Rev.'0' Dt 12.03.31 13. RDSO/2013/EL/MS/0425 Rev.'0' Dt 12.03.31 14. RDSO/2013/EL/MS/0425 Rev.'0' Dt 12.03.31 15. RDSO/2013/EL/MS/0426 Rev.'0' Dt 12.03.31 16. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 17. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 18. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 19. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 10. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 11. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 12. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 13. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 14. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 15. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 16. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 17. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 18. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 19. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.31 19. RDSO/2013/EL/MS/0428 Rev.'0' Dt 12.03.41 19. RDSO/2013/EL/MS/0429 Rev.'0' Dt 13.09.2024 19. RDSO/2013/EL/MS/0437 Rev.'0' Dt 13.09.2024 19. RDSO/2013/EL/MS/0457 Rev.'0' Dt 13.09.2024 19. RDSO/2024/EL/MS/0503 Rev'0' Dt 11.09.2024 10. RDSO/2024/EL/MS/0504 Rev'0' Dt 11.09.2024 10. RDSO/2024/EL/MS/0504 Rev'0' Dt 11.09.2024 10. RDSO/2024/EL/MS/0504 Rev'0' D	7.		hatteries in three phase electric locomotives	OK/NOT OK
Rev.'0'   assembly.   RDSO/2012/EL/MS/0413   Addification sheet to avoid simultaneous switching ON of White Rev.'1' dated 02.11.12   and Red marker light in three phase electric locomotives.   Rev.'1' Dt 25.04.16   three phase locomotives to Improve reliability.   Rev.'1' Dt 25.04.16   three phase locomotives to Improve reliability.   Rev.'0' Dt 20.12.12   RDSO/2012/EL/MS/0419   Rev.'0' Dt 20.12.12   Rev.'0' Dt 20.12.12   Controller of three phase locomotives.   Rev.'0' Dt 23.01.13   RDSO/2013/EL/MS/0425   Rev.'0' Dt 23.01.13   RDSO/2013/EL/MS/0426   Rev.'0' Dt 23.01.13   RDSO/2013/EL/MS/0426   Rev.'0' Dt 18.07.13   RDSO/2013/EL/MS/0426   Rev.'0' Dt 18.07.13   RDSO/2013/EL/MS/0426   Rev.'0' Dt 18.07.13   ROSO/2013/EL/MS/0426   Rev.'0' Dt 23.10.13   RDSO/2013/EL/MS/0426   Rev.'0' Dt 18.07.13   Rev.'0' Dt 23.10.13   RDSO/2013/EL/MS/0426   Rev.'0' Dt 18.07.13   Rev.'0' Dt 23.10.13   Rev.'0' Dt 18.07.13   Rev.'0' Dt 18.07.14   Rev.'0' Dt 18.07.15   Rev.'0' Dt 18.07.17   Rev.'0' Dt 18.09.19   Rev.'0' Dt 19.09.204   Rev.'0' Dt	<u></u>	Rev. 0' Dt 30.11.11		Old Not Ok
9. RDSO/2012/EL/MS/0411 Modification sheet to avoid simultaneous switching ON of White Rev.'1' dated 02.11.12 and Red marker light in three phase electric locomotives.  10. RDSO/2012/EL/MS/0419 Modification sheet to provide rubber sealing gasket in Master Rev.'0' Dt 23.01.12 Controller of three phase locomotives.  11. RDSO/2013/EL/MS/0420 Modification sheet to provide rubber sealing gasket in Master Controller of three phase locomotives.  12. RDSO/2013/EL/MS/0420 Modification sheet to provide mechanical locking arrangement in Primary Over Current Relay of three phase locomotives.  13. RDSO/2013/EL/MS/0426 Modification sheet to provide mechanical locking arrangement in Primary Over Current Relay of three phase locomotives.  14. RDSO/2013/EL/MS/0426 Modification sheet for improving illumination of head light in dimmer mode in three phase electric locomotives.  15. RDSO/2013/EL/MS/0427 Modification sheet of Bogie isolation rotary switch in three phase electric locomotives.  16. RDSO/2013/EL/MS/0427 Modification sheet for mCP control in three phase electric locomotives.  17. RDSO/2013/EL/MS/0428 Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.  17. RDSO/2014/EL/MS/0432 Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.  18. RDSO/2017/EL/MS/0449 Provision of Auxiliary interlock for monitoring of Harmonic filter ON Rev.'0' Dt 25.99.17 (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.  19. RDSO/2014/EL/MS/0437 Modification in blocking diodes to improve reliability in three phase electric locomotives.  20. RDSO/2018/EL/MS/0457 Rev.'0' Dt 13.09.2024  Rev.'0' Dt 13.09.2024  RDSO/2024/EL/MS/0500 Rev'0' Dt 10.10.2024  RDSO/2024/EL/MS/0500 Rev'0' Dt 10.00.2024  RDSO/2024/EL/MS/0500 Rev'0' Dt 10.00.2024  RDSO/2024/EL/MS/0500 Rev'0' Dt 10.00.2024  RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives filted with	8.		accembly	OK/NOL OK
Rev.'1' dated 02.11.12   and Red marker light in three phase electric locomotives   RDSO/2012/EL/MS/0419   Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives to improve reliability.   Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives.   Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives.   Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives.   Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives.   Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives.   Paralleling of interlocks of EP contactor in proving interlock in proving interlock in proving interlock in proving interlock interlock in proving interlock interlock in proving interlock inte			Modification sheet to avoid simultaneous switching ON of White	OKINION OF
RosO/2012/EL/MS/0413   Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives to improve reliability.   Paralleling of three phase locomotives to improve reliability.   Paralleling of three phase locomotives.   Paralleling of three phase lo	9.		and Red marker light in three phase electric locomotives.	PK/NOLOK
Rev.'1' Dt 25.04.16   of three phase locomotives to improve reliability.   RDSO/2012/EL/MS/0420   RDSO/2013/EL/MS/0420   Modification sheet to provide rubber sealing gasket in Master Controller of three phase locomotives.   QK/Not Ok Rev.'0' Dt 23.01.13   Primary Over Current Relay of three phase locomotives.   QK/Not Ok Rev.'0' Dt 23.01.13   Primary Over Current Relay of three phase locomotives.   QK/Not Ok Rev.'0' Dt 22.05.13   Modification sheet for improving illumination of head light in dimmer mode in three phase electric locomotives.   Modification sheet of Bogle isolation rotary switch in three phase electric locomotives.   Modification sheet for MCP control in three phase electric locomotives.   Modification sheet for MCP control in three phase electric locomotives.   Rev.'0' Dt 23.10.13   Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.   Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   QK/Not Ok Rev.'0' Dt 10.7.12.17   Modification in blocking diodes to improve reliability in three phase electric locomotives.   Provision of Plasher light operation either due to fault or manually by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.   Resor/2024/EL/MS/0502   Recording of Flasher light operation either due to fault or manually by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.   Rev.'0' Dt 10.10.2024   Unloader valve control circuit modification in three Phase Electric Locomotives   Rev.'0' Dt 10.10.2024   Unloader valve control circuit modification in three Phase Electric Locomotives   Rev.'0' Dt 10.10.2024   Unloader valve control circuit modification to timprove reliability of three phase electric locomotives   Sk/Not Ok   Sk/No	4.0	Rev. 1 dated 02.11.12		OK/Not Ok
RDSO/2012/EL/MS/0419   Modification sheet to provide rubber sealing gasket in Master Rev. 0 Dt 20.12.12   Controller of three phase locomotives.   QK/Not Ok	10		of three phase locomotives to improve reliability.	WKINOL OK
Rev.'0' Dt 20.12.12   Controller of three phase locomotives.   RDSO/2013/EL/MS/0420   Modification sheet to provide mechanical locking arrangement in Primary Over Current Relay of three phase locomotives.   QK/Not Ok	1		Modification sheet to provide rubber sealing gasket in Master	OldNot Ok
RDSO/2013/EL/MS/0425   Modification sheet to provide mechanical locking arrangement in Primary Over Current Relay of three phase locomotives.	11		Controller of three phase locomotives	OR/NOT OK
Rev.'0' Dt 23.01.13 Primary Over Current Relay of three phase locomotives.  RDSO/2013/EL/MS/0425 Modification sheet for improving illumination of head light in dimmer mode in three phase electric locomotives.  RDSO/2013/EL/MS/0426 Modification sheet of Bogie isolation rotary switch in three phase electric Rev.'0' Dt 18.07.13 Modification sheet of Bogie isolation rotary switch in three phase electric Rev.'0' Dt 18.07.13 Modification sheet for MCP control in three phase electric Rev.'0' Dt 10.10.13 Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.  RDSO/2013/EL/MS/0428 Rev.'0' Dt 10.12.13 Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.  REV.'0' Dt 12.03.14 Rev.'0' Dt 12.03.14 Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.  Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.  Modification in blocking diodes to improve reliability in three phase electric locomotives.  Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.  RDSO/2019/EL/MS/0477 Rev.'0' Dt 18.09.19 Modification of push pull scheme.  REV.'0' Dt 10.10.2024 Secording of Flasher light operation either due to fault or manually by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.  RDSO/2024/EL/MS/0500 Recording of interlocks of control circuit contactor to improve reliability of three phase electric locomotives.  RDSO/2024/EL/MS/0503 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives.  RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with	40	Rev. 0 Dt 20.12.12		Old let Ok
RDSO/2013/EL/MS/0425   Modification sheet for improving illumination of head light in dimmer mode in three phase electric locomotives.   Modification sheet of Bogie isolation rotary switch in three phase electric locomotives.   Modification sheet of Bogie isolation rotary switch in three phase electric locomotives.   Modification sheet for MCP control in three phase electric locomotives.   Modification sheet for MCP control in three phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.   Rev.'0' Dt 10.12.13   Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.   Rev.'0' Dt 25.09.17   RDSO/2017/EL/MS/0464   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   QK/Not Ok   QK/Not Ok   Rev.'0' Dt 12.03.14   Robso/2018/EL/MS/0467   Rev.'0' Dt 18.09.19   Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.   Implementation of push pull scheme.   QK/Not Ok   QK/Not O	12		Primary Over Current Relay of three phase locomotives.	OKNINGE OK
Rev.'0' Dt 22.05.13   dimmer mode in three phase electric locomotives.   Modification sheet of Bogie isolation rotary switch in three phase electric locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.   Modification in three phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.   Modification in three phase electric locomotives.   Modification in provided at c-d terminal of over current relay of three phase electric locomotives.   Modification in provided at c-d terminal of over current relay of three phase electric locomotives.   Modification in provided at c-d terminal of over current relay of three phase electric locomotives.   Modification in provided at c-d terminal of over current relay of three phase electric locomotives.   Modification in provided at c-d terminal of over current relay of three phase electric locomotives.   Modification in provided at c-d terminal of over current relay of three phase electric locomotives.   Modification in provided at c-d terminal of over current relay of three phase electric locomotives.   Modification in provided at c-d terminal of over current relay of three phase electric locomotives.   Modification in provided at c-d terminal of over current relay of three phase electric locomotives.   Modification in provided at c-d terminal of over current relay of three phase electric locomotives.   Modification in provided at c-d terminal of over current relay of three phase electric locomotives.   Modification in provided at c-d terminal of over current relay of three phase electric locomotives.   Modification	42			OKNIN OK
RDSO/2013/EL/MS/0426   Rev.'0' Dt 18.07.13   electric locomotives.   Modification sheet for MCP control in three phase electric locomotives.   Modification sheet for MCP control in three phase electric locomotives.   Modification sheet for mCP control in three phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.   Rev.'0' Dt 10.12.13   Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.   Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (Rev.'0' Dt 25.09.17   Modification in blocking diodes to improve reliability in three phase electric locomotives.   Modification in existing Control Electronics (CE) resetting scheme electric locomotives.   Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.   Modification in existing Control Electronics (CE) resetting scheme electric locomotives.   Modification in existing Control Electronics (CE) resetting scheme   Modification in three Phase Electric locomotives   Modification in three Phase E	13		dimmer mode in three phase electric locomotives.	QK/NOT OK
Rev.'0' Dt 18.07.13  15 RDSO/2013/EL/MS/0427 Rev.'0' Dt 23.10.13  16 RDSO/2013/EL/MS/0428 Rev.'0' Dt 10.12.13  17 RDSO/2013/EL/MS/0432 Rev.'0' Dt 10.12.13  18 RDSO/2014/EL/MS/0432 Rev.'0' Dt 12.03.14  19 RDSO/2017/EL/MS/0464 Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.  19 RDSO/2017/EL/MS/0467 Rev.'0' Dt 07.12.17  20 RDSO/2018/EL/MS/0457 Rev.'0' Dt 18.09.19  21 RDSO/2019/EL/MS/0467 Rev.'0' Dt 13.09.2024  22 RDSO/2024/EL/MS/0500 Rev'0' Dt 10.10.2024  23 RDSO/2024/EL/MS/0500 Rev'0' Dt 10.10.2024  24 RDSO/2024/EL/MS/0503 Rev'0' Dt 17.09.2024  25 RDSO/2024/EL/MS/0504  RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives  Hodification sheet for MCP control in three phase electric locomotives.  Modification sheet for MCP control in three phase electric locomotives.  Modification sheet for MCP control in three phase electric locomotives.  Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.  Removal of shorting link provided at c-d terminal of over current relay for harmonic filter on Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.  Modification sheet for MCP control electric locomotives.  Modification sheet for relocation of earth fault relays for harmonic filter ON (8.1)/Adoption (8.2) Contactor in GTO/IGBT locomotives.  Modification in blocking diodes to improve reliability in three phase electric locomotives.  Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.  Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.  Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.  Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.  Modification sheet for relocation of Harmonic filter ON (M/Not Ok)  Modification sheet fo	1.4			QL/Not Ok
15 RDSO/2013/EL/MS/0427   Modification sheet for MCP control in three phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter on the phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter on the phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter on the phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter on the phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter on the phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter on the phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter on the phase electric locomotives.   Modification sheet for relocation of earth fault relays for harmonic filter on the phase electric locomotives.   Modification sheet for relocation in three phase electric locomotives.   Modification of flasher light operation either due to fault or manually by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.   Modification in three Phase Electric locomotives.   Modification in three Phase Electric locomotives.   Modification in three phase electric locomotives   Modification in three phase electric locomotives   Modification in existing Control circuit contactor to improve reliability of three phase electric locomotives   Modification in th	14			EXMOTOR
Rev.'0' Dt 23.10.13 locomotives.  Rov.'0' Dt 10.12.13 Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.  Rov.'0' Dt 12.03.14 Rev.'0' Dt 12.03.14 relay of three phase electric locomotives.  Roso/2017/EL/MS/0464 Rev.'0' Dt 25.09.17 Rev.'0' Dt 25.09.17 (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.  Modification in blocking diodes to improve reliability in three phase electric locomotives.  Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.  Roso/2018/EL/MS/0477 Rev.'0' Dt 18.09.19  Roso/2024/EL/MS/0500 Recording of Flasher light operation either due to fault or manually by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.  Roso/2024/EL/MS/0502 Roso/2024/EL/MS/0503 Rev'0' Dt 10.10.2024 Locomotives.  Roso/2024/EL/MS/0503 Rev'0' Dt 17.09.2024 reliability of three phase electric locomotives.  Roso/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with	15		7 Modification sheet for MCP control in three phase electric	ONTINO OK
RDSO/2013/EL/MS/0428   Rev.'0' Dt 10.12.13   RDSO/2014/EL/MS/0432   Rev.'0' Dt 12.03.14   RDSO/2017/EL/MS/0434   Rev.'0' Dt 12.03.14   RDSO/2017/EL/MS/0464   Rev.'0' Dt 25.09.17   RDSO/2017/EL/MS/0467   Rev.'0' Dt 07.12.17   RDSO/2018/EL/MS/0475   Rev.'0' Dt 07.12.17   RDSO/2018/EL/MS/0475   Rev.'0' Dt 07.12.17   RDSO/2019/EL/MS/0475   Rev.'0' Dt 18.09.19   RDSO/2019/EL/MS/0477   Rev.'0' Dt 18.09.19   Rev.'0' Dt 18.09.19   Recording of Flasher light operation either due to fault or manually by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.   Unloader valve control circuit modification in three Phase Electric Locomotives.   Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives.   Ok/Not Ok   Ok/Not Ok/Not Ok	'			ØK/NOL OK
filter and hotel load along with its resistors in three phase electric locomotives.    Rev.'0' Dt 12.03.14   Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.    Rev.'0' Dt 12.03.14   Provision of Auxiliary interlock for monitoring of Harmonic filter ON Rev.'0' Dt 25.09.17   R.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.    Roso/2017/EL/MS/0467   Rev.'0' Dt 07.12.17   Modification in blocking diodes to improve reliability in three phase electric locomotives.    Roso/2018/EL/MS/0475   Rev.'0' Dt 18.09.19   Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.    Roso/2019/EL/MS/0500   Recording of Flasher light operation either due to fault or manually by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.    Roso/2024/EL/MS/0502   Rev.'0' Dt 10.10.2024   Unloader valve control circuit modification in three Phase Electric Locomotives.    Roso/2024/EL/MS/0503   Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives   Ok/Not Ok	16		Modification sheet for relocation of earth fault relays for harmonic	
locomotives.   locomotives.   RDSO/2014/EL/MS/0432   Reworld of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.   RDSO/2017/EL/MS/0464   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   QK/Not Ok (8.1)/adoption (8.1			filter and hotel load along with its resistors in three phase electric	Qk/Not Ok
Rev.'0' Dt 12.03.14   Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   Provision of Auxiliary interlock for monitoring of Harmonic filter on GK/Not Ok   Provision of Auxiliary interlock for monitoring of Harmonic filter for Marmonic filter on GK/Not Ok   Provision of Auxiliary interlock for monitoring of Harmonic filter for Marmonic filter for Marmonic filter for Marmonic filter on GK/Not Ok   Provision of Auxiliary interlock for monitoring of Harmonic filter for Marmonic filte		1.00.0 2. 10.12.10	locomotives.	
Rev.'0' Dt 12.03.14 relay of three phase electric locomotives.  18 RDSO/2017/EL/MS/0464 Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.  19 RDSO/2017/EL/MS/0467 Modification in blocking diodes to improve reliability in three phase electric locomotives.  20 RDSO/2018/EL/MS/0475 Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.  21 RDSO/2019/EL/MS/0477 Rev.'0' Dt 18.09.19  22 RDSO/2024/EL/MS/0500 Recording of Flasher light operation either due to fault or manually by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.  23 RDSO/2024/EL/MS/0502 Rev '0' Dt 10.10.2024 Unloader valve control circuit modification in three Phase Electric Locomotives.  24 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives fitted with	17	RDSO/2014/EL/MS/043		Øk/Not Ok
RDSO/2017/EL/MS/0464   Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   QK/Not Ok (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   QK/Not Ok (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.   QK/Not Ok electric locomotives.   QK/Not Ok	'.'	1	relay of three phase electric locomotives.	Civitor On
Rev.'0' Dt 25.09.17  RDSO/2017/EL/MS/0467 Rev.'0' Dt 07.12.17  RDSO/2018/EL/MS/0475 Rev.'0'  RDSO/2018/EL/MS/0475 Rev.'0'  RDSO/2019/EL/MS/0477 Rev.'0'  RDSO/2019/EL/MS/0500 Rev.'0' Dt 13.09.2024  RDSO/2024/EL/MS/0502 Rev.'0' Dt 10.10.2024  RDSO/2024/EL/MS/0503 Rev.'0' Dt 17.09.2024  RDSO/2024/EL/MS/0504	18		4 Provision of Auxiliary interlock for monitoring of Harmonic filter ON	OK/Not Ok
19 RDSO/2017/EL/MS/0467 Rev.'0' Dt 07.12.17 20 RDSO/2018/EL/MS/0475 Rev.'0' Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.  21 RDSO/2019/EL/MS/0477 Rev.'0' Dt 18.09.19  22 RDSO/2024/EL/MS/0500 Rev '0' Dt. 13.09.2024 Rev '0' Dt. 13.09.2024 Rev '0' Dt 10.10.2024  23 RDSO/2024/EL/MS/0502 Rev '0' Dt 10.10.2024  24 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024  25 RDSO/2024/EL/MS/0504  26 RDSO/2024/EL/MS/0504 Rev '0' Dt 17.09.2024  27 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024  28 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024  29 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024  20 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024  21 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024  22 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024  23 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024  24 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024  25 RDSO/2024/EL/MS/0504  26 RDSO/2024/EL/MS/0504  27 RDSO/2024/EL/MS/0504  28 RDSO/2024/EL/MS/0504  29 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024  20 RDSO/2024/EL/MS/0503		1	(8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.	QIGITOT OIL
Rev.'0' Dt 07.12.17 electric locomotives.  20 RDSO/2018/EL/MS/0475 Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.  21 RDSO/2019/EL/MS/0477 Rev.'0' Dt 18.09.19 Implementation of push pull scheme.  22 RDSO/2024/EL/MS/0500 Recording of Flasher light operation either due to fault or manually by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.  23 RDSO/2024/EL/MS/0502 Rev '0' Dt 10.10.2024 Unloader valve control circuit modification in three Phase Electric Locomotives.  24 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives Ok/Not Ok  25 RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with	19		7 Modification in blocking diodes to improve reliability in three phase	OK/Not Ok
20 RDSO/2018/EL/MS/0475 Rev.'0' Sphase electric locomotives.  21 RDSO/2019/EL/MS/0477 Rev.'0' Dt 18.09.19 Implementation of push pull scheme.  22 RDSO/2024/EL/MS/0500 Recording of Flasher light operation either due to fault or manually by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.  23 RDSO/2024/EL/MS/0502 Rev '0' Dt 10.10.2024 Unloader valve control circuit modification in three Phase Electric Locomotives.  24 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives (CE) resetting scheme of 3 phase electric locomotives.  Øk/Not Ok  Øk/Not Ok  Ok/Not Ok  Ok/Not Ok  Sev '0' Dt 17.09.2024 Isolation of Harmonic Filter from 3-phase locomotives fitted with	1.		electric locomotives.	Zeititut OK
Rev.'0' of 3 phase electric locomotives.  21 RDSO/2019/EL/MS/0477 Implementation of push pull scheme.  22 RDSO/2024/EL/MS/0500 Recording of Flasher light operation either due to fault or manually by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.  23 RDSO/2024/EL/MS/0502 Rev '0' Dt 10.10.2024 Unloader valve control circuit modification in three Phase Electric Locomotives.  24 RDSO/2024/EL/MS/0503 Rev '0' Dt 17.09.2024 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives  25 RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with	20			Ok/Not Ok
Rev.'0' Dt 18.09.19  22 RDSO/2024/EL/MS/0500 Recording of Flasher light operation either due to fault or manually by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.  23 RDSO/2024/EL/MS/0502 Unloader valve control circuit modification in three Phase Electric Locomotives.  24 RDSO/2024/EL/MS/0503 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives  25 RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with		Rev:'0'	of 3 phase electric locomotives.	estation on
22 RDSO/2024/EL/MS/0500 Rev '0' Dt. 13.09.2024 Sphase Electric Locomotives.  23 RDSO/2024/EL/MS/0502 Unloader valve control circuit modification in three Phase Electric Locomotives.  24 RDSO/2024/EL/MS/0503 Rev '0' Dt 10.10.2024 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives.  25 RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with	21	RDSO/2019/EL/MS/047	7 Implementation of push pull scheme.	OKINIO OL
Rev '0' Dt. 13.09.2024 by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.  23 RDSO/2024/EL/MS/0502 Unloader valve control circuit modification in three Phase Electric Locomotives.  24 RDSO/2024/EL/MS/0503 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives  25 RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with		Rev.'0' Dt 18.09.19		CIVINOL OK
Rev '0' Dt. 13.09.2024 by Loco Pilot in case of emergency with time stamping in VCU of 3-phase Electric Locomotives.  23 RDSO/2024/EL/MS/0502 Unloader valve control circuit modification in three Phase Electric Locomotives.  24 RDSO/2024/EL/MS/0503 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives  25 RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with	22	RDS0/2024/FL/MS/050	Recording of Flasher light operation either due to fault or manually	
3-phase Electric Locomotives.  23 RDSO/2024/EL/MS/0502 Unloader valve control circuit modification in three Phase Electric Locomotives.  24 RDSO/2024/EL/MS/0503 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives  25 RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with	~~	•	by Loco Pilot in case of emergency with time stamping in VCU of	Øk/Not Ok
23 RDSO/2024/EL/MS/0502 Unloader valve control circuit modification in three Phase Electric Ok/Not Ok  24 RDSO/2024/EL/MS/0503 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives  25 RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with				
Rev '0' Dt 10.10.2024 Locomotives  24 RDSO/2024/EL/MS/0503 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives  25 RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with	23	RDS0/2024/FL/MS/050	2 Unloader valve control circuit modification in three Phase Electric	<i>(</i>
24 RDSO/2024/EL/MS/0503 Paralleling of interlocks of control circuit contactor to improve reliability of three phase electric locomotives  25 RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with	د ا	1		Ok/Not Ok
Rev '0' Dt 17.09.2024 reliability of three phase electric locomotives  25 RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with	-			
25 RDSO/2024/EL/MS/0504 Isolation of Harmonic Filter from 3-phase locomotives fitted with	24			Ok/Not Ok
		Rev '0' Dt 17.09.2024	reliability of three phase electric locomotives	, , , , , , , , , , , , , , , , , , , ,
	25	RDSO/2024/EL/MS/050		
1 · 1 · 1 · 1 · 1 · 1 · 1 · 1 · 1 · 1 ·		Rev '0' Dt 21.11.2024	M/s Alstom (BTIPL), CGPISL and Medha make IGBT based	
Propulsion Equipment	ĺ			

Signature of JE/SSE/ECS

Loco No.: 42014

#### PLW/PATIALA

#### PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

SN	Parameters	Reference	Value	Result
	Brake Panel: M/s Faiveley			
1.0	Auxiliary Air supply system (Pantograph & VCB)			
1.1	Ensure, Air is completely vented from pantograph			0
	Reservoir (Ensure Panto gauge reading is Zero)			
1.2	Turn On BL Key. Now MCPA starts.		60 sec. (Max.)	58 sec
	Record pressure Build up time (8.0 kg/cm2)			
1.3	Auxiliary compressor safety Valve 23F setting	Faiveley Doc. No.	8.5±0.25kg/cm2	8.5 Kg/cm2
		DMTS-014-1, 8 CLW's	-	
		check sheet no.		
		F60.812 Version 2		
1.4	Check VCB Pressure Switch Setting	CLW's check sheet	Opens 4.5±0.15	4.45 Kg/cm2
		no. F60.812 Version 2	kg/cm2, closes	
			5.5±0.15 kg/cm2	5.45 Kg/cm2
1.5	Set pantograph Selector Switch is in Auto, Open pan-1&2 Is	solating Cocks & KABA c	,	•
1.6	Set Cab-1 Pan UP in Panel A.		Observed Pan-2	ОК
			Rises.	
1.7	Close Pan-2 isolating Cock		Panto-2 Falls Down	OK
4.0	Open Pan -2 isolating Cock		Panto-2 Rises	0.6
1.8	Record Pantograph Rise time		06 to 10 seconds	8 Sec
1.9	Record Pantograph Lowering Time		06 to 10 seconds	9 Sec
1.10	Panto line air leakage		0.7 kg/cm2 in 5	0.10 kg/cm2
1 11	High Doorh Donto amarganay tost and reset		Min.	in 5 Min.
2.0	High Reach Panto emergency test and reset.  Main Air Supply System			ok
	1 1 1 1	The constitution is		
2.1	Ensure, Air is completely vented from locomotive. Drain	Theoretical		
	out all the reservoirs by opening the drain cocks and then closed drain cocks. MR air pressure build up time by each	calculation and test performed by		
	compressor from 0 to 10 kg/cm2.	Railways.		
	i) with 1750 LPM compressor	Mailways.	i) 7 mins Max.	6 min. & 45
	ii) with 1450 LPM compressor		ii) 8.5 mins Max.	sec.
	III With 1430 Et W. Compressor		ny 0.5 mms wax.	Jec.
2.2	Drain air below MR 8 kg/cm2 to start both the		Check Starting of	ok
	compressors		both compressors	
2.3	Drain air from main reservoir up to 7 kg/cm2. Start		30 Sec. (Max)	CP1-29 Sec
	compressors, Check pressure build time of individual		, ,	
	compressor from 8 kg/cm2 to 9 kg/cm2			CP2-28 Sec
2.4	Check Low MR Pressure Switch Setting (37)	D&M test spec.	Closes at 6.40±0.15	6.45 Kg/cm2
		MM3882 &	kg/cm2 Opens at	
		MM3946	5.60±0.15kg/cm2	5.6 Kg/cm2
2.5	Check compressor Pressure Switch RGCP setting (35)	D&M test spec.	Opens at 10±0.20	10 Kg/cm2
		MM3882 &	kg/cm2, Closes	
		MM3946	at 8±0.2kg/cm2	8 Kg/cm2
2.6	Run both the compressors Record Pressure build up time	Trial results	3.5 Minutes Max.	3.45 minute

#### PLW/PATIALA

Loco No.: 42014

2.8   Check Auto Drain Valve functioning (124 & 87)	2.7	Check unloader val	ve operation time				Approx. 12 Sec.	11 sec
Check CP-I delivery safety valve setting (10/1). Run CP   D&M test spec.   11.50±0.35   11.6 Kg/cm2   2.10   Check CP-2 delivery safety valve setting (10/2). Run CP   Direct by BLCP   11.50±0.35   11.5 Kg/cm2   2.11   Switch 'OFF' the compressors and ensure that the safety valve to reset at pressure 1.2 kg/cm2 less than opening pressure.   D&M test spec.   MM3882 & MM3946   kg/cm2   11.5 Kg/cm2   0.00   MM3882 & MM3946   kg/cm2   0.00   MM3882 & MM3946   kg/cm2   0.00   MM3882 & MM3946   kg/cm2   0.00   0.00 Kg/cm2   0.00   0.				24 & 87)				
2.9   Check CP-I delivery safety valve setting (10/1). Run CP   D&M test spec.   MM3882 & MM3946   kg/cm2   11.5				,				
Direct by BLCP								
2.10   Check CP-2 delivery safety valve setting (10/2). Run CP   Mirest by BLCP   Mirest by Compressors and ensure that the safety valve to reset at pressure 1.2 kg/cm2 less than opening pressure.   Mirest spec.   Mi	2.9	Check CP-I delivery	safety valve setting	(10/1). Run CP	D&M t	est spec.	11.50±0.35	11.6 Kg/cm2
direct by BLCP  2.11 Switch 'OFF' the compressors and ensure that the safety valve to reset at pressure 1.2 kg/cm2 less than opening pressure.  2.12 BP Pressure: Switch 'OFF' compressor, Drain MR Pressure by drain cock of 1" Main Reservoir, Start Compressor, check setting pressure of Duplex Check Valve 92F.  2.13 FP pressure: Switch 'OFF' compressor, Check Valve 92F.  2.14 First Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.  3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2 <sup>56</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step  Check proportionality of Auto Brake system  CLW's check sheet no. F60.812 Version 2  Tower to change every minute  D&M test spec. MM3882 & MM3946  Should be less than 1 kg/cm2 in 15 minutes  0.04 Kg/cm2 in 15 minutes  0.15 kg/cm2 in 15 minutes  0.05 kg/cm2 in 15 minutes  0.06 kg/cm2 in 15 minutes  0.06 kg/cm2 in 15 minutes  0.07 kg/cm2 in 5 minutes  0.04 kg/cm2 in 5 minutes  0.06 kg/cm2 in 5 minutes  0.06 kg/cm2 in 5 minutes  0.07 kg/cm2 in 5 minutes  0.08 kg/cm2 in 5 minutes  0.09 kg/cm2 in 5 minutes  0.00 con kg/cm2 in 5 minutes  0.00		Direct by BLCP.			MM3882	& MM3946	kg/cm2	
2.11 Switch 'OFF' the compressors and ensure that the safety valve to reset at pressure 1.2 kg/cm² less than opening pressure.  2.12 BP Pressure: Switch 'OFF' compressor, Drain MR Pressure by drain cock of 1" Main Reservoir, Start Compressor, check setting pressure of Duplex Check Valve 92F.  2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.  3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2"d MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  Brake Test (Automatic Brake operation)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step  Check proportionality of Auto Brake system  CLW's check sheet no. F60.812 Version 2  D&M test spec. MM3882 & MM3946  Should be less than 1 kg/cm2 in 15 minutes  D&M test spec. MM3882 & MM3946  Check BP Air leakage (isolate BP charging cock-70)  D&M test spec. MM3882 & MM3946  Check BP Air leakage (isolate BP charging cock-70)  D&M test spec. MM3882 & MM3946  CLW's check sheet no. F60.812 Version 2  CLW's check sheet no. F60.812 Version 2  CLW's check sheet no. F60.812 Version 2  BC (WAG-9 & WAP-7) Kg/cm2 in 5 minutes  CLW's check sheet no. F60.812 Version 2  Auto controller BP Pressure kg/cm2 BC (WAG-9 & WAP-7) Kg/cm2  Value Result Value Result Value Result  Run 5±0.1 5.0 Kg/cm2  O.00 0.00 kg/cm2  O.00 - 0.00 kg/cm2  O.00 - 0.00 kg/cm2  O.00 - 0.00 kg/cm2  O.00 - 0.05 kg/cm2  Full service 3.35±0.2 3.4 Kg/cm2  S.050.0 1.2 Skg/cm2  S.050.1 0.40kg/cm2  S.0	2.10	Check CP-2 delivery	safety valve setting	g (10/2). Run CP	D&M t	est spec.	11.50±0.35	11.5 Kg/cm2
valve to reset at pressure 1.2 kg/cm2 less than opening pressure.  2.12 BP Pressure: Switch 'OFF' compressor, Drain MR Pressure by drain cock of 1" Main Reservoir, Start Compressor, check sheet no. F60.812 Version 2  2.13 FP pressure: Spressure of Duplex Check Valve 92F.  2.14 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.  3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2"d MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  Brake Test (Automatic Brake operation)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step  Check proportionality of Auto Brake system  CLW's check sheet no. F60.812 Version 2  Tower to change every minute  Tower to change every minute  Abundance of Tower to change every minute  Blue  Blue  Blue  Blue  Blue  Blue  Blue  Cleck MR M3882 & MM3946  In 15 minutes  0.014 kg/cm2 in 15 minutes  MR3882 & MM3946  MR3882 & MM3946  CLW's check sheet no. F60.812 Version 2  CLW's check sheet no. F60.812 Ve		· · · · · · · · · · · · · · · · · · ·			MM3882	& MM3946	kg/cm2	
Pressure   BP Pressure   Switch 'OFF' compressor, Drain MR Pressure   by drain cock of 1" Main Reservoir, Start Compressor, check setting pressure of Duplex Check Valve 92F.   CLW's check sheet no.   F60.812 Version 2   S.0±0.10kg/cm2   S.0 Kg/cm2   F60.812 Version 2   CLW's check sheet no.   F60.812 Version 2   CLW's check sh	2.11		•	•		•		
2.12   BP Pressure: Switch 'OFF' compressor, Drain MR Pressure by drain cock of 1" Main Reservoir, Start Compressor, check setting pressure of Duplex Check Valve 92F.   F60.812 Version 2		valve to reset at pro	essure 1.2 kg/cm2 le	ess than opening	MM3882	& MM3946		
by drain cock of 1" Main Reservoir, Start Compressor, check setting pressure of Duplex Check Valve 92F.  2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.  3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change. 3.2 Check Purge Air Stops from Air Dryer at Compressor stops 3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step  Check proportionality of Auto Brake system  Check proportionality of Auto Brake system  Check proportionality of Auto Brake system  Be C(WAG-9 & WAP-7) Kg/cm2  Auto controller position  BP Pressure kg/cm2  Value Result Value Result Value Result Value Result  Run S±0.1 5.0 Kg/cm2 0.00 0.00 Kg/cm2 0.75±0.15 - 1.15 minutes  Fol. 15 minutes  BC (WAG-9 & WAP-7) Kg/cm2  FC (WAG-9 & WAP-7) FC (WAG-9 & WAP-7) Kg/cm2  FC (WAG-9 & WAP-7) FC (WAG-9 & WAP-7) Kg/cm2  FC (WAG-9 & WAP-7) FC (WAG-9 & WAP-7) Kg/cm2  FC (WAG-9 & WAP-7) FC (WAG-9 & WAP-7) Kg/cm2  FC (WAG-9 & WAP-7) FC (WAG-9 & WAP-7) Kg/cm2  FC (WAG-9 & WAP-7) FC (WAG-9 & WAP-7) Kg/cm2  FC (WAG-9 & WAP-7) FC (WAG-9 & WAP-7) Kg/cm2  FC (WAG-9 & WAP-7) FC (WAG-9 & WAP-7) Kg/cm2  FC (WAG-9 & WAP-7) FC (WAG-9 & WAP-7) Kg/cm2  FC (WAG-9 & WAP-7) FC (WAG-9 & WAP-7) Kg/cm2  FC (WAG-9 & WAP-7) FC (WA								
check setting pressure of Duplex Check Valve 92F.  2.13 FP pressure: FI Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.  3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step  Check proportionality of Auto Brake system  CLW's check sheet no. F60.812 Version 2  CLW's check sheet no. F60.812 Version 2  BC (WAP-5) Kg/cm2  Auto controller position  Value Result Value Result Value Result Value Result Value Result Full Service Science Sc	2.12						5.0±0.10kg/cm2	5.0 Kg/cm2
FP pressure: Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.   G.05 Kg/cm2   G.05 Kg/					F60.812 Ve	ersion 2		
Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.  3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change. 3.2 Check Purge Air Stops from Air Dryer at Compressor stops 3.3 Check condition of humidity indicator 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step  Check proportionality of Auto Brake system  CLW's check sheet no. F60.812 Version 2  Auto controller position  BP Pressure kg/cm2  Value Result  Run 5±0.1 5.0 Kg/cm2  Intial 4.60±0.1 4.6 Kg/cm2  3.4 Kg/cm2  2.50±0.1 2.5Kg/cm2  5.15±0.30  Check proportion Simple Simp	2.42		ure of Duplex Check	( valve 92F.	CLVA// l	.11	6.010.201-/2	6.05
3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step  Check proportionality of Auto Brake system  Check proportionality of Auto Brake system  CLW's check sheet no. F60.812 Version 2  Auto controller position  Value Result Value Result Value Result Value Result  Run 5±0.1 5.0 Kg/cm2 0.00 0.00 Kg/cm2 0.00 - Intial 4.60±0.1 4.6 Kg/cm2 0.40±0.1 0.40Kg/cm2 0.75±0.15 -  Full service 3.35±0.2 3.4 Kg/cm2 2.50±0.1 2.5Kg/cm2 5.15±0.30 -	2.13		oct point 107E EDTD	Open isolate cock			6.0±0.20kg/cm2	
3.0 Air Dryer Operation 3.1 Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change. 3.2 Check Purge Air Stops from Air Dryer at Compressor stops 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70) 5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step  Check proportionality of Auto Brake system  CLW's check sheet no. F60.812 Version 2  BC (WAG-9 & WAP-7)  Kg/cm2  Kg/cm2  Value  Result  Value  Result  Value  Result  Value  Result  Auto Controller  Double Alexand Reycom2  O.00  O.00 Kg/cm2  O.75±0.15  - Full service  3.35±0.2  3.4 Kg/cm2  2.50±0.1  2.5Kg/cm2  5.15±0.30		_	•	Open isolate cock	F00.812 VE	:131011 2		Ng/CIIIZ
3.1 Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops 3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step  Check proportionality of Auto Brake system  Cl. W's check sheet no. F60.812 Version 2  Auto controller position  BP Pressure kg/cm2  Value Result  Value Result  Value Result  Run 5±0.1 5.0 Kg/cm2  0.00 0.00 Kg/cm2  0.00 -  Intial 4.60±0.1 4.6 Kg/cm2  2.50±0.1 2.5Kg/cm2  5.15±0.30 -	3.0		_					
Open for Test Check Air Dryer Towers to change.   Every minute				Compressor leave			Tower to change	ok
3.2   Check Purge Air Stops from Air Dryer at Compressor stops	3.1	-		•				
3.3   Check condition of humidity indicator   4.0   Main Reservoir Leakage Test	3.2							
4.0   Main Reservoir Leakage Test   Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.   D&M test spec.   MM3882 & MM3946   Should be less than 1 kg/cm2 in 15 minutes   15 minute							Blue	Blue
A.1	4.0		•					
15 minutes   15 minutes   20.04   20.04   20.04   20.05   20.04   20.05   20.04   20.05   20.04   20.05   20.04   20.05   20	4.1			eck MR Pressure air	D&M t	est spec.	Should be less	0.4 Kg/cm2
A.2   Check BP Air leakage (isolate BP charging cock-70)   D&M test spec.   MM3882 & MM3946   MM3946   MM3882 & MM3946   MM3946   MM3882 & MM3946   MM3946   MM3948   MM3946   MM3948   MM3946   MM3948   MM3946   MM3948   MM3946   MM3948   MM3946   MM3948   MM3948   MM3946   MM3948   MM3948   MM3948   MM3948   MM3948   MM3948   MM3946   MM3948   MM3948   MM3948   MM3948   MM3948   MM3946   MM3946		leakage from both	cabs.		MM3882	& MM3946	than 1 kg/cm2 in	in 15
MM3882 & MM3946   minutes   Kg/cm2 in 5   minutes							15 minutes	minutes
S.0   Brake Test (Automatic Brake operation)	4.2	Check BP Air leakag	ge (isolate BP chargi	ng cock-70)	D&M t	est spec.	0.15 kg/cm2 in 5	
S.0   Brake Test (Automatic Brake operation)					MM3882	& MM3946	minutes	
Check proportionality of Auto Brake system		_						minutes
Check proportionality of Auto Brake system		· ·	-	•				
Auto controller position   BP Pressure kg/cm2   BC (WAG-9 & WAP-7)   BC (WAP-5)   Kg/cm2   Kg/cm2   Kg/cm2   Kg/cm2   Kg/cm2   Result   Value   Result   Value   Result   Run   5±0.1   5.0 Kg/cm2   0.00   0.00 Kg/cm2   0.00   - Intial   4.60±0.1   4.6 Kg/cm2   0.40±0.1   0.40 Kg/cm2   0.75±0.15   - Full service   3.35±0.2   3.4 Kg/cm2   2.50±0.1   2.5 Kg/cm2   5.15±0.30   - Intial   5.5 Kg/cm2   5.5 Kg/c	5.1	Record Brake Pipe 8	& Brake Cylinder pr	essure at Each Step				
Auto controller position   BP Pressure kg/cm2   BC (WAG-9 & WAP-7)   BC (WAP-5)   Kg/cm2   Kg/cm2   Kg/cm2   Kg/cm2   Kg/cm2   Result   Value   Result   Value   Result   Run   5±0.1   5.0 Kg/cm2   0.00   0.00 Kg/cm2   0.00   - Intial   4.60±0.1   4.6 Kg/cm2   0.40±0.1   0.40 Kg/cm2   0.75±0.15   - Full service   3.35±0.2   3.4 Kg/cm2   2.50±0.1   2.5 Kg/cm2   5.15±0.30   - Intial   5.5 Kg/cm2   5.5 Kg/c								
Auto controller position   BP Pressure kg/cm2   BC (WAG-9 & WAP-7)   BC (WAP-5)   Kg/cm2   Kg/cm2   Kg/cm2   Kg/cm2   Kg/cm2   Result   Value   Result   Value   Result   Run   5±0.1   5.0 Kg/cm2   0.00   0.00 Kg/cm2   0.00   - Intial   4.60±0.1   4.6 Kg/cm2   0.40±0.1   0.40 Kg/cm2   0.75±0.15   - Full service   3.35±0.2   3.4 Kg/cm2   2.50±0.1   2.5 Kg/cm2   5.15±0.30   - Intial   5.5 Kg/cm2   5.5 Kg/c		Check proportional	ity of Auto Brake sy	stem	CLW's che	ck sheet no		
Auto controller position    BP Pressure kg/cm2   BC (WAG-9 & WAP-7)   BC (WAP-5)   Kg/cm2		Circer proportional	ity of Auto Brake sy	300111				
position         Kg/cm2         Kg/cm2           Value         Result         Value         Result           Run         5±0.1         5.0 Kg/cm2         0.00         0.00 Kg/cm2         0.00           Intial         4.60±0.1         4.6 Kg/cm2         0.40±0.1         0.40Kg/cm2         0.75±0.15         -           Full service         3.35±0.2         3.4 Kg/cm2         2.50±0.1         2.5Kg/cm2         5.15±0.30         -								
position         Kg/cm2         Kg/cm2           Value         Result         Value         Result           Run         5±0.1         5.0 Kg/cm2         0.00         0.00 Kg/cm2         0.00           Intial         4.60±0.1         4.6 Kg/cm2         0.40±0.1         0.40Kg/cm2         0.75±0.15         -           Full service         3.35±0.2         3.4 Kg/cm2         2.50±0.1         2.5Kg/cm2         5.15±0.30         -								
Value         Result         Value         Result         Value         Result           Run         5±0.1         5.0 Kg/cm2         0.00         0.00 Kg/cm2         0.00         -           Intial         4.60±0.1         4.6 Kg/cm2         0.40±0.1         0.40Kg/cm2         0.75±0.15         -           Full service         3.35±0.2         3.4 Kg/cm2         2.50±0.1         2.5Kg/cm2         5.15±0.30         -		Auto controller	BP Pressure kg/cn	n2	BC (WAG-9	& WAP-7)	BC (WAP-5)	
Run       5±0.1       5.0 Kg/cm2       0.00       0.00 Kg/cm2       0.00       -         Intial       4.60±0.1       4.6 Kg/cm2       0.40±0.1       0.40Kg/cm2       0.75±0.15       -         Full service       3.35±0.2       3.4 Kg/cm2       2.50±0.1       2.5Kg/cm2       5.15±0.30       -		position			Kg/cm2		Kg/cm2	
Run       5±0.1       5.0 Kg/cm2       0.00       0.00 Kg/cm2       0.00       -         Intial       4.60±0.1       4.6 Kg/cm2       0.40±0.1       0.40Kg/cm2       0.75±0.15       -         Full service       3.35±0.2       3.4 Kg/cm2       2.50±0.1       2.5Kg/cm2       5.15±0.30       -			Value	Result	Value	Result	Value	Result
Intial 4.60±0.1 4.6 Kg/cm2 0.40±0.1 <sub>0.40Kg/cm2</sub> 0.75±0.15 - Full service 3.35±0.2 3.4 Kg/cm2 2.50±0.1 <sub>2.5Kg/cm2</sub> 5.15±0.30 -								
Full service 3.35±0.2 3.4 Kg/cm2 2.50±0.1 2.5Kg/cm2 5.15±0.30 -		Run	5±0.1	5.0 Kg/cm2	0.00	0.00 Kg/ cm2	0.00	-
5 1 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		Intial	4.60±0.1	4.6 Kg/cm2	0.40±0.1	0.40Kg/ cm2	0.75±0.15	-
Emergency Less than 0.3 <b>0.2 Kg/cm2</b> 2.50±0.1 2.5Kg/cm2 5.15±0.30 -		Full service	3.35±0.2	3.4 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	-
•		Emergency	Less than 0.3	0.2 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	-

#### PLW/PATIALA

Loco No.: 42014

5.2	Record time to BP pressure drop to 3.5 kg/cm2 Ensure	D&M test spec.	8±2 sec.	9 Sec
	Automatic Brake Controller handle is Full Service from Run	MM3882 & MM3946		
5.3	Operate Asst. Driver Emergency Cock,	D&M test spec.	BP pressure falls	
		MM3882 & MM3946	to Below 2.5	ОК
			kg/cm2	
5.4	Check brake Pipe Pressure Switch 69F operates	CLW's check sheet no.	Closes at BP	4.30
		F60.812 Version 2	4.05- 4.35	Kg/cm2
			kg/cm2	
			Opens at BP	
			2.85- 3.15	3.05
			kg/cm2	Kg/cm2
5.5	Move Auto Brake Controller handle from Running to	D&M test spec.		
	Emergency BC filling time from 0.4 kg/cm2 i.e. 95% of	MM3882 & MM3946		
	Max. BC developed			
	WAP5 – BC 5.15 $\pm$ 0.3 kg/cm2 apply time		4±1 sec.	
	WAP7 - BC 2.50 ± 0.1 kg/cm2		7.5±1.5 sec.	
	WAG9 - BC 2.50 ± 0.1 kg/cm2		21±3 sec.	21 Sec.
5.6	Move Auto Brake Controller handle to full service and	D&M test spec.		
	BP pressure 3.5 kg/cm2. Move Brake controller to	MM3882 & MM3946		
	Running position BC Release time to fall BC Pressure up			
	to 0.4 kg/cm2 i.e. 95% of Max. BC developed			
	BC release Time			
	WAP7		17.5±25 sec.	
	WAG9		52±7.5 sec.	55 sec.
5.7	Move Auto Brake Controller handle to Release, Check	CLW's check sheet no.	60 to 80 Sec.	77 Sec
3.7	BP Pressure Steady at 5.5± 0.2 kg/cm2 time.	F60.812 Version 2	00 to 00 sec.	77300
5.8	Auto Brake capacity test: The capacity of the A9 valve	RDSO Motive power	BP pressure	
3.0	in released condition must conform to certain limit in	Directorate report no.	should not fall	
	order to ensure compensation for air leakage in the	MP Guide No. 11 July,	below 4.0	
	train without interfering with the automatic	1999 Rev.1	kg/cm2 with in	4.5
	functioning of brake.	1999 Nev.1	60 Sec.	Kg/cm2
	* Allow The MR pressure to build up to maximum		00 Sec.	Kg/CIIIZ
	stipulated limit.			
	* Close brake pipe angle cock and charge brake pipe to			
	5 kg/cm2 by A-9 (Automatic brake controlling) at run			
	position.			
	* Couple 7.5 dia leak hole to the brake hose pipe of			
	locomotive. Open the angle cock for brake pipe.			
	The test shall be carried out with all the compressors in			
	working condition.		BO : (5)	
5.9	Keep Auto Brake Controller (A-9) in Full Service. Press		BC comes to '0'	0
	Driver End paddle Switch (PVEF)			
6.0	Direct Brake (SA-9)			
6.1	Apply Direct Brake in Full Check BC pressure			
	WAG9/WAP7	CLW's check sheet no.	3.5±0.20 kg/cm2	3.6
	WAP5	F60.812 Version 2	5.15±0.3 kg/cm2	Kg/cm2
6.2	Apply Direct Brake, Record Brake Cylinder charging	D&M test spec.	8 sec. (Max.)	8 Sec
	time	MM3882 & MM3946		
				_

#### **PLW/PATIALA**

Loco No.: 42014

6.3	Check Direct Brake Pressure switch 59 (F)	D&M test spec. MM3882 & MM3946	0.2.±0.1 kg/cm2	0.25 kg/cm2
6.4	Release direct brake & BC Release time to fall BC pressure up to 0.4 kg/cm2		10 -15 Sec.	14 Sec
7.0	Modified System Software (only for CCB)		-NA-	-NA-
7.1	Bail-off de-activated during emergency by any means			
7.2	DPWCS and Non-DPWCS mode enabled		Multi Loco	
7.3	TCAS and Non-TCAS mode enabled		Not Yet Launched	Presently
7.4	Penalty brake application deactivated for Fault code 113 (FC 113) and CCB health signal will not drop to avoid loco detention/failure. The Brake Electronics Failure "message will not generate on DDS.	RDSO letter no.	Pressure Setting Needed is12 kg/sqcm causing mismatching with standard Pr Setting	not happening in PLW
7.5	CCB health signal logic revised (Now will remain high) for penalty condition occurring with FC 108 due to wrong operation/not affecting operation/ Not a CCB Fault (i.e Both controllers selected as LEAD etc) The Brake electronic failure message will not generate on DDS	EL/3.2.19/3-phase (CCB), dtd 30.01.2023		
7.6	CCB health signal logic for FC 102 (In case of BC request from VCU is more than 90 %-above 9V DC) is changed i.e CCB health signal will not drop for FC 102 which will avoid loco detention/failure. The brake electronic failure message will not generate on DDS.		Could not performed by M/s Knorr	Presently Not happening in PLW
7.7	Booting time for CCB with TCAS/TPM/PTWS/DPWCS mode 15-20 sec. However, in case of absence of either one or both system booting time subsequently increased to 40-50 sec.			
8.0	Sanding Equipment			
8.1	Check Isolating Cock-134F is in open position. Press sander paddle Switch. (To confirm EP valves Operates)		Sand on Rail	Ok
9.0	Test Vigilance equipment : As per D&M test specification			Ok

SAMSHE Digitally signed by SAMSHER SINGH SINGH BIST Date: 2025.03.17 11:12:06 +05'30'

Signature of SSE/Shop

				42014		
		ı	ROOF COME	PONENT CAB 1 & 2		Warranty
S.No.	Description	PL NO.	QPL /Nos.	Supplier	Sr. no.	,
1	Pantograph	29880014(HR), 29880026	2	FAIVELEY, CONTRANSYS	A25-0847/JAN-2025, 15407-10/24	
2	Servo motor	29880026	2	CONTRANSYS	15667-11/24	
3	Air Intake filter Assly	29480103	2	PARKER	O/C 1590P/A/01 (PLW) 08/24, O/C 1661P/A/02 (PLW) 10/24	
4	Insulator Panto Mtg.	29810127	8	IEC	08-24, 08-24	
			MIDDLE RC	OF COMPONENT		
5	High Voltage Bushing	29731021	1	ELECTRANEX	EIPL-5803-10-24	
6	Voltage Transformer	29695028	1	CG POWER & INDUSTRIAL	243338-18/09/2024	
7	Vacuum Circuit Breaker	25712202	1	AUTOMETERS	AALN/09/2024/045/VCBA/642	
8	Insulator Roof line	29810139	9	MIL	06-2024, 07-2024	
9	Harmonic Filter	29650033	1	Daulat Ram	24L/RHFG/06/793-2024	AS Per PO/IRS Conditions
10	Earth Switch	29700073	1	AUTOMETERS	AALN/04/2024/032/ES/032	
11	Surge Arrester	29750052	2	CG POWER & INDUSTRIAL	56243-2024, 56246-2024	
			Air B	rake Components		
12	Air Compressor (A,B)	29511008	2	ELGI	EXGS 923747 A, EXGS 923739 B	
13	Air Dryer	29162051	1	KNORR	E24 E 0420	
14	Babby compressor	25513000	1	ELGI	BXDS 109181	
15	Air Brake Panel	29180016	1	FAIVELEY	Jan-25-01-WAG9-3835	
16	Contoller (A,B)	29180016	2	FAIVELEY	M 24-158-A, M 24-153-B	
17	Breakup Valve	29180016	2	FAIVELEY		
18	wiper motor	29162026	4	ELGI		

SAMSHER Digitally signed by SAMSHER SINGH BIST Date: 2025.02.19 10:35:52 +05'30' SSE/ABS

# PLW/PTA

# ELECTRIC LOCO HISTORY SHEET (ECS)

ELECTRIC LOCO NO: 42014 LIST OF ITEMS FITTED BY ECS

RLY: NFR SHED: MLDD

PROPULSION SYSTEM: ALSTOM

2	DESCRIPTION OF ITEM	ITEM PL NO.	ITEM SR. NO CA	NO CAB-1/CAB-2	MAKE/SUPPLIER
Z		29612937		26830	POWER TECH
_	LED Based Flasher Light Cab I & II	79017907	75 44	205/ 142048	MATSUSHI P. TECH
2	Led Marker Light Cab I & II	29612925	/5,14	2938, 142934, 142940	KKI
ω	Cab Heater Cab I & II	29170011	3351	3252	
4	Crew Fan Cab I & II	29470080	5726/5810/5662	/5662	IVI
η .	Master Controller Cab I		7244		WOAMA
0	Master Collicies Cap -	29860015	7245		
0	Master Controller Cab II				KONTACT
7	Complete Panel A Cab   & II	29178265	KT1623	K11021	NONING
-	Complete Family Complete St.	20170539	3609	3618	KEPCO/ALSTOM
00	Complete Panel C Cab I & II	10000	VT1165	KT1614	KONTACT
9	Complete Panel D Cab I & II	291/8265	7 400	00000	Ca
7	10 Complete Cubicle- F Panel Cab I & II	29178162	2750/1/25	2588/8/24	
1	Speed Ind & Rec. System	29200040	5852/5852	352	LAAVEN
3	Battery (Ni- Cd)	29680025	B-166	0)	HBL
3 1	Set of Harnessed Cable Complete	29600420			QUADRANT
14	Transformer Oil Pressure Sensor (Cab-1)	20500047	2369 Aug-24	2849 Sep-24	LAXVEN
15			2331 Aug-24	2886 Sep-24	
16	Transformer Oil Temperature Sensor (Cab-1)	20500035	BG/TFP/8927 Aug-24	7 Aug-24	BG INDUSTRIES
17	Transformer Oil Temperature Sensor (Cab-2)		BG/TFP/8962 Aug -24	2 Aug -24	
200			24K/RMPU/DC/02/1374	C/02/1374	DAULAT RAM
10		02011087	24K/RMPU/DC/02/1378	C/02/1378	

			OTIVE WORKS, PAT /WAG-9HC/NFR/M			
S.No.	Equipment	PL No.		ent Serial No.	Ma	ake
1	Complete Shell Assembly with piping	29171027	08/2	22, 01/25	CHAN	IDRA
2	Side Buffer Assly Both Side Cab I		173, 09/24	not visible, 09/24	AEU	AEU
3	Side Buffer Assly Both Side Cab II	29130050	not visible, 06/24	not visible, 09/24	AEU	AEU
4	CBC Cab I & II	29130037	65, 10/24	75, 10/24	FASP	FASP
5	Hand Brake		12/24-18063 Mod		Modified	Mechwel
	Tialla blake	29045034	12/2	14 10003		
6	Set of Secondry Helical Spring	29041041			FRON	ITIER
7	Battery Boxes (both side)	29680013	10, 11/24	32, 11/24	BHARTIA BRIGHT	BHARTIA BRIGH
8	Traction Bar Bogie I			3, 12/24	KI	
9	Traction Bar Bogie II		8772, 12/24		KM	
10	Centre Pivot Housing in Shell Bogie I side	29100057		5, 12/24	AN	
11	Centre Pivot Housing in Shell Bogie II side	23100037	329	9, 12/24	AN	
12	Elastic Ring in Front in Shell Bogie I side	29100010		7, 11/24	AVADH	
13	Elastic Ring in Front in Shell Bogie II side	25100010	143	9, 10/24	AVA	DH
14	Main Transformer	29731008 for WAG 9 29731057 for WAP-7	CG-65-01-25-E	BHL11500/48, 2025	. CG	
15	Oil Cooling Radiator I		11/24. FG41	5002/24-25/185	APOLLO HEAT	EXCHANGERS
16	Oil Cooling Radiator II	29470031	11/24. FG41	5002/24-25/189	APOLLO HEAT EXCHANGERS	
17	Main Compressor I with Motor			3739, 10/24	ELGi	
18	Main Compressor II with Motor	29511008		3747, 10/24	ELGi	
_					FLOWWELL	
19	Transformer Oil Cooling Pump I		24081318, 08/23		FLOWWELL	
20	Transformer Oil Cooling Pump II			300, 08/23	SAINI ELECTRICAL PVT LTD	
21	Oil Cooling Blower OCB I	29470043		720, 32409AF3720		
22	Oil Cooling Blower OCB II			NT/24-25/548	FORCE MOTION TECHNOLOGY	
23	TM Blower I	29440075		766, CGLXLAM1583	ACCEL	
24	TM Blower II		01/25, AC-617	71, CGLXKAM23214	ACCEL	
25	Machine Room Blower I	29440105	12/24. D42-59	923, MF42/D5970	SAMAL HARAND PVT LTD	
26	Machine Room Blower II	23440103	12/24. D42-59	924, MF42/D5971	SAMAL HARAND PVT LTD	
27	Machine Room Scavenging Blower I	20440120	11/24.	SM-24.11.43	GTR CO PVT LTD	
28	Machine Room Scavenging Blower II	29440129	11/24.	SM-24.11.52	GTR CO PVT LTD	
29	TM Scavenging Blower Motor I	20440117	02/25,	ST-25.02.07	GTR CO	PVT LTD
30	TM Scavenging Blower Motor II	29440117	02/25,	ST-25.02.19	GTR CO	PVT LTD
31	Traction Convertor I		ATIL/11/2024/26	/PROPULSION A/4172		
32	Traction Convertor II			/PROPULSION A/4171		
33	Vehicle Control Unit I	29741075		/PROPULSION A/4171	B	TIL -
_	Vehicle Control Unit II			/PROPULSION A/4172		
	Aux. Converter Box I (BUR 1)			I/10303/37A/1238	-	
	Aux. Converter Box 2 (BUR 2 + 3)	20474400		1/10303/37B/1238 IB10022410350	STESAL	IT LTD
	Axillary Control Cubical HB-1	29171180		2024/J/0178/667	HIND RECT	
	Axillary Control Cubical HB-2	29171192		SB1/24110915		GL.
39	Complete Control Cubicle SB-1 Complete Control Cubicle SB-2	29171209 29171210		2024/J/0225/1294	HIND RECT	
40	Filter Cubical (FB) (COMPLETE FILTER	29480140		2/2024/16/FB/208	AUTOMETERS AI	
42	CUBICLES)  Driver Seats	29171131	1/25-3	8, 56, 25, 33	J.P S	EATS
43	Transformer oil steel pipes	29230044		NT PIPES		-
44	Conservator Tank Breather	29731057		57, 24-8187	YOGYA ENTE	RPRISES LTD
45	Ballast Assembly ( only for WAG-9)	29170163		2, 108, 119		FT
40	Dallast Assellibly ( Olily 101 WAG-3)	231/0103	000, 10	-,,		

NAME SHUBHAM SHA PMA
SSE/LAS

NAME TO MEENG

NAME ANULT UPPT

Issue No.: 05 Effective Date: July-2023

DOC NO: F/LAS/Electric Loco CHECK SHEET (Ref: WI/LAS/Elect/01, 02, 03 & 04 & QPL/LAS/Elect. Loco)

Page 1 of 1

#### पटियाला रेलइंजन कारखाना, पटियाला PATIALA LOCOMOTIVE WORKS, PATIALA **ELECTRIC LOCO CHECK SHEET**

LOCO NO: 42014

Rly: NFR

Shed: MLDD

S. No.	ITEM TO BE CHECKED	Specified Value	O	oserved Va	alue	
1.1	Check proper Fitment of Hotel Load Converter & its output contactor.	OK		10/4	_	
1.2	Check proper Fitment of MR Blower 1 & 2, MR Scavenging Blower 1 & 2, TM Blower 1 & 2, TMB Scavenging Blower 1 & 2.  TM scavenging blower 1 & 2 & Oil Cooling unit.	ОК		UKE		
1.3	Check proper of Fitment of oil cooling unit (OCU).	OK		dlr		
1.4	Check proper Fitment of HB 1 & 2 and its respected lower part on its position.	OK		J/L		
1.5	Check proper Fitment of FB panel on its position.	OK		312		
1.6	Check proper Fitment of assembled SB1 & SB2 panel.	OK		OK		
1.7	Check proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3).	OK	2	CIL		
1.8	Check proper Fitment of Traction converter 1 & 2 (SR-1 & 2).	OK		(1)2		
1.9	Check proper fitment, torquing & Locking of Main Transformer bolt.	OK ·		(1) 4		
1.10	Check proper fitment of Main compressor both side with the compressor safety wire rope.	OK		-11		
1.11	Check proper resting of Secondary Helical Springs between Bogie & Shell body.	OK		(1)		
1.12	Check proper fitment of Bogie Body Safety Chains.	OK		0/2		
1.13	Check proper fitment of Cow catcher.	OK		CV2		
1.14	Check coolant level in SR 1 & 2 Expansion Tank.	OK		012	1	
1.15	Check Transformer Oil Level in both conservators Tank (Breather Tank).	OK		012.		
1.16	Check proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any damage during online working of Locomotives.	OK	0/2			
1.17	Check proper fitment of both battery box.	OK		UIL		
1.18	Check for any gap between Main Transformer mounting base & Loco Shell.	OK		UK		
1.19	Check proper fitment of Push Pull rod its bolt torquing and fitment of fixing cable. As per Drg No 1209-01-113-001	ОК	0/2			
1.20	Secondary Vertical and Lateral Clearance on leveled track at the time of Loco Dispatch.  ELRS/TC/ 0082 (Rev 1) dated 17.09.2015	Vertical-Std :35-60 mm	LP S)	3-1 ALP LF 50 47 40 S	7 47	
4.24	Deffect beight. Dence (4000 145 5)	45-50 mm 1085-1105		L/S	R/S	
1.21	Buffer height: Range (1090, +15,-5) Drg No IB031-02002.	mm				
	big No 15051-02002.		FRONT	1092	1098	
			REAR	1097	1097	
1.22	Buffer Length: Range (641 mm + 3 to 10 mm with buffer face)	641 mm		L/S	R/S	
	Drg No-SK.DL-3430.		FRONT	650	649	
			REAR	649	647	
1.23	Height of Rail Guard. (114 mm + 5 mm,-12 mm).	114 mm + 5		L/S	R/S	
1.23	As per RDSO Pamphlet Important Bogie Clearances of Electric Locomotives.	mm,-12 mm	FRONT		116	
	no por riboo i ampinot important bogio ordinanoso or broatio bosonioures.	, 12	The second second	119		
			REAR	118	115	
1.24	CBC Height: Range (1090, +15,-5)  Drg No- IB031-02002.	1090, +15 -5 mm	FRONT: REAR:	1094		

(Signature of SSE/Elect. Loco)

NAME SHUBMAM SMARM

DATE 27/01/25

ray Meeng (Signature of /JE/Elect Loco)

NAME Ramota loom eeng

DATE 27/01/25

(Signature of JE/UF)

NAME NAME ANUIT UPPAL

DATE 27/01/25

#### **Loco No.** 42014

#### 1. BOGIE FRAME:

BOGIE	FRAME NO	Make	PL No.	PO No. & dt.	Warranty Period
FRONT	SL-2697	ACPL	29100677	102222	As per PO/IRS
REAR	SL-2688	ACPL	29100677	102223	conditions

#### 2. Hydraulic Dampers (PL No.29040012) Make: G.B. / G.B.

#### 3. AXLES:

AXLE POSITION NO	1	2	3	4	5	6
MAKE/	PLW	PLW	PLW	PLW	PLW	PLW
S.NO	28097	28192	28052	27977	28179	28094
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

#### 4. WHEEL DISCS NO. AND TYPE & BULL GEAR

AXLE POSITION NO	1	2	3	4	5	6
GEAR END	EV88-019	EV53-091	EQ94-089	EV58-86	EV90-015	EV25-013
Make	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
FREE END	EV88-38	EV37-090	EQD1-050	EQC8-018	EV71-069	EV90-095
Make	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
Bull Gear No.	24-A-1014	23-L-1673	23-L-15104	23-L-10152	23-L-10253	24-A-945
Bull Gear Make	KPCL	KPCL	KPCL	KPCL	KPCL	KPCL

#### 5. AXLE ROLLER BEARING (CRU) (PL No. 29010020, Warranty: As per PO/IRS conditions)

	AXLE POSITION NO	1	2	3	4	5	6
Gear	MAKE	FAG	NBC	FAG	NBC	FAG	NBC
End	PO NO. & dt	02312	02311	02312	02311	02312	02311
Free	MAKE	FAG	NBC	FAG	NBC	FAG	NBC
End	PO NO. & dt	02312	02311	02312	02311	02312	02311

#### 6. WHEEL DISC PRESSING PRESSURE IN KN: (SPECIFIED 80-105 T)

AXLE POSITION NO	1	2	3	4	5	6
BULL GEAR END	881 KN	100 T	791 KN	93 T	979 KN	92 T
FREE END	873 KN	101 T	801 KN	90 T	789 KN	85 T

#### Loco No. 42014

#### 7. DIAMETER AFTER PROFILE TURNING: SPECIFIED 1092 + .5 mm - 0 mm

AXLE POSITION NO	1	2	3	4	5	6
DIA IN mm GE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
DIA IN mm FE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
WHEEL PROFILE GAUGE (1596±0.5mm)	OK	OK	OK	OK	OK	OK

#### 8. SUSPENSION TUBE & ITS TAPER ROLLER BEARING:

AXLE POSITION	NO	1	2	3	4	5	6
S.T. PL 29100288	MAKE	PITTI	PITTI	SDI	KPE	PITTI	PITTI
GE Brg. PL 29030110	MAKE	NBC	NBC	NBC	NBC	NBC	NBC
FE Brg. PL 29030110	MAKE	NBC	NBC	NBC	NBC	NBC	NBC

#### 9. GEAR CASE (PL No. 29030018) & BACKLASH:

AXLE POSITION NO	1	2	3	4	5	6
MAKE	KM	EEE	EEE	EEE	KM	KM
BACKLASH (0.254 – 0.458mm)	0.300	0.300	0.290	0.300	0.320	0.300

#### 10 A/BOX TO BOGIE FRAME LATERAL CLEARANCES (SPECIFIED 15.0 to 19.0mm):

AXLE POSITION NO	1	2	3	4	5	6
RIGHT SIDE	15.65	16.14	16.72	15.52	17.10	16.95
LEFT SIDE	15.44	15.46	15.69	16.42	15.82	16.02

#### 11. TRACTION MOTOR: (PL No.29940606, Warranty: As per PO/IRS conditions)

AXLE POSITION NO	MAKE	PO No. & Date	S. NO.
1	TMS	-	PLW-3178
2	CGP	102027	2242001-7636
3	HIND RECTIFIER	101655	237010154-033
4	CGP	102027	2232006-7738
5	TMS	-	PLW-3183
6	TMS	-	PLW-3201

JE/SSE/ Bogie Shop

#### TOP 12 COSTLIEST ITEMS OF WAG9HC LOCO WITH WARRANTY CONDITIONS AS PER TENDERS

S No	PL No	DESCRIPTION	Warranty Period
1	29741075	IGBT BASED 3-PHASE DRIVE PROPULSION EQUIPMENT	60 months after commissioning or 72 months from date of supply whichever earlier as per special conditions given by CLW
2	29731057	MAIN TRANSFORMER 7775 KVA TYPE LOT 7500 FOR WAP7 3- PHASE ELECTRIC LOCOMOTIVE TO CLW SPECN NO.CLW/ES/3/0660/C	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
3	29171064	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT-8	AS PER IRS CONDITIONS-30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER.
4	29600418	LOCOMOTIVES TO CLW SPECN. NO. CLW/ES/03/646  ALT-NIL WITH DMW REQUIREMENT OF HARNESSED	As per clause no.9 of CLW Specn. CLW/ES/3/0458 & Clause No.10 of CLW SpecnCLW/ES/3/0459. [18 months after commissioning or 20 months from date of supply for single core & 18 months after commissioning or 24 months from date of supply for multi core]

7	29942007	3-PHASE ASYNCHRONOUS TRACTION MOTOR (RESISTANCE RING MECHANICALLY INTERLOCKED TO END PLATE DESIGN ROTOR, SCHEME-II), TYPE 6FRA-6068 FOR WAP-7 ELECTRIC LOCO WITHOUT ACTIVE SPEED SENSOR TO SPECIFICATION NO. 4TMS.096.081 ALT-2 AND STR NO. CLW/2008/3PHTM/STR/0001.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
6	29480140	COMPLETE FILTER CUBICLE ALONG WITH ALL EQUIPMENTS AND CABLING TO DRG./SPEC NO. [1] CLW/ES/3/0193 ALT-F OR LATEST AND CLW DRG. NO. 1209-15-143-004 ALT-10 AND PART DRG./SPEC NO AS PER ANNEXURE-A ATTACHED.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
5	29180016	BRAKE CONTROL SYSTEM INCLUDING DRIVER'S VIGILANCE CONTROL DEVICE TO SET LIST NO.EL29180016.	As per specification no. CLW/MS/3/001 Alt. 16 i.e. the manufacturer is required to guarantee that the brakevalves/equipment work satisfactorily for a period of five (5) years after commissioning. Any equipment/part which failsduring the guarantee period shall be replaced free of cost by the manufacturer. The replaced components shallfurther be under warranty for five (5) years from the date of their fitment and should the replaced components proveunsatisfactory in service, they shall be replaced by modified and improved components by the supplier free of cost.

8	29105146	Bogie Frame Complete for WAP-7 for 3 Phase Co Co Locomotive to CLW specification No. CLW/MS/3/Bogie/003 alt-1 and CLW Drg.No.1209.01.112-202 Alt-Nil	As per clause 16 of Spec.No.CLW/MS/3/Bogie/003 Alt-1. [60 months after commissioning or 72 months from date of supply]
9	29171192	COMPLETE AUXILIARY CUBICLE HB2 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0192 ALT-E OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
10	29171210	COMPLETE CONTROL CUBICLE SB2 ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0195/A ALT-H OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
11	29171209	COMPLETE CONTROL CUBICLE SB1 (PUSH PULL SCHEME COMPLIANT) ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0194 ALT-G OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
12	29171180	COMPLETE AUXILIARY CUBICLE HB1 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0191 ALT-D OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.



#### भारत सरकार GOVERNMENT OF INDIA

रेल मंत्राल्य

#### MINISTRY OF RAILWAYS

पटियाला रेलइंजन कारखाना

#### PATIALA LOCOMOTIVE WORKS

Email: dyceeloco.dmw@gmail.com फैक्स/Fax No.: 0175-2397244

फोन/ Phone: 0175-2396422 मोबाईल: 9779242310

पटियाला, 147003, भारत् PATIALA, 147003, INDIA



(An ISO 9001, ISO 14001, ISO 45001 & ISO 50001, 5S & Green Building certified Organization)

No. PLW/M/ECS/Tech/Kavach

Date: As signed

(Through Mail)

Sr. Div. Electrical Engineer, Diesel Loco Shed, Malda Town.

Email: srdeetrsmldd@gmail.com

Sub:- Fitment of KAVACH in three Phase Electric Loco. No. 42014 WAG9-HC.

Ref:- (i). Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 21.08.2023.

(ii).Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 26.09.2023

In ref. to the above letter's Loco No. 42014 has been dispatched with fittings for implementation of KAVACH system in locomotive at home shed in Zonal Railway. This Loco was dispatched to DLS/MLDD/NFR on 24.02.2025. The details of fittings are attached as Annexure-A (pneumatic fittings), Annexure-B (Kavach equipment mounting Brackets) & Annexure-C (Wago with harnessed lay out).

This is for your information & necessary action please.

Digitally signed by NISHANT BANSIWAL Date: 2025.03.27 17:30:34 +05'30'

(निशांत बंसीवाल)

उप मुख्य विद्युत अभियंता/लोको

#### प्रतिलिपि:-

CEE/Loco & CEE/D&Q, CMM, CELE/NFR:- for kind information please Dy CME/Design, Dy. CMM/Depot: for information & necessary action please WM/LAS, AWM/LFS&ABS, AWM/ECS: for necessary action please

# Loco No. 42014

SN	PL No.	Description of item	Qty.
	·	ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITH VENT	04 nos.
1	29163341	ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITHOUT VENT	02 nos.
		TEE UNION 3/8"X3/8"X3/8" BRASS FITTINGS	02 nos.
		MALE CONNECTORS 3/8" TUBE OD X 3/8" BSPT, BRASS FITTINGS	09 nos.
		MALE CONNECTORS 1/2" TUBE OD X 1/2" BSPT, BRASS FITTINGS	06 nos.
		FEMALE CONNECTORS (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	01 no.
		MALE CONNECTOR (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	03 nos
	29611994	FEMALE TEE 3/8" BSPP – BRASS	06 nos
2		HEX PLUG -3/8" BSPT – BRASS	02 nos
		FEMALE TEE 1/2" BSPP – BRASS	04 nos
		HEX NIPPLE 3/8X3/8" BSPT – BRASS	04 nos
		RED HEX NIPPLE 3/8X1/2" BSPT - BRASS	02 nos
		HEX PLUG – 1/2" BSPT – BRASS	04 nos
		MALE ELBOW CONNECTORS 3/8" TUBE OD X 3/8) BSPT. BRASS FITTINGS	02 nos
3	29170114	Copper Tube OD 9.52mm (3/8" ) X 1.245 Mm W.T X 6 Mtr	1.2Mtr

AWM/ABS & LFS

SSE/G/ABS

SN	PENo.	Description of item	Quantity
1.	29611945	Mounting bracket arrangement provided for RF Antenna on the roof top of both driver cabs.	04 nos.
2.	•	Mounting bracket arrangement provided for GPS/GSM Antenna on the roof top of both driver cabs.	02 nos.
3.		Protection Guards for RFID reader provided behind the cattle guards of both side.	04 nos.
4.		Inspection door with latch provided on the both driver desk covers (LP side) in each cab to access isolation cock.	02 nos.
5.	2.2	Cable Entry Plate fitted for routing of cable with RF Antenna & GPS/GSM Antenna bracket.	06 nos.
6.	-	WAGO bracket fitted in Machine room at back side of SB-1.	01 no.
7.	-	One circular hole of 80 mm dia. provided in each cabs on LP side behind the driver desk toward the wall for routing of OCIP (DMI) cables.	02 nos.
8.		80 mm holes provided on TM1 and TM6 Junction box inspection cover hole for drawing of RFID reader cables.	02 nos.
9.	-	DIN Rail fitted inside the driver desk (LP Side)	02 nos.

AVM/AB6 & LFS

SSEMALFS

#### Annexure-C

SN	PL No.	Description of item	Quantity
1.	42310301	Flexible conduit size 25mm <sup>2</sup> provided for RF-1, 2 & GPS Antenna cable layout from CAB-1&2 to Machine room.	06 mtr.
2.	29611982	Wago terminals in CAB-1&2 (25 nos. in each CAB).	50 nos.
3.	29611982	Wago terminal in Machine room at back side of SB-1.	75 nos.
4.	-	Harness provided from KAVACH SB to SB-1	07 wires
5.	-	Harness provided from KAVACH SB to SB-2	05 wires
6.		Harness provided from KAVACH SB to Pneumatic Panel	12 wires
7.		Harness provided from KAVACH SB to CAB-1	16 wires
8.	-	Harness provided from KAVACH SB to CAB-2	16 wires

AWMECS

SSE/G/ECS