

# भारतीय रेल Indian Railways

पटियाला रेलइंजन कारख़ाना, पटियाला Patiala Locomotive Works, Patiala



# LOCO TESTING & DISPATCH REPORT OF IGBT BASED 3 PHASE ELECTRIC LOCOMOTIVE

LOCO NO.: 39364

TYPE: WAP-7

RAILWAY SHED: NR/LDH

PROPULSION SYSTEM: CGL

HOTEL LOAD: AAL

**DATE OF DISPATCH:** 27.05.2024

लोको निर्माण रिकार्ड



## पटियाला रेलइंजिन कारख़ाना, पटियाला Patiala Locomotive Works, Patiala

**LOCO NO. - 39364** 

**RAILWAY/SHED: NR/LDH** 

DOD: May-2024

#### **INDEX**

SN	PARA	ACTIVITIES	PAGE NO.
		Testing & Commissioning (ECS)	•
1.	1.0 1.1 1.2 1.3 1.4	Continuity Test of the cables Continuity Test of Traction Circuit Cables Continuity Test of Auxiliary Circuit Cables Continuity Test of Battery Circuit Cables Continuity Test of Screened Control Circuit Cables	1-4
2.	2.0 2.1 2.2 2.3	Low Tension test Measurement of resistor in OHMS (Ω) Check Points Low Tension Test Battery Circuits (without control electronics)	5-6
3	3.0 3.1 3.2 3.3 3.4	Downloading of Software Check Points Download Software Analogue Signal Checking Functional test in simulation mode	7-10
4	4.0 4.1 4.2 4.3 4.4 4.5 4.6 4.7 4.8 4.9	Sensor test & convertor test Test wiring Transformer Circuits – Polarity Test Test wiring auxiliary transformer 1000V/415V-110V (pos. 67) Primary Voltage Transformer Minimum voltage relay (Pos. 86) Maximum current relay (Pos. 78) Test current sensors Test DC Link Voltage Sensors (Pos 15.6/*) Verification of Converter Protection Circuits (Hardware limits) Sequence of BUR contactors	11-16
5.	5.0 5.1 5.2 5.3 5.3.1 5.3.2 5.3.3 5.4 5.5 5.6 5.7 5.8 5.9	Commissioning with High Voltage Check List Safety test main circuit breaker Auxiliary Converter Commissioning Running test of 3 ph. auxiliary equipments Performance of Auxiliary Converters Performance of BURs when one BUR goes out Auxiliary circuit 415/110 Hotel Load Circuit Traction Converter Commissioning Test protective shutdown SR Test Harmonic Filter Test important components of the locomotive	16-25
6.	6.0	Running Trial of the locomotive	25-26
7.	7.0	Final Check List to be verified at the time of Loco dispatch	27
8.	1-6	Annexure HLC	28-33
9.	1-10	Pneumatic Test Parameters	34-37
10.		Loco Check Sheet(LAS)	38
11. 12.	-	Component History (LAS,ECS,ABS) Component History & Testing Parameter (Bogie Shop)	39-41 42-43
13	-	Warranty Conditions as per Tenders	44-46

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364-CQL

Type of Locomotive: WAP-7/WAG-9HC

Page: 1 of 27

1.0 Continuity Test of the cables

1.1 Continuity Test of Traction Circuit Cables

As per cable list given in Para 1.3 of document no. 3 EHX 410 124, check the continuity with continuity tester and megger each cable to be connected between following equipment with 1000V megger.

From	То	Continuity (OK/Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Filter Cubicle	Transformer	ok	100 ΜΩ	1500
Filter Cubicle	Terminal Box of Harmonic Filter Resistor (Roof)	oK	100 ΜΩ	1500
Filter Cubicle	Earthing Choke	oK	100 ΜΩ	1500.
Earthing Choke	Earth Return Brushes	ok	100 ΜΩ	2000
Transformer	Power Converter 1	oK	100 ΜΩ	1500
Transformer	Power Converter 2	ok	100 ΜΩ	1500
Power Converter 1	TM1, TM2, TM3	ok	100 ΜΩ	1500
Power Converter 2	TM4, TM5, TM6	OK	100 ΜΩ	1500
Earth	Power Converter 1		100 ΜΩ	1000
Earth	Power Converter 2		100 ΜΩ	1006

## 1.2 Continuity Test of Auxiliary Circuit Cables

As per cable list given in Para 1.4 of document no. 3 EHX 410 124, check the continuity with continuity meter and megger each cable to be connected between following equipment with the help of 1000V megger.

Signature of the JE/SŠE/Harness

Signature of the JE/SSE/Loco Cabling

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 2 of 27

From	То	Continuity(OK/ Not OK)	Prescribed Megger Value (min)	Measured Megger Value
	DUD4	OK	100 MΩ	1000
Transformer	BUR1 BUR2	-11-	$100~ extsf{M}\Omega$	1000
Transformer Transformer	BUR3	-11-	100 MΩ	1000
	BUR1	-u-	100 ΜΩ	1500
Earth Earth	BUR2	-11-	100 MΩ	1200
	BUR3	-11-	100 MΩ	1200
Earth	HB1	-4-	100 MΩ	1000
BUR1	HB2	-11 -	$100~{ m M}\Omega$	[0500]
BUR2		-11-	100 ΜΩ	1000
HB1	TM Blower 1	-11-	100 ΜΩ	150
HB1	TM Scavenge Blower 1	-11-	100 ΜΩ	140
HB1		-11-	100 MΩ	200
HB1	Oil Cooling Unit 1	-11-	100 MΩ	130
HB1	Compressor 1	-11-	100 MΩ	172
HB1	TFP Oil Pump 1		100 ΜΩ	180
HB1	Converter Coolant Pump 1	-11-		
HB1	MR Blower 1	-4-	100 MΩ	200
HB1	MR Scavenge Blower 1	-11-	100 MΩ	196
HB1	Cab1	-11-	100 MΩ	105
Cab1	Cab Heater 1	-11-		129
HB2	TM Blower 2	-11-	100 ΜΩ	200
HB2	TM Scavenge Blower 2	-11-	100 MΩ	128
HB2	Oil Cooling Unit 2	-11-	- 100 MΩ	187
HB2	Compressor 2	-11-	- 100 MΩ	159
HB2	TFP Oil Pump 2	11-		150
HB2	Converter Coolant Pump 2	! -11-	100 ΜΩ	109
HB2	MR Blower 2	_11-	100 ΜΩ	200
HB2	MR Scavenge Blower 2	!!		126
HB2	Cab2	11~	_ 100 ΜΩ	200
Cab2	Cab Heater 2	_11-	100 ΜΩ	180

Effective Date: Feb 2022

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

# <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 3 of 27

1.3 Continuity Test of Battery Circuit Cables

Check continuity of following cables as per Para 2.3 of document no. 3 EHX 610 299

From	То	Condition	Continuity (OK/Not OK)
Battery (wire no 2093)	Circuit breakers 110- 2, 112.1-1, 310.4-1	By opening and closing MCB 112	9K
MCB 110	Connector 50.X7-1	By opening and closing MCB 110	OK.
Battery (Wire no. 2052)	Connector 50.X7-2		94
SB2 (Wire no 2050)	Connector 50.X7-3		

<u> </u>		·
Close the MCB 112, 110, 112.1, and 310.4 and measure the resistance of battery wires 2093, 2052, 2050 with respect to the loco earth.	Prescribed value $> 0.5 \ M\Omega$	Measured  Value  MΩ
Measure the resistance between 2093 & 2052, 2093 & 2050, 2052 & 2050	Prescribed value: $> 50 \text{ M}\Omega$	Measured  Value  60 MΩ
<u> </u>		

Commission the indoor lighting of the locomotive as per Sheet No 7A & 7B.

## 1.4 Continuity Test of Screened Control Circuit Cables

Check the continuity and isolation of the screen cable of the following circuits with the help of sheet no. mentioned against each as per document no. 3 EHX 610 299.

Screened control circuit cables for	Corresponding Sheet Nos.	Continuity & Isolation (OK/Not OK)
Battery voltage measurement	.04B	OΚ
Memotel circuit of cab1 &2	10A	QK .
Memotel speed sensor	10A	Y.
Primary voltage detection	01A, 12A	2
Brake controller cab-1 & 2	06F, 06G	s.k

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

# <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC Page : 4 of 27

Master controller cab-1 &2	08C, 08D	OK
	08E, 08F	oK'
TE/BE meter bogie-1 & 2	09F	OK
Terminal fault indication cab-1 & 2		°K.
Brake pipe pressure actual BE electric	06H	
Primary current sensors	12B, 12F	9K,
Harmonic filter current sensors	12B, 12F	. SK
Auxiliary current sensors	12B, 12F	OK
Oil circuit transformer bogie 1	12E, 12I	94
Magnetization current	12C, 12G	<b>₽</b> K
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-1	12D	DK.
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-2	12D	٥K
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-3	12D	ox.
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-4	12H	ox.
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-5	12H	ex.
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-6	12H	ex.
Train Bus cab 1 & 2 (Wire U13A& U13B to earthing	13A	ex.
resistance= 10KΩ± ± 10%)		
UIC line	13B	ex ex
Connection FLG1-Box TB	13A	ac

DOC.NO.P/ECS/VI (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

#### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 5 of 27

## 2.0 Low Tension test

2.1 Measurement of resistor in OHMS  $(\Omega)$ 

Measure the resistances of the load resistors for primary voltage transformer, load resistors for primary current transformer and Resistor harmonic filter as per Para 3.2 of the document no. 3 EHX 610 279.

Name of the resistor	Prescribed value	Measured value
Load resistor for primary voltage transformer (Pos. 74.2).	3.9K <b>Ω</b> ± 10%	3.9KN
Resister to maximum current relay.	1Ω ± 10%	12
Load resistor for primary current transformer (Pos. 6.11).	3.3 Ω ± 10%	3.32
Resistance harmonic filter (Pos 8.3). Variation	WAP7	WAP7
allowed ± 10%	220	0.22
Between wire 5 & 6	0.2 Ω	0252
Between wire 6 & 7	0.2 Ω	
Between wire 5 & 7	0.4 Ω	0.42
For train bus, line U13A to earthing.	10 kΩ± 10%	999Kr
For train bus, line U13B to earthing.	10 kΩ ± 10%	10.0Kr
Insulation resistance of High Voltage Cable from the top of the roof to the earth (by1000 V megger).	200 ΜΩ	300MN
Resistance measurement earth return brushes Pos. 10/1.	≤0.3 Ω	0.281
Resistance measurement earth return brushes Pos. 10/2.	≤0.3 Ω	0.285
Resistance measurement earth return brushes Pos. 10/3.	≤0.3 Ω	0.291
Resistance measurement earth return brushes Pos. 10/4.	≤0.3 Ω	0.3052
Earthing resistance (earth fault detection) Harmonic Filter –I; Pos. 8.61.	2.2 kΩ± 10%	2.2KT
Earthing resistance (earth fault detection) Harmonic Filter –II; Pos 8.62.	2.7 kΩ± 10%	2.712
Earthing resistance (earth fault detection) Aux. Converter; Pos. 90.3.	3.9 k <b>Ω</b> ± 10%	3.911
Earthing resistance (earth fault detection) 415/110V; Pos. 90.41.	1.8 k <b>Ω</b> ± 10%	1.8 kv
Earthing resistance (earth fault detection) control circuit; Pos. 90.7.	390 <b>Ω</b> ± 10%	39052
Earthing resistance (earth fault detection) Hotel load; Pos. 37.1(in case of WAP5).	3.3 k <b>Ω</b> ± 10%	NA
Resistance for headlight dimmer; Pos. 332.3.	10 <b>Ω</b> ± 10%	1052

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

#### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 6 of 27

Make sure that the earthing brush device don't make direct contact with the axle housing, earth connection must go by brushes.

#### 2.2 Check Points

Items to be checked	Remarks
Check whether all the earthing connection in roof and machine room as mentioned in sheet no. 22A is done properly or not.  These earthing connections must be flexible and should be	choeted on
marked yellow & green  Check whether all the earthing connection between loco body and bogie is done properly or not. These cables must be flexible having correct length and cross section	chaeted an

## 2.3 Low Tension Test Battery Circuits (without control electronics)

These tests are done with the help of the special type test loop boxes as per procedure given in Para 3.6 of the document no. 3 EHX 610 279

Para 3.6 of the document no. 3 EHX 6: Name of the test	Schematic used.	Remarks
Test 24V supply	Sheet 04F and other linked sheets	chooked as
Test 48V supply	Sheet 04F & sheets of group 09	Fan supply to be checked.
Test traction control	Sheets of Group 08.	عرد
Test power supply bus stations.	Sheets of Group 09.	Fan supply to be checked
Test control main apparatus	Sheets of Group 05.	OK.
Test earth fault detection battery circuit by making artificial earth fault to test the earth fault detection	Sheet 04C	OK
Test control Pneumatic devices	Sheets of Group 06	ن الح
Test lighting control	Sheets of Group 07	OK
Pretest speedometer	Sheets of Group 10	ox.
Pretest vigilance control and fire system	Sheets of Group 11	Ope
Power supply train bus	Sheets of Group 13	OK

Effective Date: Feb 2022

DOC.NO.F/ECS/VI

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 7 of 27

Downloading of Software

	Yes/No
3.1 Check Points.	tei
Check that all the cards are physically present in the bus stations and all the plugs are connected.	· · · · · · · · · · · · · · · · · · ·
Check that all the fibre optic cables are correctly connected to the bus stations.	Y ey
Make sure that <b>control electronics off relay</b> is not energized i.e. disconnect Sub-D 411.LG and loco is set up in simulation mode.	Yes
Check that battery power is on and all the MCBs (Pos. 127.*) in SB1 &SB2 are on	Yes

3.2 Download Software

The software of Traction converter, Auxiliary converter and VCU should be done by commissioning engineer of the firm in presence of supervisor. Correct software version of the

propulsion equipment to be ensured and noted:

propulsion equipment to be ensured and noteu.	90
Traction converter-1 software version:	29
Traction converter-2 software version:	29
Auxiliary converter-1 software version:	5.0
Auxiliary converter-2 software version:	4.0
Auxiliary converter-3 software version:	4.0
Vehicle control unit -1 software version:	13.7
Vehicle control unit -2 software version:	1307
VEHICLE CONTROL WHILE E SOLETAND	

3.3 Analogue Signal Checking

Check for the following analogue signals with the help of diagnostic tool connected with loco.

Description	Signal name	Prescribed value	Measured Value
Brake pipe pressure	FLG2;0101XPrAutoBkLn	100% (= 5 Kg/cm2)	94
Actual BE electric	FLG2; AMSB_0201- Wpn BEdem	100% (= 10V)	AL.
TE/BE at 'o' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 9% and 11%	114,
TE/BE at 'TE maximal' position from both cab	FLG1; AMSB_0101- Xang Trans	Between 99 % and 101 %	1014,
TE/BE at 'TE minimal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 20 % and 25 %	25%

(Def. W//ECS/40)

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page : 8 of 27

TE/BE at 'BE maximal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 99% and 101%	1004,
TE/BE at 'BE Minimal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 20% and 25%	257,
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>1/3 HBB2; AMS_0101- LT/BDEM>1/3	Between 42 and 44%	444,
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>2/3 HBB2; AMS_0101- LT/BDEM>2/3	Between 72 and 74%	741,
Both temperature sensor of TM1	SLG1; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature $0^{\circ}$ C to $40^{\circ}$ C	12°C
Both temperature sensor of TM2	SLG1; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	13°C
Both temperature sensor of TM3	SLG1; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	1200
Both temperature sensor of TM4	SLG2; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	1300
Both temperature sensor of TM5	SLG2; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	·
Both temperature sensor of TM6	SLG2; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	1200

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page : 9 of 27

#### 3.4 Functional test in simulation mode

Conduct the following functional tests in simulation mode as per Para 5.5 of document no.3EHX 610 281. through the Diagnostic tool/laptop :

Test Function	Result desired in sequence	Result obtained
Emergency shutdown through emergency stop switch 244	VCB must open. Panto must lower.	cheeked on
Shut Down through cab activation switch to OFF position	VCB must open. Panto must lower.	checod or
Converter and filter contactor operation with both Power Converters during Start Up.	FB contactor 8.41 is closed.  By moving reverser handle:  Converter pre-charging contactor 12.3 must close after few seconds.  Converter contactor 12.4 must close.  Converter re-charging contactor 12.3 must opens.  By increasing TE/BE throttle:  FB contactor 8.41 must open.  FB contactor 8.2 must close.  FB contactor 8.1 must close.	o charred ac
Converter and filter contactor operation with both Power Converters during Shut Down.	Bring TE/BE to O. Bring the cab activation key to "O"  VCB must open. Panto must lower. Converter contactor 12.4 must open. FB contactor 8.1 must open. FB contactors 8.41 must close. FB contactor 8.2 must remain closed.	charada

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC Page: 10 of 27

Contactor filter adaptation by isolating any bogie	Isolate any one bogie through bogie cut out switch. Wait for self-test of the loco.  • Check that FB contactor 8.1 is open.  • Check that FB contactor 8.2 is open.  After raising panto, closing VCB, and setting TE/BE  • FB contactor 8.1 closes.	o Charol au
	• FB contactor 8.2 remains open.	N
Test earth fault detection battery circuit positive & negative	By connecting wire 2050 to earth, create earth fault negative potential.  • message for earth fault  • By connecting wire 2095 to earth, create earth	c floored a
	fault positive potential.  • message for earth fault	
Test fire system. Create a smoke in the machine room near the FDU. Watch for activation of alarm.	When smoke sensor-1 gets activated then • Alarm triggers and fault message priority 2 appears on screen. When both smoke sensor 1+2 gets activated then • A fault message priority 1 appears on screen and lamp LSF1 glow. • Start/Running interlock occurs and TE/BE becomes to 0.	c Rected a

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 11 of 27

#### 4.0 Sensor Test and Converter Test

4.1 Test wiring main Transformer Circuits

Apply  $198V_p/140V_{RMS}$  to the primary winding of the transformer (at 1u; wire no. 2 at surge arrestor and at 1v; wire no. 100 at earthing choke). Measure the output voltage and compare

the phase of the following of the transformers.

Output Winding nos.	Description of winding.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
2U <sub>1</sub> & 2V <sub>1</sub>	For line converter bogie 1 between cable 801A-804A	10.05V <sub>p</sub> and same polarity	10.0400	οχ
2U <sub>4</sub> & 2V <sub>4</sub>	For line converter bogie 1 between cable 811A-814A	10.05V <sub>p</sub> and same polarity	10,0408	OK.
2U <sub>2</sub> & 2V <sub>2</sub>	For line converter bogie 2 between cable 801B-804B	10.05V <sub>p</sub> and same polarity	10.0420	gr
2U <sub>3</sub> & 2V <sub>3</sub>	For line converter bogie 2 between cable 811B- 814B	10.05V <sub>p</sub> and same polarity	10.0501	OK
2U <sub>B</sub> & 2V <sub>B</sub>	For aux. converter 1 between cable 1103- 1117 (in HB1) For Aux converter 2 between cable 1103- 1117 (in HB2)	7.9V <sub>p</sub> , 5.6V <sub>RMS</sub> and same polarity.	7.8 Upms	) on
2U <sub>F</sub> & 2V <sub>F</sub>	For harmonic filter between cable 4-12 (in FB)	$9.12V_p$ , $6.45V_{RMS}$ and same polarity.	9.10Vl 6.44Vpms	ac.

#### 4.2 Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)

Apply  $141V_p$  /  $100V_{RMS}$  to input of the auxiliary transformer at cable no 1203 –1117 and measure the output at

Description of wire no.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
Cable no. 1218 - 1200	58.7V <sub>p</sub> , 41.5V <sub>RMS</sub> and opposite polarity.	58.5 V/ 1 41.5 VPMS/	OK
Cable no. 1218 – 6500	15.5V <sub>p</sub> , 11.0V <sub>RMS</sub> and opposite polarity.	15-5-4	04_

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 12 of 27

#### 4.3 Primary Voltage Transformer

Apply  $250V_{\rm eff}/350V_{\rm p}$  by variac to roof wire 1 and any wire 0 and measure the magnitude and polarity of the output of the primary voltage transformer for both bogies as per the procedure specified and suggested by the traction converter manufacturer. Primary voltage measurement converters (Pos. 224.1/\*) & catenary voltmeter (Pos. 74/\*)

This test is to be done for each converter.

Activate cab in driving mode and supply  $200V_{RMS}$  through variac to wire no 1501 and 1502. Monitor the following parameters through Diagnostic tool and in catenary voltmeter.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	25kV	250%	25KV	250/
SLG1_G 87-XUPrim	25 kV	250%	258V	250-1

Decrease the supply voltage below 140  $V_{RMS}$ . VCB must open at this voltage. In this case the readings in Diagnostic Tool and catenary voltmeter will be as follows.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	17kV	170%	1741	170%
SLG2 G 87-XUPrim	17 kV	170%	1712	170-1,

Reactivate VCB to on by increasing this voltage to 175% (17.5 kV).

Increase the supply to 240  $V_{RMS}$  through variac. VCB must open at this voltage, In this case the readings in **diagnostic tool** and catenary voltmeter will be as follows:

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	30kV	300%	30KU	300%
SLG2 G 87-XUPrim	30 kV	300%	30KU	3007.

Reactivate VCB to on by decreasing this voltage to 290% (29 kV).

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

## <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39364

Functionality test:

Type of Locomotive: WAP-7/WAG-9HC

Page: 13 of 27

#### 4.4 Minimum voltage relay (Pos. 86)

 $/9.9A_p$  at the open wire 1521;

display.

VCB opens with Priority 1 fault message on

Minimum voltage relay (Pos. 86) must be adjust	red to approx 68%
William Wildge Feldy (1 05.00)	(Yes/No)
Activate loco in cooling mode. Check Power supply of 48V to	
minimum voltage relay. Disconnect primary voltage transformer (wire no. 1511 and 1512) from load resistor (Pos.	
74.2) and connect variac to wire no. 1511 and 1512 from four four forms.	·
200V <sub>RMS</sub> through variac. In this case; <i>Minimum voltage relay</i>	
200V <sub>RMS</sub> through variac. In this case, whithin to kage to ay	
(Pos. 86) picks up	
Try to activate the cab in driving mode:	(Yes/No)
Contactor 218 do not close; the control	
electronics is not be working.	(Yes/No)
Turn off the variac :	
Contactor 218 closes; the control electronics is be	
working	
Test Under Voltage Protection	<u>;</u>
·	
Activate the cab in cooling mode; Raise panto;	(Yes/No)
Supply 200V <sub>RMS</sub> through variac to wire no. 1501	
& 1502; Close the VCB; Interrupt the supply	
voltage	
The VCB goes off after 2 second time delay.	
	(Yes/No)
Again supply 200V <sub>RMS</sub> through variac to wire no.	
1501 & 1502; Decrease the supply voltage below	
$140V_{RMS} \pm 4V$ ;	
Fine tune the minimum voltage relay so that VCB opens.	
4.5 Maximum current relay (Pos. 78)	
Disconnect wire 1521 & 1522 of primary current transform	ner; Connect variac to wire 1521
&1522 (including the resistor at Pos. 6.11); Put loco in simulati	ion for driving mode; Open R <sub>3</sub> - R <sub>4</sub>
on contact 136.3; Close VCB; supply 3.6A <sub>RMS</sub> at the open v	wire 1521: Tune the drum of the
maximum current relay Pos. 78 for correct over current value;	
maximum current relay Fos. 76 for correct over current value,	
NCD against the Driggity 1 fault massage on	Yes/No)
VCB opens with Priority 1 fault message on	(100)110)
display.	7045 11 1145700
Keep contact R <sub>3</sub> - R <sub>4</sub> of 136.3 closed; Close VCB; Tune the resi	stor 78.1 for the current of 7.0A <sub>RMS</sub>

Signature of the JE/SSE/Loco Testing

/(Yes/No)

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page : 14 of 27

4.6 Test current sensors		Prescribed value	Set/Measured
Name of the sensor	Description of the test	FIESCIADEA VAIAE	value
Primary return current sensor (Test-1,Pos.6.2/1 & 6.2/2)	Activate cab in driving mode supply 10A. Measure the current through diagnostic tool or measuring print.	(Variation allowed is ± 10%)	
Primary return current	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		
sensor (Test-2, Pos.6.2/1 & 6.2/2)	Supply 297mA <sub>DC</sub> to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		299mB
Auxiliary winding current sensor (Pos. 42.3/1 & 42.3/2)	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AC/1or 2 pin no. 7(+) & 8(-) Supply 333mA <sub>DC</sub> to the test winding of sensor through connector 415.AC/1 or 2 pin no. 7(+) & 8(-)	•	338 mm
Harmonic filter current sensors (Pos.8.5/1 &8.5/2)	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AE/1o 2 pin no. 7(+) & 8(-)		_
	Supply 342mA <sub>DC</sub> to the test winding of sensor through connector 415.AE/1002 pin no. 7(+) & 8(-)	,	348mb
Hotel load current sensors (Pos. 33/1 &	Switch on hotel load. Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) 8(-)	&	
33/2)	Supply 1242mA <sub>DC</sub> to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)	3	1252mo

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 15 of 27

4.7 Test DC Link Voltage Sensors (Pos 15.6/\*)

This test is to be done by the commissioning engineer of the firm if required.

## 4.8 Verification of Converter Protection Circuits (Hardware limits) -

This test is to be done as per para 6.17 of the document no. 3EHX 610 282 for both the converters.

Protection circuits	Limit on which shutdown should take place	Measured limit
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 1	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 18.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 2	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 8.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=
Fibre optic failure In Power Converter1	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	aL
Fibre optic failure In Power Converter2	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	OK_

#### 4.9 Sequence of BUR contactors

The sequence of operation of BUR contactors for 'ALL BUR OK' BUR 1 out BUR 2 out and BUR 3 out condition has to be verified by putting the Loco in driving mode (VCB should not be closed) and isolating the BURs one by one. In these condition following will be the contactor sequence.

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	Close	Open	Close	Open	Close	Open	Close	Close	Open
BUR1 off	Close	Open	Close	Close	Open	Close	Open	Open	Close
BUR2 off	Open	Open	Close	Close	Close	Close	Open	Open	Close
BUR3 off	Open	Close	Open	Close	Close	Close	Open	Open	Close

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 16 of 27

#### Monitored contactor sequence

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	clos	open	class	opey	closs	open	close .	-Case	oper
BUR1 off	close	open	closs	clos	open	Close	open		close
BUR2 off	opcy	opes	class	closs	closs	close	open	1 2	مرون کا
BUR3 off	open	close	open	close	close	close	open	gen	closs

#### 5.0 Commissioning with High Voltage

#### 5.1 Check List

Items to be checked	Yes/No
Fibre optic cables connected correctly.	109
No rubbish in machine room, on the roof, under the loco.	Yes
All the electronic Sub-D and connectors connected	Yey
All the MCBs of the HB1 & HB2 open.	Yes
All the three fuses 40/* of the auxiliary converters	Yes
The fuse of the 415/110V auxiliary circuit (in HB1) open.	Ye
Roof to roof earthing and roof to cab earthing done	Yey.
Fixing, connection and earthing in the surge arrestor done correctly.	70,
Connection in all the traction motors done correctly.	Yes
All the bogie body connection and earthing connection done correctly.	Xe,
Pulse generator (Pos. 94.1) connection done correctly.	Yey
All the oil cocks of the gate valve of the transformer in open condition.	Ycy
All covers on Aux & Power converters, Filter block, HB1, HB2 fitted	Yes
KABA key interlocking system.	Yes

#### 5.2 Safety test main circuit breaker

Prepare to switch off the catenary supply during the first charging of the locomotive in case of any unexpected behavior of the electrical component of the loco. Charge the loco for the first time by closing BLDJ switch. The VCB will trip after certain time as no oil/coolant pumps are running yet.

Perform the following safety test of main circuit breaker through both the cabs of the locomotive.

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC Page: 17 of 27

Name of the test	Description of the test	Expected result	Monitored result
Emergency stop in cooling mode	Raise panto in cooling mode. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	charted on
Emergency stop in driving mode	Raise panto in driving mode in. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	chartedal
Under voltage protection in cooling mode	Raise panto in cooling mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open.	chocked on
Under voltage protection in driving mode	Raise panto in driving mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open with diagnostic message that catenary voltage out of limits	
Shut down in cooling mode.	Raise panto in cooling mode. Close the VCB. Bring the BL- key in O position.	VCB must open. Panto must lower.	choetedu
Shutdown in driving mode	Raise panto in driving mode. Close the VCB. Bring the BL-key in O position.	VCB must open. Panto must lower.	chockedu
Interlocking pantograph- VCB in cooling mode	Raise panto in cooling mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	C-Rocked a
Interlocking pantograph-VCB in driving mode	Raise panto in driving mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	charteda

Effective Date: Feb 2022

Doc.No.F/ECS/UI (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 18 of 27

#### 5.3 Auxiliary Converter Commissioning

Switch on the high voltage supply and set up the loco in driving mode. Raise the panto. Close the VCB. Check that there is no earth fault in the auxiliary circuit, Switch off the VCB. Lower the panto. Create the earth fault in auxiliary circuit by making connection between wire no 1117(in HB2 cubicle) and earth. After 3 minutes a diagnostic message will come that "Earth fault auxiliary circuit."

5.3.1 Running test of 3 ph. auxiliary equipments

Switch on the 3 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured continuous phase current	Measured starting phase current
Oil pump transformer 1	9.8 amps	9.5	10.4
Oil pump transformer 2	9.8 amps	9.9	11.0
Coolant pump converter 1	19.6 amps	4.5	\$-5
Coolant pump converter 2	19.6 amps	4.5	5-6
Oil cooling blower unit 1	40.0 amps	40.0	170.0
Oil cooling blower unit 2	40.0 amps	46.0	165.0
Traction motor blower 1	34.0 amps	27.0	155.0
Traction motor blower 2	34.0 amps	2710	160,0
Sc. Blower to Traction motor blower 1	6.0 amps	2.9	140
Sc. Blower to Traction motor blower 1	6.0 amps	3.0	1610
Compressor 1	25 amps at 0 kg/ cm <sup>2</sup> 40 amps at 10 kg/ cm <sup>2</sup>	27.0	135.0
Compressor 2	25 amps at 0 kg/ cm <sup>2</sup> 40 amps at 10 kg/ cm <sup>2</sup>	28.0	145,0

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 19 of 27

## 5.3.2 Performance of Auxiliary Converters

Measure the performance of the auxiliary converters through software and record it. BUR1 (Condition: Switch off all the load of BUR 1)- to be filled by commissioning engineer

Signal name	Description of the signal	Prescribed value	Monitored value	Value under Limit (Yes/No)
BUR1 7303 XUUN	Input voltage to BUR1	75% (10%=125V)	9892	79
2011	DC link voltage of BUR1	60% (10%=100V)	6360	Yey
BUR1 7303 XUIZ1	DC link current of BUR1	0% (10%=50A)	1 Bong	Yey
BOK! /505 /12:				<u> </u>

BUR2 (Condition: Switch off all the load of BUR 2, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value by the firm	Monitored value	Value under Limit (Yes/No)
BUR2 7303-XUUN	Input voltage to BUR2	75% (10%=125V)	1002V	701
BUR2 7303-XUUZ1	DC link voltage of BUR2	60% (10%=100V)	637V	, Yes
BUR2 7303-XUIZ 1	DC link current of BUR2	1% (10%=50A)*	7 Amp	Yes
BUR2 7303-XUILG	Current battery charger of BUR2	3% (10%=100A)*	21 Amb	Yes
BUR2 7303-XUIB1	Current battery of BUR2	1.5%(10%=100A)*	11 Amb	Yes
BUR2 7303 -XUUB	Voltage battery of BUR2	110%(10%=10V)	1100	76)

<sup>\*</sup> Readings are dependent upon charging condition of the battery.

BUR3 (Condition: Switch off all the load of BUR 3, Battery Charger on) to be filled by

Signal name	Description of the signal	Prescribed set value by the firm	Monitored value	Value under limit (Yes/No)
BUR3 7303-XUUN	Input voltage to BUR3	75% (10%=125V	1003V	Yey
BUR3 7303- XUUZ1	DC link voltage of BUR3	60% (10%=100V)	6374	Yes
BUR3 7303-XUIZ 1	DC link current of BUR3	1% (10%=50A)*	2 Amp	Yey
BUR3 7303-XUILG	Current battery charger of BUR 3	3% (10%=100A)*	22Amp	PG
BUR3 7303-XUIB1	Current battery of BUR 3	1.5%(10%=100A)*	12 Amp	Key .
BUR3 7303-XUUB	Voltage battery of BUR 3	110%(10%=10V)	1107	Kes

Readings are dependent upon charging condition of the battery.

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 38364

Type of Locomotive: WAP-7/WAG-9HC Page: 20 of 27

5.3.3 Performance of BURs when one BUR goes out

When any one BUR goes out then rest of the two BURs should take the load of all the

auxiliaries at ventilation level 3 of the locomotive.

Condition of	Loads on BUR1	Loads in BUR2	Loads in BUR3
BURs		400 TFD -:1	Compressor 1&2, Battery
All BURs OK	Oil Cooling unit 1&2	TM blower1&2, TFP oil pump 1&2, SR coolant pump 1&2.	charger and TM Scavenger blower 1&2
BUR 1 out		Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2,TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 2 out	Oil Cooling unit 1&2, TM blower 1&2, TM Scavenger blower 1&2		Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 3 out	Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.	

5.4 Auxiliary circuit 415/110

For checking earth fault detection, make a connection between wire no. 1218 and vehicle body. On switching on VCB, Earth fault relay 89.5 must pick up and after 3 minutes a message will come in the Diagnostic display that Earth Fault 415/110V Circuit

Switch on the 1 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Typical phase current	Measured phase current	Measured starting current
15.0 amps*	3.8	180
15.0 amps*	3 '8	20.0
1.3 amps	1.6	6.0
1.3 amps	1.8	8-5
1.1 amps	1.1	1.5
1.1 amps	101	1.5
4.8 amps	5-0	5-1
4.8 amps	5.0	5-1
	current 15.0 amps* 15.0 amps* 1.3 amps 1.3 amps 1.1 amps 4.8 amps	current       15.0 amps*       3 · 8         15.0 amps*       3 · 8         1.3 amps       ( · 6         1.3 amps       / · 8         1.1 amps       / · 1         4.8 amps       5 · 0

\* For indigenous MR blowers.

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39384

Type of Locomotive: WAP-7/WAG-9HC

Page: 21 of 27

## 5.5 Hotel load circuit (Not applicable for WAG-9HC)

For WAP-7 locomotive with Hotel load converter refer to Annexure-HLC

#### 5.6 Traction Converter Commissioning

#### This test is carried out in association with Firm.

Traction converter commissioning is being done one at a time. For testing Converter 1, switch off the traction converter 2 by switch bogie cut out switch 154. For testing Converter 2, switch off the traction converter 2 by switch bogie cut out switch 154. Isolate the harmonic filter also by switch 160. Start up the loco by one converter. Follow the functionality tests.

For Converter 1

For Converter 1 Test Function	Results desired	Result obtained
Measurement of charging and pre-charging and charging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	clocked of
Measurement of discharging of DC Link of Converter 1	Traction converter manufacturer to	chelteda
Earth fault detection on positive potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeted on
Earth fault detection on negative potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Cholted UK
Earth fault detection on Alpart of the traction circuit of Converter 1	declare the successful operation and demonstrate the same to the PLW supervisor.	chocked ar
Pulsing of line converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chocked on
Pulsing of drive converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Challed or

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC Page: 22 of 27

#### For Converter 2

For Converter 2		Result obtained	
Test Function	Results desired in sequence	Wearit optanies	
charging and pre- charging and charging of DC Link of Converter	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Areyod or	
discharging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Choeked ve	
positive potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeped on	
negative potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/v	c Deted of	
AC part of the traction circuit of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chooked as	
Pulsing of line converter of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chooked ax	
Pulsing of drive converter of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chooked a	

Effective Date: Feb 2022

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 23 of 27

#### 5.7 Test protective shutdown SR

T F	Results desired in sequence	Result obtained
Test Function	Results desired in sequence	_
Measurement of protective shutdown by Converter 1 electronics.	Start up the loco with both the converter. Raise panto. Close VCB.  Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 1Check that converter 1 electronics produces a protective shut down.  • VCB goes off • Priority 1 fault mesg. on DDU appears	p chaeted on
Measurement of protective shutdown by Converter 2 electronics.	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 2. Check that converter 2 electronics produces a protective shu down.  • VCB goes off • Priority 1 fault mesg. on diagnostic display appears  Disturbance in Converter 2	

#### 5.8 Test Harmonic Filter

Switch on the filter by switch 160

Test Function	Results desired in sequence	Result obtained	
Measurement of filter currents	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Apply a small value of TE/BE by moving the throttle.  • FB contactor 8.41 must open.	o crocked ax	

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 24 of 27

Test earth fault detection harmonic filter circuit.	<ul> <li>FB contactor 8.1must open.</li> <li>FB discharging contactor 8.41 must close</li> <li>Check the filter current in diagnostic laptop</li> <li>Make a connection between wire no. 12 and vehicle body. Start up the loco. Close VCB.</li> <li>Earth fault relay 89.6 must pick up.</li> <li>Diagnostic message comes that - Earth fault in harmonic filter circuit</li> </ul>	ochected on
Test traction motor speed sensors for both bogie in both cabs	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	ac

#### 5.9 Test important components of the locomotive

Items to be tested	Description of the test	Monitored value/remarks
Speedometer	VCU converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	cheeked on
Time delay module of MR blower	The time after which the starting capacitor for MR blower should go off the circuit should be set to 10-12 seconds	Alexad a
Ni-Cd battery voltage	At full charge, the battery voltage should be 110V DC.	chalted of
Flasher light	From both cab flasher light should blink at least 65 times in one minute.	chockedk
Head light	Head light should glow from both cabs by operating ZLPRD. Dimmer operation of headlight should also occur by operating the switch ZLPRD.	choexeel ox

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 25 of 27

Marker light	Both front and tail marker light should glow from both the cabs	chocked or
Cab Light	Cab light should glow in both the cabs by operating the switch ZLC	charted on
Spot lights	Both Drivers and Asst. Drivers Spot light should glow in both cabs by operating ZLDD	
Instrument lights	Instrument light should glow from both cab by operating the switch ZLI	charted or
Illuminated Push button	All illuminated push buttons should glow during the operation	1
Contact pressure of the high rating contactors	The contact pressure of FB contactors (8.1, 8.2) is to be measured  Criteria:  The minimum contact pressure is 54 to 66	For contactor 8.1: 7 For contactor 8.2:
Crew Fan	All crew fans should work properly when VCB of the loco is switched on. The airflow from each cab fan is to be measured.	Cab 1 LHS: Cab 1 RHS: Cab 2 LHS:
	Criteria:  The minimum flow of air of cab fan should be 25 m³/minute	Cab 2 RHS: U

#### 6.0 Running Trial of the locomotive

SN	Description of the items to be seen during trail run	Action which should take place	Remarks	
1	Cab activation in driving mode	No fault message should appear on the diagnostic panel of the loco.	Lookele	
	Loco charging	Loco to be charged and all auxiliaries should run.  No fault message to appear on the diagnostic panel of the loco. Raise MR pressure to 10 Kg/cm <sup>2</sup> , BP to 5 Kg/cm <sup>2</sup> , FP to 6 Kg/cm <sup>2</sup> .	chooser	
3.	Check function of Emergency push stop.	This switch is active only in activated cab. By pushing this switch VCB should open & pantograph should be lowered.	Rocked	
4.	Check function of BPCS.	<ul> <li>Beyond 5 kmph, press BPCS, the speed of loco should be constant.</li> <li>BPCS action should be cancelled by moving TE/BE throttle, by dropping BP below 4.75 Kg/cm², by pressing BPCS again.</li> </ul>	Roots	
5.	Check train parting operation of the Locomotive.	Operate the emergency cock to drop the BP Pressure LSAF should glow.	octor	

#### Doc.No.F/ECS/01

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

# Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 26 of 27

		4.5 Lumb and angura that	
6.	Check vigilance	Set the speed more than 1.5 kmph and ensure that	4
	operation of the	brakes are released i.e. BC < 1 Kg/cm <sup>2</sup> .	
	locomotive	For 60 seconds do not press vigilance foot switch or	
		sanding foots switch or TE/BE throttle or BPVG	
Ì		switch then	
		Buzzer should start buzzing.	
-		<ul> <li>LSVW should glow continuously.</li> </ul>	Rockes
		Do not acknowledge the alarm through BPVG or	6
1	,	vigilance foot switch further for 8 seconds then:-	
}		<ul> <li>Emergency brake should be applied</li> </ul>	
		automatically.	
		<ul> <li>VCB should be switched off.</li> </ul>	l l
Ì		Resetting of this penalty brake is possible only after	
		180 seconds by bringing TE/BE throttle to 0 and	
		acknowledge BPVR and press & release vigilance	
		foot switch.	1.0
7.	Check start/run interlock	• At low pressure of MR (< 5.6 Kg/cm <sup>2</sup> ).	chaeked a
		With park brake in applied condition.	- rep
		• With direct loco brake applied (BP< 4.75Kg/cm <sup>2</sup> ).	Dooked a
		• With automatic train brake applied (BP<4.75Kg/cm <sup>2</sup> ).	G CARRY
		• With emergency cock (BP < 4.75 Kg/cm <sup>2</sup> ).	
8.	Check traction interlock	Switch of the brake electronics. The	7 chores
		Tractive /Braking effort should ramp down, VCB	g ox
	•	should open and BP reduces rapidly.	
9.	Check regenerative	Bring the TE/BE throttle to BE side. Loco speed	2 charted in
	braking.	should start reducing.	
10.	Check for BUR	In the event of failure of one BUR, rest of the two	9
	redundancy test at	BURs can take the load of all the auxiliaries. For this	Lookeda
	ventilation level 1 & 3 of	switch off one BUR.	
	loco operation	Auxiliaries should be catered by rest of two BURs.	
		Switch off the 2 BURs; loco should trip in this case.	
11.	Check the power	Create disturbance in power converter by switching	9 Enoreton
	converter	off the electronics. VCB should open and converter	Exacted se
	isolation test	should get isolated and traction is possible with	
		another power converter.	

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39364

Type of Locomotive: WAP-7/WAG-9HC

Page: 27 of 27

## 7.0 Final check list to be verified at the time of Loco dispatch

Condition /Operations of the following items are to be checked:

SN	Item	Cab-1	Cab-2	Remarks
1	Head lights	OV_	OK C	
2	Marker Red	04	ck	
3	Marker White	04	de	
4	Cab Lights	OK_	De	
5	Dr Spot Light	0¥	OR	
6	Asst Dr Spot Light	OVE	4c \	a chocked workers in
7	Flasher Light	D14	OK	
8	Instrument Lights	OX_	OK	
9	Corridor Light	ac	OR	
10	Cab Fans	OK	ax	
11	Cab Heater/Blowers	O'A_	UK	
12	All Cab Signal Lamps Panel 'A'	ac	OK	

## PATIALA LOCOMOTIVE WORKS, PATIALA

## Testing & Commissioning Format for 2x500KVA IGBT based Hotel Load Converter for 3-phase Electric Locomotives

Locomotive No.: 29364	Page: 1 of 6
Type of Locomotive:ぬAP寻	
Make of Hotel Load Converter:	
$\cdot$	

Details of Equipment: -

Equipment	SI. No	Equipment	SI. No
HLC1	0324020171	IV Coupler CAB1 ALP	
HLC2	0324020172	IV Coupler CAB1 LP	
Converter-1	0324020131	IV Coupler CAB2 ALP	
Converter-2	0324020172	IV Coupler CAB2 LP	
UIC Coupler for Hotel Load Converter (353.3/2 CAB2)		UIC Coupler for Hotel Load Converter (353.3/3 CAB1)	_

#### 1. Polarity test of Hotel Load Winding:

Apply 198 /140 to the primary winding of the transformer (at 1U; wire no. 2 at surge arrestor and at 1V; wire no. 100 at earthing choke). Measure the output voltage and compare the phase of the following of the transformer.

Output Winding Nos.	Description of winding	Prescribed Output Voltage &Polarity with input supply	Measured Output	Measured Polarity
2UH1 & 2VH1	For Hotel load between cable 91- 94	5.9 ,4.2 and same polarity	O.L.	OK
2UH2 & 2VH2	For Hotel load between cable 91A- 94A	5.9 ,4.2 and same polarity	Ô.a	UR

Page: 2 of 6

## 2. Visual Inspection:

## Fitment of Units and Earthing to Sub-assemblies

Verify the following Equipments Fitment and grounding cables are connected to Locomotive body.

SI. No.	Equipment Name	Unit Fitment (Yes/No)	Provision of Earthing (Yes/No)
1	HLC1	Y98	428
2	HLC2	4	7
3	Output Contactor unit1 HLC1	4	4
4	Output Contactor unit2 HLC2	4	-72
5	IV Coupler CAB1 ALP	4	4
6	IV Coupler CAB1 LP	-	. 4
7	IV Coupler CAB2 ALP	7	7
8	IV Coupler CAB2 LP	. 4	4
9	UIC Coupler for Hotel Load Converter (353.3/3 CAB1)	4	4
10	UIC Coupler for Hotel Load Converter (353.3/2 CAB2)	" "	4
11	CT (LEM sensor) under HLC1	4	4
12	CT(LEM sensor) under HLC2	4)	4

Page: 3 of 6

#### 30

## 3. Cable Routing and Laying

## 3.1 Control cable routing and layout

Verify the connections, tightness and cable routing of the following Control cable.

il.	Cables Details	Performed (Yes/No)
<b>lo.</b> 1	From Wago SB1 to HLC1 are connected as per wiring	Man
ı	format	7 25
	·	· · · · · · · · · · · · · · · · · · ·
2	From SB1 to UIC Coupler Hotel Load Converter (353.3/3	-
_	CAB2) through Bayonet connector XK22HL:01(22pin)is	4
	CADZ) (illough Bayonet comments)	
	connected as per wiring format	
3	From SB1 wago(XF22S:01/53) to IV coupler CAB1 ALP	4
	are connected as per wiring format	, <del>,</del> ,
4	From SB1 wago(XF22S:01/54) to IV coupler CAB1 LP	
4	are connected as per wiring format	7
	are connected as bel witing former	
5	From Wago SB2 to HLC2 are connected as per wiring	
5	format	9
6	From SB2 to UIC Coupler Hotel Load Converter (353.3/2	
•	CAB2) through Bayonet connector XK77HL:02 (22 pin) is	u
	connected as per wiring format	
	From SB2 wago (XF77S:01/53) to IV coupler CAB2 ALP	<del>                                     </del>
7	From SB2 Wago (XF/75.01/95) to TV-couplet O/ID2 / IE	4
	are connected as per wiring format	(
	From SB2 wago (XF77S:01/54) to IV coupler CAB2 LP	
8	are connected as per wiring format	4
	are connected as per wiring format	·
9	From HLC1 to Contactor unit 1 through 4 Core Cable are	
9	connected as per wiring format	-
	Connected as per wiring format	9
10	From HLC2 to Contactor unit 2 through 4 Core Cable are	<u> </u>
10	connected as per wiring format	
	Connected as per wining former	4
11	From SB to VCU are connected as per wiring format	
	.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
		4
12	From CT (HLC1 LEM sensor) to SR1 are connected as	
	per wiring format	1-
	F-1	9
13	From CT (HLC2 LEM sensor) to SR2 are connected as	
	per wiring format	4

## 3.2 Power cable routing and layout

Verify the connections, tightness and cable routing of the following Power cable.

SI. No.	Cables Details	Performed Yes/No)
1	From Transformer to HLC1(2UH1 & 2VH1) are connected as per wiring format	Yes
2	From Transformer to HLC2(2UH2 &2VH2) are	4
3	From HLC1 to Output Contactor unit1 are connected as per	7
4	From HLC 2 to Output Contactor unit 2 are connected as per wiring format	9
5	From Output Contactor unit 1 to IV Coupler CAB1 ALP and IV Coupler CAB2ALP through Junction box are connected as	4
6	From Output Contactor unit 2 to IV Coupler CAB2 LP and IV Coupler CAB1 LP through Junction box are connected as per wiring format	7

#### 4. Continuity test:

Check the continuity test for the External connections made to Equipments.

Note: This continuity test should be done before power ON the Locomotive Battery.

#### 4.1 Control cable continuity

SI. No.		
1	From Wago SB1 to HLC1 are connected as per wiring format	425
2	From SB1 to UIC Coupler Hotel Load Converter (353.3/3 CAB2) through Bayonet connector XK22HL:01(22pin)is connected as per wiring format	
3	From SB1 wago(XF22S:01/53) to IV coupler CAB1 ALP are connected as per wiring format	4
4	From SB1 wago(XF22S:01/54) to IV coupler CAB1 LP are connected as per wiring format	4
5	From Wago SB2 to HLC2 are connected as per wiring format	
6	From SB2 to UIC Coupler Hotel Load Converter (353.3/2 CAB2) through Bayonet connector XK77HL:02(22pin) is connected as per wiring format	
7	From SB2 wago (XF77S:01/53) to IV coupler CAB2 ALP are connected as per wiring format	9
8	From SB2 wago(XF77S:01/54) to IV coupler CAB2 LP are connected as per wiring format	
9	From HLC1 to Contactor unit 1 through 4 Core Cable are connected as per wiring format	
10	From HLC2 to Contactor unit 2 through 4 Core Cable are connected as per wiring format	4
11	From SB to VCU are connected as per wiring format	4
12	From HLC1 LEM sensor to SR1 are connected as per wiring format	9
13	From HLC2 LEM sensor to SR2 are connected as per wiring format	1

Page: 5 of 6

#### 4.2 Power cable continuity

These cables continuity should be checked before mounting of converter in the locomotive.

SI. No.	Cables Details	Performed (Yes/No)
1	From Transformer to HLC1(2UH1 & 2VH1) are connected as per wiring format	
2	From Transformer to HLC2(2UH2 &2VH2) are connected as per wiring format	
3	From HLC1 to Output Contactor unit1 are connected as per wiring format	
4	From HLC 2 to Output Contactor unit 2 are connected as per wiring format	
5	From Output Contactor unit 1 to IV Coupler CAB1 ALP and IV Coupler CAB2ALP through Junction box are connected as per wiring format	
6	From Output Contactor unit 2 to IV Coupler CAB1 LP and IV Coupler CAB2 LP through Junction box are connected as per wiring format	

#### 5. Battery power ON

#### Tests Supply Voltages

Remove all Control cable connectors (Analog and Digital Input/output connectors) from HLC1, HLC2. While Switch ON Battery supply observe is there any MCBs tripping. Wait for one or two minutes after switching ON Circuit breaker(MCB1) and observe for any overheating symptoms like smell, smoke, temperature etc. from the wire bunches. If any such symptoms are noticed, there might be a short circuit in the wire bunch. Check up once again continuity wherever suspected. After that check the Voltage levels at all equipments connectors as mentioned below.

Test Details	Acceptance	Observations
Voltage Level at HLC1: I. Between wago terminal XF22S:03/54 and XF22S:03/58 II. Between wago terminal XF22S:03/53 and XF22S:03/58	~110VDC	OL.
Voltage Level at HLC2: I. Between wago terminal XF77S:03/52 and XF77S:03/56 II. Between wago terminal XF77S:03/51 and XF77S:03/56	~110VDC	Sec.

**Note:** After Above tests switch off the Power and restore all removed connectors and once again switch ON the 110 V Supply and ensure that no MCB tripping due to abnormality.

Page: 6 of 6

#### 6. Converter operation (ON/OFF) test

Power supply is directly available to the Hotel Load Converter via Hotel Load Converter winding (2UH1-2VH1) and (2UH2-2VH2). As soon as BLDJ is closed power will be available to the Hotel Load Converter. Connect the test jig of Hotel Load Converter to the UIC and IV Coupler. Charge the locomotive and switch on the BLHO, LSHO indication should glow. Hotel Load Converter screen will show message "waiting for ON command". One by one Hotel Load Converter can be switched on by test jig. Finally both the Hotel Load Converter should be turned out simultaneously. Observe the flow of air from the air duct, this will ensure that Hotel Load Converter is ON. Both the Hotel Load Converters are ON, then voltage and frequency should be measured as per the table below:-

Converters should run without any irregularities.

lotel Load Convert			O to t Francisco
	Output Voltage		Output Frequency (Hz)
U-V	V-W	U-W	(ПZ)
01	OK_	- Or	a

2		
tel Load Converter 2 Output Voltage		Output Frequency
V-W	U-W	— (Hz)
OF	UK	S/_
	Output Voltage	Output Voltage

#### 7. Earth Fault Test

- 7.1 Input Earth Fault:-Ground the input terminal of the Hotel Load Converter using a proper resistance and then turn on the Hotel Load Converter. The converter should trip with the message "Input earth fault".
- 7.2 Output Earth Fault:-Ground the output terminal of the Hotel Load Converter using a proper resistance and then turn on the Hotel Load Converter. The converter should trip with the message "Output earth fault".

Note: These to be done for the both the converters (HLC1 and HLC2) separately.

Page: 33/A

33 A

Status of RDSO modifications

LOCO NO: 39364

Sn	Modification No.	Description	Remarks
		Modification in control circuit of Flasher Light and Head	
1.	RDSO/2008/EL/MS/0357 Rev.'0' Dt 20.02.08	Light of three phase electric locomotives.	OK/Not Ok
		" electric	
2.	RDSO/2009/EL/MS/0377	Modification to voltage contains	Øk/Not Ok
	Rev.'0' Dt 22.04.09	locomotives.  Paralleling of interlocks of EP contactors and Relays of	
3.	RDSO/2010/EL/MS/0390 Rev.'0' Dt 31.12.10	three phase locomotives to improve reliability.	OK/Not Ok
	RDSO/2011/EL/MS/0399	Removal of interlocks of control circuit contactors no. 126	Øk/Not Ok
4.	RDSO/2011/EL/MS/03991 Rev.'0' Dt 08.08.11	from MCPA circuit	ZKINOL OK
5.	RDSO/2011/EL/MS/0400	Modification sheet for shifting the termination of \$GKW, 1.8	,
<b>U</b> .	Rev.'0' Dt 10.08.11	LKA 70 sq mm cables and 2x2.5 sq mm cables housed in (	Øk/Not Ok
		lower portion of HB2 panel and provision of Synthetic resin	
	110/0404	bonded glass fiber sheet for three phase locomotives.  Modification sheet for relaying of cables in HB-2 panel of	OKINI-A OK
6.	RDSO/2011/EL/MS/0401 Rev.'0' Dt 10.08.11	three phase locomotives to avoid fire hazards.	ØK/Not Ok
7.	RDSO/2011/EL/MS/0403	Auto switching of machine room/corridor lights to avoid	OK/Not Ok
7.	Rev. 0' Dt 30.11.11	draining of hatteries in three phase electric locorifolives.	7.07101
8.	RDSO/2012/EL/MS/0408		Ok/Not Ok
٥.	Rev.'0'	assambly	
9.	RDSO/2012/EL/MS/0411	Modification sheet to avoid simultaneous switching ON of	Ok/Not Ok
	Rev.'1' dated 02.11.12	White and Red marker light in three phase electric	
4.5	RDSO/2012/EL/MS/0413	Paralleling of interlocks of EP contactors and auxiliary	OK/Not Ok
10	RDSO/2012/EL/MS/0413 Rev.'1' Dt 25.04.16	contactors of three phase locomotives to improve reliability.	CK/NOLOK
11	RDSO/2012/EL/MS/0419	Modification sheet to provide rubber sealing gasket in	Ok/Not Ok
, ,	Rev.'0' Dt 20.12.12	Master Controller of three phase locomotives.	
12	RDSO/2013/EL/MS/0420	Modification sheet to provide mechanical locking	QK/Not Ok
	Rev.'0' Dt 23.01.13	arrangement in Primary Over Current Relay of three phase	DK/140LOK
		locomotives.  Modification sheet for improving illumination of head light in	0141-101-
13	RDSO/2013/EL/MS/0425 Rev.'0' Dt 22.05.13	dimmer mode in three phase electric locomotives.	Qk/Not Ok
14			OK/Not Ok
14	Rev.'0' Dt 18.07.13	phase electric locomotives	Jan
15	RDSO/2013/EL/MS/042	7 Modification sheet for MCP control in three phase electric	Ok/Not Ok
ļ.	Rev.'0' Dt 23.10.13	locomotives.	
16		Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in	Øk/Not Ok
-	Rev.'0' Dt 10.12.13	three phase electric locomotives.	
1-	RDSO/2014/EL/MS/043		ØK/Not Ok
17	Rev.'0' Dt 12.03.14	current relay of three phase electric locomotives.	
18		4 Provision of Auxiliary interlock for monitoring of Harmonic	06110
	Rev.'0' Dt 25.09.17	filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT	OK/Not Ok
		locomotives.	1
19		7 Modification in blocking diodes to improve reliability in three	OK/Not Ok
-	Rev.'0' Dt 07.12.17 RDSO/2018/EL/MS/047	phase electric locomotives.  5 Modification in existing Control Electronics (CE) resetting	OK/Not Ok
20	RDSU/2018/EL/MS/04/	scheme of 3 phase electric locomotives.	WK/NOT UK
2			QK/Not Qk
1 ~	Rev.'0' Dt 18.09.19		A. A. M. A. M.

Signature of JE/SSE/ECS

#### PLW/PATIALA

#### Loco No.39364

### PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

SN	Parameters	Reference	Value	Result
	Brake Panel: FAIVELEY			
1.0	Auxiliary Air supply system (Pantograph & VCB)			
1.1	Ensure, Air is completely vented from pantograph			0
	Reservoir (Ensure Panto gauge reading is Zero)			
1.2	Turn On BL Key. Now MCPA starts.	For Faiveley	60 sec. (Max.)	58 sec.
	Record pressure Build up time (8.0 kg/cm2)	For Knorr	120 sec. (Max.)	
1.3	Auxiliary compressor safety Valve 23F setting	Faiveley Doc. No.	8.5±0.25kg/cm2	8.5 kg/cm2
		DMTS-014-1, 8 CLW's	-	
		check sheet no.		
		F60.812 Version 2		
1.4	Check VCB Pressure Switch Setting	CLW's check sheet	Opens 4.5±0.15	4.6
		no. F60.812 Version 2	kg/cm2, closes	
			5.5±0.15 kg/cm2	5.5
1.5	Set pantograph Selector Switch is in Auto, Open pan-1&2 Is	solating Cocks & KABA co		-
1.6	Set Cab-1 Pan UP in Panel A.		Observed Pan-2	Ok
			Rises.	
1.7	Close Pan-2 isolating Cock		Panto-2 Falls Down	Ok
1.0	Open Pan -2 isolating Cock		Panto-2 Rises	
1.8	Record Pantograph Rise time		06 to 10 seconds	9 sec
1.9	Record Pantograph Lowering Time		06 to 10 seconds	10 sec
1.10	Panto line air leakage		0.7 kg/cm2 in 5 Min.	0.6 kg/cm2 in 5 min.
1 11	High Doogh Danta amargangu tagt and recet		IVIIII.	
2.0	High Reach Panto emergency test and reset.  Main Air Supply System			Ok
		Theoryptical		
2.1	Ensure, Air is completely vented from locomotive. Drain	Theoretical calculation and		
	out all the reservoirs by opening the drain cocks and then closed drain cocks. MR air pressure build up time by each	test performed by		
	compressor from 0 to 10 kg/cm2.	Railways.		
	i) with 1750 LPM compressor	Kanways.	i) 7 mins Max.	6 min.& 40
	ii) with 1450 LPM compressor		ii) 8.5 mins Max.	sec.
	, , , , , , , , , , , , , , , , , , ,		, 6.66	
2.2	Drain air below MR 8 kg/cm2 to start both the		Check Starting of	Ok
	compressors		both compressors	
2.3	Drain air from main reservoir up to 7 kg/cm2. Start		30 Sec. (Max)	CP1-29 sec
	compressors, Check pressure build time of individual		, ,	CP2-28 sec
	compressor from 8 kg/cm2 to 9 kg/cm2			
2.4	Check Low MR Pressure Switch Setting (37)	D&M test spec.	Closes at 6.40±0.15	6.4 kg/cm2
		MM3882 &	kg/cm2 Opens at	
		MM3946	5.60±0.15kg/cm2	5.65 kg/cm2
2.5	Check compressor Pressure Switch RGCP setting (35)	D&M test spec.	Opens at 10±0.20	10 .2kg/cm2
		MM3882 &	kg/cm2, Closes at	
		MM3946	8±0.20 kg/cm2	8 kg/cm2
2.6	Run both the compressors Record Pressure build up time	Trial results	3.5 Minutes Max.	3.4 min

### PLW/PATIALA

Loco No.: 39364

2.7	Check unloader val	ve operation time				Approx. 12 Sec.	11 sec.
2.8		alve functioning (12	4 & 87)			Operates when	11.5
						Compressor	kg/cm2
						starts	<u> </u>
2.9	Check CP-I delivery	safety valve setting	(10/1). Run CP	D&M t	est spec.	11.50±0.35	11.4
	Direct by BLCP.			MM3882	& MM3946	kg/cm2	kg/cm2
2.10	Check CP-2 delivery	y safety valve setting	g (10/2). Run CP	D&M t	est spec.	11.50±0.35	
	direct by BLCP			MM3882	& MM3946	kg/cm2	
2.11		mpressors and ensu	•	D&M t	est spec.		
	valve to reset at pr	essure 1.2 kg/cm2 le	ess than opening	MM3882	& MM3946		
	pressure.						
2.12		1 /		CLW's chec	k sheet no.	5.0±0.10kg/cm2	5.0 kg/cm2
	1 7	Main Reservoir, Sta	•	F60.812 Ve	rsion 2		
		ure of Duplex Check	Valve 92F.				
2.13	FP pressure:				k sheet no.	6.0±0.20kg/cm2	6.0 kg/cm2
	_	est point 107F FPTP.	Open isolate cock	F60.812 Ve	ersion 2		
	136F. Check pressu						
3.0	Air Dryer Operati						
3.1	1 -	of 2 <sup>nd</sup> MR to start (	•			Tower to change	Ok
		k Air Dryer Towers to				every minute	
3.2		ck Purge Air Stops from Air Dryer at Compressor stops				51	Ok
3.3		neck condition of humidity indicator				Blue	Blue
4.0	Main Reservoir Lea		1 4 4 D D	5014			0.61 / 0
4.1	· ·	9) in full service, Che	ck MR Pressure air	D&M test spec. MM3882 & MM3946		Should be less	0.6 kg/cm2
	leakage from both	Cabs.		IVIIVI3882	& 1/11/13946	than 1 kg/cm2 in	in 15 min.
4.2	Charle DD Air lanks	ro /icalata DD sharsi	og oogk 70)	D0 M +	ost spoo	15 minutes 0.15 kg/cm2 in 5	0.05
4.2	CHECK BY All leakage	ge (isolate BP chargii	ig COCK-70)		est spec. & MM3946	minutes	kg/cm2 in 5
				1011013002	& WIWI3340	illilates	min.
5.0	Brake Test (Auto	matic Brake opera	ntion)				1111111
5.1		& Brake Cylinder pre					
5.1	Record Brake ripe	& Brake Cymraer pro	sourc at Each Step				
	Check proportional	ity of Auto Brake sys	stem	CLW's che	ck sheet no.		
				F60.812	Version 2		
	Auto controller	BP Pressure kg/cm	12	BC (WAG-9	& WAP-7)	BC (WAP-5)	
	position			Kg/cm2		Kg/cm2	
		Value	Result	Value	Result	Value	
	Run	5±0.1	5.05 Kg/cm2	0.00	0.00 Kg/ cm2	0.00	-
	Intial	4.60±0.1	4.6 Kg/cm2	0.40±0.1	0.40Kg/ cm2	0.75±0.15	-
	Full service	3.35±0.2	3.4 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	-
	Emergency	Less than 0.3	0.25 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	-
	1 5 -1	1	· · ·	1	2.3Ng/ CITIZ	1	1

Loco No.: 39364

5.2	Record time to BP pressure drop to 3.5 kg/cm2 Ensure	D&M test spec.	8±2 sec.	6 sec.
	Automatic Brake Controller handle is Full Service from Run	MM3882 & MM3946		
5.3	Operate Asst. Driver Emergency Cock,	D&M test spec. MM3882 & MM3946	BP pressure falls to Below 2.5 kg/cm2	Ok
5.4	Check brake Pipe Pressure Switch 69F operates	CLW's check sheet no. F60.812 Version 2	Closes at BP 4.05- 4.35 kg/cm2 Opens at BP 2.85- 3.15 kg/cm2	4.1 kg/cm2 3 kg/cm2
5.5	Move Auto Brake Controller handle from Running to Emergency BC filling time from 0.4 kg/cm2 i.e. 95% of Max. BC developed WAP5 – BC $5.15 \pm 0.3$ kg/cm2 apply time WAP7 - BC $2.50 \pm 0.1$ kg/cm2 WAG9 - BC $2.50 \pm 0.1$ kg/cm2	D&M test spec. MM3882 & MM3946	4±1 sec. <b>7.5±1.5 sec.</b> 21±3 sec.	8 sec.
5.6	Move Auto Brake Controller handle to full service and BP pressure 3.5 kg/cm2. Move Brake controller to Running position BC Release time to fall BC Pressure up to 0.4 kg/cm2 i.e. 95% of Max. BC developed BC release Time  WAP7  WAG9	D&M test spec. MM3882 & MM3946	<b>17.5±2.5 sec.</b> 52±7.5 sec.	18 sec.
5.7	Move Auto Brake Controller handle to Release, Check BP Pressure Steady at 5.5± 0.2 kg/cm2 time.	CLW's check sheet no. F60.812 Version 2	60 to 80 Sec.	79 sec.
5.8	Auto Brake capacity test: The capacity of the A9 valve in released condition must conform to certain limit in order to ensure compensation for air leakage in the train without interfering with the automatic functioning of brake.  * Allow The MR pressure to build up to maximum stipulated limit.  * Close brake pipe angle cock and charge brake pipe to 5 kg/cm2 by A-9 (Automatic brake controlling) at run position.  * Couple 7.5 dia leak hole to the brake hose pipe of locomotive. Open the angle cock for brake pipe.  The test shall be carried out with all the compressors in working condition.	RDSO Motive power Directorate report no. MP Guide No. 11 July, 1999 Rev.1	BP pressure should not fall below 4.0 kg/cm2 with in 60 Sec.	4.7 kg/cm2
5.9	Keep Auto Brake Controller (A-9) in Full Service. Press Driver End paddle Switch (PVEF)		BC comes to '0'	0
6.0	Direct Brake (SA-9)			
6.1	Apply Direct Brake in Full Check BC pressure WAG9/WAP7 WAP5	CLW's check sheet no. F60.812 Version 2	3.5±0.20 kg/cm2 5.15±0.3 kg/cm2	3.6 kg/cm2
6.2	Apply Direct Brake, Record Brake Cylinder charging time	D&M test spec. MM3882 & MM3946	8 sec. (Max.)	7 sec.

#### PLW/PATIALA

Loco No.: 39364

6.3	Check Direct Brake Pressure switch 59 (F)	D&M test spec. MM3882 & MM3946	0.2.±0.1 kg/cm2	0.25 kg/cm2
6.4	Release direct brake & BC Release time to fall BC pressure up to 0.4 kg/cm2		10 -15 Sec.	14 Sec
7.0	Modified System Software (only for CCB)			
7.1	Bail-off de-activated during emergency by any means			Now De- activated
7.2	DPWCS and Non-DPWCS mode enabled		Multi Loco	
7.3	TCAS and Non-TCAS mode enabled		Not Yet Launched	Presently
7.4	Penalty brake application deactivated for Fault code 113 (FC 113) and CCB health signal will not drop to avoid loco detention/failure. The Brake Electronics Failure "message will not generate on DDS.	DDCO letter no	Pressure Setting Needed is12 kg/sqcm Causing mismatching with standard Pr Setting	not happening in PLW
7.5	CCB health signal logic revised (Now will remain high) for penalty condition occurring with FC 108 due to wrong operation/not affecting operation/ Not a CCB Fault (i.e Both controllers selected as LEAD etc) The Brake electronic failure message will not generate on DDS	RDSO letter no. EL/3.2.19/3-phase (CCB), dtd 30.01.2023		Brake electronic failure message not generate on DDS
7.6	CCB health signal logic for FC 102 (In case of BC request from VCU is more than 90 %-above 9V DC) is changed i.e CCB health signal will not drop for FC 102 which will avoid loco detention/failure. The brake electronic failure message will not generate on DDS.		Could not performed by M/s faiveley	Presently not happening in PLW
7.7	Booting time for CCB with TCAS/TPM/PTWS/DPWCS mode 15-20 sec. However, in case of absence of either one or both system booting time subsequently increased to 40-50 sec.			50 sec
8.0	Sanding Equipment			
8.1	Check Isolating Cock-134F is in open position. Press sander paddle Switch. (To confirm EP valves Operates)		Sand on Rail	Ok
9.0	Test Vigilance equipment : As per D&M test specification			Ok

#### 

Roof compnent Cab-1 & Cab-2								
S.NO.	DESCRIPTION	PL NO.	QPL/Nos.	SUPPLIER	Sr.No.	Warranty		
1	Pantograph	25880068	2	Contansys	14138-03/24,14173-03/24			
2	Servo Motor	25880068	2	Contansys	14158-03/24,14157-03/24			
	Air Intake Filter Assembly	29480103	2	PARKER	O/C1440P/B/LH/02, O/C1440P/B/LH/01			
3	All littake Filter Assembly	29460103		PARKER	(PLW)-03-24			
4	Insulator Panto Mounting	29810127	8	MIL	12-2023, 01-2024			
			Middle roo	f Component				
5	High Voltage Bushing	29731021	1	RADIANT	RE/07/03/24/HVB-05			
6	Voltage Transformer	2965028	1	Sadtem	2024-N-664315			
7	Vaccum Circuit Breaker	25712202	1	AUTOMETER	AALN/04/2024/064/VCBA/064			
8	Insulator Roof Line	29810139	9	IEC	04-23, 04-23			
9	Harmonic Filter	29650033	1	RESITECH	02/24/232496/01	Ass per PO/IRS Conditions		
10	Earthing Switch	29700073	1	AUTOMETER	AALN/03/2024/012/ES/332			
11	Surge Aresster	29750052	2	CG POWER	54856-2023,55149-2023			
			Air Brake (	Components				
12	Air Compressor (A,B)	29511008	2	ELGI	EXKS-922024 A EXKS -922064 B			
13	Air Dryer	29162051	1	TRIDENT	LD2-02-9741-24			
14	Auxillary Compressor	25513000	1	CEC	132-04-24			
15	Air Brake Panel	29180016	1	FAIVELEY	NOV-23-14-WAG9-3226			
16	Controller (A,B)	29180016	2	FAIVELEY	L23-136 A L23-110 B			
17	Break Up Valve	29162026	2	FAIVELEY				
18	Wiper Motor		4	AUTO INDUSTRY				



#### PLW/PTA

# ELECTRIC LOCO HISTORY SHEET (ECS)

**ELECTRIC LOCO NO: 39364** 

RLY: NR

SHED: LDH

PROPULSION SYSTEM: CGL

HOTEL LOAD CONVERTER: AAL

LIST OF ITEMS FITTED BY ECS

	DESCRIPTION OF ITEM	ITEM PL NO.	ITEM SR. NO	CAB-1/CAB-2	MAKE/SUPPLIER
SN	DESCRIPTION OF THE SECOND	29612937	22628		ALTOS/PTC
	LED Based Flasher Light Cab I & II	29612925		2487/2381/2590/2531	
2	Led Marker Light Cab I & II	29170011	3119/		KKI
3	Cab Heater Cab I & II		4535/4479/		MTI
4	Crew Fan Cab I & II	29470080	64		· · · · · · · · · · · · · · · · · · ·
5	Master Controller Cab I	24-22-4	0224		WOAMA/SAITRONIX
6	Master Controller Cab II	29860015		KT-1356	KONTACT
7	Complete Panel A Cab I & II	29170564	KT-1353	K1-1330	((0)17.07
8	Complete Panel C Cab I & II	29170539		1/7 4050	KONTACT
9	Complete Panel D Cab I & II	29170564	KT-1353	KT-1356	HIND
10	Complete Cubicle- F Panel Cab I & II	29178162	CF-2024B0590-641B	CF2024B0590-641A	
11	Speed Ind & Rec. System	29200040	MTELS2308322/MTELS2308322		AAL
12	Battery (Ni- Cd)	29680025	B07		HBL_
13	Set of Harnessed Cable Complete	29600418			PPS INTERNATIONAL
14	Transformer Oil Pressure Sensor (Cab-1) (pressure sensor oil circuit transformer)	29500047	TGIC/CLW/2410-FEB-2024	TGIC/CLW/2419-FEB-2024	TOPGRIP INDUSTRIES
15	Transformer Oil Pressure Sensor (Cab-2)	2500001	TGIC/CLW/2420-FEB-2024	TGIC/CLW/2409-FEB-2024	INDOOTTILO
16	Transformer Oil Temperature Sensor (Cab- 1)(temperature sensor oil circuit transformer)	29500035	BG/TFP/56	640-FEB-24	BG INDUSTRIES
17	T	1		38-FEB-24	
	Roof mounted Air Conditioner I		KKI/CL	W/2440	KKI
	Roof mounted Air Conditioner II	29811028	KKI/CLW/2457		
19	Roof mounted Air Condition of it	<del>                                     </del>	India rail navigator	3645	
20	RTIS(Real time information system)		Power supply module	3867	Aventel Ltd., India
20	Triogram unio momento ay a sandy		Rail MSS Terminal	3867	

SSE/ECS

JEFECS

	V		TVE WORKS, PATIAL 64/NR/LDHE/WAP-7	Α •		
S.N.	Equipment	PL No.	Equipment	Serial No.	M	ake
1	Complete Shell Assembly with piping	29171064	Sr. 148, (			ILAI
2	Side Buffer Assly Both Side Cab I	25171004	207, 03/24	NV, 03/24	AEU	AEU
3	Side Buffer Assly Both Side Cab II	29130050	26, 02/24	41, 04/24	AEU	* AEU
4	CBC Cab I & II	29130037	1264, 04/24	1254, 04/24	ESCORTS	ESCORTS
5	Hand Brake	23130037	06/23-			Mechwel
		29045034	00/20	13023		
6	Set of Secondry Helical Spring	29041041			AB	OKE
7	Battery Boxes (both side)	29680013	Not visible	06, 03/24	Bhartia bright	D R Steel
8	Traction Bar Bogie I		684, 0	05/23	. N	KE.
9	Traction Bar Bogie II		654, 0	05/23	N	KE
10	Centre Pivot Housing in Shell Bogie I side	29100057	49, 0		- Al	NIL
11	Centre Pivot Housing in Shell Bogie II side	25100057	59, 0		Al	VIL
12	Elastic Ring in Front in Shell Bogie I side	29100010	Sr. 27, Batch (	06, Mfg 12/23	SS	SPL
13	Elastic Ring in Front in Shell Bogie II side	29100010	Sr. 23, Batch (	06, Mfg 12/23	SS	SPL .
14	Main Transformer	29731008 for WAG 9 29731057 for WAP-7	HVE-77-04-2	4-3295, 2024	Н	VE
15	Oil Cooling Radiator I	29470031	02/24, 1	3-24-21	BANCO PROD	UCTS PVT LTD
16	Oil Cooling Radiator II	294/0031	02/24,	B-24-27	BANCO PROD	UCTS PVT LTD
17	Main Compressor I with Motor	20511000	EXKS 9220	31, 02/24	EI	.Gi
18	Main Compressor II with Motor	29511008	EXKS 9220	30, 02/24	EI	.Gi
19	Transformer Oil Cooling Pump I		2309141	3, 09/23	Flov	vwell
20	Transformer Oil Cooling Pump II		2309139	2, 09/23	Flov	vwell
21	Oil Cooling Blower OCB I	20.1700.10	04/24, AC-58195, LHP1001471399		AC	CEL
22	Oil Cooling Blower OCB II	29470043	03/24, AC-58194 LHP1001471397		AC	CEL
23	TM Blower I		04/24, 23P2601A	F04, 23P2601/04	SAINI ELECTRICAL PVT LTD	
24	TM Blower II	29440075	03/24, 23P3116A	F01, 23P3116/01	SAINI ELECTRICAL PVT LTD	
25	Machine Room Blower I		02/24, MF-24.03.20		G.T.R COP(P) LTD	
26	Machine Room Blower II	29440105	03/24, MF	-24.02.75	G.T.R COP(P) LTD	
27	Machine Room Scavenging Blower I		02/24, SM	1-24.02.60	G.T.R COP(P) LTD	
28	Machine Room Scavenging Blower II	29440129	02/24, SN	1-24.02.29	G.T.R CC	P(P) LTD
29	TM Scavenging Blower Motor I		02/24, ST	-24.02.90	G.T.R CC	P(P) LTD
30	TM Scavenging Blower Motor II	29440117	ST-24.02.1	.02, 02/24	G.T.R CC	P(P) LTD
31	Traction Convertor I		05/24, CGP12			
32	Traction Convertor II		05/24, CGP12			
33	Vehicle Control Unit I		05/24, T24	05613-P758		
34	Vehicle Control Unit II	29741075		05614-P758	C.	G.L
35	Aux. Converter Box I (BUR'1)			12451172-P758		
36	Aux. Converter Box 2 (BUR 2 + 3)		05/24, CGA100	22451172-P758		
37	Axillary Control Cubical HB-1	29176645	CG/HB1/2	23120014	C.	G.L
38	Axillary Control Cubical HB-2	29176657		20012403140	STESA	LIT LTD
39	Complete Control Cubicle SB-1	29176669	LE-SB1-C		LUB	ELEC
40	Complete Control Cubicle SB-2	29178174	LE-SB2-C		LUB	ELEC
41	Filter Cubical (FB) (COMPLETE FILTER	29480140	SLFB0001240			LIT LTD
42	Driver Seats	29171131		37, 53, 57		S WORKS
43	Hotel Load Converter I			71, 03/24		AL
44	Hotel Load Converter II	29741087		.72, 03/24	A	AL
45	Transformer oil steel pipes	29230044		l pipes		
46	Hotel Load Contactor I		0324030		¥ ME	DHA AAL
47	Hotel Load Contactor II		03240 3186			DHA AA2
48	Conservator Tank Breather Silica Gel	29731057		23-14445		TRPRISES LTD
49	Ballast Assembly ( only for WAG-9)	29170163				
50	Head Light	29611908	9:	31		CORP
51	Ducting Assembly	29470067				PHEL
52	FILETR FRAME	29480103		Tales of the second		RKER
53	IV COUPLER 0		11109/39, 1110	0/11, 11100/23	S.INTERI	NATIONAL

NAME SATECH TUMAK SSE/LAS

NAME SHUBMA SMRMA.

NAME ANKIT UPRA L

Issue No. : 05 Effective Date: July-2023

DOC NO: F/LAS/Electric Loco CHECK SHEET (Ref: WI/LAS/Elect/01, 02, 03 & 04 & QPL/LAS/Elect. Loco)
Page 1 of 1

# पटियाला रेलइंजन कारखाना, पटियाला

# PATIALA LOCOMOTIVE WORKS, PATIALA ELECTRIC LOCO CHECK SHEET

LOCO NO: 39364

Rly: NR

Shed: LOHE

S. No.	ITEM TO BE CHECKED	Specified Value	0	bserved	Value
1.1	Check proper Fitment of Hotel Load Converter & its output contactor.	OK		OK	
1.2	Check proper Fitment of MR Blower 1 & 2, MR Scavenging Blower 1 & 2, TM Blower 1 & 2, TMB Scavenging Blower 1 & 2.  TM scavenging blower 1 & 2 & Oil Cooling unit.	ОК		OK	
1.3	Check proper of Fitment of oil cooling unit (OCU).	OK		OK	
1.4	Check proper Fitment of HB 1 & 2 and its respected lower part on its position.	OK		OK	
1.5	Check proper Fitment of FB panel on its position.	OK		OK	
1.6	Check proper Fitment of assembled SB1 & SB2 panel.	OK		ok	
1.7	Check proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3).	OK		on	
1.8	Check proper Fitment of Traction converter 1 & 2 (SR-1 & 2).	OK		OK	The state of the s
1.9	Check proper fitment, torquing & Locking of Main Transformer bolt.	OK		ox	
1.10	Check proper fitment of Main compressor both side with the compressor safety wire rope.	OK		σχ	
1.11	Check proper resting of Secondary Helical Springs between Bogie & Shell body.	OK		oχ	6.
1.12	Check proper fitment of Bogie Body Safety Chains.	OK		04	
1.13	Check proper fitment of Cow catcher.	OK		OL	
1.14	Check coolant level in SR 1 & 2 Expansion Tank.	OK		OK	
1.15	Check Transformer Oil Level in both conservators Tank (Breather Tank).	OK		ox	
1.16	Check proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any damage during online working of Locomotives.	ОК		OK	
1.17	Check proper fitment of both battery box.	OK		OK	
1.18	Check for any gap between Main Transformer mounting base & Loco Shell.	OK		or	
1.19	Check proper fitment of Push Pull rod its bolt torquing and fitment of fixing cable. As per Drg No 1209-01-113-001	OK		014	_
1.20	Secondary Vertical and Lateral Clearance on leveled track at the time of Loco Dispatch.		CAE	B-1	CAB-2
	ELRS/TC/ 0082 (Rev 1) dated 17.09.2015	Vertical-Std	LP	ALP	LP ALP
		:35-60 mm		_	
		Lateral Std- 45-50 mm	46 5		53 48
1.21	Buffer height: Range (1090, +15,-5)	1085-1105		L/S	R/S
	Drg No IB031-02002.	mm	FRONT		
			1 2 3 5 5 5	1093	
			REAR	109	
1.22	Buffer Length: Range (641 mm + 3 to 10 mm with buffer face)	641 mm		L/S	R/S
	Drg No-SK.DL-3430.		FRONT	646	645
			REAR	647	645
1.23	Height of Rail Guard. (114 mm + 5 mm,-12 mm).	114 mm + 5		L/S	R/S
	As per RDSO Pamphlet Important Bogie Clearances of Electric Locomotives.	mm,-12 mm	FRONT	112	115
			REAR	112	
1 24	CBC Height: Range (1090, +15,-5)	4000 :45			- (18
1.24	Drg No- IB031-02002.	1090, +15		1095	
	DIG NO-10001-02002.	-5 mm	REAR:	1095	

(Signature of SSE/Elect. Loco (UF))

NAME Duh Bendhol

DATE 27/01/29

(Signature of SSE/JE/Elect Loco)

NAME SHUBHAM SHAPMA

DATE 27/05/29

(Signature of JE/UF)

NAME ANICIT UPPAL

DATE 27/05/24

### Loco No. 39364

#### 1. BOGIE FRAME:

BOGIE	FRAME NO	Make	PL No.	PO No. & dt.	Warranty Period
FRONT	SL-339	SIMPLEX	29105146	100190	As per PO/IRS
REAR	SL-21	SIMPLEX	29100677	100950	conditions

### 2. Hydraulic Dampers (PL No. 29040140) Make: KONI

#### 3. AXLES:

AXLE POSITION NO	1	2	3	4	5	6
MAKE/	PLW	PLW	PLW	PLW	PLW	PLW
S.NO	26589	26523	26200	26591	26576	26387
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

#### 4. WHEEL DISCS NO. AND TYPE & BULL GEAR

AXLE POSITION NO	1	2	3	4	5	6
GEAR END	DX96-008	DX90-007	DX95-067	DW17-123	DWJ3-054	DX95-135
Make	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
FREE END	DX96-065	DX96-025	DX96-179	DW17-005	DTC1-063	DWJ3-027
Make	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
Bull Gear No.	23-A-03	5011	23-A-57	23-C-18	5054	4955
Bull Gear Make	LMS	GGAG	LMS	LMS	GGAG	GGAG

### 5. AXLE ROLLER BEARING (CRU) (PL No. 29010020, Warranty: As per PO/IRS conditions)

	AXLE POSITION NO	1	2	3	4	5	6
Gear	MAKE	FAG	FAG	FAG	FAG	NBC	FAG
End	PO NO. & dt	2312	2312	2312	2312	2875	2312
Free	MAKE	FAG	FAG	FAG	FAG	NBC	FAG
End	PO NO. & dt	2312	2312	2312	2312	2875	2312

### 6. WHEEL DISC PRESSING PRESSURE IN KN: (SPECIFIED 80-105 T)

AXLE POSITION NO	1	2	3	4	5	6
BULL GEAR END	1010	788	957	945	978	900
FREE END	1018	783	1018	896	933	790

### **Loco No.** 39364

#### 7. DIAMETER AFTER PROFILE TURNING: SPECIFIED 1092 + 5 mm - 0 mm

AXLE POSITION NO	1	2	3	4	5	6
DIA IN mm GE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
DIA IN mm FE	1092.5	1092.5	1092.3	1092.5	1092.5	1092.5
WHEEL PROFILE GAUGE (1596±0.5mm)	OK	OK	OK	OK	OK	OK

#### 8. SUSPENSION TUBE & ITS TAPER ROLLER BEARING:

AXLE POSITION	1	2	3	4	5	6	
S.T. PL 29100288 MAKE		IN	IN	IN	IN	IN	IN
GE Brg. PL 29030110	MAKE	FAG	NBC	NBC	NBC	NBC	NBC
FE Brg. PL 29030110	MAKE	FAG	NBC	NBC	NBC	NBC	NBC

#### 9. GEAR CASE (PL No. 29030018) & BACKLASH:

AXLE POSITION NO	1	2	3	4	5	6
MAKE	KM	KPE	KPE	KM	KM	KM
BACKLASH (0.254 – 0.458mm)	0.310	0.265	0.260	0.300	0.320	0.260

#### 10 A/BOX TO BOGIE FRAME LATERAL CLEARANCES (SPECIFIED 15.0 to 19.0mm):

AXLE POSITION NO	1	2	3	4	5	6
RIGHT SIDE	17.52	17.04	16.75	17.05	18.72	15.55
LEFT SIDE	16.52	16.60	16.80	15.39	15.40	16.65

#### 11. TRACTION MOTOR: (PL No. 29940606, Warranty: As per PO/IRS conditions)

AXLE POSITION NO	MAKE	PO No. & date	S. NO.
1	PLW	-	PLW-2716
2	CGP	101656	2232006-5928
3	PLW	-	PLW-2707
4	BB	566661	J 2400009
5	BB	566661	J 2300298
6	BB	566661	J 2400005

B

SSE/ Bogie Shop

### TOP 13 COSTLIEST ITEMS OF WAP-7 LOCO WITH WARRANTY CONDITIONS AS PER TENDERS

S No	PL No	DESCRIPTION	Warranty Period
1	29741075	IGBT BASED 3-PHASE DRIVE PROPULSION EQUIPMENT	60 months after commissioning or 72 months from date of supply whichever earlier as per special conditions given by CLW
2	29741087	2X500KVA IGBT Based Hotel Load Converter to CLW Specn. no. CLW/ES/3/IGBT/0490 aLT.D (REV.1) issued on December,2017	As per clause no. 3.1.6 of CLW SPECN. NO. CLW/ES/3/IGBT/0490 ALT.D REV.1 ISSUED ON DEC-2017. [60 months after commissioning or 72 months from date of supply whichever earlier]
3	29731057	MAIN TRANSFORMER 7775 KVA TYPE LOT 7500 FOR WAP7 3- PHASE ELECTRIC LOCOMOTIVE TO CLW SPECN NO.CLW/ES/3/0660/C	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
4	29171064	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT-8	AS PER IRS CONDITIONS-30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER.
5	29600418	SET OF HARNESSED CABLE FOR 3-PHASE ELECTRIC LOCOMOTIVES TO CLW SPECN. NO. CLW/ES/03/646 ALT-NIL WITH DMW REQUIREMENT OF HARNESSED CABLE FOR WAP-7, ALT-A1 DATED 27/11/2018.	As per clause no.9 of CLW Specn. CLW/ES/3/0458 & Clause No.10 of CLW SpecnCLW/ES/3/0459. [18 months after commissioning or 20 months from date of supply for single core & 18 months after commissioning or 24 months from date of supply for multi core]

6	29180016	BRAKE CONTROL SYSTEM INCLUDING DRIVER'S VIGILANCE CONTROL DEVICE TO SET LIST NO.EL29180016.	As per specification no. CLW/MS/3/001 Alt. 16 i.e. the manufacturer is required to guarantee that the brakevalves/equipment work satisfactorily for a period of five (5) years after commissioning. Any equipment/part which failsduring the guarantee period shall be replaced free of cost by the manufacturer. The replaced components shallfurther be under warranty for five (5) years from the date of their fitment and should the replaced components proveunsatisfactory in service, they shall be replaced by modified and improved components by the supplier free of cost.
		COMPLETE ELLTED CUDICUE ALCANO MUTULALI	
7	29480140	COMPLETE FILTER CUBICLE ALONG WITH ALL EQUIPMENTS AND CABLING TO DRG./SPEC NO. [1] CLW/ES/3/0193 ALT-F OR LATEST AND CLW DRG. NO. 1209-15-143-004 ALT-10 AND PART DRG./SPEC NO AS PER ANNEXURE-A ATTACHED.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
8	29942007	3-PHASE ASYNCHRONOUS TRACTION MOTOR (RESISTANCE RING MECHANICALLY INTERLOCKED TO END PLATE DESIGN ROTOR, SCHEME-II), TYPE 6FRA-6068 FOR WAP-7 ELECTRIC LOCO WITHOUT ACTIVE SPEED SENSOR TO SPECIFICATION NO. 4TMS.096.081 ALT-2 AND STR NO. CLW/2008/3PHTM/STR/0001.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.

9	29105146	Bogie Frame Complete for WAP-7 for 3 Phase Co Co Locomotive to CLW specification No. CLW/MS/3/Bogie/003 alt-1 and CLW Drg.No.1209.01.112-202 Alt-Nil	As per clause 16 of Spec.No.CLW/MS/3/Bogie/003 Alt-1. [60 months after commissioning or 72 months from date of supply]
10	29171192	COMPLETE AUXILIARY CUBICLE HB2 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0192 ALT-E OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
11	29171210	COMPLETE CONTROL CUBICLE SB2 ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0195/A ALT-H OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
12	29171209	COMPLETE CONTROL CUBICLE SB1 (PUSH PULL SCHEME COMPLIANT) ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0194 ALT-G OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
13	29171180	COMPLETE AUXILIARY CUBICLE HB1 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0191 ALT-D OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.



#### भारत सरकार GOVERNMENT OF INDIA

रेल मंत्राल्य

MINISTRY OF RAILWAYS पटियाला रेलइंजन कारखाना PATIALA LOCOMOTIVE WORKS Email: dyceeloco.dmw@gmail.com फैक्स/Fax No.: 0175-2397244 फोन/ Phone: 0175-2396422 मोबाईल: 9779242310 पटियाला. 147003, भारत

PATIALA, 147003, INDIA



(An ISO 9001, ISO 14001, ISO 45001 & ISO 50001, 5S & Green Building certified Organization)

संख्या. PLW/M/ECS/Tech/Kavach

तिथि: 03.07.2024

(Through Mail)

Sr. Div. Electrical Engineer, Electrical Loco Shed, Ludhiana.

Email: elsIdhnr01@gmail.com

विषय:- Fitment of KAVACH in three Phase Electric Loco. No. 39364 WAP-7.

संदर्भ:- (i) Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 21.08.2023. (ii)Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 26.09.2023

In ref. to the above letter's Loco No. 39364 has been dispatched with fittings for implementation of KAVACH system in locomotive at home shed in Zonal Railway. This Loco was dispatched to ELS/LDH/NR on 21.06.2024. The details of fittings are attached as Annexure-A (pneumatic fittings), Annexure-B (Kavach equipment mounting Brackets) & Annexure-C (Wago with harnessed lay out).

This is for your information & necessary action please.

(निशांत बंसीवाल)

उप मुख्य विद्युत अभियंता/लोको

प्रतिलिपि:-

CEE/Loco & CEE/D&Q, CMM, CELE/NR:- for kind information please Dy CME/Design, Dy. CMM/Depot: for information & necessary action please WM/LAS, AWM/LFS&ABS, AWM/ECS: for necessary action please

# Loco No. 39364

List of balance items of KAVACH pneumatic pipes & fitting yet to be supplied later on . These items are currently under procurement process at PLW. The same will be advised to the shed for collection of the material as soon as it will be received at PLW.

		Description of Item	Qty.
١ .	PLNo.	ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITH VENT	04 nos.
	-		
		ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITHOUT	•
t	29163341		02 nos
		VENT	
		TEE UNION 3/8"X3/8"X3/8" BRASS FITTINGS	02 nos.
	<del></del>	<del></del>	
		MALE CONNECTORS 3/8" TUBE OD X 3/8" BSPT, BRASS	
		MALE CONNECTORS 5/8 TODE OF 1/3	09 nos.
		FITTINGS	
		MALE CONNECTORS 1/2" TUBE OD X 1/2" BSPT, BRASS	
			06 nos.
		FITTINGS	
• .		FEMALE CONNECTORS (NYLON TUBE) DIA 6 TUBE X 3/8"	01 no.
Ì		FEMALE CONNECTORS (NYLON TODE) DIAG	01110.
.		BSPP BRASS FITTINGS  MALE CONNECTOR (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP	03 nos.
		MALE CONNECTOR (NYLON TOBE) DIAG TOBE X 5/5	03 1105.
		BRASS FITTINGS	05.000
_	29611994	FEMALE TEE 3/8" BSPP — BRASS	06 nos.
2.	29011334	DDACC	00
		HEX PLUG -3/8" BSPT – BRASS	02 nos.
!		DDACC	
-		FEMALE TEE 1/2" BSPP - BRASS	04 nos.
	Ì	TO A	1
		HEX NIPPLE 3/8X3/8" BSPT – BRASS	04 nos.
		A CONTROL DON'T DOACS	
		RED HEX NIPPLE 3/8X1/2" BSPT - BRASS	02 nos.
•		DDACC	1
		HEX PLUG - 1/2" BSPT - BRASS	04 nos.
		THE OD V 2/01 PCDT	
		MALE ELBOW CONNECTORS 3/8" TUBE OD X 3/8) BSPT.	02 nos.
		BRASS FITTINGS (S. F.) AVI 245 Nam W. T. Y. 6 Mtr.	<del>                                     </del>
	20170114	Copper Tube OD 9.52mm (3/8" ) X 1.245 Mm W.T X 6 Mtr	1.2 Mtr
3	29170114		

AWMIABS

SSEIGIABS



		- Constitution	Quantity
SN	PL No.	Mounting bracket arrangement provided for RF Antenna on	. 04 nos.
2.	29611945	the roof top of both driver caus.	02 nos.
3.		Antenna on the roof top of both driver cabs.  Protection Guards for RFID reader provided behind the cattle	04 nos.
4.		guards of both side.  Inspection door with latch provided on the both driver desk covers (LP side) in each cab to access isolation cock.	02 nos.
5.		Cable Entry Plate fitted for routing of cable with RF Afferma	06 nos.
6.		WAGO bracket fitted in Machine room at back side of SB-1.	01. no.
7.	-	One circular hole of 80 mm dia. provided in each cabs on LP side behind the driver desk toward the wall for routing of	02 nos.
8.		OCIP (DMI) cables.  80 mm holes provided on TM1 and TM6 Junction box inspection cover hole for drawing of RFID reader cables.	02 nos.
9	-	DIN Rail fitted inside the driver desk (LP Side)	02 nos.
ا ع.			~/





### Annexure-C

06 nos.
50 nos.
75 nos.
05 wires
05 wires
12 wires
24 wires
16 wires
To wifes

AWW/ECS

SSE/G/ECS