

भारतीय रेल Indian Railways

पटियाला रेलइंजन कारख़ाना, पटियाला Patiala Locomotive Works, Patiala



LOCO TESTING & DISPATCH REPORT OF IGBT BASED 3 PHASE ELECTRIC LOCOMOTIVE

LOCO NO.: 39403

TYPE: WAP-7

RAILWAY SHED: CR/PADX

PROPULSION SYSTEM: MEDHA

HOTEL LOAD: MEDHA

DATE OF DISPATCH: 30.09.2024

लोको निर्माण रिकार्ड



पटियाला रेलइंजिन कारख़ाना, पटियाला Patiala Locomotive Works, Patiala

LOCO NO. - 39403

RAILWAY/SHED: CR/PADX

DOD: Sep-2024

INDEX

SN	PARA	ACTIVITIES	PAGE NO.		
	Testing & Commissioning (ECS)				
1.	1.0	Continuity Test of the cables			
	1.1	Continuity Test of Traction Circuit Cables			
	1.2	Continuity Test of Auxiliary Circuit Cables	1-4		
	1.3	Continuity Test of Battery Circuit Cables			
	1.4	Continuity Test of Screened Control Circuit Cables			
2.	2.0	Low Tension test			
	2.1	Measurement of resistor in OHMS (Ω)	5-6		
	2.2	Check Points	5-0		
	2.3	Low Tension Test Battery Circuits (without control electronics)			
3	3.0	Downloading of Software			
	3.1	Check Points			
	3.2	Download Software	7-10		
	3.3	Analogue Signal Checking			
	3.4	Functional test in simulation mode			
4	4.0	Sensor test & convertor test			
	4.1	Test wiring Transformer Circuits – Polarity Test			
	4.2	Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)			
	4.3	Primary Voltage Transformer			
	4.4	Minimum voltage relay (Pos. 86)	11.10		
	4.5	Maximum current relay (Pos. 78)	11-16		
	4.6	Test current sensors			
	4.7	Test DC Link Voltage Sensors (Pos 15.6/*)			
	4.8	Verification of Converter Protection Circuits (Hardware limits)			
	4.9	Sequence of BUR contactors			
5.	5.0	Commissioning with High Voltage			
	5.1	Check List			
	5.2	Safety test main circuit breaker			
	5.3	Auxiliary Converter Commissioning			
	5.3.1	Running test of 3 ph. auxiliary equipments			
	5.3.2	Performance of Auxiliary Converters			
	5.3.3	Performance of BURs when one BUR goes out	16-25		
	5. <i>4</i>	Auxiliary circuit 415/110			
	5.5	Hotel Load Circuit			
	5.6	Traction Converter Commissioning			
	5.7	Test protective shutdown SR			
	5.8 5.9	Test Harmonic Filter Test important components of the locametive			
6.	6.0	Test important components of the locomotive Running Trial of the locomotive	25-26		
7.	7.0	Final Check List to be verified at the time of Loco dispatch	25-20		
8.	1-6	Annexure HLC	28-33		
9.	1-10	Pneumatic Test Parameters	34-37		
	, 10				
	_				
	_		42-43		
	-		44-46		
10. 11. 12.		Loco Check Sheet(LAS) Component History (LAS,ECS,ABS) Component History & Testing Parameter (Bogie Shop) Warranty Conditions as per Tenders	38 39-4 42-43		

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39403 - MEDHA

Type of Locomotive: WAP-7/WAG-9HC

Page: 1 of 27

1.0 Continuity Test of the cables

1.1 Continuity Test of Traction Circuit Cables

As per cable list given in Para 1.3 of document no. 3 EHX 410 124, check the continuity with continuity tester and megger each cable to be connected between following equipment with 1000V megger.

From	То	Continuity (OK/Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Filter Cubicle	Transformer	οK	100 ΜΩ	1000ma
Filter Cubicle	Terminal Box of Harmonic Filter Resistor (Roof)	OK	100 ΜΩ	1000 M2
Filter Cubicle	Earthing Choke	oK	100 ΜΩ	800M2.
Earthing Choke	Earth Return Brushes	OK	100 ΜΩ	900ma
Transformer	Power Converter 1	σK	100 ΜΩ	800 max
Transformer	Power Converter 2	OK	100 ΜΩ	200 m2
Power Converter 1	TM1, TM2, TM3	OK	100 ΜΩ	Gooma
Power Converter 2	TM4, TM5, TM6	oK	100 ΜΩ	700 ma
Earth	Power Converter 1	oK	100 ΜΩ	900ma
Earth	Power Converter 2	oK	100 ΜΩ	800251

1.2 Continuity Test of Auxiliary Circuit Cables

As per cable list given in Para 1.4 of document no. 3 EHX 410 124, check the continuity with continuity meter and megger each cable to be connected between following equipment with the help of 1000V megger.

Signature of the JE/SSE/Harness

Signature of the JE/SSE/Loco Cabling

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC

Page: 2 of 27

From	То	Continuity(OK/ Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Transformer	BUR1	OK	100 ΜΩ	600 M/L
Transformer	BUR2	OK	100 MΩ	SOOMA
Transformer	BUR3	OK	100 MΩ	600MM
Earth	BUR1	OL	100 MΩ	SOOM
Earth	BUR2	Oh	100 ΜΩ	FUOMA
Earth	BUR3	OL	100 MΩ	SOOMA
BUR1	HB1	Sk	100 MΩ	600 MM
BUR2	HB2	Oh	100 M Ω	400 MJ
HB1	HB2	ok	100 M Ω	500ML
HB1	TM Blower 1	NS	100 ΜΩ	600 MM
HB1	TM Scavenge Blower 1	ok	100 ΜΩ	FOOM
HB1	Oil Cooling Unit 1	Ole	100 MΩ	600 M
HB1	Compressor 1	ok	100 M Ω	400
HB1	TFP Oil Pump 1	ok	100 MΩ	500
HB1	Converter Coolant Pump 1	Ole	100 MΩ	600
HB1	MR Blower 1	ok	100 MΩ	500
HB1	MR Scavenge Blower 1	ok.	100 ΜΩ	600
HB1	Cab1	OK	100 MΩ	700
Cab1	Cab Heater 1	oh	100 MΩ	600
HB2	TM Blower 2	ou	100 ΜΩ	500
HB2	TM Scavenge Blower 2	Ole	100 ΜΩ	600
HB2	Oil Cooling Unit 2	oh.	100 MΩ	500
HB2	Compressor 2	de	100 ΜΩ	600
HB2	TFP Oil Pump 2	تاد	100 MΩ	400
HB2	Converter Coolant Pump 2	ole	100 MΩ	600
HB2	MR Blower 2	de	100 ΜΩ	700
HB2	MR Scavenge Blower 2	ok	100 MΩ	600
HB2	Cab2	ok	100 ΜΩ	500
Cab2	Cab Heater 2	OK	100 MΩ	600

Harton

PATIALA LOCOMOTIVE WORKS, PATIALA

(Ref: WI/ECS/10)

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39103

Type of Locomotive: WAP-7/WAG-9HC

Page: 3 of 27

1.3 Continuity Test of Battery Circuit Cables

Check continuity of following cables as per Para 2.3 of document no. 3 EHX 610 299

From	То	Condition	Continuity (OK/Not OK)
Battery (wire no 2093)	Circuit breakers 110- 2, 112.1-1, 310.4-1	By opening and closing MCB 112	OK
MCB 110	Connector 50.X7-1	By opening and closing MCB 110	OK
Battery (Wire no. 2052)	Connector 50.X7-2		Ok
SB2 (Wire no 2050)	Connector 50.X7-3		0 احـ

Close the MCB 112, 110, 112.1, and 310.4 and	Prescribed value	Measured
measure the resistance of battery wires 2093, 2052, 2050 with respect to the loco earth.	> 0.5 MΩ	Value <u>6</u> ΜΩ
Measure the resistance between 2093 & 2052, 2093 & 2050, 2052 &	Prescribed value:	Measured
2050	> 50 MΩ	Value <u>60</u> ΜΩ

Commission the indoor lighting of the locomotive as per Sheet No 7A & 7B.

1.4 Continuity Test of Screened Control Circuit Cables

Check the continuity and isolation of the screen cable of the following circuits with the help of sheet no. mentioned against each as per document no. 3 EHX 610 299.

Screened control circuit cables for	Corresponding Sheet Nos.	Continuity & Isolation (OK/Not OK)
Battery voltage measurement	04B	Ok
Memotel circuit of cab1 &2	10A	OK
Memotel speed sensor	10A	ok
Primary voltage detection	01A, 12A	OK
Brake controller cab-1 & 2	06F, 06G	ok

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC
Page: 4 of 27

Master controller cab-1 &2	08C, 08D	OK
TE/BE meter bogie-1 & 2	08E, 08F	OK
Terminal fault indication cab-1 & 2	09F	OK .
Brake pipe pressure actual BE electric	06H	OK
Primary current sensors	12B, 12F	oK
Harmonic filter current sensors	12B, 12F	OK
Auxiliary current sensors	12B, 12F	OK
Oil circuit transformer bogie 1	12E, 12l	ak
Magnetization current	12C, 12G	OK
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-1	12D	OK
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-2	12D	04
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-3	12D	OK
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-4	12H	OK
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-5	12H	OK
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-6	12H	OK
Train Bus cab 1 & 2 (Wire U13A& U13B to earthing resistance=	13A	
10KΩ± ± 10%)		Ok
UIC line	13B	OK
Connection FLG1-Box TB	13A	OK

DOC.NO.F/ECS/VI (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC

Page: 5 of 27

2.0 Low Tension test

2.1 Measurement of resistor in OHMS (Ω)

Measure the resistances of the load resistors for primary voltage transformer, load resistors for primary current transformer and Resistor harmonic filter as per Para 3.2 of the document no. 3 EHX 610 279.

Name of the resistor	Prescribed value	Measured value
Load resistor for primary voltage transformer (Pos. 74.2).	3.9K Ω ± 10%	3.9102
Resister to maximum current relay.	1Ω ± 10%	152
Load resistor for primary current transformer (Pos. 6.11).	3.3 Ω ± 10%	3:352
Resistance harmonic filter (Pos 8.3). Variation allowed ± 10%	1	WAP7
Between wire 5 & 6	0.2 Ω	0.252
Between wire 6 & 7	0.2 Ω	0.21
Between wire 5 & 7	0.4 Ω	0.62
For train bus, line U13A to earthing.	10 kΩ± 10%	999 pr
For train bus, line U13B to earthing.	10 k Ω ± 10%	10.0kz
Insulation resistance of High Voltage Cable from the top of the roof to the earth (by1000 V megger).	200 ΜΩ	400MM
Resistance measurement earth return brushes Pos. 10/1.	≤0.3 Ω	0.301
Resistance measurement earth return brushes Pos. 10/2.	≤0.3 Ω	0.281
Resistance measurement earth return brushes Pos. 10/3.	≤0.3 Ω	0.28M
Resistance measurement earth return brushes Pos. 10/4.	≤0.3 Ω	0.29,52
Earthing resistance (earth fault detection) Harmonic Filter –I; Pos. 8.61.	2.2 kΩ± 10%	2.242
Earthing resistance (earth fault detection) Harmonic Filter –II; Pos 8.62.	2.7 kΩ± 10%	2.782
Earthing resistance (earth fault detection) Aux. Converter; Pos. 90.3.	3.9 k Ω ± 10%	3.910
Earthing resistance (earth fault detection) 415/110V; Pos. 90.41.	1.8 kΩ± 10%	1.8 kv
Earthing resistance (earth fault detection) control circuit; Pos. 90.7.	390 Ω ± 10%	390N
Earthing resistance (earth fault detection) Hotel load; Pos. 37.1(in case of WAP5).	3.3 kΩ± 10%	MA
Resistance for headlight dimmer; Pos. 332.3.	10 Ω ± 10%	105

DOC.NO.F/ECS/VI (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC

Page: 6 of 27

Make sure that the earthing brush device don't make direct contact with the axle housing, earth connection must go by brushes.

2.2 Check Points

Items to be checked	Remarks
Check whether all the earthing connection in roof and machine room as mentioned in sheet no. 22A is done properly or not. These earthing connections must be flexible and should be marked yellow & green	Checked ox
Check whether all the earthing connection between loco body and bogie is done properly or not. These cables must be flexible having correct length and cross section	Checked OK

2.3 Low Tension Test Battery Circuits (without control electronics)

These tests are done with the help of the special type test loop boxes as per procedure given in Para 3.6 of the document no. 3 EHX 610 279

Para 3.6 of the document no. 3 EHX 6 Name of the test	Schematic used.	Remarks
Test 24V supply	Sheet 04F and other linked sheets	Cheched OK
Test 48V supply	Sheet 04F & sheets of group 09	Fan supply to be checked. りと
Test traction control ,	Sheets of Group 08.	OK
Test power supply bus stations.	Sheets of Group 09.	Fan supply to be checked.
Test control main apparatus	Sheets of Group 05.	OK
Test earth fault detection battery circuit by making artificial earth fault to test the earth fault detection	Sheet 04C	0k
Test control Pneumatic devices	Sheets of Group 06	OK
Test lighting control	Sheets of Group 07	OK
Pretest speedometer	Sheets of Group 10	OK
Pretest vigilance control and fire system	Sheets of Group 11	OK
Power supply train bus	Sheets of Group 13	OK

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

omotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC

Page: 7 of 27

LOCO	IIIOtive Ivo 🥒 .	/ V 7
3.0	Downloading (of Software

Yes/No
4es
Yes
4es
Yes

3.2 Download Software

The software of Traction converter, Auxiliary converter and VCU should be done by commissioning engineer of the firm in presence of supervisor. Correct software version of the

propulsion equipment to be ensured and noted:

propulsion equipment to be ensured and noted.	
Traction converter-1 software version:	1.09
Traction converter-2 software version:	1.09
Auxiliary converter-1 software version:	1.04
Auxiliary converter-2 software version:	1.04
Auxiliary converter-3 software version:	1.04
Vehicle control unit -1 software version:	3.0
Vehicle control unit -2 software version:	3.0

3.3 Analogue Signal Checking

Check for the following analogue signals with the help of diagnostic tool connected with loco

Description	Signal name	Prescribed value	Measured Value
Brake pipe pressure	FLG2;0101XPrAutoBkLn	100% (= 5 Kg/cm2)	OK
Actual BE electric	FLG2; AMSB_0201- Wpn BEdem	100% (= 10V)	0K
TE/BE at 'o' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 9% and 11 %	10-1/2
TE/BE at 'TE maximal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 99 % and 101 %	100.1
TE/BE at 'TE minimal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 20 % and 25 %	257,

(Ref. WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39 403

Type of Locomotive: WAP-7/WAG-9HC

Page : 8 of 27

TE/BE at 'BE maximal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 99% and 101%	1004,
TE/BE at 'BE Minimal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 20% and 25%	241,
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>1/3 HBB2; AMS_0101- LT/BDEM>1/3	Between 42 and 44%	444,
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>2/3 HBB2; AMS_0101- LT/BDEM>2/3	Between 72 and 74%	74.
Both temperature sensor of TM1	SLG1; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature 0° C to 40° C	ly°C
Both temperature sensor of TM2	SLG1; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	13°C
Both temperature sensor of TM3	SLG1; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	l4°C
Both temperature sensor of TM4	SLG2; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	13.5°C
Both temperature sensor of TM5	SLG2; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	14°C
Both temperature sensor of TM6	SLG2; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	14°C

DOC.NO.F/ECS/VI

(Ref: WI/ECS/10)

Effective Date: Feb 2022 PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC

Page: 9 of 27

Functional test in simulation mode 3.4

Conduct the following functional tests in simulation mode as per Para 5.5 of document no.3EHX 610 281. through the Diagnostic tool/laptop:

Test Function	Result desired in sequence	Result obtained
Emergency shutdown through emergency stop switch 244	VCB must open. Panto must lower.	Cheched OK
Shut Down through cab activation switch to OFF position	VCB must open. Panto must lower.	(hecked)
Converter and filter contactor operation with both Power Converters during Start Up.	FB contactor 8.41 is closed. By moving reverser handle: Converter pre-charging contactor 12.3 must close after few seconds. Converter contactor 12.4 must close. Converter re-charging contactor 12.3 must opens. By increasing TE/BE throttle: FB contactor 8.41 must open. FB contactor 8.2 must close. FB contactor 8.1 must close.	(hecked OK
Converter and filter contacto operation with both Powe Converters during Shut Down.	 Bring TE/BE to O. Bring the cab activation key to "O" VCB must open. Panto must lower. Converter contactor 12.4 must open. FB contactor 8.1 must open. FB contactors 8.41 must close. FB contactor 8.2 must remain closed. 	,

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 59403

Type of Locomotive: WAP-7/WAG-9HC Page: 10 of 27

Contactor filter adaptation by isolating any bogie	Isolate any one bogie through bogie cut out switch. Wait for self-test of the loco.	(hecker
	 Check that FB contactor 8.1 is open. 	OK
	 Check that FB contactor 8.2 is open. After raising panto, closing VCB, and 	
	setting TE/BE	
	• FB contactor 8.1 closes.	
	 FB contactor 8.2 remains open. 	
Test earth fault detection battery	By connecting wire 2050 to	
circuit positive & negative	earth, create earth fault negative potential.	Classicad
	message for earth fault	Checked
	By connecting wire 2095	OF
	to earth, create earth	
	fault positive potential.	
	message for earth fault	
Test fire system. Create a smoke in	When smoke sensor-1 gets	
the machine room near the FDU.	activated then	
Watch for activation of alarm.	 Alarm triggers and fault message priority 2 	Checked
·	appears on screen.	OK
	When both smoke sensor 1+2 gets activated then	
•	A fault message priority	
	1 appears on screen and	
	lamp LSF1 glow.	
	Start/Running interlock occurs and	
Time, date & loco number	TE/BE becomes to 0. Ensure correct date time and Loco	
rime, date w loco number	Ensure correct date time and roco	OK

Effective Date: Feb 2022

DOC.NO.F/ECO/UI (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39 403

Type of Locomotive: WAP-7/WAG-9HC

Page: 11 of 27

Sensor Test and Converter Test

4.1 Test wiring main Transformer Circuits

Apply $198V_p/140V_{RMS}$ to the primary winding of the transformer (at 1u; wire no. 2 at surge arrestor and at 1v; wire no. 100 at earthing choke). Measure the output voltage and compare

following of the transformers.

Output Winding nos.	Description of winding.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
2U ₁ & 2V ₁	For line converter bogie 1 between cable 801A- 804A	10.05V _p and same polarity	10.0420	9k
2U ₄ & 2V ₄	For line converter bogie 1 between cable 811A-814A	10.05V _p and same polarity	10.0476	or
2U ₂ & 2V ₂	For line converter bogie 2 between cable 801B-804B	10.05V _p and same polarity	10.0276	TK.
2U ₃ & 2V ₃	For line converter bogie 2 between cable 811B- 814B	10.05V _p and same polarity	10.0400	ek.
2U _B & 2V _B	For aux. converter 1 between cable 1103- 1117 (in HB1) For Aux converter 2 between cable 1103- 1117 (in HB2)	7.9V _p , 5.6V _{RMS} and same polarity.	7. BUP S-supms	OK.
2U _F & 2V _F	For harmonic filter between cable 4-12 (in FB)	9.12V _p , 6.45V _{RMS} and same polarity.	9.10 VP 6.44 VRMS	arc

4.2 Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)

Apply $141V_p$ / $100V_{RMS}$ to input of the auxiliary transformer at cable no 1203 –1117 and measure the output at

Description of wire no.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
Cable no. 1218 - 1200	58.7V _p , 41.5V _{RMS} and opposite polarity.	58-54 41-44pms	ak
Cable no. 1218 – 6500	15.5V _p , 11.0V _{RMS} and opposite polarity.	15-408	Op.
-		11.0 URMS	•

issue No.03

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC

Page: 12 of 27

Primary Voltage Transformer 4.3

Apply 250Veff/350Vp by variac to roof wire 1 and any wire 0 and measure the magnitude and polarity of the output of the primary voltage transformer for both bogies as per the procedure specified and suggested by the traction converter manufacturer. Primary voltage measurement converters (Pos. 224.1/*) & catenary voltmeter (Pos. 74/*)

This test is to be done for each converter.

Activate cab in driving mode and supply $200V_{RMS}$ through variac to wire no 1501 and 1502. Monitor the following parameters through Diagnostic tool and in catenary voltmeter.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	25kV	250%	25 KU	2504
SLG2 G 87-XUPrim	25 kV	250%	28KV	2507

Decrease the supply voltage below 140 V_{RMS} . VCB must open at this voltage. In this case the readings in Diagnostic Tool and catenary voltmeter will be as follows.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	17kV	170%	ITKU	170 %
SLG2 G 87-XUPrim	17 kV	170%	17KU	1701,

Reactivate VCB to on by increasing this voltage to 175% (17.5 kV).

Increase the supply to 240 V_{RMS} through variac. VCB must open at this voltage, In this case the readings in diagnostic tool and catenary voltmeter will be as follows:

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	30kV	300%	30KU	3004.
SLG2_G 87-XUPrim	30 kV	300%	30K U	3004.

Reactivate VCB to on by decreasing this voltage to 290% (29 kV).

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 59403

Type of Locomotive: WAP-7/WAG-9HC

Page: 13 of 27

Minimum voltage relay (Pos. 86) 4.4

Functionality test:	ted to approx 68%
Minimum voltage relay (Pos. 86) must be adjus	teu to approx 00%
Activate loco in cooling mode. Check Power supply of 48V to	(Yes/No)
minimum voltage relay. Disconnect primary voltage	
transformer (wire no. 1511 and 1512) from load resistor (POS.	
74.3) and connect variac to wire no. 1501 and 1502. Supply	· · · · · · · · · · · · · · · · · · ·
200V _{RMS} through variac. In this case; <i>Minimum voltage relay</i>	· ·
(Pos. 86) picks up	
(1 dd) dd) paraire (
	6
Try to activate the cab in driving mode:	(Yes/No)
Contactor 218 do not close; the control	1
electronics is not be working.	
Turn off the variac :	(Yes/No)
Contactor 218 closes; the control electronics is be	
· ·	
working	
Test Under Voltage Protection	<u>1)</u>
	()//01->
Activate the cab in cooling mode; Raise panto;	(Yes/No)
Supply 200V _{RMS} through variac to wire no. 1501	
& 1502; Close the VCB; Interrupt the supply	
voltage	
The VCB goes off after 2 second time delay.	
Again supply 200V _{RMS} through variac to wire no.	(Yes/No)
Again supply 2007 _{RMS} till ough value to whe no. 1501 & 1502; Decrease the supply voltage below	1
140V _{RMS} ± 4V;	
Fine tune the minimum voltage relay so that VCB opens.	<u> </u>

4.5 Maximum current relay (Pos. 78)	
Disconnect wire 1521 & 1522 of primary current transfo &1522 (including the resistor at Pos. 6.11); Put loco in simu on contact 136.3; Close VCB; supply 3.6A _{RMS} at the ope maximum current relay Pos. 78 for correct over current value.	lation for driving mode; Open $R_3 - R_4$ n wire 1521; Tune the drum of the
VCB opens with Priority 1 fault message on	(Yes/No)
display.	
Keep contact $R_3 - R_4$ of 136.3 closed; Close VCB; Tune the r	esistor 78.1 for the current of 7.0A _{RMS}
/9.9A _p at the open wire 1521;	
	· · · · · · · · · · · · · · · · · · ·
VCB opens with Priority 1 fault message on	(Yes/No)
display.	·

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC

Page: 14 of 27

1.6 Test current sensors Name of the sensor	Description of the test	Prescribed value	Set/Measured value
Primary return current sensor (Test-1,Pos.6.2/1 & 6.2/2)	Activate cab in driving mode supply 10A. Measure the current through diagnostic tool or measuring print.	(Variation allowed is ± 10%)	
	Supply 90mA _{DC} to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		
Primary return current sensor (Test-2, Pos.6.2/1 & 6.2/2)	Supply 297mA _{DC} to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		298ma
Auxiliary winding current sensor (Pos. 42.3/1 & 42.3/2)	Supply 90mA _{DC} to the test winding of sensor through connector 415.AC/1or 2 pin no. 7(+) & 8(-) Supply 333mA _{DC} to the test winding of sensor through connector 415.AC/1 or 2 pin no. 7(+) & 8(-)		4husse
Harmonic filter current sensors (Pos.8.5/1 &8.5/2)	Supply 90mA _{DC} to the test winding of sensor through connector 415.AE/10/2 pin no. 7(+) & 8(-)		
	Supply 342mA _{DC} to the test winding of sensor through connector 415.AE/1or 2 pin no. 7(+) & 8(-)		346mg
Hotel load current sensors (Pos. 33/1 &	Switch on hotel load. Supply 90mA _{DC} to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) 8(-)		
33/2)	Supply 1242mA _{DC} to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)		1248mm

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC

Page: 15 of 27

4.7 Test DC Link Voltage Sensors (Pos 15.6/*)

This test is to be done by the commissioning engineer of the firm if required.

4.8 Verification of Converter Protection Circuits (Hardware limits) -

This test is to be done as per para 6.17 of the document no. 3EHX 610 282 for both the converters.

Protection circuits	Limit on which shutdown should take place	Measured limit	
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 1	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 18.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=	OK
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 2	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 8.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=	OK
Fibre optic failure In Power Converter1	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	OŁ	
Fibre optic failure In Power Converter2	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	OK	

4.9 Sequence of BUR contactors

The sequence of operation of BUR contactors for 'ALL BUR OK' BUR 1 out BUR 2 out and BUR 3 out condition has to be verified by putting the Loco in driving mode (VCB should not be closed) and isolating the BURs one by one. In these condition following will be the contactor sequence.

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	Close	Open	Close	Open	Close	Open	Close	Close	Open
BUR1 off	Close	Open	Close	Close	Open	Close	Open	Open	Close
BUR2 off	Open	Open	Close	Close	Close	Close	Open	Open	Close
BUR3 off	Open	Close	Open	Close	Close	Close	Open	Open	Close

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39 (03

Type of Locomotive: WAP-7/WAG-9HC

Page: 16 of 27

Monitored contactor sequence

Chadusa	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
Status		Oben	cliss	oben	clos	open	clox	close.	den
AI BUR OK	closs					- O08	Spess	oben	clos
BUR1 off	close	open		Clos			open		los
BUR2 off	open	open	Cler	cles		clos			close
BUR3 off	Open	Close	open	close	clos	clase	open	Open	CEUS!

5.0 Commissioning with High Voltage

5.1 Check List

Items to be checked	Yes/No
Fibre optic cables connected correctly.	Yes
No rubbish in machine room, on the roof, under the loco.	Yes
All the electronic Sub-D and connectors connected	Yes
All the MCBs of the HB1 & HB2 open.	Yes
All the three fuses 40/* of the auxiliary converters	Yes
The fuse of the 415/110V auxiliary circuit (in HB1) open.	Yes
Roof to roof earthing and roof to cab earthing done	403
Fixing, connection and earthing in the surge arrestor done correctly.	Yes
Connection in all the traction motors done correctly.	Yes
All the bogie body connection and earthing connection done correctly.	ye.
Pulse generator (Pos. 94.1) connection done correctly.	Yes
All the oil cocks of the gate valve of the transformer in open condition.	Yes
All covers on Aux & Power converters, Filter block, HB1, HB2 fitted	Yes
KABA key interlocking system.	Yes

5.2 Safety test main circuit breaker

Prepare to switch off the catenary supply during the first charging of the locomotive in case of any unexpected behavior of the electrical component of the loco. Charge the loco for the first time by closing BLDJ switch. The VCB will trip after certain time as no oil/coolant pumps are running yet.

Perform the following safety test of main circuit breaker through both the cabs of the locomotive.

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 38403

Type of Locomotive: WAP-7/WAG-9HC Page: 17 of 27

Name of the test	Description of the test	Expected result	Monitored result
Emergency stop in cooling mode	Raise panto in cooling mode. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	Checked OK
Emergency stop in driving mode	Raise panto in driving mode in. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	cheeted on
Under voltage protection in cooling mode	Raise panto in cooling mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open.	checked ax
Under voltage protection in driving mode	Raise panto in driving mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open with diagnostic message that catenary voltage out of limits	Chekedok
Shut down in cooling mode.	Raise panto in cooling mode. Close the VCB. Bring the BL- key in O position.	VCB must open. Panto must lower.	CReeked &
Shutdown in driving mode	Raise panto in driving mode. Close the VCB. Bring the BL-key in O position.	VCB must open. Panto must lower.	chockeday
Interlocking pantograph- VCB in cooling mode	Raise panto in cooling mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	CRooped 4
Interlocking pantograph- VCB in driving mode	Raise panto in driving mode. Close the VCB. Lower the pantograph by ZPT		cheereda

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC

Page: 18 of 27

5.3 Auxiliary Converter Commissioning

Switch on the high voltage supply and set up the loco in driving mode. Raise the panto. Close the VCB. Check that there is no earth fault in the auxiliary circuit, Switch off the VCB. Lower the panto. Create the earth fault in auxiliary circuit by making connection between wire no 1117(in HB2 cubicle) and earth. After 3 minutes a diagnostic message will come that "Earth fault auxiliary circuit."

5.3.1 Running test of 3 ph. auxiliary equipments

Switch on the 3 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured continuous phase current	Measured starting phase current
Oil pump transformer 1	9.8 amps	11.6	12.5
Oil pump transformer 2	9.8 amps	11.7	12.2
Coolant pump converter 1	19.6 amps	4.6	7.7
Coolant pump converter 2	19.6 amps	4.6	8-1
Oil cooling blower unit 1	40.0 amps	25.0	140.0
Oil cooling blower unit 2	40.0 amps	25-1	145:0
Traction motor blower 1	34.0 amps	32-5	80.0
Traction motor blower 2	34.0 amps	31.8	75-0
Sc. Blower to Traction motor blower 1	6.0 amps	5-4	12.5
Sc. Blower to Traction motor blower 1	6.0 amps	4.8	12.0
Compressor 1	25 amps at 0 kg/ cm ² 40 amps at 10 kg/ cm ²	29.5	60.0
Compressor 2	25 amps at 0 kg/cm ² 40 amps at 10 kg/cm ²	25.5	62.0

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 38403

Type of Locomotive: WAP-7/WAG-9HC

Page: 19 of 27

5.3.2 Performance of Auxiliary Converters

Measure the performance of the auxiliary converters through software and record it. BUR1 (Condition: Switch off all the load of BUR 1)- to be filled by commissioning engineer

of the firm.

Signal name	Description of the signal	Prescribed value	Monitored value	Value under Limit (Yes/No)
BUR1 7303 XUUN	Input voltage to BUR1	75% (10%=125V)	10041	Yes
BUR1 7303 XUUZ1	DC link voltage of BUR1	60% (10%=100V)	636 V	Yey
BUR1 7303 XUIZ1	DC link current of BUR1	0% (10%=50A)	1 Amp	Ye

BUR2 (Condition: Switch off all the load of BUR 2, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value by the firm	Monitored value	Value under Limit (Yes/No)
BUR2 7303-XUUN	Input voltage to BUR2	75% (10%=125V)	1002~	Yey
BUR2 7303-XUUZ1	DC link voltage of BUR2	60% (10%=100V)	637V	Yey
BUR2 7303-XUIZ 1	DC link current of BUR2	1% (10%=50A)*	7 Amp	(e)
BUR2 7303-XUILG	Current battery charger of BUR2	3% (10%=100A)*	22 Anj	Yes
BUR2 7303-XUIB1	Current battery of BUR2	1.5%(10%=100A)*	12 Am	Yey
BUR2 7303 -XUUB	Voltage battery of BUR2	110%(10%=10V)	1101	Yol

^{*} Readings are dependent upon charging condition of the battery.

BUR3 (Condition: Switch off all the load of BUR 3, Battery Charger on) to be filled by commissioning engineer of the firm

Signal name	Description of the signal	Prescribed set value by the firm	Monitored value	Value under limit (Yes/No)
BUR3 7303-XUUN	Input voltage to BUR3	75% (10%=125V	10014	Yey
BUR3 7303- XUUZ1	DC link voltage of BUR3	60% (10%=100V)	637 ^V	Yey
BUR3 7303-XUIZ 1	DC link current of BUR3	1% (10%=50A)*	7 Amp	Key .
BUR3 7303-XUILG	Current battery charger of BUR 3	3% (10%=100A)*	21 Ang	Ney .
BUR3 7303-XUIB1	Current battery of BUR 3	1.5%(10%=100A)*	11 Am)	Key
BUR3 7303-XUUB	Voltage battery of BUR 3	110%(10%=10V)	1101	By

^{*} Readings are dependent upon charging condition of the battery.

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39103

Type of Locomotive: WAP-7/WAG-9HC Page: 20 of 27

5.3.3 Performance of BURs when one BUR goes out

When any one BUR goes out then rest of the two BURs should take the load of all the

auxiliaries at ventilation level 3 of the locomotive.

Condition of BURs	Loads on BUR1	Loads in BUR2	Loads in BUR3	, `
All BURs OK	Oil Cooling unit 1&2	TM blower1&2, TFP oil pump 1&2, SR coolant pump 1&2.	Compressor 1&2, Battery charger and TM Scavenger blower 1&2	
BUR 1 out		Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2,TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.	cheeked ok
BUR 2 out	Oil Cooling unit 1&2, TM blower 1&2, TM Scavenger blower 1&2		Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.	
BUR 3 out	Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.		

5.4 Auxiliary circuit 415/110

For checking earth fault detection, make a connection between wire no. 1218 and vehicle body. On switching on VCB, Earth fault relay 89.5 must pick up and after 3 minutes a message will come in the Diagnostic display that Earth Fault 415/110V Circuit

Switch on the 1 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured phase current	Measured starting current
Machine room blower 1	15.0 amps*	4.4	9.5
Machine room blower 2	15.0 amps*	4.6	9.3
Sc. Blower to MR blower 1	1.3 amps	1.5	3.2
Sc. Blower to MR blower 2	1.3 amps	1.4	5.9
Ventilator cab heater 1	1.1 amps	50	52
Ventilator cab heater 2	1.1 amps	50	5.2
Cab heater 1	4.8 amps	1,2	1.6
Cab heater 2	4.8 amps	1.2	1.6

^{*} For indigenous MR blowers.

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 38403

Type of Locomotive: WAP-7/WAG-9HC

Page: 21 of 27

5.5 Hotel load circuit (Not applicable for WAG-9HC)

For WAP-7 locomotive with Hotel load converter refer to Annexure-HLC

5.6 Traction Converter Commissioning

This test is carried out in association with Firm.

Traction converter commissioning is being done one at a time. For testing Converter 1, switch off the traction converter 2 by switch bogie cut out switch 154. For testing Converter 2, switch off the traction converter 2 by switch bogie cut out switch 154. Isolate the harmonic filter also by switch 160. Start up the loco by one converter. Follow the functionality tests.

For Converter 1

For Converter 1 Test Function	Results desired	Result obtained
Measurement of charging and precharging and charging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chocked of
Measurement of discharging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	charted on
Earth fault detection on positive potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Chelled &
Earth fault detection on negative potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chocked or
Earth fault detection on AC part of the traction circuit of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeked of
Pulsing of line converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	CREEKED OK
Pulsing of drive converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheked on

Effective Date: Feb 2022

DOC.NO.F/ECS/VI (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC Page: 22 of 27

For Converter 2	Results desired in sequence	Result obtained
Test Function	Results desired in sequence	
charging and pre- charging and charging of DC Link of Converter	Fraction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	charted or
discharging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeteed a
positive potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeteed &
negative potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/v	charted a
AC part of the traction circuit of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chelled &
Pulsing of line converter of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeked a
Pulsing of drive converter of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	c-Rolled &

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC

Page: 23 of 27

5.7 Test protective shutdown SR

Test Function	Results desired in sequence	Result obtained
Measurement of protective shutdown by Converter 1 electronics.	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 1Check that converter 1 electronics produces a protective shut down. • VCB goes off • Priority 1 fault mesg. on DDU	checked a
	appears Disturbance in Converter 1	
Measurement of protective shutdown by Converter 2 electronics.	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 2. Check that converter 2 electronics produces a protective shut down. • VCB goes off • Priority 1 fault mesg. on diagnostic display appears Disturbance in Converter 2	o checal on

5.8 Test Harmonic Filter

Switch on the filter by switch 160

Test Function	Results desired in sequence	Result obtained	
Measurement of filter currents	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Apply a small value of TE/BE by moving the throttle. • FB contactor 8.41 must open.	e cheeked on	

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC

Page: 24 of 27

	 FB contactor 8.1must open. FB discharging contactor 8.41 must close Check the filter current in diagnostic laptop 	- chekeelok
Test earth fault detection harmonic filter circuit.	Make a connection between wire no. 12 and vehicle body. Start up the loco. Close VCB. • Earth fault relay 89.6 must pick up. • Diagnostic message comes that - Earth fault in harmonic filter circuit	, cheeked or
Test traction motor speed sensors for both bogie in both cabs	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	QL.

5.9 Test important components of the locomotive

Items to be tested	Description of the test	Monitored value/remarks	
Speedometer	VCU converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	cholted on	
Time delay module of MR blower	The time after which the starting capacitor for MR blower should go off the circuit should be set to 10-12 seconds	cholled &	
Ni-Cd battery voltage	At full charge, the battery voltage should be 110V DC.	checked a	
Flasher light	From both cab flasher light should blink at least 65 times in one minute.	CROKAL OR	
Head light	Head light should glow from both cabs by operating ZLPRD. Dimmer operation of headlight should also occur by operating the switch ZLPRD.	chooped of	

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39403

Type of Locomotive: WAP-7/WAG-9HC

Page: 25 of 27

Marker light	Both front and tail marker light should glow from both the cabs	chaeted or chaeted or chaeted or
Cab Light	Cab light should glow in both the cabs by operating the switch ZLC	choetedva
Spot lights	Both Drivers and Asst. Drivers Spot light should glow in both cabs by operating ZLDD	cheeteda
Instrument lights	Instrument light should glow from both cab by operating the switch ZLI	chocked of
Illuminated Push button	All illuminated push buttons should glow during the operation	
Contact pressure of the high rating contactors	The contact pressure of FB contactors (8.1, 8.2) is to be measured Criteria: The minimum contact pressure is 54 to 66 Newton.	For contactor 8.1: For contactor 8.2:
Crew Fan	All crew fans should work properly when VCB of the loco is switched on. The airflow from each cab fan is to be measured. Criteria: The minimum flow of air of cab fan should be 25 m³/minute	Cab 1 LHS: Cab 1 RHS: Cab 2 LHS: Cab 2 RHS:

6.0 Running Trial of the locomotive

SN	Description of the items to Action which should take place be seen during trail run		Remarks
1	Cab activation in driving mode	No fault message should appear on the diagnostic panel of the loco.	feeted or
	Loco charging	Loco to be charged and all auxiliaries should run. No fault message to appear on the diagnostic panel of the loco. Raise MR pressure to 10 Kg/cm ² , BP to 5 Kg/cm ² , FP to 6 Kg/cm ² .	Looked of
3.	Check function of Emergency push stop.	This switch is active only in activated cab. By pushing this switch VCB should open & pantograph should be lowered.	Rocked
4.	Check function of BPCS.	 Beyond 5 kmph, press BPCS, the speed of loco should be constant. BPCS action should be cancelled by moving TE/BE throttle, by dropping BP below 4.75 Kg/cm², by pressing BPCS again. 	Locked
5.	Check train parting operation of the Locomotive.	Operate the emergency cock to drop the BP Pressure LSAF should glow.	hoored

22 PATIALA LOCOMOTIVE WORKS, PATIALA

<u>.A</u>

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39603

Type of Locomotive: WAP-7/WAG-9HC

Page: 26 of 27

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

				
6.	Check vigilance	Set the speed more than 1.5 kmph and ensure that		
	operation of the	brakes are released i.e. BC < 1 Kg/cm².		
	locomotive	For 60 seconds do not press vigilance foot switch or		
		sanding foots switch or TE/BE throttle or BPVG		
		switch then		
		Buzzer should start buzzing.		
		LSVW should glow continuously.		
		Do not acknowledge the alarm through BPVG or	choos	red or
		vigilance foot switch further for 8 seconds then:-	\chi_	
		Emergency brake should be applied		٠
		automatically.	∦ .	
		VCB should be switched off.		
		Resetting of this penalty brake is possible only after		
		32 seconds by bringing TE/BE throttle to 0 and		
		acknowledge BPVR and press & release vigilance		
	·	foot switch.		2.0
7.	Check start/run interlock	• At low pressure of MR (< 5.6 Kg/cm ²).	choekes	el or
		With park brake in applied condition.		
		• With direct loco brake applied (BP< 4.75Kg/cm ²).	CROOK	nd 00
		• With automatic train brake applied (BP<4.75Kg/cm ²).	Churc	254 44
		• With emergency cock (BP < 4.75 Kg/cm ²).		
8.	Check traction interlock	Switch of the brake electronics. The	9 0.000	nol de
		Tractive /Braking effort should ramp down, VCB	Check	
		should open and BP reduces rapidly.		
9.	Check regenerative	Bring the TE/BE throttle to BE side. Loco speed	Creek	ed or
10	braking.	should start reducing.		
10.	Check for BUR	In the event of failure of one BUR, rest of the two	\mathcal{C}	
	redundancy test at	BURs can take the load of all the auxiliaries. For this	(creek	ed &
	ventilation level 1 & 3 of	switch off one BUR.		
	loco operation	Auxiliaries should be catered by rest of two BURs.	\	
11.	Check the power	Switch off the 2 BURs; loco should trip in this case.		¥
	converter	Create disturbance in power converter by switching	(cROOK	ool 9k
	isolation test	off the electronics. VCB should open and converter should get isolated and traction is possible with	Acura	
		another power converter.		
		another power converter.		

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39 403

Type of Locomotive: WAP-7/WAG-9HC

Page: 27 of 27

7.0 Final check list to be verified at the time of Loco dispatch

Condition /Operations of the following items are to be checked:

SN	Item	Cab-1	Cab-2	Remarks
1	Head lights	04	,ou C	
2	Marker Red	Su.	ok	
3	Marker White	00	OK	
4	Cab Lights	٥٧_	OR.	
5	Dr Spot Light	01_	OK /	
6	Asst Dr Spot Light	O/L	De (choised worker or
7	Flasher Light	D1¢	OR 1	
8	Instrument Lights	07L_	30	
9	Corridor Light	Op	G _K	
10	Cab Fans	SL_	OK	
11	Cab Heater/Blowers	Or_	ac	
12	All Cab Signal Lamps Panel 'A'	Dil_	Oa	

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format for 2x500KVA IGBT based Hotel Load Converter for 3-phase Electric Locomotives

Locomotive No.:	39403		Page: 1 of 6
Type of Locomotive: _	WAPT		
Make of Hotel Load Co	nverter: MEDHA		
Details of Equipment:	_	-8.	

Equipment	SI. No	Equipment	SI. No
HLC1	5303	IV Coupler CAB1 ALP	
HLC2	3304	IV Coupler CAB1 LP	—
Converter-1	3303	IV Coupler CAB2 ALP	+
Converter-2	3304	IV Coupler CAB2 LP	
UIC Coupler for Hotel Load Converter (353.3/2 CAB2)		UIC Coupler for Hotel Load Converter (353.3/3 CAB1)	

1. Polarity test of Hotel Load Winding:

Apply 198 /140 to the primary winding of the transformer (at 1U; wire no. 2 at surge arrestor and at 1V; wire no. 100 at earthing choke). Measure the output voltage and compare the phase of the following of the transformer.

	Description of winding	Prescribed Output Voltage &Polarity with input supply	Measured Output	Measured Polarity
2UH1 & 2VH1	For Hotel load between cable 91- 94	5.9 ,4.2 and same polarity	Ov-	8rl
2UH2 & 2VH2	For Hotel load between cable 91A- 94A	5.9 ,4.2 and same polarity	Ou	02

2. Visual Inspection:

Fitment of Units and Earthing to Sub-assemblies

Verify the following Equipments Fitment and grounding cables are connected to Locomotive body.

SI. No.	Equipment Name	Unit Fitment (Yes/No)	Provision of Earthing (Yes/No)
1	HLC1	yes	" yes
2	HLC2	yes "	Jes
3	Output Contactor unit1 HLC1	yes	yes
4	Output Contactor unit2 HLC2	yes	yes
5	IV Coupler CAB1 ALP	yes	yes
6	IV Coupler CAB1 LP	yes	yes
7	IV Coupler CAB2 ALP	yes	yes
8	IV Coupler CAB2 LP	yes	Jes
9	UIC Coupler for Hotel Load Converter (353.3/3 CAB1)	Yes	Yes
10	UIC Coupler for Hotel Load Converter (353.3/2 CAB2)	Yes	yes
11	CT (LEM sensor) under HLC1	Yes	yes
12	CT(LEM sensor) under HLC2	yes	Yes

3. Cable Routing and Laying

3.1 Control cable routing and layout

Verify the connections, tightness and cable routing of the following Control cable.

SI. No.	Cables Details	Performed (Yes/No)
1	From Wago SB1 to HLC1 are connected as per wiring format	yes
2	From SB1 to UIC Coupler Hotel Load Converter (353.3/3 CAB2) through Bayonet connector XK22HL:01(22pin)is connected as per wiring format	yes
3	From SB1 wago(XF22S:01/53) to IV coupler CAB1 ALP are connected as per wiring format	yes
4	From SB1 wago(XF22S:01/54) to IV coupler CAB1 LP are connected as per wiring format	yes
5	From Wago SB2 to HLC2 are connected as per wiring format	yes
6	From SB2 to UIC Coupler Hotel Load Converter (353.3/2 CAB2) through Bayonet connector XK77HL:02 (22 pin) is connected as per wiring format	yes
7	From SB2 wago (XF77S:01/53) to IV coupler CAB2 ALP are connected as per wiring format	yes
8	From SB2 wago (XF77S:01/54) to IV coupler CAB2 LP are connected as per wiring format	Yes
9	From HLC1 to Contactor unit 1 through 4 Core Cable are connected as per wiring format	yes Yes
10	From HLC2 to Contactor unit 2 through 4 Core Cable are connected as per wiring format	Jes
11	From SB to VCU are connected as per wiring format	Yes
12	From CT (HLC1 LEM sensor) to SR1 are connected as per wiring format	yes Yes
13	From CT (HLC2 LEM sensor) to SR2 are connected as per wiring format	Jes

3.2 Power cable routing and layout

Verify the connections, tightness and cable routing of the following Power cable.

SI. No.	Cables Details	Performed Yes/No)
1	From Transformer to HLC1(2UH1 & 2VH1) are connected as per wiring format	دع
2	From Transformer to HLC2(2UH2 &2VH2) are connected as per wiring format	yes
3	From HLC1 to Output Contactor unit1 are connected as per wiring format	yes
4	From HLC 2 to Output Contactor unit 2 are connected as per wiring format	yes
5	From Output Contactor unit 1 to IV Coupler CAB1 ALP and IV Coupler CAB2ALP through Junction box are connected as per wiring format	gus
6	From Output Contactor unit 2 to IV Coupler CAB2 LP and IV Coupler CAB1 LP through Junction box are connected as per wiring format	yes

4. Continuity test:

Check the continuity test for the External connections made to Equipments.

Note: This continuity test should be done before power ON the Locomotive Battery.

4.1 Control cable continuity

Si. No.	Cables Details	Performed (Yes/No)
1	From Wago SB1 to HLC1 are connected as per wiring format	yes
2	From SB1 to UIC Coupler Hotel Load Converter (353.3/3 CAB2) through Bayonet connector XK22HL:01(22pin)is connected as per wiring format	yes
3	From SB1 wago(XF22S:01/53) to IV coupler CAB1 ALP are connected as per wiring format	yes
4	From SB1 wago(XF22S:01/54) to IV coupler CAB1 LP are connected as per wiring format	yes
5	From Wago SB2 to HLC2 are connected as per wiring format	yes
6	From SB2 to UIC Coupler Hotel Load Converter (353.3/2 CAB2) through Bayonet connector XK77HL:02(22pin) is connected as per wiring format	yes
7	From SB2 wago (XF77S:01/53) to IV coupler CAB2 ALP are connected as per wiring format	Yes
8	From SB2 wago(XF77S:01/54) to IV coupler CAB2 LP are connected as per wiring format	yes
9	From HLC1 to Contactor unit 1 through 4 Core Cable are connected as per wiring format	yes
10	From HLC2 to Contactor unit 2 through 4 Core Cable are connected as per wiring format	yes
11	From SB to VCU are connected as per wiring format	yes
12	From HLC1 LEM sensor to SR1 are connected as per wiring format	yes
13	From HLC2 LEM sensor to SR2 are connected as per wiring format	yes

4.2 Power cable continuity

These cables continuity should be checked before mounting of converter in the locomotive.

SI. No.	Cables Details	Performed (Yes/No)
1	From Transformer to HLC1(2UH1 & 2VH1) are connected as per wiring format	yes
2	From Transformer to HLC2(2UH2 &2VH2) are connected as per wiring format	yes
3	From HLC1 to Output Contactor unit1 are connected as per wiring format	Jus
4	From HLC 2 to Output Contactor unit 2 are connected as per wiring format	Hay
5	From Output Contactor unit 1 to IV Coupler CAB1 ALP and IV Coupler CAB2ALP through Junction box are connected as per wiring format	yes
6	From Output Contactor unit 2 to IV Coupler CAB1 LP and IV Coupler CAB2 LP through Junction box are connected as per wiring format	yes

5. Battery power ON

Tests Supply Voltages

Remove all Control cable connectors (Analog and Digital Input/output connectors) from HLC1, HLC2. While Switch ON Battery supply observe is there any MCBs tripping. Wait for one or two minutes after switching ON Circuit breaker(MCB1) and observe for any overheating symptoms like smell, smoke, temperature etc. from the wire bunches. If any such symptoms are noticed, there might be a short circuit in the wire bunch. Check up once again continuity wherever suspected. After that check the Voltage levels at all equipments connectors as mentioned below.

Test Details	Acceptance	Observations
Voltage Level at HLC1: I. Between wago terminal XF22S:03/54 and XF22S:03/58 II. Between wago terminal XF22S:03/53 and XF22S:03/58	~110VDC	OK
Voltage Level at HLC2: I. Between wago terminal XF77S:03/52 and XF77S:03/56 II. Between wago terminal XF77S:03/51 and XF77S:03/56	~110VDC	OK

Note: After Above tests switch off the Power and restore all removed connectors and once again switch ON the 110 V Supply and ensure that no MCB tripping due to abnormality.

Page: 6 of 6

6. Converter operation (ON/OFF) test

Power supply is directly available to the Hotel Load Converter via Hotel Load Converter winding (2UH1-2VH1) and (2UH2-2VH2). As soon as BLDJ is closed power will be available to the Hotel Load Converter. Connect the test jig of Hotel Load Converter to the UIC and IV Coupler. Charge the locomotive and switch on the BLHO, LSHO indication should glow. Hotel Load Converter screen will show message "waiting for ON command". One by one Hotel Load Converter can be switched on by test jig. Finally both the Hotel Load Converter should be turned out simultaneously. Observe the flow of air from the air duct, this will ensure that Hotel Load Converter is ON. Both the Hotel Load Converters are ON, then voltage and frequency should be measured as per the table below:-

Converters should run without any irregularities.

Hotel Load Converter 1					
Output Voltage			Output Frequency		
U-V	V-W	U-W	(Hz)		
OK	Ox-	O/L	2		

Hotel Load Converter 2					
	Output Voltage		Output Frequency		
U-V	V-W	U-W	(Hz)		
BL	01	v/L	0%		

7. Earth Fault Test

- 7.1 Input Earth Fault:-Ground the input terminal of the Hotel Load Converter using a proper resistance and then turn on the Hotel Load Converter. The converter should trip with the message "Input earth fault".
- **7.2 Output Earth Fault:-**Ground the output terminal of the Hotel Load Converter using a proper resistance and then turn on the Hotel Load Converter. The converter should trip with the message "Output earth fault".

Note: These to be done for the both the converters (HLC1 and HLC2) separately.

Page: 33/A

33 A

Status of RDSO modifications

LOCO NO: 39403

Sn	Modification No.	Description	Remarks
1.	RDSO/2008/EL/MS/0357 Rev.'0' Dt 20.02.08	Light of three phase electric locomotives.	Ok/Not Ok
2.	RDSO/2009/EL/MS/0377 Rev. '0' Dt 22.04.09	Modification to voltage sensing circuit in electric locomotives.	,Øk/Not Ok
3.	RDSO/2010/EL/MS/0390 Rev.'0' Dt 31.12.10	three phase locomotives to improve reliability.	Ok#Not Ok
4.	RDSO/2011/EL/MS/0399 Rev.'0' Dt 08.08.11	Removal of interlocks of control circuit contactors no. 126 from MCPA circuit.	Ok/Not Ok
5.	RDSO/2011/EL/MS/0400 Rev.'0' Dt 10.08.11	Modification sheet for shifting the termination of \$GKW, 1.8 KV, 70 sq mm cables and 2x2.5 sq mm cables housed in lower portion of HB2 panel and provision of Synthetic resin bonded glass fiber sheet for three phase locomotives.	Ok/Not Ok
6.	RDSO/2011/EL/MS/0401 Rev.'0' Dt 10.08.11	Modification sheet for relaying of cables in HB-2 panel of three phase locomotives to avoid fire hazards.	Qk/Not Ok
7.	RDSO/2011/EL/MS/0403 Rev.'0' Dt 30.11.11	Auto switching of machine room/corridor lights to avoid draining of batteries in three phase electric locomotives.	Ok/Not Ok
8.	RDSO/2012/EL/MS/0408 Rev.'0'	Modification of terminal connection of heater cum blower assembly.	Ok/Not Ok
9.	RDSO/2012/EL/MS/0411 Rev.'1' dated 02.11.12	Modification sheet to avoid simultaneous switching ON of White and Red marker light in three phase electric locomotives.	Qk/Not Ok
10	RDSO/2012/EL/MS/0413 Rev.'1' Dt 25.04.16	contactors of three phase locomotives to improve reliability.	Ok/Not Ok
11	RDSO/2012/EL/MS/0419 Rev.'0' Dt 20.12.12	Modification sheet to provide rubber sealing gasket in Master Controller of three phase locomotives.	Øk/Not Ok
12	RDSO/2013/EL/MS/0420 Rev.'0' Dt 23.01.13	Modification sheet to provide mechanical locking arrangement in Primary Over Current Relay of three phase locomotives.	Ók/Not Ok
13	RDSO/2013/EL/MS/0425 Rev.'0' Dt 22.05.13	Modification sheet for improving illumination of head light in dimmer mode in three phase electric locomotives.	Ok/Not Ok
14	RDSO/2013/EL/MS/0426 Rev.'0' Dt 18.07.13	Modification sheet of Bogie isolation rotary switch in three phase electric locomotives.	₽k/Not Ok
15	RDSO/2013/EL/MS/0427 Rev.'0' Dt 23.10.13	Modification sheet for MCP control in three phase electric locomotives.	ρk/Not Ok
16	RDSO/2013/EL/MS/0428 Rev.'0' Dt 10.12.13	Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.	Ok/Not Ok
	RDSO/2014/EL/MS/0432 Rev.'0' Dt 12.03.14	Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.	Ok/Not Ok
18	RDSO/2017/EL/MS/0464 Rev.'0' Dt 25.09.17	Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.	Ok/Not Ok
19	RDSO/2017/EL/MS/0467 Rev.'0' Dt 07.12.17	Modification in blocking diodes to improve reliability in three phase electric locomotives.	Ok/Not Ok
20	RDSO/2018/EL/MS/0475 Rev.'0'	Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.	Øk/Not Ok
21	RDSO/2019/EL/MS/0477 Rev.'0' Dt 18.09.19	Implementation of push pull scheme.	Ok/Not Ok

Signature of JE/SSE/ECS

Loco No.: 39403

PLW/PATIALA

PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

SN	Parameters	Reference	Value	Result
	Brake Panel: Faiveley			
1.0	Auxiliary Air supply system (Pantograph & VCB)			
1.1	Ensure, Air is completely vented from pantograph			0
	Reservoir (Ensure Panto gauge reading is Zero)			
1.2	Turn On BL Key. Now MCPA starts.		60 sec. (Max.)	58
	Record pressure Build up time (8.0 kg/cm2)			
1.3	Auxiliary compressor safety Valve 23F setting	Faiveley Doc. No.	8.5±0.25kg/cm2	8.54
		DMTS-014-1, 8 CLW's	-	
		check sheet no.		
		F60.812 Version 2		
1.4	Check VCB Pressure Switch Setting	CLW's check sheet	Opens 4.5±0.15	4.55 Kg/cm2
		no. F60.812 Version 2	kg/cm2, closes	
			5.5±0.15 kg/cm2	5.55 Kg/cm2
1.5	Set pantograph Selector Switch is in Auto, Open pan-1&2 Is	olating Cocks & KABA co		
1.6	Set Cab-1 Pan UP in Panel A.		Observed Pan-2	ОК
			Rises.	
1.7	Close Pan-2 isolating Cock		Panto-2 Falls Down	ОК
	Open Pan -2 isolating Cock		Panto-2 Rises	
1.8	Record Pantograph Rise time		06 to 10 seconds	8 Sec
1.9	Record Pantograph Lowering Time		06 to 10 seconds	9 Sec
1.10	Panto line air leakage		0.7 kg/cm2 in 5	0.2 kg/cm2
			Min.	in 5 Min.
1.11	High Reach Panto emergency test and reset.		-NA-	-NA-
2.0	Main Air Supply System			
2.1	Ensure, Air is completely vented from locomotive. Drain	Theoretical		
	out all the reservoirs by opening the drain cocks and then	calculation and		
	closed drain cocks. MR air pressure build up time by each	test performed by		
	compressor from 0 to 10 kg/cm2.	Railways.		
	i) with 1750 LPM compressor		i) 7 mins Max.	6 min. & 45
	ii) with 1450 LPM compressor		ii) 8.5 mins Max.	sec.
2.2	Drain air below MR 8 kg/cm2 to start both the		Check Starting of	ok
	compressors		both compressors	
2.3	Drain air from main reservoir up to 7 kg/cm2. Start		30 Sec. (Max)	CP1-28 Sec
	compressors, Check pressure build time of individual			
_	compressor from 8 kg/cm2 to 9 kg/cm2			CP2-26 Sec
2.4	Check Low MR Pressure Switch Setting (37)	D&M test spec.	Closes at 6.40±0.15	6.47 Kg/cm2
		MM3882 &	kg/cm2 Opens at	
		MM3946	5.60±0.15kg/cm2	5. 7 Kg/cm2
2.5	Check compressor Pressure Switch RGCP setting (35)	D&M test spec.	Opens at 10±0.20	10 Kg/cm2
		MM3882 &	kg/cm2, Closes at	
		MM3946	8±0.20 kg/cm2	8 Kg/cm2
2.6	Run both the compressors Record Pressure build up time	Trial results	3.5 Minutes Max.	3.35 minute

PLW/PATIALA

Loco No.: 39403

2.8 Check Auto Drain Valve functioning (124 & 87)	2.7	Check unloader va	alve operation time				Approx. 12 Sec.	10 sec
Check CP-1 delivery safety valve setting (10/1). Run CP D&M test spec. MM3882 & MM3946 kg/cm2 Kg/cm2 MM3862 & MM3946 MM3862 & MM3846 MM3862 & MM3862			•	.24 & 87)			Operates when Compressor	
Direct by BLCP	2.9	Check CP-I deliver	y safety valve settin	g (10/1). Run CP	D&M t	est spec.		11.55
Minasez & Mina					MM3882 & MM3946		kg/cm2	Kg/cm2
2.11 Switch 'OFF' the compressors and ensure that the safety valve to reset at pressure 1.2 kg/cm2 less than opening pressure.	2.10	Check CP-2 delive	ry safety valve settir	ng (10/2). Run CP	D&M t	est spec.	11.50±0.35	11.50
valve to reset at pressure 1.2 kg/cm2 less than opening pressure. 2.12 BP Pressure: Switch 'OFF' compressor, Drain MR Pressure by drain cock of 1" Main Reservoir, Start Compressor, check estiting pressure of Duplex Check Valve 92F. 2.13 PP pressure: FIT Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge. 3.0 Air Dryer Operation 3.1 Open Drain Cock 90 of 2" MR to start Compressor, leave open for Test Check Air Dryer Towers to change. 3.2 Check Purge Air Stops from Air Dryer at Compressor stops 3.3 Check condition of humidity indicator 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cock-70) Brake Test (Automatic Brake operation) 5.0 Brake Test (Automatic Brake operation) Auto controller position BP Pressure kg/cm2 BP Pressure kg/cm2 BP Pressure kg/cm2 BP Pressure kg/cm2 Auto controller position BC (WAG-9 & WAG-7) Kg/cm2 CLW's check sheet no. F60.812 Version 2 CLW's check sheet no. F60.812 Version 2 CLW's check sheet no. F60.812 Version 2 BC (WAG-9 & WAG-7) Kg/cm2 BC (WAP-5) Kg/cm2 BC (WAP-5) Kg/cm2 Find the suit Value Result Value Resul		direct by BLCP			MM3882	& MM3946	kg/cm2	Kg/cm2
by drain cock of 1" Main Reservoir, Start Compressor, check setting pressure of Duplex Check Valve 92F. 2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge. 3.0 Air Dryer Operation 3.1 Open Drain Cock 90 of 2" MR to start Compressor, leave open for Test Check Air Dryer Towers to change. 3.2 Check Purge Air Stops from Air Dryer at Compressor stops 3.3 Check Purge Air Stops from Air Dryer at Compressor stops 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cock-70) 5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step Check proportionality of Auto Brake system Check proportionality of Auto Brake system BP Pressure kg/cm2 BP Pressure kg/cm2 BP Pressure kg/cm2 Value Result Value Result Value Result Value Result Value Result Value Result Full service 3.35±0.2 3.4 Kg/cm2 5.5±0.50 CLW's check sheet no. F60.812 Version 2 Should be less than 1 kg/cm2 in 15 minutes 0.4 Kg/cm2 in 15 minutes 0.4 Kg/cm2 in 15 minutes 0.4 Kg/cm2 in 15 minutes CLW's check sheet no. F60.812 Version 2 CLW's check sheet no. F60.812 Version 2 Should be less than 1 kg/cm2 in 15 minutes 0.4 Kg/cm2 in 15 minutes	2.11	valve to reset at p	•	-		•		
Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge. 3.0 Air Dryer Operation 3.1 Open Drain Cock 90 of 2 nd MR to start Compressor, leave open for Test Check Air Dryer Towers to change. 3.2 Check Purge Air Stops from Air Dryer at Compressor stops 3.3 Check condition of humidity indicator 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cock-70) 5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step Check proportionality of Auto Brake system CLW's check sheet no. F60.812 Version 2 Auto controller position BC (WAG-9 & WAG-7) Kg/cm2 Result Value Result Value Result Run 5±0.1 5.05 Kg/cm2 Full service 3.35±0.2 3.4 Kg/cm2 5.5±0.1 2.55±0.1 3.5±5±0.3 3.4 Kg/cm2 5.5±0.1 3.55±0.2 3.4 Kg/cm2 5.5±0.1 5.5±0.30 5	2.12	by drain cock of 1	" Main Reservoir, St	art Compressor,			5.0±0.10kg/cm2	5.0 Kg/cm2
3.0 Air Dryer Operation 3.1 Open Drain Cock 90 of 2 nd MR to start Compressor, leave open for Test Check Air Dryer Towers to change. 3.2 Check Purge Air Stops from Air Dryer at Compressor stops 3.3 Check condition of humidity indicator 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cock-70) 5.0 Brake Test (Automatic Brake Operation) 5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step Check proportionality of Auto Brake system CLW's check sheet no. F60.812 Version 2 Auto controller position BC (WAG-9 & WAG-7) Kg/cm2 BP Pressure kg/cm2 Value Result Value Result Value Result Value Result Full service 3.35±0.2 3.4 Kg/cm2 Scott On Air Dryer at Compressor, leave every minute of every minute every minute every minute. Tower to change every minute D&M test spec. MM3882 & MM3946 D&M test spec. MM3882 & MM3946 D.5 Mg/cm2 in 5 minutes O.15 kg/cm2 in 5 minutes O.02 Kg/cm2 in 5 minutes O.02 Kg/cm2 in 5 Minutes D.6 (WAG-9 & WAG-7) Kg/cm2 Result Value Result Value Result Full service 3.35±0.2 3.4 Kg/cm2 3.50±0.1 2.5Kg/cm2 5.15±0.30 -	2.13	Fit Test Gauge in 1	•	P. Open isolate cock			6.0±0.20kg/cm2	
3.1 Open Drain Cock 90 of 2 nd MR to start Compressor, leave open for Test Check Air Dryer Towers to change. 3.2 Check Purge Air Stops from Air Dryer at Compressor stops 3.3 Check condition of humidity indicator 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cock-70) 5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step Check proportionality of Auto Brake system Check proportionality of Auto Brake system BP Pressure kg/cm2 BP Pressure kg/cm2 Value Result Value Result Value Result Value Result Run 5±0.1 5.05 Kg/cm2 0.00 0.00 Kg/cm2 0.00 - Initial 4.60±0.1 4.6 Kg/cm2 2.50±0.1 2.5Kg/cm2 5.15±0.30 - Oke Pressure to change every minute D&M test spec. MM3882 & MM3946 Should be less than 1 kg/cm2 in 15 minutes D&M test spec. MM3882 & MM3946 Check BP Air leakage (isolate BP charging cock-70) D&M test spec. MM3882 & MM3946 Check BP Air leakage (isolate BP charging cock-70) BM test spec. MM3882 & MM3946 Check BP Air leakage (isolate BP charging cock-70) Sminutes O.4Kg/cm2 CLW's check sheet no. F60.812 Version 2 BC (WAP-5) Kg/cm2 Value Result Sign minutes CLW's check sheet no. F60.812 Version 2 Sign minutes CLW's check sheet no. F60.812 Version 2 Sign minutes O.00 0.00 Kg/cm2 O.00 0.00 Kg/cm2 O.75±0.15 - Full service 3.35±0.2 3.4 Kg/cm2 2.50±0.1 2.5Kg/cm2 5.15±0.30 -	3.0							
open for Test Check Air Dryer Towers to change. 3.2 Check Purge Air Stops from Air Dryer at Compressor stops 3.3 Check condition of humidity indicator 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs. Blue 4.2 Check BP Air leakage (isolate BP charging cock-70) 5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step Check proportionality of Auto Brake system Check proportionality of Auto Brake system BP Pressure kg/cm2 BP Pressure kg/cm2 Value Result Run 5±0.1 5.05 Kg/cm2 Run 5±0.1 5.05 Kg/cm2 Value Result Value Result Run 5±0.1 5.05 Kg/cm2 0.00 0.00 Kg/cm2 0.00 0.00 Kg/cm2 0.75±0.15 - Full service 3.35±0.2 3.4 Kg/cm2 2.50±0.1 2.5Kg/cm2 5.15±0.30 - 5.15±0.30 - 5.15±0.30 - 5.15±0.20				Compressor leave			Tower to change	ok
3.2 Check Purge Air Stops from Air Dryer at Compressor stops	J.1				_			
4.0 Main Reservoir Leakage Test	3.2				every minute			
A.1	3.3	Check condition of humidity indicator					Blue	Blue
leakage from both cabs.	4.0	Main Reservoir Leakage Test						
D&M test spec. MM3882 & MM3946 O.15 kg/cm2 in 5 minutes MM3882 & MM3946 MM3882 & MM3946 Section 2 Kg/cm2 in 5 minutes MM3882 & MM3946 MM3882 & MM3946 Section 2 Kg/cm2 in 5 minutes MM3882 & MM3946 MM3882 & MM3946 Section 2 Kg/cm2 in 5 minutes MM3882 & MM3946 MM3882 & MM3946 Section 2 Kg/cm2 in 5 minutes MM3882 & MM3946 MM3946 MM3882 & MM3946 MM3882 & MM3946 MM3946 MM3882 & MM3946 MM3946 MM3882 & MM3946 MM3946 MM3882 & MM3946 MM3946 MM3942 MM3946 MM3882 & MM3946 MM3946 MM3946 MM3942 MM3946 MM3942 MM3942 MM3946 MM3942 M	4.1	· · ·				•	than 1 kg/cm2 in	
S.0 Brake Test (Automatic Brake operation)	4.2	Check BP Air leaka	age (isolate BP charg	ging cock-70)		•	0.15 kg/cm2 in 5	0.02 Kg/cm2 in 5
Check proportionality of Auto Brake system	5.0	Brake Test (Auto	omatic Brake opei	ration)				
Auto controller position BC (WAG-9 & WAG-7) BC (WAP-5) Kg/cm2 Kg/cm2			•	•				
Run 5±0.1 5.05 Kg/cm2 0.00 0.00 Kg/cm2 0.00 -		Check proportion	Check proportionality of Auto Brake system					
Run 5±0.1 5.05 Kg/cm2 0.00 0.00 Kg/cm2 0.00 - Initial 4.60±0.1 4.6 Kg/cm2 0.40±0.1 0.35Kg/cm2 0.75±0.15 - Full service 3.35±0.2 3.4 Kg/cm2 2.50±0.1 2.5Kg/cm2 5.15±0.30 -		Auto controller po	osition			9 & WAG-7)	, ,	
Initial 4.60±0.1 4.6 Kg/cm2 0.40±0.1 _{0.35Kg/cm2} 0.75±0.15 - Full service 3.35±0.2 3.4 Kg/cm2 2.50±0.1 _{2.5Kg/cm2} 5.15±0.30 -		BP Pressure kg/cm2		Value	Result	Value	Result	
Initial 4.60±0.1 4.6 Kg/cm2 0.40±0.1 _{0.35Kg/cm2} 0.75±0.15 - Full service 3.35±0.2 3.4 Kg/cm2 2.50±0.1 _{2.5Kg/cm2} 5.15±0.30 -		Run	5±0.1	5.05 Kg/cm2	0.00	0.00 Kg/ cm2	0.00	-
5 2.5kg/ cm2		Initial	4.60±0.1				0.75±0.15	-
Emergency Less than 0.3 0.25 Kg/cm2 2.50±0.1 3.5V-1.3-3 5.15±0.30 -		Full service	3.35±0.2	3.4 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	-
2.5kg/ cm2		Emergency	Less than 0.3	0.25 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	-

PLW/PATIALA

Loco No.: 39403

5.2	Record time to BP pressure drop to 3.5 kg/cm2 Ensure	D&M test spec.	8±2 sec.	7 Sec
	Automatic Brake Controller handle is Full Service from Run	MM3882 & MM3946		
5.3	Operate Asst. Driver Emergency Cock,	D&M test spec.	BP pressure falls	OK
		MM3882 & MM3946	to Below 2.5 kg/cm2	ОК
5.4	Check brake Pipe Pressure Switch 69F operates	CLW's check sheet no.	Closes at BP	4.20
5.4	Check brake ripe rressure switch 69r operates	F60.812 Version 2	4.05- 4.35	
		FOU.612 VEISION 2		Kg/cm2
			kg/cm2	
			Opens at BP	2.0
			2.85- 3.15	3.0
	Maria Anta Barlas Cantarillan Landia Grana Barrain ata	DONAL	kg/cm2	Kg/cm2
5.5	Move Auto Brake Controller handle from Running to	D&M test spec.		
	Emergency BC filling time from 0.4 kg/cm2 i.e. 95% of	MM3882 & MM3946		
	Max. BC developed		414	
	WAP5 – BC 5.15 ± 0.3 kg/cm2 apply time		4±1 sec.	
	WAP7 - BC 2.50 ± 0.1 kg/cm2		7.5±1.5 sec.	8 sec
F 6	WAG9 - BC 2.50 ± 0.1 kg/cm2	D014.	21±3 sec.	
5.6	Move Auto Brake Controller handle to full service and	D&M test spec.		
	BP pressure 3.5 kg/cm2. Move Brake controller to	MM3882 & MM3946		
	Running position BC Release time to fall BC Pressure up			
	to 0.4 kg/cm2 i.e. 95% of Max. BC developed			
	BC release Time		4==.4=	
	WAP7		17.5±2.5 sec.	18 sec.
	WAG9		52±7.5 sec.	
5.7	Move Auto Brake Controller handle to Release, Check	CLW's check sheet no.	60 to 80 Sec.	78 Sec
	BP Pressure Steady at 5.5±0.2 kg/cm2 time.	F60.812 Version 2		
5.8	Auto Brake capacity test : The capacity of the A9 valve	RDSO Motive power	BP pressure	
	in released condition must conform to certain limit in	Directorate report no.	should not fall	
	order to ensure compensation for air leakage in the	MP Guide No. 11 July,	below 4.0	
	train without interfering with the automatic	1999 Rev.1	kg/cm2 with in	4.6
	functioning of brake.		60 Sec.	Kg/cm2
	* Allow The MR pressure to build up to maximum			
	stipulated limit.			
	* Close brake pipe angle cock and charge brake pipe to			
	5 kg/cm2 by A-9 (Automatic brake controlling) at run			
	position.			
	* Couple 7.5 dia leak hole to the brake hose pipe of			
	locomotive. Open the angle cock for brake pipe.			
	The test shall be carried out with all the compressors in			
	working condition.		B0 : (5)	
5.9	Keep Auto Brake Controller (A-9) in Full Service. Press		BC comes to '0'	0
	Driver End paddle Switch (PVEF)			
6.0	Direct Brake (SA-9)			
6.1	Apply Direct Brake in Full Check BC pressure			
	WAG9/WAP7	CLW's check sheet no.	3.5±0.20 kg/cm2	3.6
	WAP5	F60.812 Version 2	5.15±0.3 kg/cm2	Kg/cm2
6.2	Apply Direct Brake, Record Brake Cylinder charging	D&M test spec.	8 sec. (Max.)	7 Sec
	time	MM3882 & MM3946		

PLW/PATIALA

Loco No.: 39403

6.3	Check Direct Brake Pressure switch 59 (F)	D&M test spec. MM3882 & MM3946	0.20±0.1 kg/cm2	0.20 kg/cm2
6.4	Release direct brake & BC Release time to fall BC pressure up to 0.4 kg/cm2		10 -15 Sec.	14 Sec
7.0	Modified System Software (only for CCB)		-NA-	-NA-
7.1	Bail-off de-activated during emergency by any means	_		
7.2	DPWCS and Non-DPWCS mode enabled	-	Multi Loco	
7.3	TCAS and Non-TCAS mode enabled	-	Not Yet Launched	Presently
7.4	Penalty brake application deactivated for Fault code 113 (FC 113) and CCB health signal will not drop to avoid loco detention/failure. The Brake Electronics Failure "message will not generate on DDS.	RDSO letter no.	Pressure Setting Needed is12 kg/sqcm causing mismatching with standard Pr Setting	not happening in PLW
7.5	CCB health signal logic revised (Now will remain high) for penalty condition occurring with FC 108 due to wrong operation/not affecting operation/ Not a CCB Fault (i.e Both controllers selected as LEAD etc) The Brake electronic failure message will not generate on DDS	EL/3.2.19/3-phase (CCB), dtd 30.01.2023		
7.6	CCB health signal logic for FC 102 (In case of BC request from VCU is more than 90 %-above 9V DC) is changed i.e CCB health signal will not drop for FC 102 which will avoid loco detention/failure. The brake electronic failure message will not generate on DDS.		Could not performed by M/s Knorr	Presently Not happening in PLW
7.7	Booting time for CCB with TCAS/TPM/PTWS/DPWCS mode 15-20 sec. However, in case of absence of either one or both system booting time subsequently increased to 40-50 sec.			
8.0	Sanding Equipment			
8.1	Check Isolating Cock-134F is in open position. Press sander paddle Switch. (To confirm EP valves Operates)		Sand on Rail	Ok
9.0	Test Vigilance equipment : As per D&M test specification			Ok

SAMSHER Digitally signed by SAMSHER SINGH BIST Date: 2025.01.27 15:33:00 +05'30'

Signature of SSE/Shop

39403

			Roof	compnent Cab-1 &	Cab-2	
S.NO.	DESCRIPTION	PL NO.	QPL/Nos.	SUPPLIER	Sr.No.	Warranty
1	Pantograph	25880068	2	Contransys	15149-08/24, 15150-08/24	
2	Servo Motor	25880068	2	Contransys	15151-08/24,15152-08/24	
3	Air Intake Filter Assembly	29480103	2	AFI	AFI/OC/527A-05/24, AFI/OC/519B- 05/24	
4	Insulator Panto Mounting	29810127	8	IEC	04-24, 04-24	
			Middle root	Component		
5	High Voltage Bushing	29731021	1	ELECTRANEX	EIPL-5507-06-24	
6	Voltage Transformer	29695028	1	SADTEM	2024-N-672454	
7	7 Vaccum Circuit Breaker 25 8 Insulator Roof Line 298		1	SCHNEIDER	226609873-33N2/MAY/24	
8			9	BHEL	10-2023, 10-2023	
9	Harmonic Filter	29650033	1	TELEMA	TEPL/RHF/009/2024/404	As per PO/IRS Conditions
10	Earthing Switch	29700073	1	PATRA&CHANDA	PCE/SL.No.76 M/Y . 4/2024	
11	Surge Aresster	29750052	2	CG POWER	55114-2023, 55116-2023	
			Air Brake C	omponents		
12	Air Compressor (A,B)	29511008	2	ELGI	EXFS 923434 A, EXFS 923438 B	
13	Air Dryer	29162051	1	TRIDENT	LD2-08-0492-24	
14	Auxillary Compressor	25513000	1	ELGI	BXES 109301	
15	Air Brake Panel	29180016	1	Faiveley	SEP 24-24-WAG9-3604	
16	Controller (A,B)	29180016	2	Faiveley	D 24-039 A , D 24-044 B	
17	Break Up Valve	29162026	2	Faiveley		
18	Wiper Motor		4	Auto Industry		

SAMSHER Digitally signed by SAMSHER SINGH BIST Date: 2025.01.24 17:09:54 +05'30' SSE/ABS

PLW/PTA

ELECTRIC LOCO HISTORY SHEET (ECS)

ELECTRIC LOCO NO: 39403 LIST OF ITEMS FITTED BY ECS

RLY: CR

SHED: PADX PROPULSION SYSTEM: MEDHA HOTEL LOAD CONVERTER: MEDHA

SN **DESCRIPTION OF ITEM** ITEM PL NO. ITEM SR. NO CAB-1/CAB-2 MAKE/SUPPLIER LED Based Flasher Light Cab I & II 29612937 26535/26591 MATSUSHI P.TECH Led Marker Light Cab I & II 29612925 4265/4272/4270/4211 KEPCO 3 | Cab Heater Cab | & II 29170011 3185/3216 KKI Crew Fan Cab I & II 29470080 4197/4207/4456/4442 SARIA Master Controller Cab I 0035 STESALIT Master Controller Cab II 29860015 0033 Complete Panel A Cab I & II 29170564 0520B HIND 0512A 8 | Complete Panel C Cab I & II 29170539 3261 3253 KEPCO/MEDHA 9 Complete Panel D Cab I & II 29170564 0518A 0517B HIND 10 Complete Cubicle- F Panel Cab | & || 29178162 SLFC00012405199 SLFC00012404170 STESALIT 11 Speed Ind.& Rec. System 29200040 5708/5035 MEDHA 12 Battery (Ni- Cd) 29680025 SAFT URJA 9062-9074,9114-9126 13 | Set of Harnessed Cable Complete 29600418 PPS INTERNATIONAL Transformer Oil Pressure Sensor (Cab-1) (pressure sensor oil circuit transformer) BG/PS/1339 Jun 2024 BG/PS/1345 Jun 2024 29500047 **BG INDUSTRIES** 15 | Transformer Oil Pressure Sensor (Cab-2) BG/PS/1381 Jun 2024 BG/PS/1301 Jun 2024 Transformer Oil Temperature Sensor (Cab-1)(temperature sensor oil circuit transformer) BG/TFP/7772 Jun 2024 **BG INDUSTRIES** 29500035 17 Transformer Oil Temperature Sensor (Cab-2) BG/TFP/7699 Jun 2024 18 Roof mounted Air Conditioner I CLW/AC/09/24/079 29811028 SSM 19 Roof mounted Air Conditioner II CLW/AC/09/24/077 India rail navigator 20. RTIS(Real time information system) Power supply module Aventel Ltd., India Rail MSS Terminal

		PATIALA LOCOMO					
CN	Equipment		03/WAP-7/CR/PA		T	D.A.	-1
S.N.		PL No.		ent Serial No.			ake
	Complete Shell Assembly with piping	29171064		67, 09/24			ILAI
-	Side Buffer Assly Both Side Cab I	29130050	380, 04/24	Not visible, 09/24		AEU	AEU
-	Side Buffer Assly Both Side Cab II	2242227	Not visible, 09/24		4	AEU	AEU
-	CBC Cab I & II	29130037	1118, 10/23	1108, 10/23	1 6	ESCORTS	ESCORTS
5	Hand Brake		07/24	4 - 17353	444	Modified	Mechwel
	Set of Secondry Helical Spring	29045034 29041041				G.B	
	Battery Boxes (both side)	29680013	144, 09/24	151, 09/24	D	R STEEL	D R STEEL
-	Traction Bar Bogie I		5398	8, 08/24		TE	W
9	Traction Bar Bogie II		540€	6, 08/24	l lid	TE	W
	Centre Pivot Housing in Shell Bogie I side	20100057	8031	1, 08/24		TE\	W
11	Centre Pivot Housing in Shell Bogie II side	29100057	8020	0, 08/24		TEV	W
	Elastic Ring in Front in Shell Bogie I side	20120010		9, 07/24		AVA	DH
	Elastic Ring in Front in Shell Bogie II side	29100010		07/24		AVA	ADH
	Main Transformer	29731008 for WAG 9 29731057 for WAP-7	CG-77-09-24-BI	HL11462/25, 2024		.co	1000
15	Oil Cooling Radiator I			, G-24-27	B/	ANCO PRODI	UCTS PVT LTD
	Oil Cooling Radiator II	29470031		, G-24-25	-	**	UCTS PVT LTD
	Main Compressor I with Motor			3438, 09/24		ELGi	
-	Main Compressor II with Motor	29511008		3434, 09/24		ELGi	
	Transformer Oil Cooling Pump I			3, 05/24		SAMAL H	
	Transformer Oil Cooling Pump II			2, 05/24		SAMAL H	100
-	Oil Cooling Blower OCB I			017, LHP1001559036		PD STEELS	
-	Oil Cooling Blower OCB II	29470043				PD STEELS	
	TM Blower I			LHP1001559035	FOR	11-	
	TM Blower II	29440075		T/24-25/414	-	-	TECHNOLOGY
				1T/24-25/400	FURG		TECHNOLOGY
	Machine Room Blower I	29440105		/F-24.09.70		G.T.R CO	
-	Machine Room Blower II			LXGCM15628(NOT CLR)	-	ACC	
	Machine Room Scavenging Blower I	29440129		113, CF25/D6785			ND PVT LTD
	Machine Room Scavenging Blower II			132, CF25/D6804	SA	AMAL HARAI	
	TM Scavenging Blower Motor I	29440117	07/24, 5	ST-24.07.86		G.T.R CO	(P) LTD
	TM Scavenging Blower Motor II	23440117	07/24, S	T-24.07.68		G.T.R CO((P) LTD
	Traction Convertor I		07/24	4, 5643			
32 T	Traction Convertor II		07/24	4, 5644		and the second	
	Vehicle Control Unit I	29741075		, 07/24		MEDI	A LI
-	Vehicle Control Unit II	23741073		, 07/24		WILE.	AA
-	Aux. Converter Box I (BUR 1)			, 07/24		Michael Carlo	
-	Aux. Converter Box 2 (BUR 2 + 3)			, 07/24			
-	Axillary Control Cubical HB-1	29176645		012407305		STESALI	
	Axillary Control Cubical HB-2	29176657		012407172	J. J.	STESALIT	
	Complete Control Cubicle SB-1	29176669		/2024, 02/24		-	RICAL PVT LTD
-	Complete Control Cubicle SB-2	29178174		/2024, 02/24		-	RICAL PVT LTD
	Filter Cubical (FB) (COMPLETE FILTER Driver Seats	29480140		1/0656/589	Tit	IND RECTIFIE	
	Hotel Load Converter I	29171131		9/24-11, 22, 30, 44		ABI MEDH	
	Hotel Load Converter II	29741087		, 09/24		MEDH	
	Transformer oil steel pipes	29230044		NT PIPES			IA .
46 H	Hotel Load Contactor I			09/24		MEDH	
	Hotel Load Contactor II		3304,	09/24		MEDH	HA
	Conservator Tank Breather Silica Gel	29731057	24-3509,	24-3490	YOG	YA ENTERPR	RISES PVT LTD
-	Ballast Assembly (only for WAG-9)	29170163					
-	Head Light	29611908		/1173		Matsushi po	
53 1	V COUPLER O		11812/1, 11812/29, 1	11812/3, 11812/27		S. INTERNA	TIONAL

NAME SHUBM STARM SSE/LAS

NAME KOYAN SINGH

NAME. A.S.LUT. CRPAC JE/LAS/UF Issue No.: 05

Effective Date: July-2023

DOC NO: F/LAS/Electric Loco CHECK SHEET (Ref: WI/LAS/Elect/01, 02, 03 & 04 & QPL/LAS/Elect. Loco)

Page 1 of 1

पटियाला रेलइंजन कारखाना, पटियाला

PATIALA LOCOMOTIVE WORKS, PATIALA ELECTRIC LOCO CHECK SHEET

LOCO NO: 39403

PADX Shed:

heck proper Fitment of Hotel Load Converter & its output contactor. heck proper Fitment of MR Blower 1 & 2, MR Scavenging Blower 1 & 2, TM Blower 1 & 2, TMB cavenging Blower 1 & 2. M scavenging Blower 1 & 2 & Oil Cooling unit. heck proper of Fitment of oil cooling unit (OCU). heck proper Fitment of HB 1 & 2 and its respected lower part on its position. heck proper Fitment of FB panel on its position. heck proper Fitment of assembled SB1 & SB2 panel. heck proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3). heck proper Fitment of Traction converter 1 & 2 (SR-1 & 2). heck proper fitment, torquing & Locking of Main Transformer bolt. heck proper fitment of Main compressor both side with the compressor safety wire rope. heck proper resting of Secondary Helical Springs between Bogie & Shell body. heck proper fitment of Bogie Body Safety Chains. heck proper fitment of Cow catcher. heck coolant level in SR 1 & 2 Expansion Tank. heck Transformer Oil Level in both conservators Tank (Breather Tank). heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	OK O		012 012 012 012 012 012 012 012 012 012	-	
heck proper Fitment of MR Blower 1 & 2, MR Scavenging Blower 1 & 2, TM Blower 1 & 2, TMB cavenging Blower 1 & 2. M scavenging blower 1 & 2 & Oil Cooling unit. heck proper of Fitment of oil cooling unit (OCU). heck proper Fitment of HB 1 & 2 and its respected lower part on its position. heck proper Fitment of FB panel on its position. heck proper Fitment of assembled SB1 & SB2 panel. heck proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3). heck proper Fitment of Traction converter 1 & 2 (SR-1 & 2). heck proper fitment, torquing & Locking of Main Transformer bolt. heck proper fitment of Main compressor both side with the compressor safety wire rope. heck proper resting of Secondary Helical Springs between Bogie & Shell body. heck proper fitment of Bogie Body Safety Chains. heck proper fitment of Cow catcher. heck coolant level in SR 1 & 2 Expansion Tank. heck Transformer Oil Level in both conservators Tank (Breather Tank). heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	OK OK OK OK OK OK OK OK OK		012 012 012 012 012 012 012 012	-	
heck proper Fitment of HB 1 & 2 and its respected lower part on its position. heck proper Fitment of FB panel on its position. heck proper Fitment of assembled SB1 & SB2 panel. heck proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3). heck proper Fitment of Traction converter 1 & 2 (SR-1 & 2). heck proper fitment, torquing & Locking of Main Transformer bolt. heck proper fitment of Main compressor both side with the compressor safety wire rope. heck proper resting of Secondary Helical Springs between Bogie & Shell body. heck proper fitment of Bogie Body Safety Chains. heck proper fitment of Cow catcher. heck coolant level in SR 1 & 2 Expansion Tank. heck Transformer Oil Level in both conservators Tank (Breather Tank). heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	OK OK OK OK OK OK OK OK OK			-	
heck proper Fitment of HB 1 & 2 and its respected lower part on its position. heck proper Fitment of FB panel on its position. heck proper Fitment of assembled SB1 & SB2 panel. heck proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3). heck proper Fitment of Traction converter 1 & 2 (SR-1 & 2). heck proper fitment, torquing & Locking of Main Transformer bolt. heck proper fitment of Main compressor both side with the compressor safety wire rope. heck proper resting of Secondary Helical Springs between Bogie & Shell body. heck proper fitment of Bogie Body Safety Chains. heck proper fitment of Cow catcher. heck coolant level in SR 1 & 2 Expansion Tank. heck Transformer Oil Level in both conservators Tank (Breather Tank). heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	OK OK OK OK OK OK OK OK				
heck proper Fitment of FB panel on its position. heck proper Fitment of assembled SB1 & SB2 panel. heck proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3). heck proper Fitment of Traction converter 1 & 2 (SR-1 & 2). heck proper fitment, torquing & Locking of Main Transformer bolt. heck proper fitment of Main compressor both side with the compressor safety wire rope. heck proper resting of Secondary Helical Springs between Bogie & Shell body. heck proper fitment of Bogie Body Safety Chains. heck proper fitment of Cow catcher. heck coolant level in SR 1 & 2 Expansion Tank. heck Transformer Oil Level in both conservators Tank (Breather Tank). heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	OK OK OK OK OK OK OK				
heck proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3). heck proper Fitment of Traction converter 1 & 2 (SR-1 & 2). heck proper fitment, torquing & Locking of Main Transformer bolt. heck proper fitment of Main compressor both side with the compressor safety wire rope. heck proper resting of Secondary Helical Springs between Bogie & Shell body. heck proper fitment of Bogie Body Safety Chains. heck proper fitment of Cow catcher. heck coolant level in SR 1 & 2 Expansion Tank. heck Transformer Oil Level in both conservators Tank (Breather Tank). heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	OK OK OK OK OK OK OK		01 01 01 01	-	
heck proper Fitment of Traction converter 1 & 2 (SR-1 & 2). heck proper fitment, torquing & Locking of Main Transformer bolt. heck proper fitment of Main compressor both side with the compressor safety wire rope. heck proper resting of Secondary Helical Springs between Bogie & Shell body. heck proper fitment of Bogie Body Safety Chains. heck proper fitment of Cow catcher. heck coolant level in SR 1 & 2 Expansion Tank. heck Transformer Oil Level in both conservators Tank (Breather Tank). heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	OK OK OK OK OK OK		di di ul	2	
heck proper Fitment of Traction converter 1 & 2 (SR-1 & 2). heck proper fitment, torquing & Locking of Main Transformer bolt. heck proper fitment of Main compressor both side with the compressor safety wire rope. heck proper resting of Secondary Helical Springs between Bogie & Shell body. heck proper fitment of Bogie Body Safety Chains. heck proper fitment of Cow catcher. heck coolant level in SR 1 & 2 Expansion Tank. heck Transformer Oil Level in both conservators Tank (Breather Tank). heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	ОК ОК ОК ОК ОК ОК		d	2	
heck proper fitment, torquing & Locking of Main Transformer bolt. heck proper fitment of Main compressor both side with the compressor safety wire rope. heck proper resting of Secondary Helical Springs between Bogie & Shell body. heck proper fitment of Bogie Body Safety Chains. heck proper fitment of Cow catcher. heck coolant level in SR 1 & 2 Expansion Tank. heck Transformer Oil Level in both conservators Tank (Breather Tank). heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	ОК ОК ОК ОК ОК		al		
heck proper resting of Secondary Helical Springs between Bogie & Shell body. heck proper fitment of Bogie Body Safety Chains. heck proper fitment of Cow catcher. heck coolant level in SR 1 & 2 Expansion Tank. heck Transformer Oil Level in both conservators Tank (Breather Tank). heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	ОК ОК ОК ОК		al		
Check proper fitment of Bogie Body Safety Chains. Check proper fitment of Cow catcher. Check coolant level in SR 1 & 2 Expansion Tank. Check Transformer Oil Level in both conservators Tank (Breather Tank). Check proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	ОК ОК ОК			-	
heck proper fitment of Cow catcher. Check coolant level in SR 1 & 2 Expansion Tank. Check Transformer Oil Level in both conservators Tank (Breather Tank). Check proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	OK OK		C		1
heck coolant level in SR 1 & 2 Expansion Tank. heck Transformer Oil Level in both conservators Tank (Breather Tank). heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	OK OK				*
heck Transformer Oil Level in both conservators Tank (Breather Tank). heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	OK		-	IL	
theck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any			OL		
heck proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any	OIL	oL d			
amage during online working of Locomotives.	OK	OIL			
heck proper fitment of both battery box.	OK	oll			
heck for any gap between Main Transformer mounting base & Loco Shell.	OK	OLL			
theck proper fitment of Push Pull rod its bolt torquing and fitment of fixing cable. As per Drg No 1209-01-113-001	OK	OK			
econdary Vertical and Lateral Clearance on leveled track at the time of Loco Dispatch.		CAL	B-1	(CAB-2
LRS/TC/ 0082 (Rev 1) dated 17.09.2015	Vertical-Std :35-60 mm	28	ALP 38	LP 44	ALP
	Lateral Std-	57	42	58	42
suffer height: Range (1090, +155)	1085-1105		L/S	3	R/S
org No IB031-02002.	mm	FRONT	1-0	0	1097
			-	-	****
		REAR			1100
	641 mm	FDONT	_	-	·R/S
org No-SK.DL-3430.					648
		REAR			650
leight of Rail Guard. (114 mm + 5 mm,-12 mm).	114 mm + 5		L/S	3	R/S
As per RDSO Pamphlet Important Bogie Clearances of Electric Locomotives.	mm,-12 mm	FRONT	110	5	114
					111
	Charles and Land	FRONT:	1100		111
Or He	uffer Length: Range (641 mm + 3 to 10 mm with buffer face) rg No-SK.DL-3430. eight of Rail Guard. (114 mm + 5 mm,-12 mm).	### 45-50 mm #### 1085-1105 #	### ### ### ### #### #### ############	### ### ##############################	### ### ### ### ### ### ### ### ### ##

(Signature of SSE/Elect. Loco)

NAMESTO BILLIAM SHAPM

(Signature of /JE/Elect Loco)

NAME Karan Sigh

Ankit uppel (Signature of JE/UF)

NAME ANKIT UPPAL

DATE 30/09/2024

Loco No. 39403

1. BOGIE FRAME:

BOGIE	FRAME NO	Make	PL No.	PO No. & dt.	Warranty Period
FRONT	SL-153	ECBT	29100677	102221	As per PO/IRS
REAR	SL-223	ECBT	29100677	101682	conditions

2. Hydraulic Dampers (PL No.29040140) Make: KONI/KONI

3. AXLES:

AXLE POSITION NO	1	2	3	4	5	6
MAKE/	PLW	PLW	PLW	PLW	PLW	PLW
S.NO	27179	27190	26845	27283	26944	27181
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

4. WHEEL DISCS NO. AND TYPE & BULL GEAR

AXLE POSITION NO	1	2	3	4	5	6
GEAR END	23422	E0L5-087	E0G8-009	20151	E0L5-042	E016-085
Make	DP	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
FREE END	O3139	E0J2-023	E0G8-051	20157	E0IL-035	E015-055
Make	DP	IMPORTED	IMPORTED	DP	IMPORTED	IMPORTED
Bull Gear No.	24-A-1091	5529	5658	23-M-9223	23-M-9203	5627
Bull Gear Make	KPCL	GGAG	GGAG	KPCL	KPCL	GGAG

5. AXLE ROLLER BEARING (CRU) (PL No. 29010020, Warranty: As per PO/IRS conditions)

	AXLE POSITION NO	1	2	3	4	5	6
Gear	MAKE	FAG	FAG	FAG	FAG	FAG	FAG
End	PO NO. & dt	02312	02312	02312	02312	02312	02312
Free	MAKE	FAG	FAG	FAG	FAG	FAG	FAG
End	PO NO. & dt	02312	02312	02312	02312	02312	02312

6. WHEEL DISC PRESSING PRESSURE IN KN: (SPECIFIED 80-105 T)

AXLE POSITION NO	1	2	3	4	5	6
BULL GEAR END	816 KN	102 T	785 KN	91 T	797 KN	890 KN
FREE END	795 KN	82 T	802 KN	80 T	802 KN	1002 KN

Loco No. 39403

7. DIAMETER AFTER PROFILE TURNING: SPECIFIED 1092 + 5 mm - 0 mm

AXLE POSITION NO	1	2	3	4	5	6
DIA IN mm GE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
DIA IN mm FE	1092.5 1092.	1092.5	1092.5	1092.5	1092.5	1092.5
WHEEL PROFILE GAUGE (1596±0.5mm)	OK	OK	OK	OK	OK	OK

8. SUSPENSION TUBE & ITS TAPER ROLLER BEARING:

AXLE POSITION NO		1	2	3	4	5	6
S.T. PL 29100288	MAKE	KM	SD	KM	KM	SD	KM
GE Brg. PL 29030110	MAKE	NBC	FAG	FAG	FAG	FAG	FAG
FE Brg. PL 29030110	MAKE	NBC	FAG	FAG	FAG	FAG	FAG

9. GEAR CASE (PL No. 29030018) & BACKLASH:

AXLE POSITION NO	1	2	3	4	5	6
MAKE	KPE	PITTI	PITTI	PITTI	PITTI	PITTI
BACKLASH (0.254 – 0.458mm)	0.280	0.290	0.305	0.302	0.280	0.290

10 A/BOX TO BOGIE FRAME LATERAL CLEARANCES (SPECIFIED 15.0 to 19.0mm):

AXLE POSITION NO	1	2	3	4	5	6
RIGHT SIDE	15.67	16.20	15.65	16.71	16.65	15.57
LEFT SIDE	15.35	15.45	15.57	15.83	15.81	15.60

11. TRACTION MOTOR: (PL No.29942007, Warranty: As per PO/IRS conditions)

AXLE POSITION NO	MAKE	PO No. & date	S. NO.
1	TMS	-	PLW-2833
2	SAINI	101654	204342406
3	GOVIK	101652	G-241317
4	SAINI	101654	204402406
5	GOVIK	101652	G-241321
6	GOVIK	101652	G-241326

SSE/ Bogie Shop

TOP 13 COSTLIEST ITEMS OF WAP-7 LOCO WITH WARRANTY CONDITIONS AS PER TENDERS

S No	PL No	DESCRIPTION	Warranty Period
1	29741075	IGBT BASED 3-PHASE DRIVE PROPULSION EQUIPMENT	60 months after commissioning or 72 months from date of supply whichever earlier as per special conditions given by CLW
2	29741087	2X500KVA IGBT Based Hotel Load Converter to CLW Specn. no. CLW/ES/3/IGBT/0490 aLT.D (REV.1) issued on December,2017	As per clause no. 3.1.6 of CLW SPECN. NO. CLW/ES/3/IGBT/0490 ALT.D REV.1 ISSUED ON DEC-2017. [60 months after commissioning or 72 months from date of supply whichever earlier]
3	29731057	MAIN TRANSFORMER 7775 KVA TYPE LOT 7500 FOR WAP7 3- PHASE ELECTRIC LOCOMOTIVE TO CLW SPECN NO.CLW/ES/3/0660/C	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
4	29171064	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT-8	AS PER IRS CONDITIONS-30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER.
5	29600418	SET OF HARNESSED CABLE FOR 3-PHASE ELECTRIC LOCOMOTIVES TO CLW SPECN. NO. CLW/ES/03/646 ALT-NIL WITH DMW REQUIREMENT OF HARNESSED CABLE FOR WAP-7, ALT-A1 DATED 27/11/2018.	As per clause no.9 of CLW Specn. CLW/ES/3/0458 & Clause No.10 of CLW SpecnCLW/ES/3/0459. [18 months after commissioning or 20 months from date of supply for single core & 18 months after commissioning or 24 months from date of supply for multi core]

6	29180016	BRAKE CONTROL SYSTEM INCLUDING DRIVER'S VIGILANCE CONTROL DEVICE TO SET LIST NO.EL29180016.	As per specification no. CLW/MS/3/001 Alt. 16 i.e. the manufacturer is required to guarantee that the brakevalves/equipment work satisfactorily for a period of five (5) years after commissioning. Any equipment/part which failsduring the guarantee period shall be replaced free of cost by the manufacturer. The replaced components shallfurther be under warranty for five (5) years from the date of their fitment and should the replaced components proveunsatisfactory in service, they shall be replaced by modified and improved components by the supplier free of cost.
		COMPLETE ELLTED CUDICLE ALONG WITH ALL	
7	29480140	COMPLETE FILTER CUBICLE ALONG WITH ALL EQUIPMENTS AND CABLING TO DRG./SPEC NO. [1] CLW/ES/3/0193 ALT-F OR LATEST AND CLW DRG. NO. 1209-15-143-004 ALT-10 AND PART DRG./SPEC NO AS PER ANNEXURE-A ATTACHED.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
8	29942007	3-PHASE ASYNCHRONOUS TRACTION MOTOR (RESISTANCE RING MECHANICALLY INTERLOCKED TO END PLATE DESIGN ROTOR, SCHEME-II), TYPE 6FRA-6068 FOR WAP-7 ELECTRIC LOCO WITHOUT ACTIVE SPEED SENSOR TO SPECIFICATION NO. 4TMS.096.081 ALT-2 AND STR NO. CLW/2008/3PHTM/STR/0001.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.

9	29105146	Bogie Frame Complete for WAP-7 for 3 Phase Co Co Locomotive to CLW specification No. CLW/MS/3/Bogie/003 alt-1 and CLW Drg.No.1209.01.112-202 Alt-Nil	As per clause 16 of Spec.No.CLW/MS/3/Bogie/003 Alt-1. [60 months after commissioning or 72 months from date of supply]
10	29171192	COMPLETE AUXILIARY CUBICLE HB2 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0192 ALT-E OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
11	29171210	COMPLETE CONTROL CUBICLE SB2 ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0195/A ALT-H OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
12	29171209	COMPLETE CONTROL CUBICLE SB1 (PUSH PULL SCHEME COMPLIANT) ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0194 ALT-G OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
13	29171180	COMPLETE AUXILIARY CUBICLE HB1 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0191 ALT-D OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.



भारत सरकार GOVERNMENT OF INDIA रेल मंत्राल्य

MINISTRY OF RAILWAYS पटियाला रेलइंजन कारखाना

पाटयाला रलइजन कारखाना
PATIALA LOCOMOTIVE WORKS

Email: dyceeloco.dmw@gmail.com फैक्स/Fax No.: 0175-2397244 फोन/ Phone: 0175-2396422 मोबाईल: 9779242310 पटियाला, 147003, भारत्

PATIALA, 147003, INDIA



(An ISO 9001, ISO 14001, ISO 45001 & ISO 50001, 5S & Green Building certified Organization)

संख्या. PLW/M/ECS/Tech/Kavach

तिथि: As signed

(Through Mail)

Sr. Div. Mechanical Engineer, Diesel Loco Shed, Pune.

Email: srdmedpune@gmail.com

विषय:- Fitment of KAVACH in three Phase Electric Loco. No. 39403 WAP-7.

संदर्भ:- (i) Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 21.08.2023.

(ii)Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 26.09.2023

In ref. to the above letter's Loco No. 39403 has been dispatched with fittings for implementation of KAVACH system in locomotive at home shed in Zonal Railway. This Loco was dispatched to DLS/PADX/CR on 12.11.2024. The details of fittings are attached as Annexure-A (pneumatic fittings), Annexure-B (Kavach equipment mounting Brackets) & Annexure-C (Wago with harnessed lay out).

This is for your information & necessary action please.

(निशांत बंसीवाल)

उप म्ख्य विद्युत अभियंता/लोको

प्रतिलिपि:-

CEE/Loco & CEE/D&Q, CMM, CELE/CR:- for kind information please Dy CME/Design, Dy. CMM/Depot: for information & necessary action please WM/LAS, AWM/LFS&ABS, WM/ECS: for necessary action please

Loco No. 39403

8X	PLINO	Dessiption of tom	(e) iy
1	20162244	ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITH VENT	04 nos.
1	29163341	ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITHOUT VENT	02 nos.
		TEE UNION 3/8"X3/8" BRASS FITTINGS	02 nos.
		MALE CONNECTORS 3/8" TUBE OD X 3/8" BSPT, BRASS FITTINGS	09 nos.
		MALE CONNECTORS 1/2" TUBE OD X 1/2" BSPT, BRASS FITTINGS	06 nos.
		FEMALE CONNECTORS (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	01 no.
		MALÉ CONNECTOR (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	03 nos
		FEMALE TEE 3/8" BSPP – BRASS	06 nos
2	29611994	HEX PLUG -3/8" BSPT – BRASS	02 nos
		FEMALE TEE 1/2" BSPP – BRASS	04 nos
		HEX NIPPLE 3/8X3/8" BSPT – BRASS	04 nos
		RED HEX NIPPLE 3/8X1/2" BSPT - BRASS	02 nos
		HEX PLUG - 1/2" BSPT - BRASS	04 nos
		MALE ELBOW CONNECTORS 3/8" TUBE OD X 3/8) BSPT. BRASS FITTINGS	02 nos
3	29170114	Copper Tube OD 9.52mm (3/8") X 1.245 Mm W.T X 6 Mtr	1.2Mtr

AWM/ABS & LFS

SSE/G/ABS

SN	PL No.	Description of item	Quantity
1.	29611945	Mounting bracket arrangement provided for RF Antenna on the roof top of both driver cabs.	04 nos.
2.		Mounting bracket arrangement provided for GPS/GSM Antenna on the roof top of both driver cabs.	02 nos.
3.		Protection Guards for RFID reader provided behind the cattle guards of both side.	04 nos.
4.		Inspection door with latch provided on the both driver desk covers (LP side) in each cab to access isolation cock.	02 nos.
5.		Cable Entry Plate fitted for routing of cable with RF Antenna & GPS/GSM Antenna bracket.	06 nos.
6.	•	WAGO bracket fitted in Machine room at back side of SB-1.	01 no.
7.	_	One circular hole of 80 mm dia. provided in each cabs on LP side behind the driver desk toward the wall for routing of OCIP (DMI) cables.	02 nos.
8.		80 mm holes provided on TM1 and TM6 Junction box inspection cover hole for drawing of RFID reader cables.	02 nos.
9.		DIN Rail fitted inside the driver desk (LP Side)	02 nos.

AWMIABS & LFS

SSE/G/LFS

Annexure-C

SN	PLNo.	Description of Item	Quantity
1.	42310301	Flexible conduit size 25mm ² provided for RF-1, 2 & GPS Antenna cable layout from CAB-1&2 to Machine room.	06 micter
, 2.	29611982	Wago terminals in CAB-1&2 (25 nos. in each CAB).	50 nos.
3.	29611982	Wago terminal in Machine room at back side of SB-1.	75 nos.
4.	-	Harness provided from KAVACH SB to SB-1	07 wires
5.	-	Harness provided from KAVACH SB to SB-2	05 wires
6.	-	Harness provided from KAVACH SB to Pneumatic Panel	12 wires
7.	-	Harness provided from KAVACH SB to CAB-1	24 wires
8.	-	Harness provided from KAVACH SB to CAB-2	16 wires

AWMYECS

SSEIGIECS