

# भारतीय रेल Indian Railways

पटियाला रेलइंजन कारख़ाना, पटियाला Patiala Locomotive Works, Patiala



# LOCO TESTING & DISPATCH REPORT OF IGBT BASED 3 PHASE ELECTRIC LOCOMOTIVE

LOCO NO.: 39407

TYPE: WAP-7

RAILWAY SHED: CR/PADX

PROPULSION SYSTEM: MEDHA

HOTEL LOAD: AAL

**DATE OF DISPATCH:** 25.10.2024

लोको निर्माण रिकार्ड



## पटियाला रेलइंजिन कारख़ाना, पटियाला Patiala Locomotive Works, Patiala

**LOCO NO. - 39407** 

**RAILWAY/SHED: CR/PADX** 

**DOD: Oct-2024** 

#### **INDEX**

SN	PARA	ACTIVITIES	PAGE NO.
<u> </u>		Testing & Commissioning (ECS)	
1.	1.0 1.1 1.2 1.3 1.4	Continuity Test of the cables Continuity Test of Traction Circuit Cables Continuity Test of Auxiliary Circuit Cables Continuity Test of Battery Circuit Cables Continuity Test of Screened Control Circuit Cables	1-4
2.	2.0 2.1 2.2 2.3	Low Tension test Measurement of resistor in OHMS (Ω) Check Points Low Tension Test Battery Circuits (without control electronics)	5-6
3	3.0 3.1 3.2 3.3 3.4	Downloading of Software Check Points Download Software Analogue Signal Checking Functional test in simulation mode	7-10
4	4.0 4.1 4.2 4.3 4.4 4.5 4.6 4.7 4.8 4.9	Sensor test & convertor test Test wiring Transformer Circuits – Polarity Test Test wiring auxiliary transformer 1000V/415V-110V (pos. 67) Primary Voltage Transformer Minimum voltage relay (Pos. 86) Maximum current relay (Pos. 78) Test current sensors Test DC Link Voltage Sensors (Pos 15.6/*) Verification of Converter Protection Circuits (Hardware limits) Sequence of BUR contactors	11-16
5.	5.0 5.1 5.2 5.3 5.3.1 5.3.2 5.3.3 5.4 5.5 5.6 5.7 5.8 5.9	Commissioning with High Voltage Check List Safety test main circuit breaker Auxiliary Converter Commissioning Running test of 3 ph. auxiliary equipments Performance of Auxiliary Converters Performance of BURs when one BUR goes out Auxiliary circuit 415/110 Hotel Load Circuit Traction Converter Commissioning Test protective shutdown SR Test Harmonic Filter Test important components of the locomotive	16-25
6.	6.0	Running Trial of the locomotive	25-26
7.	7.0	Final Check List to be verified at the time of Loco dispatch	27
8.	1-6	Annexure HLC	28-33
9.	1-10	Pneumatic Test Parameters	34-37
10.	<del></del> _	Loco Check Sheet(LAS)	38
11.	_	Component History (LAS,ECS,ABS)	39-41
12.		Component History & Testing Parameter (Bogie Shop)	42-43
13	-	Warranty Conditions as per Tenders	44-46

2

(Ref: WI/ECS/10)

DOC.NO.F/EUS/VI

### PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 37407 -MEDHA

Type of Locomotive: WAP-7/WAG-9HC

Page: 1 of 27

1.0 Continuity Test of the cables

1.1 Continuity Test of Traction Circuit Cables

As per cable list given in Para 1.3 of document no. 3 EHX 410 124, check the continuity with continuity tester and megger each cable to be connected between following equipment with 1000V megger.

From	То	Continuity (OK/Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Filter Cubicle	Transformer	oK	100 ΜΩ	900m2
Filter Cubicle	Terminal Box of Harmonic Filter Resistor (Roof)	σK	100 ΜΩ	Boums
Filter Cubicle	Earthing Choke	oK	100 ΜΩ	600mg
Earthing Choke	Earth Return Brushes	οK	100 ΜΩ	900Ma
Transformer	Power Converter 1	οK	100 ΜΩ	800000
Transformer	Power Converter 2	OK	100 ΜΩ	700ma
Power Converter 1	TM1, TM2, TM3	οK	100 ΜΩ	Booms
Power Converter 2	TM4, TM5, TM6	oK	100 ΜΩ	900 m2
Earth	Power Converter 1	οK	100 ΜΩ	800 ms
Earth	Power Converter 2	øK	100 ΜΩ	700ma

#### 1.2 Continuity Test of Auxiliary Circuit Cables

As per cable list given in Para 1.4 of document no. 3 EHX 410 124, check the continuity with continuity meter and megger each cable to be connected between following equipment with the help of 1000V megger.

Signature of the JE/SSE/Harness

Signature of the JE/SSE/Loco Cabling

Doc.No.F/ECS/07 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

## Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 2 of 27

From	То	Continuity(OK/ Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Transformer	BUR1	OK	100 ΜΩ	1000 M/
Transformer	BUR2	OK	100 ΜΩ	500 MM
Transformer	BUR3	oK	100 MΩ	500 M/
Earth	BUR1	0K	100 ΜΩ	500 M/
Earth	BUR2	OK	100 MΩ	200m
Earth	BUR3	o.K	100 ΜΩ	200 MV
BUR1	HB1	oK	100 M $\Omega$	"600 M
BUR2	HB2	OK	100 MΩ	Feo my
HB1	HB2	oK.	100 ΜΩ	600 m/
HB1	TM Blower 1	oK	100 MΩ	600 M/L
HB1	TM Scavenge Blower 1	oK	100 ΜΩ	500 MM
HB1	Oil Cooling Unit 1	οK	100 MΩ	706 M/
HB1	Compressor 1	oK	100 M $\Omega$	600 W
HB1	TFP Oil Pump 1	oK	100 ΜΩ	700 MM
HB1	Converter Coolant Pump 1	oK	100 ΜΩ	600m
HB1	MR Blower 1	oK	100 MΩ	700 MM
HB1	MR Scavenge Blower 1	οK	100 ΜΩ	SOOM
HB1	Cab1	οK	100 MΩ	600M/
Cab1	Cab Heater 1	oK	100 ΜΩ	700 M
HB2	TM Blower 2	oK	100 ΜΩ	600 M/
HB2	TM Scavenge Blower 2	OK	100 MΩ	400 M
HB2	Oil Cooling Unit 2	oK	100 ΜΩ	700 IN/
HB2	Compressor 2	οK	100 MΩ	600 MA
HB2	TFP Oil Pump 2	oK	100 ΜΩ	400 MM
HB2	Converter Coolant Pump 2	oK	100 MΩ	500 M
HB2	MR Blower 2	OK	100 ΜΩ	TOOML
HB2	MR Scavenge Blower 2	οK	100 MΩ	600 MR
HB2	Cab2	oK	100 MΩ	Feb m/
Cab2	Cab Heater 2	OK	100 MΩ	600 MA

Effective Date: Feb 2022

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

## <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 3 of 27

1.3 Continuity Test of Battery Circuit Cables

Check continuity of following cables as per Para 2.3 of document no. 3 EHX 610 299

From	То	Condition	Continuity (OK/Not OK)
Battery (wire no 2093)	Circuit breakers 110- 2, 112.1-1, 310.4-1	By opening and closing MCB 112	OK
MCB 110	Connector 50.X7-1	By opening and closing MCB 110	OK
Battery (Wire no. 2052)	Connector 50.X7-2		0/4
SB2 (Wire no 2050)	Connector 50.X7-3		OK

Close the MCB 112, 110, 112.1, and 310.4 and	Prescribed value	Measured
measure the resistance of battery wires 2093, 2052, 2050 with respect to the loco earth.	> 0.5 MΩ	Value <u>6</u> ΜΩ
Measure the resistance between 2093 & 2052, 2093 & 2050, 2052 &	Prescribed value:	Measured
2050	> 50 MΩ	Value <u> </u>

Commission the indoor lighting of the locomotive as per Sheet No 7A & 7B.

#### 1.4 Continuity Test of Screened Control Circuit Cables

Check the continuity and isolation of the screen cable of the following circuits with the help of sheet no. mentioned against each as per document no. 3 EHX 610 299.

Screened control circuit cables for	Corresponding Sheet Nos.	Continuity & Isolation (OK/Not OK)	
Battery voltage measurement	04B	OK	
Memotel circuit of cab1 &2	10A	οk	
Memotel speed sensor	10A	OK	
Primary voltage detection	01A, 12A	OK	
Brake controller cab-1 & 2	06F, 06G	O.K	

DOC.NO.F/EUS/UT (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 4 of 27

•		
Master controller cab-1 &2	08C, 08D	OK
TE/BE meter bogie-1 & 2	08E, 08F	OK
Terminal fault indication cab-1 & 2	09F	OK
Brake pipe pressure actual BE electric	06H	OK
Primary current sensors	12B, 12F	OK
Harmonic filter current sensors	12B, 12F	OK
Auxiliary current sensors	12B, 12F	OK
Oil circuit transformer bogie 1	12E, 12I	OK
Magnetization current	12C, 12G	OK
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-1	12D	ok
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-2	12D	OK
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-3	12D	OK
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-4	12H	OK
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-5	12H	0/<
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-6	12H	OK
Train Bus cab 1 & 2 (Wire U13A& U13B to earthing resistance= $10K\Omega \pm 10\%$ )	13A	OK
UIC line	13B	OK
Connection FLG1-Box TB	13A	OK

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

## <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 5 of 27

#### 2.0 Low Tension test

#### 2.0 LOW Tension test

2.1 Measurement of resistor in OHMS  $(\Omega)$ 

Measure the resistances of the load resistors for primary voltage transformer, load resistors for primary current transformer and Resistor harmonic filter as per Para 3.2 of the document no. 3 EHX 610 279.

Name of the resistor	Prescribed value	Measured value
Load resistor for primary voltage transformer (Pos. 74.2).	3.9K <b>Ω</b> ± 10%	3.4 kV
Resister to maximum current relay.	1Ω ± 10%	12
Load resistor for primary current transformer (Pos. 6.11).	3.3 Ω ± 10%	3.31
Resistance harmonic filter (Pos 8.3). Variation allowed ± 10%	WAP7	WAP7
Between wire 5 & 6	0.2 Ω	0.21
Between wire 6 & 7	0.2 Ω	0.20
Between wire 5 & 7	0.4 Ω	0.42
For train bus, line U13A to earthing.	10 kΩ± 10%	10.0KJ
For train bus, line U13B to earthing.	10 k <b>Ω</b> ± 10%	10:0K1
Insulation resistance of High Voltage Cable from the top of the roof to the earth (by1000 V megger).	200 ΜΩ	Looper
Resistance measurement earth return brushes Pos. 10/1.	≤0.3 Ω	0.281
Resistance measurement earth return brushes Pos. 10/2.	≤0.3 Ω	0.201
Resistance measurement earth return brushes Pos. 10/3.	≤0.3 Ω	0,281
Resistance measurement earth return brushes Pos. 10/4.	≤0.3 Ω	0,281
Earthing resistance (earth fault detection) Harmonic Filter –I; Pos. 8.61.	2.2 kΩ± 10%	2.2kr
Earthing resistance (earth fault detection) Harmonic Filter –II; Pos 8.62.	2.7 k <b>Ω</b> ± 10%	2.7kr
Earthing resistance (earth fault detection) Aux. Converter; Pos. 90.3.	3.9 k <b>Ω</b> ± 10%	3.8 Kr
Earthing resistance (earth fault detection) 415/110V; Pos. 90.41.	1.8 k <b>Ω</b> ± 10%	1.82
Earthing resistance (earth fault detection) control circuit; Pos. 90.7.	390 <b>Ω</b> ± 10%	3905
Earthing resistance (earth fault detection) Hotel load; Pos. 37.1(in case of WAP5).	3.3 k <b>Ω</b> ± 10%	MA
Resistance for headlight dimmer; Pos. 332.3.	10 <b>Ω</b> ± 10%	105

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 3947

Type of Locomotive: WAP-7/WAG-9HC

Page: 6 of 27

Note:

Make sure that the earthing brush device don't make direct contact with the axle housing, earth connection must go by brushes.

#### 2.2 Check Points

Items to be checked	Remarks	
Check whether all the earthing connection in roof and machine room as mentioned in sheet no. 22A is done properly or not.  These earthing connections must be flexible and should be marked yellow & green	Checked OK	
Check whether all the earthing connection between loco body and bogie is done properly or not. These cables must be flexible having correct length and cross section	Cheched ox	

#### 2.3 Low Tension Test Battery Circuits (without control electronics)

These tests are done with the help of the special type test loop boxes as per procedure given in Para 3.6 of the document no. 3 EHX 610 279

Name of the test	Schematic used.	Remarks
Test 24V supply	Sheet 04F and other linked sheets	Checked ox
Test 48V supply	Sheet 04F & sheets of group 09	Fan supply to be checked. $\bigcirc \mathcal{K}$
Test traction control	Sheets of Group 08.	0k
Test power supply bus stations.	Sheets of Group 09.	Fan supply to be checked.
Test control main apparatus	Sheets of Group 05.	0k
Test earth fault detection battery circuit by making artificial earth fault to test the earth fault detection	Sheet 04C	OK
Test control Pneumatic devices	Sheets of Group 06	OK
Test lighting control	Sheets of Group 07	OK.
Pretest speedometer	Sheets of Group 10	oK
Pretest vigilance control and fire system	Sheets of Group 11	OK
Power supply train bus	Sheets of Group 13	ok

DOC.NO.F/ECS/VI (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 7 of 27

Downloading of Software

3.1 Check Points.	Yes/No
Check that all the cards are physically present in the bus stations and all the plugs are connected.	Yes
Check that all the fibre optic cables are correctly connected to the bus stations.	Yes
Make sure that <b>control electronics off relay</b> is not energized i.e. disconnect Sub-D 411.LG and loco is set up in simulation mode.	Yes.
Check that battery power is on and all the MCBs (Pos. 127.*) in SB1 &SB2 are on	4es

3.2 Download Software

The software of Traction converter, Auxiliary converter and VCU should be done by commissioning engineer of the firm in presence of supervisor. Correct software version of the

propulsion equipment to be ensured and noted:

Traction converter-1 software version:	1.09
The state of the s	
Traction converter-2 software version:	1.09
Auxiliary converter-1 software version:	1.09
Auxiliary converter-2 software version:	1.04
Auxiliary converter-3 software version:	1.04
Vehicle control unit -1 software version:	3.0
Vehicle control unit -2 software version:	3.3

#### 3.3 Analogue Signal Checking

Check for the following analogue signals with the help of diagnostic tool connected with loco.

Description	Signal name	Prescribed value	Measured Value
Brake pipe pressure	FLG2;0101XPrAutoBkLn	100% (= 5 Kg/cm2)	ok
Actual BE electric	FLG2; AMSB_0201- Wpn BEdem	100% (= 10V)	OK
TE/BE at 'o' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 9% and 11 %	10 f.
TE/BE at 'TE maximal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 99 % and 101 %	1001
TE/BE at 'TE minimal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 20 % and 25 %	244

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

## <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 8 of 27

TE/BE at 'BE maximal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 99% and 101%	1001
TE/BE at 'BE Minimal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 20% and 25%	244
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>1/3 HBB2; AMS_0101- LT/BDEM>1/3	Between 42 and 44%	444,
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>2/3 HBB2; AMS_0101- LT/BDEM>2/3	Between 72 and 74%	741
Both temperature sensor of TM1	SLG1; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature $0^{\circ}$ C to $40^{\circ}$ C	12°C
Both temperature sensor of TM2	SLG1; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	1200
Both temperature sensor of TM3	SLG1; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	12.5°C
Both temperature sensor of TM4	SLG2; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	13°C
Both temperature sensor of TM5	SLG2; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	12°C
Both temperature sensor of TM6	SLG2; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	1200

Effective Date: Feb 2022

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 9 of 27

#### 3.4 Functional test in simulation mode

Conduct the following functional tests in simulation mode as per Para 5.5 of document no.3EHX 610 281. through the Diagnostic tool/laptop :

Test Function	Result desired in sequence	Result obtained
Emergency shutdown through emergency stop switch 244	VCB must open. Panto must lower.	Checked OK
Shut Down through cab activation switch to OFF position	VCB must open. Panto must lower.	Chechedox
Converter and filter contactor operation with both Power Converters during Start Up.	FB contactor 8.41 is closed.  By moving reverser handle:  Converter pre-charging contactor 12.3 must close after few seconds.  Converter contactor 12.4 must close.  Converter re-charging contactor 12.3 must opens.  By increasing TE/BE throttle:  FB contactor 8.41 must open.  FB contactor 8.2 must close.  FB contactor 8.1 must close.	(heched OK
Converter and filter contactor operation with both Power Converters during Shut Down.		Cheched

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC Page: 10 of 27

•	,	
Contactor filter adaptation by isolating any bogie	Isolate any one bogie through bogie cut out switch. Wait for self-test of the loco.  • Check that FB contactor 8.1 is open.  • Check that FB contactor 8.2 is open.  After raising panto, closing VCB, and setting TE/BE  • FB contactor 8.1 closes.	Checked OK
	• FB contactor 8.2 remains open.	
Test earth fault detection battery circuit positive & negative	By connecting wire 2050 to earth, create earth fault negative potential.  • message for earth fault	Checked
	<ul> <li>By connecting wire 2095 to earth, create earth fault positive potential.</li> <li>message for earth fault</li> </ul>	
Test fire system. Create a smoke in	When smoke sensor-1 gets	
the machine room near the FDU.	activated then	
Watch for activation of alarm.	<ul> <li>Alarm triggers and fault message priority 2</li> </ul>	Cheebeal
	appears on screen. When both smoke sensor 1+2 gets activated then	OK
	<ul> <li>A fault message priority</li> <li>1 appears on screen and lamp LSF1 glow.</li> <li>Start/Running interlock occurs and TE/BE becomes to 0.</li> </ul>	
Time, date & loco number	Ensure correct date time and Loco number	ok

Effective Date: Feb 2022

(Ref: WI/ECS/10)

### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page : 11 of 27

#### 4.0 Sensor Test and Converter Test

#### 4.1 Test wiring main Transformer Circuits

Apply  $198V_p/140V_{RMS}$  to the primary winding of the transformer (at 1u; wire no. 2 at surge arrestor and at 1v; wire no. 100 at earthing choke). Measure the output voltage and compare

the phase of the following of the transformers.

Output Winding nos.	Description of winding.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
2U <sub>1</sub> & 2V <sub>1</sub>	For line converter bogie 1 between cable 801A- 804A	10.05V <sub>p</sub> and same polarity	10,0578	ek.
2U <sub>4</sub> & 2V <sub>4</sub>	For line converter bogie 1 between cable 811A- 814A	10.05V <sub>p</sub> and same polarity	10.0520	90
2U <sub>2</sub> & 2V <sub>2</sub>	For line converter bogie 2 between cable 801B- 804B	10.05V <sub>p</sub> and same polarity	10.01	. ox
2U <sub>3</sub> & 2V <sub>3</sub>	For line converter bogie 2 between cable 811B- 814B	10.05V <sub>p</sub> and same polarity	10.054	٥٤
2U <sub>B</sub> & 2V <sub>B</sub>	For aux. converter 1 between cable 1103- 1117 (in HB1) For Aux converter 2 between cable 1103- 1117 (in HB2)	7.9V <sub>p</sub> , 5.6V <sub>RMS</sub> and same polarity.	7.8VP 5.5VPMS	on
2U <sub>F</sub> & 2V <sub>F</sub>	For harmonic filter between cable 4-12 (in FB)	9.12V <sub>p</sub> , 6.45V <sub>RMS</sub> and same polarity.	9.10Vl	9k

#### 4.2 Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)

Apply  $141V_p$  /  $100V_{RMS}$  to input of the auxiliary transformer at cable no 1203 –1117 and measure the output at

Description of wire no.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
Cable no. 1218 - 1200	58.7V <sub>p</sub> , 41.5V <sub>RMS</sub> and opposite polarity.	58.5V1 41.5VRMS	٥٨
Cable no. 1218 – 6500	15.5V <sub>p</sub> , 11.0V <sub>RMS</sub> and opposite polarity.	1221	R

Effective Date: Feb 2022

DOC.NO.F/ECS/VI

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 12 of 27

#### **Primary Voltage Transformer** 4.3

Apply 250Veff/350Vp by variac to roof wire 1 and any wire 0 and measure the magnitude and polarity of the output of the primary voltage transformer for both bogies as per the procedure specified and suggested by the traction converter manufacturer. Primary voltage measurement converters (Pos. 224.1/\*) & catenary voltmeter (Pos. 74/\*)

This test is to be done for each converter.

Activate cab in driving mode and supply 200V<sub>RMS</sub> through variac to wire no 1501 and 1502. Monitor the following parameters through Diagnostic tool and in catenary voltmeter.

Signal name	Prescribed value in catenary voltmeter		Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XU	Prim 25kV	250%	25KU	250%
SLG2 G 87-XU	Prim 25 kV	250%	25KU	250.1

Decrease the supply voltage below 140 V<sub>RMS</sub>. VCB must open at this voltage. In this case the readings in Diagnostic Tool and catenary voltmeter will be as follows.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	17kV	170%	TKU	1704
SLG2 G 87-XUPrim	17 kV	170%	17KU	1707 -

Reactivate VCB to on by increasing this voltage to 175% (17.5 kV).

Increase the supply to 240 V<sub>RMS</sub> through variac. VCB must open at this voltage, In this case the readings in diagnostic tool and catenary voltmeter will be as follows:

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	30kV	300%	30KU	300-1,
SLG2_G 87-XUPrim	30 kV	300%	30KU	300 y.

Reactivate VCB to on by decreasing this voltage to 290% (29 kV).

Effective Date: Feb 2022

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 13 of 27

### 4.4 Minimum voltage relay (Pos. 86)

Functionality test.	- 1 to a name COO/
Minimum voltage relay (Pos. 86) must be adjus	ted to approx 68%
Activate loco in cooling mode. Check Power supply of 48V to minimum voltage relay. Disconnect primary voltage transformer (wire no. 1511 and 1512) from load resistor (Pos. 74.2) and connect variac to wire no. 1501 and 1502. Supply 200V <sub>RMS</sub> through variac. In this case; <i>Minimum voltage relay (Pos. 86) picks up</i>	√(Yes/No)
Try to activate the cab in driving mode:  Contactor 218 do not close; the control  electronics is not be working.	(Yes/No)
Turn off the variac : Contactor 218 closes; the control electronics is be working	(Yes/No)
Test Under Voltage Protection	
Activate the cab in cooling mode; Raise panto;	(Yes/No)
Supply 200V <sub>RMS</sub> through variac to wire no. 1501 & 1502; Close the VCB; Interrupt the supply	
voltage	
The VCB goes off after 2 second time delay.	
Again supply 200 $V_{RMS}$ through variac to wire no. 1501 & 1502; Decrease the supply voltage below 140 $V_{RMS}$ $\pm$ 4 $V$ ; Fine tune the minimum voltage relay so that VCB opens.	(Xes/No)
4.5 Maximum current relay (Pos. 78)	
Disconnect wire 1521 & 1522 of primary current transform	
&1522 (including the resistor at Pos. 6.11); Put loco in simulation	
on contact 136.3; Close VCB; supply 3.6A <sub>RMS</sub> at the open w	ire 1521; Tune the drum of the

4.5 Maximum current relay (Pos. 78)			
Disconnect wire 1521 & 1522 of primary current transformer; Connect variac to wire 1521 & 1522 (including the resistor at Pos. 6.11); Put loco in simulation for driving mode; Open $R_3 - R_4$ on contact 136.3; Close VCB; supply 3.6A <sub>RMS</sub> at the open wire 1521; Tune the drum of the maximum current relay Pos. 78 for correct over current value;			
VCB opens with Priority 1 fault message on display.	MYes/No)		
Keep contact $R_3$ – $R_4$ of 136.3 closed; Close VCB; Tune the resistor /9.9 $A_p$ at the open wire 1521;	or 78.1 for the current of 7.0A <sub>RMS</sub>		
VCB opens with Priority 1 fault message on display.	U(Tes/No)		

Effective Date: Feb 2022

DOC.NO.F/ECS/UI (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39107

Type of Locomotive: WAP-7/WAG-9HC

Page: 14 of 27

4.6 Test current sensors		Prescribed value	Set/Measured
Name of the sensor	Description of the test	Prescribed value	value
Primary return current sensor (Test-1,Pos.6.2/1 & 6.2/2)	Activate cab in driving mode supply 10A. Measure the current through diagnostic tool or measuring print.	(Variation allowed is ± 10%)	
Primary return current	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		
sensor (Test-2, Pos.6.2/1 & 6.2/2)	Supply 297mA <sub>DC</sub> to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		299mg
Auxiliary winding current sensor (Pos. 42.3/1 & 42.3/2)	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AC/1or 2 pin no. 7(+) & 8(-)		
	Supply 333mA <sub>DC</sub> to the test winding of sensor through connector 415.AC/1 or 2 pin no. 7(+) & 8(-)		335mg
Harmonic filter current sensors (Pos.8.5/1 &8.5/2)	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AE/1or 2 pin no. 7(+) & 8(-)	,	
	Supply 342mA <sub>DC</sub> to the test winding of sensor through connector 415.AE/1or 2 pin no. 7(+) & 8(-)	-	348mm
Hotel load current sensors (Pos. 33/1 &	Switch on hotel load. Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)		
33/2)	Supply 1242mA <sub>DC</sub> to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)		1250mp

Effective Date: Feb 2022

Doc.No.F/ECS/01 b 2022 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39 407

Type of Locomotive: WAP-7/WAG-9HC

Page: 15 of 27

4.7 Test DC Link Voltage Sensors (Pos 15.6/\*)

This test is to be done by the commissioning engineer of the firm if required.

#### 4.8 Verification of Converter Protection Circuits (Hardware limits) -

This test is to be done as per para 6.17 of the document no. 3EHX 610 282 for both the converters.

Protection circuits	Limit on which shutdown should take place	Measured limit	
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 1	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 18.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=	01
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 2	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 8.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=	04
Fibre optic failure In Power Converter1	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	ok	
Fibre optic failure In Power Converter2	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	Ok	

#### 4.9 Sequence of BUR contactors

The sequence of operation of BUR contactors for 'ALL BUR OK' BUR 1 out BUR 2 out and BUR 3 out condition has to be verified by putting the Loco in driving mode (VCB should not be closed) and isolating the BURs one by one. In these condition following will be the contactor sequence.

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	Close	Open	Close	Open	Close	Open	Close	Close	Open
BUR1 off	Close	Open	Close	Close	Open	Close	Open	Open	Close
BUR2 off	Open	Open	Close	Close	Close	Close	Open	Open	Close
BUR3 off	Open	Close	Open	Close	Close	Close	Open	Open	Close

Effective Date: Feb 2022

2022 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

## Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 394.7

Type of Locomotive: WAP-7/WAG-9HC

Page: 16 of 27

#### Monitored contactor sequence

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	closs.	open	clos	open	clos	open	clos	clos	open
BUR1 off	clos	Open	c 208	close	open	clos	opas	Open	clo8
BUR2 off	open	open	close	clos	008	OF8	open	open	clos
BUR3 off	open	loge	open	close	closs	close	open	open	e9081

#### 5.0 Commissioning with High Voltage

#### 5.1 Check List

Items to be checked	Yes/No
Fibre optic cables connected correctly.	4es
No rubbish in machine room, on the roof, under the loco.	Yes
All the electronic Sub-D and connectors connected	9er
All the MCBs of the HB1 & HB2 open.	401
All the three fuses 40/* of the auxiliary converters	4es
The fuse of the 415/110V auxiliary circuit (in HB1) open.	Yes
Roof to roof earthing and roof to cab earthing done	4es
Fixing, connection and earthing in the surge arrestor done correctly.	4es
Connection in all the traction motors done correctly.	Yes
All the bogie body connection and earthing connection done correctly.	Yes.
Pulse generator (Pos. 94.1) connection done correctly.	4es
All the oil cocks of the gate valve of the transformer in open condition.	Yes .
All covers on Aux & Power converters, Filter block, HB1, HB2 fitted	Yes
KABA key interlocking system.	703

#### 5.2 Safety test main circuit breaker

Prepare to switch off the catenary supply during the first charging of the locomotive in case of any unexpected behavior of the electrical component of the loco. Charge the loco for the first time by closing BLDJ switch. The VCB will trip after certain time as no oil/coolant pumps are running yet.

Perform the following safety test of main circuit breaker through both the cabs of the locomotive.

Effective Date: Feb 2022

DOC.NO.F/ECS/VI (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC Page: 17 of 27

Name of the test	Description of the test	Expected result	Monitored result
Emergency stop in cooling mode	Raise panto in cooling mode. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	Checheol OK
Emergency stop in driving mode	Raise panto in driving mode in. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	Cheched
Under voltage protection in cooling mode	Raise panto in cooling mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open.	Cheched
Under voltage protection in driving mode	Raise panto in driving mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open with diagnostic message that catenary voltage out of limits	Checked OK
Shut down in cooling mode.	Raise panto in cooling mode. Close the VCB. Bring the BL- key in O position.	VCB must open. Panto must lower.	Checked
Shutdown in driving mode	Raise panto in driving mode. Close the VCB. Bring the BL-key in O position.	VCB must open. Panto must lower.	Checked
Interlocking pantograph- VCB in cooling mode	Raise panto in cooling mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	Checked O1<
Interlocking pantograph- VCB in driving mode	Raise panto in driving mode. Close the VCB. Lower the pantograph by ZPT		Cheched

Effective Date: Feb 2022

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

## <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 18 of 27

#### 5.3 Auxiliary Converter Commissioning

Switch on the high voltage supply and set up the loco in driving mode. Raise the panto. Close the VCB. Check that there is no earth fault in the auxiliary circuit, Switch off the VCB. Lower the panto. Create the earth fault in auxiliary circuit by making connection between wire no 1117(in HB2 cubicle) and earth. After 3 minutes a diagnostic message will come that "Earth fault auxiliary circuit."

5.3.1 Running test of 3 ph. auxiliary equipments

Switch on the 3 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured continuous phase current	Measured starting phase current
Oil pump transformer 1	9.8 amps	12:5	13.2
Oil pump transformer 2	9.8 amps	11.8	130
Coolant pump converter 1	19.6 amps	4.0	6.5
Coolant pump converter 2	19.6 amps	4.0	6.4
Oil cooling blower unit 1	40.0 amps	35.7	16000
Oil cooling blower unit 2	40.0 amps	32.0	16500
Traction motor blower 1	34.0 amps	32.5	150:0
Traction motor blower 2	34.0 amps	31.4	140.0
Sc. Blower to Traction motor blower 1	6.0 amps	3.5	1810
Sc. Blower to Traction motor blower 1	6.0 amps	3.2	160
Compressor 1	25 amps at 0 kg/cm <sup>2</sup> 40 amps at 10 kg/cm <sup>2</sup>	29.5	130.0
Compressor 2	25 amps at 0 kg/ cm <sup>2</sup> 40 amps at 10 kg/ cm <sup>2</sup>	31.4	1350

Effective Date: Feb 2022

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

## Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 38407

Type of Locomotive: WAP-7/WAG-9HC

Page: 19 of 27

### **5.3.2 Performance of Auxiliary Converters**

Measure the performance of the auxiliary converters through software and record it.

BUR1 (Condition: Switch off all the load of BUR 1)- to be filled by commissioning engineer

of the firm.

Signal name	Description of the signal	Prescribed value	Monitored value	Value under Limit (Yes/No)
BUR1 7303 XUUN	Input voltage to BUR1	75% (10%=125V)	10040	Yey
BUR1 7303 XUUZ1	DC link voltage of BUR1	60% (10%=100V)	637V	Yey
BUR1 7303 XUIZ1	DC link current of BUR1	0% (10%=50A)	1 Amp	los

BUR2 (Condition: Switch off all the load of BUR 2, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value by the firm	Monitored value	Value under Limit (Yes/No)
BUR2 7303-XUUN	Input voltage to BUR2	75% (10%=125V)	100CV	K,
BUR2 7303-XUUZ1	DC link voltage of BUR2	60% (10%=100V)	6374	Yen
BUR2 7303-XUIZ 1	DC link current of BUR2	1% (10%=50A)*	7 Amb	Yes
BUR2 7303-XUILG	Current battery charger of BUR2	3% (10%=100A)*	21 Anj	Ney .
BUR2 7303-XUIB1	Current battery of BUR2	1.5%(10%=100A)*	[18mg	Yes
BUR2 7303 -XUUB	Voltage battery of BUR2	110%(10%=10V)	1/04	Yes

<sup>\*</sup> Readings are dependent upon charging condition of the battery.

BUR3 (Condition: Switch off all the load of BUR 3, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed set value by the firm	Monitored value	Value under limit (Yes/No)
BUR3 7303-XUUN	Input voltage to BUR3	75% (10%=125V	10054	Yes
BUR3 7303- XUUZ1	DC link voltage of BUR3	60% (10%=100V)	6371	tes
BUR3 7303-XUIZ 1	DC link current of BUR3	1% (10%=50A)*	7 Amp	Yey
BUR3 7303-XUILG	Current battery charger of BUR 3	3% (10%=100A)*	2/Amp	169
BUR3 7303-XUIB1	Current battery of BUR 3	1.5%(10%=100A)*	1) Amj	Yes
BUR3 7303-XUUB	Voltage battery of BUR 3	110%(10%=10V)	110~	Yey

\* Readings are dependent upon charging condition of the battery.

Effective Date: Feb 2022

(Ref: WI/ECS/10)

### PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC Page: 20 of 27

Doc.No.F/ECS/UT

5.3.3 Performance of BURs when one BUR goes out

When any one BUR goes out then rest of the two BURs should take the load of all the

auxiliaries at ventilation level 3 of the locomotive.

Condition of BURs	Loads on BUR1	Loads in BUR2	Loads in BUR3
All BURs OK	Oil Cooling unit 1&2	TM blower1&2, TFP oil pump 1&2, SR coolant pump 1&2.	Compressor 1&2, Battery of charger and TM Scavenger blower 1&2
BUR 1 out		Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2,TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 2 out	Oil Cooling unit 1&2, TM blower 1&2, TM Scavenger blower 1&2		Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 3 out	Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.	

5.4 Auxiliary circuit 415/110

For checking earth fault detection, make a connection between wire no. 1218 and vehicle body. On switching on VCB, Earth fault relay 89.5 must pick up and after 3 minutes a message will come in the Diagnostic display that Earth Fault 415/110V Circuit

Switch on the 1 ph. auxiliary equipment one by one. Check the direction of rotation of each

Name of the auxiliary machine	Typical phase current	Measured phase current	Measured starting current
Machine room blower 1	15.0 amps*	4.5	160
Machine room blower 2	15.0 amps*	4.5	17.0
Sc. Blower to MR blower 1	1.3 amps	3.7	3,8
Sc. Blower to MR blower 2	1.3 amps	1.4	3.5
Ventilator cab heater 1	1.1 amps	1.5	1.9
Ventilator cab heater 2	1.1 amps	1.5	1.9
Cab heater 1	4.8 amps	5.3	2.2
Cab heater 2	4.8 amps	5.3	5.5

For indigenous MR blowers.

Effective Date: Feb 2022

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39467

Type of Locomotive: WAP-7/WAG-9HC

Page: 21 of 27

### 5.5 Hotel load circuit (Not applicable for WAG-9HC)

For WAP-7 locomotive with Hotel load converter refer to Annexure-HLC

#### 5.6 Traction Converter Commissioning

#### This test is carried out in association with Firm.

Traction converter commissioning is being done one at a time. For testing Converter 1, switch off the traction converter 2 by switch bogie cut out switch 154. For testing Converter 2, switch off the traction converter 2 by switch bogie cut out switch 154. Isolate the harmonic filter also by switch 160. Start up the loco by one converter. Follow the functionality tests.

#### For Converter 1

Test Function	Results desired	Result obtained
Measurement of charging and precharging and charging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked ox
Measurement of discharging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked Olz
Earth fault detection on positive potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Chechedok
Earth fault detection on negative potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Cheched ox
Earth fault detection on AC part of the traction circuit of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked ok
Pulsing of line converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked Ole
Pulsing of drive converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked OK

Effective Date: Feb 2022

DOC.NO.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC Page: 22 of 27

For Converter 2			
Test Function	Results desired in sequence	Result obtained	
charging and pre- charging and charging	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked OK	
Measurement of discharging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked OK	
positive potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked ox	
negative potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/v	Cheched OK	
AC part of the traction circuit of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked OK	
of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked ok	
Pulsing of drive converter of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Chechood ox	

Effective Date: Feb 2022

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 23 of 27

#### 5.7 Test protective shutdown SR

Test Function	Results desired in sequence	Result obtained
Measurement of protective shutdown by Converter 1 electronics.	Start up the loco with both the converter. Raise panto. Close VCB.  Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 1Check that converter 1 electronics produces a protective shut down.  • VCB goes off  • Priority 1 fault mesg. on DDU appears	Checked 012
Measurement of	Start up the loco with both the	
protective shutdown by Converter 2 electronics.	converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 2. Check that converter 2 electronics produces a protective shut down.  • VCB goes off • Priority 1 fault mesg. on diagnostic	Checked OK
	display appears  Disturbance in Converter 2	

#### 5.8 Test Harmonic Filter

Switch on the filter by switch 160

Test Function	Results desired in sequence	Result obtained	
Measurement of filter currents	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Apply a small value of TE/BE by moving the throttle.  • FB contactor 8.41 must open.	Cheched ok	

Effective Date: Feb 2022

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 24 of 27

	<ul> <li>FB contactor 8.2 must close.</li> <li>FB contactor 8.1 must close</li> <li>Check the filter current in diagnostic laptop</li> <li>Bring the TE/BE throttle to O</li> <li>Switch off the VCB</li> <li>FB contactor 8.1must open.</li> <li>FB discharging contactor 8.41 must close</li> <li>Check the filter current in diagnostic laptop</li> </ul>	Cheeked OK
Test earth fault detection harmonic filter circuit.	Make a connection between wire no. 12 and vehicle body. Start up the loco. Close VCB.  • Earth fault relay 89.6 must pick up.  • Diagnostic message comes that - Earth fault in harmonic filter circuit	Cheched ox
Test traction motor speed sensors for both bogie in both cabs	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	OK

#### 5.9 Test important components of the locomotive

Items to be tested	Description of the test	Monitored value/remarks	
Speedometer	VCU converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	Checked ox	
Time delay modulé of MR blower	The time after which the starting capacitor for MR blower should go off the circuit should be set to 10-12 seconds	Cheched or	
Ni-Cd battery voltage	At full charge, the battery voltage should be 110V DC.	Cheched OK	
Flasher light	From both cab flasher light should blink at least 65 times in one minute.	Cheched ox	
Head light	Head light should glow from both cabs by operating ZLPRD. Dimmer operation of headlight should also occur by operating the switch ZLPRD.	Cheched ox	

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 25 of 27

Marker light	Both front and tail marker light should glow from both the cabs	Chechedok
Cab Light	Cab light should glow in both the cabs by operating the switch ZLC	Checked OK
Spot lights	Both Drivers and Asst. Drivers Spot light should glow in both cabs by operating ZLDD	Chapted 012 Chapted 014
Instrument lights	Instrument light should glow from both cab by operating the switch ZLI	(haped of
Illuminated Push button	All illuminated push buttons should glow during the operation	Checked ok
Contact pressure of the high rating contactors	The contact pressure of FB contactors (8.1, 8.2) is to be measured  Criteria:  The minimum contact pressure is 54 to 66  Newton.	For contactor 8.1: For contactor 8.2:
Crew Fan	All crew fans should work properly when VCB of the loco is switched on. The airflow from each cab fan is to be measured.  Criteria:  The minimum flow of air of cab fan should be 25 m³/minute	Cab 1 LHS: Cab 1 RHS: Cab 2 LHS: Cab 2 RHS:

## **6.0** Running **Trial of the locomotive**

SN	Description of the items to be seen during trail run	Action which should take place	
1	Cab activation in driving mode	No fault message should appear on the diagnostic panel of the loco.	eched
	Loco charging	Loco to be charged and all auxiliaries should run.  No fault message to appear on the diagnostic panel of the loco. Raise MR pressure to 10 Kg/cm <sup>2</sup> , BP to 5 Kg/cm <sup>2</sup> , FP to 6 Kg/cm <sup>2</sup> .	eched
3.	Check function of Emergency push stop.	This switch is active only in activated cab By	eched
4.	Check function of BPCS.	<ul> <li>Beyond 5 kmph, press BPCS, the speed of loco should be constant.</li> <li>BPCS action should be cancelled by moving TE/BE throttle, by dropping BP below 4.75</li> <li>Kg/cm<sup>2</sup>, by pressing BPCS again.</li> </ul>	cken. ok
5.	Check train parting operation of the Locomotive.	Operate the emergency cock to drop the BP Pressure LSAF should glow.	ked 015

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 26 of 27

6.	Check vigilance	Set the speed more than 1.5 kmph and ensure that	
	operation of the	brakes are released i.e. BC < 1 Kg/cm <sup>2</sup> .	}
	locomotive	For 60 seconds do not press vigilance foot switch or	
	,	sanding foots switch or TE/BE throttle or BPVG	
	·	switch then	
	,	• Buzzer should start buzzing. ( No.	oched
		LSVW should glow continuously.	0/2
		Do not acknowledge the alarm through BPVG or	\$
		vigilance foot switch further for 8 seconds then:-	
		Emergency brake should be applied	
		automatically.	
		VCB should be switched off.	
		Resetting of this penalty brake is possible only after	1.
		32 seconds by bringing TE/BE throttle to 0 and	
		acknowledge BPVR and press & release vigilance	
		foot switch.	
7.	Check start/run interlock	• At low pressure of MR ( $< 5.6 \text{ Kg/cm}^2$ ).	eched of
		With park brake in applied condition.	NA
		• With direct loco brake applied (BP< 4.75Kg/cm <sup>2</sup> ).	'`
		• With automatic train brake applied (BP<4.75Kg/cm <sup>2</sup> ).	hecked
		• With emergency cock (BP < 4.75 Kg/cm <sup>2</sup> ).	0K
8.	Check traction interlock	Switch of the brake electronics. The	
		Tractive /Braking effort should ramp down, VCB	Checkes
		should open and BP reduces rapidly.	OK
9.	Check regenerative	Bring the TE/BE throttle to BE side. Loco speed	eched
	braking.	should start reducing.	OL
10.	Check for BUR	In the event of failure of one BUR, rest of the two	
	redundancy test at	BURs can take the load of all the auxiliaries. For this $\mathcal{C}_{h}$	ches
	ventilation level 1 & 3 of	switch off one BUR.	014
	loco operation	Auxiliaries should be catered by rest of two BURs.	'
44		Switch off the 2 BURs; loco should trip in this case.	
11.	Check the power	Create disturbance in power converter by switching	
	converter	off the electronics. VCB should open and converter CN	ecked UK
	isolation test		OK
		another power converter.	

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 39407

Type of Locomotive: WAP-7/WAG-9HC

Page: 27 of 27

## 7.0 Final check list to be verified at the time of Loco dispatch

Condition /Operations of the following items are to be checked:

SN	Item	Cab-1	Cab-2	Remarks
1	Head lights	01-	Ok	
2	Marker Red	014	Or	
3	Marker White	012	0/2	
4	Cab Lights	014	OK	
. 5	Dr Spot Light	OK	OK	
6	Asst Dr Spot Light	OŁ	ok	Checked Working OK
7	Flasher Light	OK	0k	8
8	Instrument Lights	OF	OK	
9	Corridor Light	QL.	OK	
10	Cab Fans	OK	OK	
11	Cab Heater/Blowers	OK	OŁ	
12	All Cab Signal Lamps Panel 'A'	01-	OK	

#### PATIALA LOCOMOTIVE WORKS, PATIALA

## Testing & Commissioning Format for 2x500KVA IGBT based Hotel Load Converter for 3-phase Electric Locomotives

Locomotive No.: <u>दुव्य ०न</u>	Page: 1 of 6
ype of Locomotive: <u>ゅみや</u> す	
Make of Hotel Load Converter:	•
Potails of Equipment:	•

Equipment	SI. No	Equipment	SI. No
HLC1	0824040137	IV Coupler CAB1 ALP	_
HLC2	0824040138	IV Coupler CAB1 LP	
Converter-1	0824040137	IV Coupler CAB2 ALP	
Converter-2	0824040138	IV Coupler CAB2 LP	
UIC Coupler for Hotel Load Converter (353.3/2 CAB2)	_	UIC Coupler for Hotel Load Converter (353.3/3 CAB1)	

## 1. Polarity test of Hotel Load Winding:

Apply 198 /140 to the primary winding of the transformer (at 1U; wire no. 2 at surge arrestor and at 1V; wire no. 100 at earthing choke). Measure the output voltage and compare the phase of the following of the transformer.

Output Winding Nos.	Description of winding	Prescribed Output Voltage &Polarity with input supply	Measured Output	Measured Polarity
2UH1 & 2VH1	For Hotel load between cable 91- 94	5.9 ,4.2 and same polarity	u	OJC
2UH2 & 2VH2	For Hotel load between cable 91A- 94A	5.9 ,4.2 and same polarity	gr.	or_

Page: 2 of 6

### 2. Visual Inspection:

#### Fitment of Units and Earthing to Sub-assemblies

Verify the following Equipments Fitment and grounding cables are connected to Locomotive body.

SI. No.	Equipment Name	Unit Fitment (Yes/No)	Provision of Earthing (Yes/No)
1	HLC1	ryes	yes
2	HLC2	yes	yes
3	Output Contactor unit1 HLC1	yes	yes
4	Output Contactor unit2 HLC2	yes	yes
5	IV Coupler CAB1 ALP	yes	yes
6	IV Coupler CAB1 LP	yes	yes
7	IV Coupler CAB2 ALP	yes	yes
8	IV Coupler CAB2 LP	yes	yes
9	UIC Coupler for Hotel Load Converter (353.3/3 CAB1)	yes	yes
10	UIC Coupler for Hotel Load Converter (353.3/2 CAB2)	yes	Her
11	CT (LEM sensor) under HLC1	yes	yes
12	CT(LEM sensor) under HLC2	yes	Mer

Page: 3 of 6

### 3. Cable Routing and Laying

#### 3.1 Control cable routing and layout

Verify the connections, tightness and cable routing of the following Control cable.

SI. No.	Cables Details	Performed (Yes/No)
1	From Wago SB1 to HLC1 are connected as per wiring format	ryee
2	From SB1 to UIC Coupler Hotel Load Converter (353.3/3 CAB2) through Bayonet connector XK22HL:01(22pin)is connected as per wiring format	yes
3	From SB1 wago(XF22S:01/53) to IV coupler CAB1 ALP are connected as per wiring format	yes
4	From SB1 wago(XF22S:01/54) to IV coupler CAB1 LP are connected as per wiring format	yes
5	From Wago SB2 to HLC2 are connected as per wiring format	yes
6	From SB2 to UIC Coupler Hotel Load Converter (353.3/2 CAB2) through Bayonet connector XK77HL:02 (22 pin) is connected as per wiring format	yes
7	From SB2 wago (XF77S:01/53) to IV coupler CAB2 ALP are connected as per wiring format	yes
8	From SB2 wago (XF77S:01/54) to IV coupler CAB2 LP are connected as per wiring format	yes
9	From HLC1 to Contactor unit 1 through 4 Core Cable are connected as per wiring format	yes
10	From HLC2 to Contactor unit 2 through 4 Core Cable are connected as per wiring format	yer
11	From SB to VCU are connected as per wiring format	yel
12	From CT (HLC1 LEM sensor) to SR1 are connected as per wiring format	yel yel
13	From CT (HLC2 LEM sensor) to SR2 are connected as per wiring format	yee

#### 3.2 Power cable routing and layout

Verify the connections, tightness and cable routing of the following Power cable.

SI.	Cables Details	Performed	
No.		Yes/No)	
1	From Transformer to HLC1(2UH1 & 2VH1) are connected as per wiring format	ryll	
2	From Transformer to HLC2(2UH2 &2VH2) are connected as per wiring format	yes	
3	From HLC1 to Output Contactor unit1 are connected as per wiring format	yes	
4	From HLC 2 to Output Contactor unit 2 are connected as per wiring format	yes	
5	From Output Contactor unit 1 to IV Coupler CAB1 ALP and IV Coupler CAB2ALP through Junction box are connected as per wiring format	zee	
6	From Output Contactor unit 2 to IV Coupler CAB2 LP and IV Coupler CAB1 LP through Junction box are connected as per wiring format	yes	

### 4. Continuity test:

Check the continuity test for the External connections made to Equipments.

Note: This continuity test should be done before power ON the Locomotive Battery.

#### 4.1 Control cable continuity

SI. No.	Cables Details	Performed (Yes/No)
1	From Wago SB1 to HLC1 are connected as per wiring format	yes
2	From SB1 to UIC Coupler Hotel Load Converter (353.3/3 CAB2) through Bayonet connector XK22HL:01(22pin)is connected as per wiring format	yes
3	From SB1 wago(XF22S:01/53) to IV coupler CAB1 ALP are connected as per wiring format	yes
4	From SB1 wago(XF22S:01/54) to IV coupler CAB1 LP are connected as per wiring format	yls
5	From Wago SB2 to HLC2 are connected as per wiring format	748
6 7	From SB2 to UIC Coupler Hotel Load Converter (353.3/2 CAB2) through Bayonet connector XK77HL:02(22pin) is connected as per wiring format	yes
	connected as per wiring format	yes
8	From SB2 wago(XF77S:01/54) to IV coupler CAB2 LP are connected as per wiring format	yer
9	From HLC1 to Contactor unit 1 through 4 Core Cable are connected as per wiring format	yer
10	From HLC2 to Contactor unit 2 through 4 Core Cable are connected as per wiring format	yee
11	From SB to VCU are connected as per wiring format	
12	From HLC1 LEM sensor to SR1 are connected as per wiring format	yee
13	From HLC2 LEM sensor to SR2 are connected as per wiring format	yee

Page: 5 of 6

#### 4.2 Power cable continuity

These cables continuity should be checked before mounting of converter in the locomotive.

SI. No.	Cables Details	Performed (Yes/No)
1	From Transformer to HLC1(2UH1 & 2VH1) are connected as per wiring format	yes
2	From Transformer to HLC2(2UH2 &2VH2) are connected as per wiring format	yes
3	From HLC1 to Output Contactor unit1 are connected as per wiring format	yer
4	From HLC 2 to Output Contactor unit 2 are connected as per wiring format	yes
5	From Output Contactor unit 1 to IV Coupler CAB1 ALP and IV Coupler CAB2ALP through Junction box are connected as per wiring format	zes
6	From Output Contactor unit 2 to IV Coupler CAB1 LP and IV Coupler CAB2 LP through Junction box are connected as per wiring format	yes

#### 5. Battery power ON

#### **Tests Supply Voltages**

Remove all Control cable connectors (Analog and Digital Input/output connectors) from HLC1, HLC2. While Switch ON Battery supply observe is there any MCBs tripping. Wait for one or two minutes after switching ON Circuit breaker(MCB1) and observe for any overheating symptoms like smell, smoke, temperature etc. from the wire bunches. If any such symptoms are noticed, there might be a short circuit in the wire bunch. Check up once again continuity wherever suspected. After that check the Voltage levels at all equipments connectors as mentioned below.

Test Details	Acceptance	Observations
Voltage Level at HLC1:  I. Between wago terminal XF22S:03/54 and XF22S:03/58  II. Between wago terminal XF22S:03/53 and XF22S:03/58	~110VDC	OK
Voltage Level at HLC2: I. Between wago terminal XF77S:03/52 and XF77S:03/56 II. Between wago terminal XF77S:03/51 and XF77S:03/56	~110VDC	SL

**Note:** After Above tests switch off the Power and restore all removed connectors and once again switch ON the 110 V Supply and ensure that no MCB tripping due to abnormality.

Page: 6 of 6

#### 6. Converter operation (ON/OFF) test

Power supply is directly available to the Hotel Load Converter via Hotel Load Converter winding (2UH1-2VH1) and (2UH2-2VH2). As soon as BLDJ is closed power will be available to the Hotel Load Converter. Connect the test jig of Hotel Load Converter to the UIC and IV Coupler. Charge the locomotive and switch on the BLHO, LSHO indication should glow. Hotel Load Converter screen will show message "waiting for ON command". One by one Hotel Load Converter can be switched on by test jig. Finally both the Hotel Load Converter should be turned out simultaneously. Observe the flow of air from the air duct, this will ensure that Hotel Load Converter is ON. Both the Hotel Load Converters are ON, then voltage and frequency should be measured as per the table below:-

#### Converters should run without any irregularities.

Hotel Load Converter 1						
•	Output Voltage	Output Frequency				
U-V	V-W	U-W	(Hz)			
Oyc	W.	V-	UL			

Hotel Load Conver	ter 2		****
	Output Voltage		Output Frequency
U-V	V-W	U-W	(Hz)
- aL	0 VL	ð N	au.

#### 7. Earth Fault Test

- 7.1 Input Earth Fault:-Ground the input terminal of the Hotel Load Converter using a proper resistance and then turn on the Hotel Load Converter. The converter should trip with the message "Input earth fault".
- **7.2 Output Earth Fault:** Ground the output terminal of the Hotel Load Converter using a proper resistance and then turn on the Hotel Load Converter. The converter should trip with the message "Output earth fault".

Note: These to be done for the both the converters (HLC1 and HLC2) separately.

## Status of RDSO modifications

LOCO NO: 39 40 7

Sn	Modification No.	Description	Remarks
1.	RDSO/2008/EL/MS/0357 Rev.'0' Dt 20.02.08	Modification in control circuit of Flasher Light and Head Light of three phase electric locomotives.	Ok/Not Ok
2.	RDSO/2009/EL/MS/0377 Rev.'0' Dt 22.04.09	Modification to voltage sensing circuit in electric locomotives.	Ok/Not Ok
3.	RDSO/2010/EL/MS/0390 Rev.'0' Dt 31.12.10	Paralleling of interlocks of EP contactors and Relays of three phase locomotives to improve reliability.	Ok/Not Ok
4.	RDSO/2011/EL/MS/0399 Rev.'0' Dt 08.08.11	Removal of interlocks of control circuit contactors no. 126 from MCPA circuit.	Ok/Not Ok
5.	RDSO/2011/EL/MS/0400 Rev.'0' Dt 10.08.11	Modification sheet for shifting the termination of \$GKW, 1.8 KV, 70 sq mm cables and 2x2.5 sq mm cables housed in lower portion of HB2 panel and provision of Synthetic resin bonded glass fiber sheet for three phase locomotives.	Ók/Not Ok
6.	RDSO/2011/EL/MS/0401 Rev.'0' Dt 10.08.11		Ök/Not Ok
7.	RDSO/2011/EL/MS/0403 Rev.'0' Dt 30.11.11	Auto switching of machine room/corridor lights to avoid draining of batteries in three phase electric locomotives.	Ok/Not Ok
8.	RDSO/2012/EL/MS/0408 Rev.'0'	Modification of terminal connection of heater cum blower assembly.	Ok/Not Ok
9.	RDSO/2012/EL/MS/0411 Rev.'1' dated 02.11.12	White and Red marker light in three phase electric locomotives.	Ok/Not Ok
10	RDSO/2012/EL/MS/0413 Rev.'1' Dt 25.04.16	contactors of three phase locomotives to improve reliability	Ok/Not Ok
11	RDSO/2012/EL/MS/0419 Rev.'0' Dt 20.12.12	Modification sheet to provide rubber sealing gasket in Master Controller of three phase locomotives.	OK/Not Ok
12 ·	RDSO/2013/EL/MS/0420 Rev.'0' Dt 23.01.13	Modification sheet to provide mechanical locking arrangement in Primary Over Current Relay of three phase locomotives.	Ok/Not Ok
13 	RDSO/2013/EL/MS/0425 Rev.'0' Dt 22.05.13	Modification sheet for improving illumination of head light in dimmer mode in three phase electric locomotives.	Ok/Not Ok
14	RDSO/2013/EL/MS/0426 Rev.'0' Dt 18.07.13	Modification sheet of Bogie isolation rotary switch in three phase electric locomotives.	Ok/Not Ok
15	RDSO/2013/EL/MS/0427 Rev.'0' Dt 23.10.13	Modification sheet for MCP control in three phase electric locomotives.	Ok/Not Ok
16	RDSO/2013/EL/MS/0428 Rev. 0' Dt 10.12.13	Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.	Ok/Not Ok
	RDSO/2014/EL/MS/0432 Rev.'0' Dt 12.03.14	Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.	Ok/Not Ok
18	RDSO/2017/EL/MS/0464 Rev.'0' Dt 25.09.17	Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.	bk/Not Ok
19	RDSO/2017/EL/MS/0467 Rev.'0' Dt 07.12.17	Modification in blocking diodes to improve reliability in three phase electric locomotives.	Ok/Not Ok
20	RDSO/2018/EL/MS/0475 Rev.'0'	Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.	Ok/Not Ok
21	RDSO/2019/EL/MS/0477 Rev.'0' Dt 18.09.19	Implementation of push pull scheme.	6k/Not Ok

Signature of JE/SSE/ECS

Loco No.: 39407

## PLW/PATIALA

## PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

SN	Parameters	Reference	Value	Result
	Brake Panel: Faiveley			
1.0	Auxiliary Air supply system (Pantograph & VCB)			
1.1	Ensure, Air is completely vented from pantograph			0
	Reservoir (Ensure Panto gauge reading is Zero)			
1.2	Turn On BL Key. Now MCPA starts.		60 sec. (Max.)	55
	Record pressure Build up time (8.0 kg/cm2)			
1.3	Auxiliary compressor safety Valve 23F setting	Faiveley Doc. No.	8.5±0.25kg/cm2	8.6
		DMTS-014-1, 8 CLW's	-	
		check sheet no.		
		F60.812 Version 2		
1.4	Check VCB Pressure Switch Setting	CLW's check sheet	Opens 4.5±0.15	4.55 Kg/cm2
		no. F60.812 Version 2	kg/cm2, closes	
			5.5±0.15 kg/cm2	5.55 Kg/cm2
1.5	Set pantograph Selector Switch is in Auto, Open pan-1&2 Is	olating Cocks & KABA co	ock by Key (KABA Key	)
1.6	Set Cab-1 Pan UP in Panel A.		Observed Pan-2	ОК
			Rises.	
1.7	Close Pan-2 isolating Cock		Panto-2 Falls Down	ОК
	Open Pan -2 isolating Cock		Panto-2 Rises	
1.8	Record Pantograph Rise time		06 to 10 seconds	7 Sec
1.9	Record Pantograph Lowering Time		06 to 10 seconds	7 Sec
1.10	Panto line air leakage		0.7 kg/cm2 in 5	0.2 kg/cm2
			Min.	in 5 Min.
1.11	High Reach Panto emergency test and reset.		-NA-	-NA-
2.0	Main Air Supply System			
2.1	Ensure, Air is completely vented from locomotive. Drain	Theoretical		
	out all the reservoirs by opening the drain cocks and then	calculation and		
	closed drain cocks. MR air pressure build up time by each	test performed by		
	compressor from 0 to 10 kg/cm2.	Railways.		
	i) with 1750 LPM compressor		i) 7 mins Max.	6 min. & 35
	ii) with 1450 LPM compressor		ii) 8.5 mins Max.	sec.
2.2	Drain air below MR 8 kg/cm2 to start both the		Check Starting of	ok
	compressors		both compressors	
2.3	Drain air from main reservoir up to 7 kg/cm2. Start		30 Sec. (Max)	CP1-28 Sec
	compressors, Check pressure build time of individual			
	compressor from 8 kg/cm2 to 9 kg/cm2			CP2-28 Sec
2.4	Check Low MR Pressure Switch Setting (37)	D&M test spec.	Closes at 6.40±0.15	6.40 Kg/cm2
		MM3882 &	kg/cm2 Opens at	
		MM3946	5.60±0.15kg/cm2	5.60 Kg/cm2
2.5	Check compressor Pressure Switch RGCP setting (35)	D&M test spec.	Opens at 10±0.20	10.0 Kg/cm2
		MM3882 &	kg/cm2, Closes at	
		MM3946	8±0.20 kg/cm2	8.0 Kg/cm2
2.6	Run both the compressors Record Pressure build up time	Trial results	3.5 Minutes Max.	3.2 minute

## PLW/PATIALA

Loco No.: 39407

2.8 Check Auto Drain Valve functioning (124 & 87)  2.9 Check CP-I delivery safety valve setting (10/1). Run CP Direct by BLCP.  2.10 Check CP-2 delivery safety valve setting (10/2). Run CP direct by BLCP  2.11 Switch 'OFF' the compressors and ensure that the safety valve to reset at pressure 1.2 kg/cm2 less than opening pressure.  2.12 BP Pressure: Switch 'OFF' compressor, Drain MR Pressure by drain cock of 1" Main Reservoir, Start Compressor, check setting pressure of Duplex Check Valve 92F.  2.13 FP pressure: If Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.  3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  5.0 Brake Test (Automatic Brake Operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step	O sec ok 11.55 g/cm2 11.55
2.9   Check CP-I delivery safety valve setting (10/1). Run CP   D&M test spec.   MM3882 & MM3946   kg/cm2   kg/cm2   check CP-2 delivery safety valve setting (10/2). Run CP   D&M test spec.   MM3882 & MM3946   kg/cm2	g/cm2
Direct by BLCP.  Check CP-2 delivery safety valve setting (10/2). Run CP direct by BLCP  D&M test spec. 11.50±0.35 kg/cm2  D&M test spec. MM3882 & MM3946  D&M special	
direct by BLCP  Switch 'OFF' the compressors and ensure that the safety valve to reset at pressure 1.2 kg/cm2 less than opening pressure.  2.12 BP Pressure: Switch 'OFF' compressor, Drain MR Pressure by drain cock of 1" Main Reservoir, Start Compressor, check setting pressure of Duplex Check Valve 92F.  2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.  3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step	L1.55
2.11 Switch 'OFF' the compressors and ensure that the safety valve to reset at pressure 1.2 kg/cm2 less than opening pressure.  2.12 BP Pressure: Switch 'OFF' compressor, Drain MR Pressure by drain cock of 1" Main Reservoir, Start Compressor, check setting pressure of Duplex Check Valve 92F.  2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.  3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  D&M test spec. MM3882 & MM3946  D&M test spec. Should be less than 1 kg/cm2 in 15 minutes  Kg/m  5.0 Brake Test (Automatic Brake operation)  Record Brake Pipe & Brake Cylinder pressure at Each Step	
valve to reset at pressure 1.2 kg/cm2 less than opening pressure.  2.12 BP Pressure: Switch 'OFF' compressor, Drain MR Pressure by drain cock of 1" Main Reservoir, Start Compressor, check setting pressure of Duplex Check Valve 92F.  2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.  3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2 nd MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  D&M test spec. MM3882 & MM3946  SERVICT OF SERVIC	g/cm2
by drain cock of 1" Main Reservoir, Start Compressor, check setting pressure of Duplex Check Valve 92F.  2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.  3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  D&M test spec. MM3882 & MM3946  D&M te	
2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.  3.0 Air Dryer Operation  3.1 Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step  CLW's check sheet no. F60.812 Version 2  6.0 6.0±0.20kg/cm2 6.0 F60.812 Version 2  6.0 Brown in CLW's check sheet no. F60.812 Version 2  6.0 Brown in CLW's check sheet no. F60.812 Version 2  6.0 Brown in CLW's check sheet no. F60.812 Version 2  F60.812 Version 2  6.0 Brown in CLW's check sheet no. F60.812 Version 2  F60.812 Vers	Kg/cm2
3.1 Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step	Kg/cm2
open for Test Check Air Dryer Towers to change.  3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step	
3.2 Check Purge Air Stops from Air Dryer at Compressor stops  3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  5.0 Check BP Air leakage (isolate BP charging cock-70)  Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step	ok
3.3 Check condition of humidity indicator  4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step	
4.0 Main Reservoir Leakage Test  4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step	
4.1 Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.  4.2 Check BP Air leakage (isolate BP charging cock-70)  5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step  D&M test spec. MM3882 & MM3946  D&M	Blue
leakage from both cabs.   MM3882 & MM3946   than 1 kg/cm2 in 15 minutes   15 minu	
4.2 Check BP Air leakage (isolate BP charging cock-70)  D&M test spec. MM3882 & MM3946  D&M test spec. MM3882 & MM3946  S.O Brake Test (Automatic Brake operation)  S.1 Record Brake Pipe & Brake Cylinder pressure at Each Step	0.20 cm2 in ninutes
5.0 Brake Test (Automatic Brake operation)  5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step	).05 m2 in 5 nutes
5.1 Record Brake Pipe & Brake Cylinder pressure at Each Step	
Check proportionality of Auto Brake system  CLW's check sheet no. F60.812 Version 2	
Auto controller position  BC (WAG-9 & WAG-7)  Kg/cm2  BC (WAP-5)  Kg/cm2	
BP Pressure kg/cm2 Value Result Value F	esult
Run 5±0.1 <b>5.05 Kg/cm2</b> 0.00 <sub>0.00 Kg/cm2</sub> 0.00	-
Initial 4.60±0.1 4.6 Kg/cm2 0.40±0.1 <sub>0.35Kg/cm2</sub> 0.75±0.15	-
Full service 3.35±0.2 <b>3.4 Kg/cm2</b> 2.50±0.1 <sub>2.5Kg/cm2</sub> 5.15±0.30	-

## PLW/PATIALA

Loco No.: 39407

5.2	Record time to BP pressure drop to 3.5 kg/cm2 Ensure	D&M test spec.	8±2 sec.	8 Sec
	Automatic Brake Controller handle is Full Service from Run	MM3882 & MM3946		
5.3	Operate Asst. Driver Emergency Cock,	D&M test spec.	BP pressure falls	
		MM3882 & MM3946	to Below 2.5	ОК
			kg/cm2	
5.4	Check brake Pipe Pressure Switch 69F operates	CLW's check sheet no.	Closes at BP	
		F60.812 Version 2	4.05- 4.35	4.15Kg/cm2
			kg/cm2	
			Opens at BP	
			2.85- 3.15	3.0Kg/cm2
			kg/cm2	
5.5	Move Auto Brake Controller handle from Running to	D&M test spec.		
	Emergency BC filling time from 0.4 kg/cm2 i.e. 95% of	MM3882 & MM3946		
	Max. BC developed			
	WAP5 – BC 5.15 $\pm$ 0.3 kg/cm2 apply time		4±1 sec.	
	WAP7 - BC 2.50 ± 0.1 kg/cm2		7.5±1.5 sec.	8 sec
	WAG9 - BC 2.50 ± 0.1 kg/cm2		21±3 sec.	
5.6	Move Auto Brake Controller handle to full service and	D&M test spec.		
	BP pressure 3.5 kg/cm2. Move Brake controller to	MM3882 & MM3946		
	Running position BC Release time to fall BC Pressure			
	up to 0.4 kg/cm2 i.e. 95% of Max. BC developed			
	BC release Time			
	WAP7		17.5±2.5 sec.	18 sec.
	WAG9		52±7.5 sec.	
5.7	Move Auto Brake Controller handle to Release, Check	CLW's check sheet no.	60 to 80 Sec.	75 Sec
	BP Pressure Steady at 5.5±0.2 kg/cm2 time.	F60.812 Version 2		
5.8	Auto Brake capacity test : The capacity of the A9 valve	RDSO Motive power	BP pressure	
	in released condition must conform to certain limit in	Directorate report no.	should not fall	
	order to ensure compensation for air leakage in the	MP Guide No. 11 July,	below 4.0	
	train without interfering with the automatic	1999 Rev.1	kg/cm2 with in	4.65
	functioning of brake.		60 Sec.	Kg/cm2
	* Allow The MR pressure to build up to maximum			
	stipulated limit.			
	* Close brake pipe angle cock and charge brake pipe to			
	5 kg/cm2 by A-9 (Automatic brake controlling) at run			
	position.			
	* Couple 7.5 dia leak hole to the brake hose pipe of			
	locomotive. Open the angle cock for brake pipe.			
	The test shall be carried out with all the compressors			
F 0	in working condition.		DC	
5.9	Keep Auto Brake Controller (A-9) in Full Service. Press		BC comes to '0'	0
	Driver End paddle Switch (PVEF)			
6.0	Direct Brake (SA-9)			
6.1	Apply Direct Brake in Full Check BC pressure	CDA//	2510201 / 5	2.5
	WAG9/WAP7	CLW's check sheet no.	3.5±0.20 kg/cm2	3.5
	WAP5	F60.812 Version 2	5.15±0.3 kg/cm2	Kg/cm2
6.2	Apply Direct Brake, Record Brake Cylinder charging	D&M test spec.	8 sec. (Max.)	7 Sec
	time	MM3882 & MM3946		

#### **PLW/PATIALA**

Loco No.: 39407

6.3	Check Direct Brake Pressure switch 59 (F)	D&M test spec. MM3882 & MM3946	0.20±0.1 kg/cm2	0.20 kg/cm2
6.4	Release direct brake & BC Release time to fall BC pressure up to 0.4 kg/cm2		10 -15 Sec.	13 Sec
7.0	Modified System Software (only for CCB)		-NA-	-NA-
7.1	Bail-off de-activated during emergency by any means	-		
7.2	DPWCS and Non-DPWCS mode enabled	-	Multi Loco	
7.3	TCAS and Non-TCAS mode enabled	-	Not Yet Launched	Presently
7.4	Penalty brake application deactivated for Fault code 113 (FC 113) and CCB health signal will not drop to avoid loco detention/failure. The Brake Electronics Failure "message will not generate on DDS.	RDSO letter no.	Pressure Setting Needed is12 kg/sqcm causing mismatching with standard Pr Setting	not happening in PLW
7.5	CCB health signal logic revised (Now will remain high) for penalty condition occurring with FC 108 due to wrong operation/not affecting operation/ Not a CCB Fault (i.e Both controllers selected as LEAD etc) The Brake electronic failure message will not generate on DDS	EL/3.2.19/3-phase (CCB), dtd 30.01.2023		
7.6	CCB health signal logic for FC 102 (In case of BC request from VCU is more than 90 %-above 9V DC) is changed i.e CCB health signal will not drop for FC 102 which will avoid loco detention/failure. The brake electronic failure message will not generate on DDS.		Could not performed by M/s Knorr	Presently Not happening in PLW
7.7	Booting time for CCB with TCAS/TPM/PTWS/DPWCS mode 15-20 sec. However, in case of absence of either one or both system booting time subsequently increased to 40-50 sec.			
8.0	Sanding Equipment			
8.1	Check Isolating Cock-134F is in open position. Press sander paddle Switch. (To confirm EP valves Operates)		Sand on Rail	Ok
9.0	Test Vigilance equipment : As per D&M test specification			Ok



Signature of SSE/Shop

39407

			R	oof compnent Cab-1	& Cab-2	
S.NO.	DESCRIPTION	PL NO.	QPL/Nos.	SUPPLIER	Sr.No.	Warranty
1	Pantograph	25880068	2	Contransys	15558-10/24, 15559-10/24	
2	Servo Motor	25880068	2	Contransys	15153-08/24,15156-08/24	
3	Air Intake Filter Assembly	29480103	2	AFI	AFI/OC/544A-06/24, AFI/OC/541A- 06/24	
4	Insulator Panto Mounting	29810127	8	BHEL	07-2024, 08-2024	
			Middle	roof Component	•	
5	High Voltage Bushing	29731021	1	ELECTRANEX	EIPL-5525-06-24	
6	6 Voltage Transformer 296950		1	ELIXIR Engineering	15612409005	
7	Vaccum Circuit Breaker	25712202	1	SCHNEIDER	226609873-13N2-MAY/24	
8	Insulator Roof Line	29810139	9	BHEL	10-2023, 11-2023, 12-2023	
9	Harmonic Filter	29650033	1	RESITECH	05/24/232496/63	As per PO/IRS Conditions
10	Earthing Switch	29700073	1	PATRA&CHANDA	PCE/SL.No.13 M/Y - 4/2024	
11	Surge Aresster	29750052	2	C G POWER	57432-2024, 57433-2024	
			Air Bra	ke Components		
12	Air Compressor (A,B)	29511008	2	ELGI	EXGS-923603 A, EXGS -923612 B	
13	Air Dryer	29162051	1	TRIDENT	LD2-08-0562-24	
14	Auxillary Compressor	25513000	1	CEC	RH 3369-8-24	
15	Air Brake Panel	29180016	1	FAIVELEY	SEP 24-52-WAG9-3632	
16	Controller (A,B)	29180016	2	FAIVELEY	D24-088 A, D24-094 B	
17	Break Up Valve	29162026	2	FAIVELEY		
18	Wiper Motor		4	AUTO INDS		

SAMSHER
Digitally signed by
SAMSHER SINGH
BIST
Date: 2025.01.24
17:11:25 +05'30'
SSE/ABS

## PLW/PTA

## **ELECTRIC LOCO HISTORY SHEET (ECS)**

**ELECTRIC LOCO NO: 39407** 

RLY: CR

SHED: PADX

PROPULSION SYSTEM: MEDHA

HOTEL LOAD CONVERTER: AAL

LIST OF ITEMS FITTED BY ECS

SN	DESCRIPTION OF ITEM	ITEM PL NO.	ITEM SR. NO	CAB-1/CAB-2	MAKE/SUPPLIER
1	LED Based Flasher Light Cab I & II	29612937	26588/26555		MATSUSHI P.TECH
2	Led Marker Light Cab I & II	29612925	4273/4245/	/4188/4290	KEPCO
3	Cab Heater Cab I & II	29170011	2516	/2595	TOPGRIP
4	Crew Fan Cab I & II	29470080	24070137/24070106/	/24070134/24070121	KAPSONS
5	Master Controller Cab I		36	60	KEPCO/STESALIT
6	Master Controller Cab II	29860015	00	12	REFOO/STEGALIT
7	Complete Panel A Cab I & II	29170564	1427	1424	KONTACT
8	Complete Panel C Cab I & II	29170539	1180	1181	KONTACT/MEDHA
9	Complete Panel D Cab I & II	29170564	1392	1385	KONTACT
10	Complete Cubicle- F Panel Cab I & II	29178162	SLCF00012404167	SLCF00012404167 SLFC00012404172	
11	Speed Ind & Rec. System	29200040	5045/5704		MEDHA
12	Battery (Ní- Cd)	29680025	11389-11401, 11480-11492		SAFT URJA
13	Set of Harnessed Cable Complete	29600418			PPS INTERNATIONAL
14	Transformer Oil Pressure Sensor (Cab-1) (pressure sensor oil circuit transformer)	29500047	2386/08-2024	2376/08-2024	LAXVEN
15	Transformer Oil Pressure Sensor (Cab-2)		2435/08-2024	2425/08-2024	· · · · · · · · · · · · · · · · · · ·
16	Transformer Oil Temperature Sensor (Cab- 1)(temperature sensor oil circuit transformer)	29500035	BG/TFP/759	7 May 2024	BG INDUSTRIES
17	Transformer Oil Temperature Sensor (Cab-2)		BG/TFP/770	08 May 2024	
18	Roof mounted Air Conditioner I	29811028	CLW/AC/0	CLW/AC/09/24/095	
19	Roof mounted Air Conditioner II	25011020	CLW/AC/09/24/087		SSM
			India rail navigator		
20.	RTIS(Real time information system)		Power supply module	•	Aventel Ltd., India
			Rail MSS Terminal		

SSE/ECS

JEVECS

48 Conservator Tank Breather Silica Gel       29731057       241433         49 Ballast Assembly (only for WAG-9)       29170163       Matsushi power tech         50 Head Light       29611908       0754/0764       S.INTERNATIONAL         51 IV COUPLER       11586/26, 09, 58,67       S.INTERNATIONAL			PATIALA LOCOMOTI	VE WORKS, PAI	DX		
Complete Shell Assembly with piping   29171064   Sr. 168, 09/24   433, 08/24   FASP   FASP   FASP   Side Buffer Assly Both Side Cab I   29130050   41, 09/24   12, 09/24   FASP   FASP   FASP   FASP   Side Buffer Assly Both Side Cab I   29130037   3672, 10/23   3674, 04/24   FASP   FASP   FASP   FASP   Hand Brake   29045034   Set of Secondry Helical Spring   Se	2.21	Faultment		Equipmen	it Serial No.	1 1 1	
Compress ni Assembly With Indiana   29130000   41,09/24   12,09/24   FASP   FASP   FASP   SASP   S							BHILAI
29   3   3   3   3   3   3   3   3   3							
Security			29130050			FASP	
Set of Secondry Helical Spring   29043041   161,0974   159,09724   D.R.   D.R.   STEEL			29130037			FAS	FAS
Set of Secondry Helical Spring   29943081   39943081   39943081   39943081   39943081   39943081   39943081   39943081   39943081   39943081   39943081   3161,09/24   159,09/24   TEW   TEXT   3795,08/24   TEW   3795,08/25   TEW   3795,08/2			2513003.			1511	
6         Set of Secondry Helical Spring         29641041         161,09/24         159,09/24         D R         D R STEEL           7         Battery Boxes (both side)         29680013         161,09/24         159,09/24         D R         D R STEEL           91         Traction Bar Bogle II         5333,08/24         TEW           10         Centre Proof Housing in Shell Bogle I side         29000057         8060,09/24         TEW           11         Centre Proof Housing in Shell Bogle I side         29000057         50,07/24         AVADH           12         Elastic Ring in Front in Shell Bogle II side         29073108 for WAG 9         29731087 for WAP-7         71/24, 5045RH         AVADH           14         Main Transformer         29731087 for WAP-7         07/24, 5045RH         STANDARD RADIATORS           15         Oil Cooling Radiator I         29470031         47458PL, 07/24         STANDARD RADIATORS           16         Oil Cooling Radiator I         29470031         47458PL, 07/24         STANDARD RADIATORS           18         Main Compressor I with Motor         29511008         EKGS92363, 10/2024I         ELGI           18         Main Compressor I with Motor         29511008         EKGS923631, 10/2024I         SAMAL HARAND           20         Transfo			29045034		1 s Lp ( = 1p)	1 10 42 14	GBD
Traction Bar Bogie   Satary Boxes (both side)   29680013   163,0974   TEW   5393,08/24   TEW   5493,08/24   AVADH   5493,08/24	6	Set of Secondry Helical Spring	29041041				
Station Bar Bogie	7	Battery Boxes (both side)	29680013			DK	
10							
10   Centre Pivot Housing in Shell Bogie I side   11   Centre Pivot Housing in Shell Bogie I side   12   Elastic Ring in Front in Shell Bogie I side   29100010   216,08/24   TEW   AVADH   13   Elastic Ring in Front in Shell Bogie I side   29100010   216,08/24   AVADH   AVADH   13   Elastic Ring in Front in Shell Bogie I side   29100010   216,08/24   Tribhuwan Enterprises   15   Oil Cooling Radiator I   29470031   4748/RPL, 07/24   STANDARD RADIATORS   16   Oil Cooling Radiator I   29470031   4748/RPL, 07/24   STANDARD RADIATORS   17   Main Compressor I with Motor   29511008   EXGS 9236013, 10/2024   ELGI   EL							
11   Centre Pivot Housing in Shell Bogie II side   12   12   12   13   13   15   15   15   16   16   17   17   17   17   17   18   18   18	10	Centre Pivot Housing in Shell Bogie I side	29100057				
12   Elastic Ring in Front in Shell Bogie I side   29100010   216, 08/24   18 AVADH   AVADH   216, 08/24   18 AVADH   216, 08/24   18 AVADH   216, 08/24   18 AVADH   216, 08/24   18 AVADH   216, 08/24   216, 08/24   18 AVADH   216, 08/24			29100037				
13   Elastic Ring in Front in Shell Bogie II side   29731008 for WAG 9   TE/7708/24/0013, 2024   Tribhuwan Enterprises   2973107 for WAP-7   07/24, 504SRPL   571ANDARD RADIATORS   15 Oil Cooling Radiator   29470031   29470031   4745RPL   07/24   571ANDARD RADIATORS   17 Main Compressor I with Motor   29511008   EXGS923603, 10/2024   ELGI   E						the the HV	
Main Transformer				216,	, 08/24		
15   Oil Cooling Radiator   29470031   474SRPL, 07/24   STANDARO RADIATIONS   474SRPL, 07/24   STANDARO RADIATIONS   29511008   EXGS 923603, 10/2024   ELGI   ELG					2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	10 10 10 11	
16	15	Oil Cooling Padiator					
Total Cooling Radiator   File   Fil	-		29470031			S	1111
17   Main Compressor   With Motor   29511008   EXGS 923603, 10/2024   ELGI       19   Transformer Oil Cooling Pump   5573, 05/24   SAMAL HARAND   5597, 05/24   PD STEELS PVT LTD   10   Cooling Blower OCB   29470043   FMT/24-25/341, 09/24   PD STEELS PVT LTD   10   Cooling Blower OCB   29440075   08/24, AC-57701, CGLXGAM23068   ACCEL   ACCEL   Acchine Room Blower   29440105   09/24, AC-57466, CGLXGCM15824   ACCEL   Acchine Room Blower   29440105   09/24, AC-57466, CGLXGCM15824   ACCEL   Acchine Room Scavenging Blower   29440129   07/24, D25-6551, CF25/D6923   SAMAL HARAND   29440129   07/24, D25-6541, CF25/D6913   SAMAL HARAND   29440129   07/24, D25-6541, CF25/D6913   SAMAL HARAND   29440117   D30-7919, CF30/D8208, 09/24   SAMAL HARAND   30   TM Scavenging Blower Motor   29440117   D30-7919, CF30/D8208, 09/24   SAMAL HARAND   31   Traction Convertor   29440117   29741075   3899   MEDHA   3899   MEDHA   34   Vehicle Control Unit   29741075   3899   MEDHA   39176669   07/24, SLBS10012407304   STESALIT LTD   37   Axillary Control Cubical BB-1   29176669   07/24, SLBS10012407304   STESALIT LTD   38071669   07/24, SLBS10012407304   STESALIT LTD   38071669   07/24, SLBS10012407304   STESALIT LTD   3824040137, 08/24   AUTOMETERS ALLAINCE PVT   48   Hotel Load Converter   29480140   RANSAL PIPES   49171331   0824040137, 08/24   AUTOMETERS ALLAINCE PVT   48   Hotel Load Converter   29480140   RANSAL PIPES   49171331   0824040138, 08/24   AUTOMETERS ALLAINCE PVT   48   Hotel Load Converter   29480140   RANSAL PIPES   49171331   0824040137, 08/24   AUTOMETERS ALLAINCE PVT   48   Hotel Load Contactor   29731057   2414533   YOGYA ENETRPRISES LTD   1000000000000000000000000000							NE CONTRACTOR OF THE PERSON OF
18   Man Compress of I With World   18   18   18   18   18   18   19   19	-		29511008				
Transformer Oil Cooling Pump II	-					The state of the s	
1	-		A /				
29470043   FMT/24-25/341, 09/24   PD STEELS PVT LTD	-						
20	-		29470043				PD STEELS PVT LTD
2940105	-			18.7	3/3-12/		
24   TM Blower	23		29440075	20/24 AC-5770	01 CGLXGAM23068		ACCEL
25 Machine Room Blower   29440105   09/24, A.C-57466, CGLXGCM15824   ACCEL	-			08/24, AC-574	77. CGLXGCM15613		
26   Machine Room Blower II	25		29440105				HIS I I I I I I I I I I I I I I I I I I
29   Machine Room Scavenging Blower   29440129   07/24, D25-6541, CF25/D6913   SAMAL HARAND   29440117   D30-7919, CF30/D8208, 09/24   SAMAL HARAND   D30-7919, CF30/D8208, 09/24   SAMAL HARAND   D30-7919, CF30/D8208, 09/24   SAMAL HARAND   D30-7927, CF30/D8216, 09/24   SAMAL HARAND   SAMAL HARAND   D30-7927, CF30/D8216, 09/24   SAMAL HARAND   D30-7927, CF30/D8216, 09/24   SAMAL HARAND   SAMAL HARAND   D30-7927, CF30/D8216, 09/24   SAMAL HARAND   D30-7927, CF30/D8216, 09/24   SAMAL HARAND   D30-7927, CF30/D8216, 09/24   SAMAL HARAND   SAMAL HARAND   D30-7927, CF30/D8216, 09/24   SAMAL HARAND   D30-	26						
28   Machine Room Scavenging Blower II   29440117   D30-7919, CF30/D8208, 09/24   SAMAL HARAND	27		29440129				
D30-7919, CF30/D8208, 09/24   D30-7919, CF30/D8208, 09/24   D30-7919, CF30/D8208, 09/24   D30-7927, CF30/D8208, 09/24   SAMAL HARAND	28						11 4
30 TM Scavenging Blower Motor II   31 Traction Convertor I   32 Traction Convertor I   32 Traction Convertor II   3899   MEDHA   3808/24, 3919   MEDHA   3808/24, 3819   MEDHA   3808/24, 3919	-		29440117			4-1-1-11	
S686, 08/24   S685   S68, 08/24   S685   S6			2377011.				SAIVIALTIA
32   Traction Convertor   1   33   Vehicle Control Unit   34   Vehicle Control Unit   1   35   Aux. Converter Box   (BUR 1)   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, SLHBI0012407304   STESALIT LTD   08/24, ALIN/09/2024/05/HB2P7/033   AUTOMETERS ALLAINCE PVT   09/24, ALIN/09/2024/05/HB2P7/033   AUTOMETERS ALLAINCE PVT   09/24, ALIN/09/2024/05/HB2P7/033   AUTOMETERS ALLAINCE PVT   08/24/G/0321/1213, 09/23   HIND RECTIFIERS PVT LTD   HIND RECTIFIERS PVT LTD   18/24						41111	
33   Vehicle Control Unit   3899   08/24, 3919   08/24,	-					4	
34   Vehicle Control Unit    3899   08/24, 3919   09/24, SHB10012407304   STESALIT LTD   09/24, SLB10012407484   STESALIT LTD   09/24, AALN/09/2024/05/HB2P7/033   AUTOMETERS ALLAINCE PVT   29176669   07/24, SLSB10012407484   STESALIT LTD   07/24, SLSB10012407484   STESALIT LTD   07/24, SLSB10012407484   STESALIT LTD   082/2024/G/0321/1213, 09/23   HIND RECTIFIERS PVT LTD   082/2024/G/0321/1213, 09/23   HIND RECTIFIERS PVT LTD   07/24, SLSB10012407484   STESALIT LTD   082/2024/G/0321/1213, 09/23   HIND RECTIFIERS PVT LTD   07/24, SLSB10012407484   STESALIT LTD   082/2024/G/0321/1213, 09/23   HIND RECTIFIERS PVT LTD   07/24, SLSB10012407484   STESALIT LTD   082/2024/G/0321/1213, 09/23   HIND RECTIFIERS PVT LTD   082/2024/G/0321/1213, 09/23   AUTOMETERS ALLAINCE PVT   082/2024/G/0321/1213, 09/24   AUTOMETERS ALLAINCE PVT   082/2024/G/0321/1213, 09/23   AUTOMETERS ALLAINCE PVT   082/2024/G/0321/1213, 09/23   AUTOMETERS ALLAINCE PVT   082/2024/G/0321/1213, 09/23   AUTOMETERS ALLAINCE			29741075				MEDHA
35   Aux. Converter Box   (BUR 1)   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   08/24, 3919   07/24, SLHB10012407304   STESALIT LTD   09/24, AALN/09/2024/05/HB2P7/033   AUTOMETERS ALLAINCE PVT   09/24, ALN/09/2024/05/HB2P7/033   AUTOMETERS PVT LTD   09/24, AALN/09/2024/05/HB2P7/033   AUTOMETERS ALLAINCE PVT   09/24, AALN/09/2024/05/HB2P7/033   09/24   AUTOMETERS ALLAINCE PVT   09/24, AALN/09/2024/05/HB2P7/033   09/24   AUTOMETERS ALLAINCE PVT   09/24, AALN/09/2024/05/HB2P7/033   09/24   AUTOMETERS ALLAINCE PVT   09/24, AALN/09/2024/09/18, 0	-	Vehicle Control Unit II	1 201			Alle	
36 Aux. Converter Box 2 (BUR 2 + 3)   37   Axillary Control Cubical HB-1   29176645   07/24, SLHB10012407304   STESALIT LTD     38 Axillary Control Cubical HB-2   29176657   09/24, AALN/09/2024/05/HB2P7/033   AUTOMETERS ALLAINCE PVT     39 Complete Control Cubical SB-1   29176669   07/24, SLSB10012407484   STESALIT LTD     40 Complete Control Cubical SB-2   29178174   SB2/2024/G/0321/1213, 09/23   HIND RECTIFIERS PVT LTD     41 Filter Cubical (FB) (COMPLETE FILTER   29480140   KPL/CFC/2407/65   KAPATRONICXS PVT LTD     42 Driver Seats   29171131   0824040137, 08/24   AUTOMETERS ALLAINCE PVT     43 Hotel Load Converter   29741087   0824040138, 08/24   AUTOMETERS ALLAINCE PVT     44 Hotel Load Converter II   29230044   RANSAL PIPES   0824040138, 08/24   AUTOMETERS ALLAINCE PVT     45 Transformer oil steel pipes   29230044   0824040138, 08/24   AUTOMETERS ALLAINCE PVT     46 Hotel Load Contactor II   0824040137, 08/24   AUTOMETERS ALLAINCE PVT     47 Hotel Load Contactor II   0824040137, 08/24   AUTOMETERS ALLAINCE PVT     48 Conservator Tank Breather Silica Gel   29731057   24-1453   YOGYA ENETRPRISES LTD     49 Ballast Assembly ( only for WAG-9)   29170163   0754/0764   Matsushi power tech     50 Head Light   11586/26, 09, 58,67   S.INTERNATIONAL	-	Aux. Converter Box I (BUR 1)	1			Alle	
37 Axillary Control Cubical HB-1         29176645         07/24, SLHB10012407304         AUTOMETERS ALLAINCE PVT I           38 Axillary Control Cubical HB-2         29176657         09/24, AALN/09/2024/05/HB2P7/033         AUTOMETERS ALLAINCE PVT I           39 Complete Control Cubicle SB-1         29176669         07/24, SLSB10012407484         HIND RECTIFIERS PVT LTD           40 Complete Control Cubicle SB-2         29178174         SB2/2024/G/0321/1213, 09/23         HIND RECTIFIERS PVT LTD           41 Filter Cubical (FB) (COMPLETE FILTER         29480140         KPL/CFC/2407/65         KAPATRONICXS PVT LTD           42 Driver Seats         29171131         0824040137, 08/24         AUTOMETERS ALLAINCE PVT           43 Hotel Load Converter I         29741087         0824040138, 08/24         AUTOMETERS ALLAINCE PVT           44 Hotel Load Converter II         29230044         RANSAL PIPES         AUTOMETERS ALLAINCE PVT           46 Hotel Load Contactor I         0824040138, 08/24         AUTOMETERS ALLAINCE PVT           47 Hotel Load Contactor II         0824040137, 08/24         AUTOMETERS ALLAINCE PVT           48 Conservator Tank Breather Silica Gel         29731057         24-1453         YOGYA ENETRPRISES LTD           49 Ballast Assembly ( only for WAG-9)         29170163         0754/0764         Matsushi power tech           50 Head Light         29611908 <td></td> <td>Aux. Converter Box 2 (BUR 2 + 3)</td> <td>1</td> <td></td> <td></td> <td></td> <td></td>		Aux. Converter Box 2 (BUR 2 + 3)	1				
38 Axillary Control Cubical HB-2         29176657         09/24, AALN/09/2024/05/HB2F/F055         STESALIT LTD           39 Complete Control Cubicle SB-1         29176669         07/24, SLSB10012407484         STESALIT LTD           40 Complete Control Cubicle SB-2         29178174         SB2/2024/G/0321/1213, 09/23         HIND RECTIFIERS PVT LTD           41 Filter Cubical (FB) (COMPLETE FILTER         29480140         KPL/CFC/2407/65         KAPATRONICXS PVT LTD           42 Driver Seats         29171131         0824040137, 08/24         AUTOMETERS ALLAINCE PVT           43 Hotel Load Converter II         29741087         0824040138, 08/24         AUTOMETERS ALLAINCE PVT           44 Hotel Load Converter II         29230044         RANSAL PIPES         AUTOMETERS ALLAINCE PVT           46 Hotel Load Contactor I         0824040138, 08/24         AUTOMETERS ALLAINCE PVT           47 Hotel Load Contactor II         0824040137, 08/24         AUTOMETERS ALLAINCE PVT           48 Conservator Tank Breather Silica Gel         29731057         24-1453         YOGYA ENETRPRISES LTD           49 Ballast Assembly ( only for WAG-9)         29170163         0754/0764         Matsushi power tech           50 Head Light         29611908         0754/0764         S.INTERNATIONAL	37	7 Axillary Control Cubical HB-1	_	07/24, 521	181001240730 12024/05/HB2P7/03	2 AUT	OMETERS ALLAINCE PVT LTE
39 Complete Control Cubicle SB-1 40 Complete Control Cubicle SB-2 41 Filter Cubical (FB) (COMPLETE FILTER 42 Driver Seats 43 Hotel Load Converter I 44 Hotel Load Converter II 45 Transformer oil steel pipes 46 Hotel Load Contactor I 47 Hotel Load Contactor II 48 Conservator Tank Breather Silica Gel 49 Ballast Assembly ( only for WAG-9) 50 Head Light 51 IV COUPLER 582/2024/G/0321/1213, 09/23 5	38	Axillary Control Cubical HB-2		09/24, AALIN, 05,	CP10012407484		STESALIT LTD
40 Complete Control Cubicle SB-2 41 Filter Cubical (FB) (COMPLETE FILTER 42 Driver Seats 43 Hotel Load Converter I 44 Hotel Load Converter II 45 Transformer oil steel pipes 46 Hotel Load Contactor I 47 Hotel Load Contactor I 48 Conservator Tank Breather Silica Gel 49 Ballast Assembly ( only for WAG-9) 50 Head Light 51 IV COUPLER 51 KAPATRONICXS PVT LTD 529480140 5382/2024/6/36324 54 KPL/CFC/2407/65 56 KAPATRONICXS PVT LTD 5824040137, 08/24 5824040137, 08/24 5824040137, 08/24 5824040138, 08/24 5824040138, 08/24 5824040138, 08/24 5824040138, 08/24 5824040138, 08/24 5824040138, 08/24 5824040138, 08/24 5824040137, 08/24 5824040137, 08/24 5824040137, 08/24 59230044	-			SR2/2024/G/	/0221/1213, 09/23	H	HIND RECTIFIERS PVT LTD
41 Filter Cubical (FB) (COMPLETE FILTER         29171131           42 Driver Seats         29171131           43 Hotel Load Converter I         29741087           44 Hotel Load Converter II         29741087           45 Transformer oil steel pipes         29230044           46 Hotel Load Contactor I         0824040138, 08/24           47 Hotel Load Contactor II         0824040137, 08/24           48 Conservator Tank Breather Silica Gel         29731057           49 Ballast Assembly ( only for WAG-9)         29170163           50 Head Light         29611908           51 IV COUPLER         11586/26, 09, 58,67				KPL/C	FC/2407/65		KAPATRONICXS PVT LTD
A   Hotel Load Converter   29741087   0824040137, 08/24   AUTOMETERS ALLAINCE PVT					Land the second		TOTAL TI
29741087   29741087						AUT	OMETERS ALLAINCE PVI LIL
45       Transformer oil steel pipes       29230044       RANSAL PIPES         46       Hotel Load Contactor I       0824040138, 08/24       AUTOMETERS ALLAINCE PVT         47       Hotel Load Contactor II       0824040137, 08/24       AUTOMETERS ALLAINCE PVT         48       Conservator Tank Breather Silica Gel       29731057       24-1453       YOGYA ENETRPRISES LTD         49       Ballast Assembly ( only for WAG-9)       29170163       Matsushi power tech         50       Head Light       29611908       0754/0764       S.INTERNATIONAL         51       IV COUPLER       11586/26, 09, 58,67       S.INTERNATIONAL			2974108/	082404	40138, 08/24	AUI	OMETERS ALLAINCE FV. 2
46 Hotel Load Contactor I	-		29230044	RAN	ISAL PIPES	AUT	TOMETERS ALLAINCE PVT LT
47       Hotel Load Contactor II       6024076137, 667         48       Conservator Tank Breather Silica Gel       29731057       24-1453       YOGYA ENETRPRISES LTD         49       Ballast Assembly (only for WAG-9)       29170163       Matsushi power tech         50       Head Light       29611908       0754/0764       S.INTERNATIONAL         51       IV COUPLER       11586/26, 09, 58,67       S.INTERNATIONAL				082404	40138, 08/24	AUT	TOMETERS ALLAINCE PVT LT
48 Conservator Tank Breather Silica Gel       29731057       241433         49 Ballast Assembly (only for WAG-9)       29170163       Matsushi power tech         50 Head Light       29611908       0754/0764       S.INTERNATIONAL         51 IV COUPLER       11586/26, 09, 58,67       S.INTERNATIONAL	47	7 Hotel Load Contactor II					YOGYA ENETRPRISES LTD
50 Head Light 29611908 0754/0764  51 IV COUPLER 5.INTERNATIONAL	48	8 Conservator Tank Breather Silica Gel			,4-1455		
50 Head Light 25011308 11586/26, 09, 58,67 S.INTERNATIONAL	49	9 Ballast Assembly (only for WAG-9)		07	754/0764		
1 51 IIV COUPLER			59011900				S.INTERNATIONAL
	51	1 IV COUPLER		(W	20,		*

NAME SHURMAN SHA PMA SSE/LAS NAME Kayan Siyy

NAME TRULT UPPAL JE/LAS/UF Issue No.: 05

Effective Date: July-2023

DOC NO: F/LAS/Electric Loco CHECK SHEET (Ref: WI/LAS/Elect/01, 02, 03 & 04 & QPL/LAS/Elect. Loco)

Page 1 of 1

## पटियाला रेलइंजन कारखाना, पटियाला

# PATIALA LOCOMOTIVE WORKS, PATIALA ELECTRIC LOCO CHECK SHEET

LOCO NO: 39407

Shed: PADX

S. No.	ITEM TO BE CHECKED	Specified Value	Ob	served V	alue
1.1	Check proper Fitment of Hotel Load Converter & its output contactor.	OK	012		
1.2	Check proper Fitment of MR Blower 1 & 2, MR Scavenging Blower 1 & 2, TM Blower 1 & 2, TMB Scavenging Blower 1 & 2.  TM scavenging blower 1 & 2 & Oil Cooling unit.	ОК	CIC		
1.3	Check proper of Fitment of oil cooling unit (OCU).	OK		710	
1.4	Check proper Fitment of HB 1 & 2 and its respected lower part on its position.	OK		OIL	
1.5	Check proper Fitment of FB panel on its position.	OK		OIL	
1.6	Check proper Fitment of assembled SB1 & SB2 panel.	OK		OIL	
1.7	Check proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3).	OK		OK	
1.8	Check proper Fitment of Traction converter 1 & 2 (SR-1 & 2).	OK		UL	
1.9	Check proper fitment, torquing & Locking of Main Transformer bolt.	OK		CIL	
1.10	Check proper fitment of Main compressor both side with the compressor safety wire rope.	OK		0/2	
1.11	Check proper resting of Secondary Helical Springs between Bogie & Shell body.	OK		OL	*
1.12	Check proper fitment of Bogie Body Safety Chains.	OK		012	•
1.13	Check proper fitment of Cow catcher.	OK		02	
1.14	Check coolant level in SR 1 & 2 Expansion Tank.	OK		UK	
1.15	Check Transformer Oil Level in both conservators Tank (Breather Tank).	OK		012	
1.16	Check proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any damage during online working of Locomotives.	OK		UIL	
1.17	Check proper fitment of both battery box.	OK		012	
1.18	Check for any gap between Main Transformer mounting base & Loco Shell.	OK		012	
1.19	Check proper fitment of Push Pull rod its bolt torquing and fitment of fixing cable. As per Drg No 1209-01-113-001	OK		010	
1.20	Secondary Vertical and Lateral Clearance on leveled track at the time of Loco Dispatch. <u>ELRS/TC/ 0082 (Rev 1) dated 17.09.2015</u>	Vertical-Std :35-60 mm	45	ALP L 45 4	CAB-2 P ALP 3 44
		45-50 mm	52	76 5	8 42
1.21	Buffer height: Range (1090, +15,-5)	1085-1105		L/S	R/S
	Drg No IB031-02002.	mm	FRONT	1094	1094
			REAR	1096	1093
1.22	Buffer Length: Range (641 mm + 3 to 10 mm with buffer face)	641 mm		L/S	R/S
	Drg No-SK.DL-3430.		FRONT	647	645
			REAR	647	647
1.23	Height of Rail Guard. (114 mm + 5 mm,-12 mm).	114 mm + 5		L/S	R/S
1.23	As per RDSO Pamphlet Important Bogie Clearances of Electric Locomotives.	mm,-12 mm	FRONT	116	117
			REAR	119	119
1.24	CBC Height; Range (1090, +15,-5)  Drg No- IB031-02002.	1090, +15 -5 mm	FRONT: REAR:		

(Signature of SSE/Elect. Loco)

NAME SHUBHAM SHAPMA

DATE 25/10/2024

(Signature of /JE/Elect Loco)

NAME KARAN SIN SU

(Signature of JE/UF)

NAME ANKIT UPPAL

# **Loco No.** 39407

#### 1. BOGIE FRAME:

BOGIE	FRAME NO	Make	PL No.	PO No. & dt.	Warranty Period
FRONT	SL-201	ECBT	29101104	102221	As per PO/IRS
REAR	SL-193	ECBT	29101104	102221	conditions

## 2. Hydraulic Dampers (PL No.29040140 ) Make: KONI/KONI

#### 3. AXLES:

AXLE POSITION NO	1	2	3	4	5	6
MAKE/	PLW	PLW	PLW	PLW	PLW	PLW
S.NO	27344	27332	27281	26171	27186	27398
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

#### 4. WHEEL DISCS NO. AND TYPE & BULL GEAR

AXLE POSITION NO	1	2	3	4	5	6
GEAR END	EP46-029	EOH0-014	EOH4-048	EO16-070	EOH9-55	EOL5-070
Make	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
FREE END	EOG7-031	EOH9-068	EOH8-094	EO14-077	EOH8-38	EOJ0-021
Make	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
Bull Gear No.	5640	5589	23-M-9144	23-M-972	5556	23-M-9133
Bull Gear Make	GGAG	GGAG	KPCL	KPCL	GGAG	KPCL

## 5. AXLE ROLLER BEARING (CRU) (PL No. 29010020, Warranty: As per PO/IRS conditions)

	AXLE POSITION NO	1	2	3	4	5	6
Gear	MAKE	FAG	FAG	FAG	FAG	NBC	NBC
End	PO NO. & dt	02312	02312	02312	02312	02875	02875
Free	MAKE	FAG	FAG	FAG	FAG	NBC	NBC
End	PO NO. & dt	02312	02312	02312	02312	02875	02875

## 6. WHEEL DISC PRESSING PRESSURE IN KN: (SPECIFIED 80-105 T)

AXLE POSITION NO	1	2	3	4	5	6
BULL GEAR END	876 KN	802 KN	990 KN	1003 KN	869 KN	825 KN
FREE END	943 KN	850 KN	853 KN	804 KN	795 KN	1023 KN

## **Loco No.** 39407

## 7. DIAMETER AFTER PROFILE TURNING: SPECIFIED 1092 + 5 mm - 0 mm

AXLE POSITION NO	1	2	3	4	5	6	
DIA IN mm GE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5	
DIA IN mm FE	1092.5	1092.5	1092.5		1092.5	1092.5	
WHEEL PROFILE GAUGE (1596±0.5mm)	OK	OK	OK	OK	OK	OK	

#### 8. SUSPENSION TUBE & ITS TAPER ROLLER BEARING:

AXLE POSITION NO		1	2	3	4	5	6
S.T. PL 29100288 MAKE		KPE	IN	IN	IN	KPE	IN
GE Brg. PL 29030110	MAKE	FAG	FAG	FAG	NBC	FAG	FAG
FE Brg. PL 29030110	MAKE	FAG	FAG	FAG	NBC	FAG	FAG

## 9. GEAR CASE (PL No. 29030018) & BACKLASH:

AXLE POSITION NO	1	2	3	4	5	6
MAKE	KPE	KPE	KPE	KPE	KM	KPE
BACKLASH (0.254 – 0.458mm)	0.360	0.310	0.410	0.415	0.265	0.305

### 10 A/BOX TO BOGIE FRAME LATERAL CLEARANCES (SPECIFIED 15.0 to 19.0mm):

AXLE POSITION NO	1	2	3	4	5	6
RIGHT SIDE	15.80	16.11	15.75	16.02	15.80	16.10
LEFT SIDE	15.41	15.80	16.25	17.48	15.62	16.75

#### 11. TRACTION MOTOR: (PL No.29942007, Warranty: As per PO/IRS conditions)

AXLE POSITION NO	MAKE	PO No. & date	S. NO.
1	TMS	-	PLW-2915
2	TMS	-	PLW-2889
3	TMS	-	PLW-2901
4	TMS	-	PLW-2920
5	TMS	-	PLW-2910
6	TMS	-	PLW-2881

SSE/ Bogie Shop

## TOP 13 COSTLIEST ITEMS OF WAP-7 LOCO WITH WARRANTY CONDITIONS AS PER TENDERS

S No	PL No	DESCRIPTION	Warranty Period
1	29741075	IGBT BASED 3-PHASE DRIVE PROPULSION EQUIPMENT	60 months after commissioning or 72 months from date of supply whichever earlier as per special conditions given by CLW
2	29741087	2X500KVA IGBT Based Hotel Load Converter to CLW Specn. no. CLW/ES/3/IGBT/0490 aLT.D (REV.1) issued on December,2017	As per clause no. 3.1.6 of CLW SPECN. NO. CLW/ES/3/IGBT/0490 ALT.D REV.1 ISSUED ON DEC-2017. [60 months after commissioning or 72 months from date of supply whichever earlier]
3	29731057	MAIN TRANSFORMER 7775 KVA TYPE LOT 7500 FOR WAP7 3- PHASE ELECTRIC LOCOMOTIVE TO CLW SPECN NO.CLW/ES/3/0660/C	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
4	29171064	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT-8	AS PER IRS CONDITIONS-30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER.
5	29600418	SET OF HARNESSED CABLE FOR 3-PHASE ELECTRIC LOCOMOTIVES TO CLW SPECN. NO. CLW/ES/03/646 ALT-NIL WITH DMW REQUIREMENT OF HARNESSED CABLE FOR WAP-7, ALT-A1 DATED 27/11/2018.	As per clause no.9 of CLW Specn. CLW/ES/3/0458 & Clause No.10 of CLW SpecnCLW/ES/3/0459. [18 months after commissioning or 20 months from date of supply for single core & 18 months after commissioning or 24 months from date of supply for multi core]

6	29180016	BRAKE CONTROL SYSTEM INCLUDING DRIVER'S VIGILANCE CONTROL DEVICE TO SET LIST NO.EL29180016.	As per specification no. CLW/MS/3/001 Alt. 16 i.e. the manufacturer is required to guarantee that the brakevalves/equipment work satisfactorily for a period of five (5) years after commissioning. Any equipment/part which failsduring the guarantee period shall be replaced free of cost by the manufacturer. The replaced components shallfurther be under warranty for five (5) years from the date of their fitment and should the replaced components proveunsatisfactory in service, they shall be replaced by modified and improved components by the supplier free of cost.
		COMPLETE ELLTED CUDICUE ALCANO MUTULALI	
7	29480140	COMPLETE FILTER CUBICLE ALONG WITH ALL EQUIPMENTS AND CABLING TO DRG./SPEC NO. [1] CLW/ES/3/0193 ALT-F OR LATEST AND CLW DRG. NO. 1209-15-143-004 ALT-10 AND PART DRG./SPEC NO AS PER ANNEXURE-A ATTACHED.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
8	29942007	3-PHASE ASYNCHRONOUS TRACTION MOTOR (RESISTANCE RING MECHANICALLY INTERLOCKED TO END PLATE DESIGN ROTOR, SCHEME-II), TYPE 6FRA-6068 FOR WAP-7 ELECTRIC LOCO WITHOUT ACTIVE SPEED SENSOR TO SPECIFICATION NO. 4TMS.096.081 ALT-2 AND STR NO. CLW/2008/3PHTM/STR/0001.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.

9	29105146	Bogie Frame Complete for WAP-7 for 3 Phase Co Co Locomotive to CLW specification No. CLW/MS/3/Bogie/003 alt-1 and CLW Drg.No.1209.01.112-202 Alt-Nil	As per clause 16 of Spec.No.CLW/MS/3/Bogie/003 Alt-1. [60 months after commissioning or 72 months from date of supply]
10	29171192	COMPLETE AUXILIARY CUBICLE HB2 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0192 ALT-E OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
11	29171210	COMPLETE CONTROL CUBICLE SB2 ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0195/A ALT-H OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
12	29171209	COMPLETE CONTROL CUBICLE SB1 (PUSH PULL SCHEME COMPLIANT) ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0194 ALT-G OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
13	29171180	COMPLETE AUXILIARY CUBICLE HB1 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0191 ALT-D OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.



#### भारत सरकार GOVERNMENT OF INDIA

रेल मंत्राल्य

MINISTRY OF RAILWAYS

पटियाला रेलइंजन कारखाना

PATIALA LOCOMOTIVE WORKS

Email: dyceeloco.dmw@gmail.com फैक्स/Fax No.: 0175-2397244

फोन/ Phone: 0175- 2396422

मोबाईल: 9779242310 पटियाला, 147003, भारत

PATIALA, 147003, INDIA



(An ISO 9001, ISO 14001, ISO 45001 & ISO 50001, 5S & Green Building certified Organization)

संख्या. PLW/M/ECS/Tech/Kavach

तिथि: As signed

(Through Mail)

Sr. Div. Mechanical Engineer, Diesel Loco Shed, Pune.

Email: srdmedpune@gmail.com

विषय:- Fitment of KAVACH in three Phase Electric Loco. No. 39407 WAP-7.

संदर्भ:- (i) Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 21.08.2023.

(ii)Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 26.09.2023

In ref. to the above letter's Loco No. 39407 has been dispatched with fittings for implementation of KAVACH system in locomotive at home shed in Zonal Railway. This Loco was dispatched to DLS/PADX/CR on 17.11.2024. The details of fittings are attached as Annexure-A (pneumatic fittings), Annexure-B (Kavach equipment mounting Brackets) & Annexure-C (Wago with harnessed lay out).

This is for your information & necessary action please.

उप मुख्य विदयुत अभियंता/लोको

CEE/Loco & CEE/D&Q, CMM, CELE/CR:- for kind information please Dy CME/Design, Dy. CMM/Depot: for information & necessary action please WM/LAS, AWM/LFS&ABS, WM/ECS: for necessary action please

#### Loco No. 39407

SW	РЦДЬ.	Description of them	ନାଙ୍
1	29163341	ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITH VENT	04 nos.
	29103341	ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITHOUT VENT	02 nos.
		TEE UNION 3/8"X3/8"X3/8" BRASS FITTINGS	02 nos.
		MALE CONNECTORS 3/8" TUBE OD X 3/8" BSPT, BRASS FITTINGS	09 nos.
		MALE CONNECTORS 1/2" TUBE OD X 1/2" BSPT, BRASS FITTINGS	06 nos.
		FEMALE CONNECTORS (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	01 no.
	29611994	MALE CONNECTOR (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	03 nos
2		FEMALE TEE 3/8" BSPP – BRASS	06 nos
		HEX PLUG -3/8" BSPT BRASS	02 nos
		FEMALE TEE 1/2" BSPP – BRASS	04 nos
	·	HEX NIPPLE 3/8X3/8" BSPT – BRASS	04 nos
		RED HEX NIPPLE 3/8X1/2" BSPT - BRASS	02 nos
	·	HEX PLUG – 1/2" BSPT – BRASS	04 nos
		MALE ELBOW CONNECTORS 3/8" TUBE OD X 3/8) BSPT. BRASS FITTINGS	02 nos
3	29170114	Copper Tube OD 9.52mm (3/8") X 1.245 Mm W.T X 6 Mtr	1.2Mtr

AWM/ABS & LFS

SSFIGIARS

SN	PL No.	Description of item	Quantity
1.	29611945	Mounting bracket arrangement provided for RF Antenna on the roof top of both driver cabs.	04 nos.
2.		Mounting bracket arrangement provided for GPS/GSM Antenna on the roof top of both driver cabs.	02 nos.
3.		Protection Guards for RFID reader provided behind the cattle guards of both side.	04 nos.
4.		Inspection door with latch provided on the both driver desk covers (LP side) in each cab to access isolation cock.	02 nos.
5.		Cable Entry Plate fitted for routing of cable with RF Antenna & GPS/GSM Antenna bracket.	06 nos.
6.	<u>.</u>	WAGO bracket fitted in Machine room at back side of SB-1.	01 no.
7.	_	One circular hole of 80 mm dia. provided in each cabs on LP side behind the driver desk toward the wall for routing of OCIP (DMI) cables.	02 nos.
8.	_	80 mm holes provided on TM1 and TM6 Junction box inspection cover hole for drawing of RFID reader cables.	02 nos.
9.	-	DIN Rail fitted inside the driver desk (LP Side)	02 nos.

AWMABS & FS

SSE/G/LFS

Annexure-C

SN	PL No.	Description of item	Quantity
1.	42310301	Flexible conduit size 25mm <sup>2</sup> provided for RF-1, 2 & GPS Antenna cable layout from CAB-1&2 to Machine room.	06 meter
2.	29611982	Wago terminals in CAB-1&2 (25 nos. in each CAB).	50 nos.
3.	29611982	Wago terminal in Machine room at back side of SB-1.	75 nos.
4	-	Harness provided from KAVACH SB to SB-1	07 wires
5.	-	Harness provided from KAVACH SB to SB-2	05 wires
6.	-	Harness provided from KAVACH SB to Pneumatic Panel	12 wires
7.	-	Harness provided from KAVACH SB to CAB-1	24 wires
8	-	Harness provided from KAVACH SB to CAB-2	16 wires

AWMACS

SSE/G/ECS