भारतीय रेल Indian Railways

डीजल रेलइंजिन आधुनिकीकरण कारखाना, पटियाला Miesel Loco Modernation Chorks, Patiala



LOCO TESTING & DISPATCH REPORT OF IGBT BASED WAG9HC ELECTRIC LOCOMOTIVE

LOCO NO.:

41559

TYPE:

WAG9HC

RAILWAY SHED:

WCR/ET

PROPULSION SYSTEM:

CGL

DATE OF DISPATCH:

29.11.2021

लोको निर्माण रिकार्ड



डीजल रेलइंजिन आधुनिकीकरण कारखाना, पटियाला Miesel Loco Modernisation Cooks, Patiala

LOCO NO.: 41559

RAILWAY/SHED: WCR/BT DOD: NOVEMBER 2021

INDEX

N	PARA	ACTIVITIES	PAGE NO.
		Testing & Commissioning (TRS)	
1.	1.0	Continuity Test of the cables	
	1.1	Continuity Test of Traction Circuit Cables	
	1.2	Continuity Test of Auxiliary Circuit Cables	1-4
1 2	1.3	Continuity Test of Battery Circuit Cables	
-	1.4	Continuity Test of Screened Control Circuit Cables	
2.	2.0	Low Tension test	
	2.1	Measurement of resistor in OHMS (Ω)	5-6
	2.2	Check Points	2000 2000
	2.3	Low Tension Test Battery Circuits (without control electronics)	
3	3.0	Downloading of Software	2 5
	3.1	Check Points	
	3.2	Download Software	7-10
	3.3	Analogue Signal Checking	*
	3.4	Functional test in simulation mode	
4	4.0	Sensor test & convertor test	
	4.1	Test wiring Transformer Circuits – Polarity Test	
	4.2	Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)	
	4.3	Primary Voltage Transformer	- 2
	4.4	Minimum voltage relay (Pos. 86)	11-16
	4.5	Maximum current relay (Pos. 78)	1 1 2 3
	4.6	Test current sensors	
	4.7	Test DC Link Voltage Sensors (Pos 15.6/*)	
	4.8	Verification of Converter Protection Circuits (Hardware limits)	
	4.9	Sequence of BUR contactors	
5.	5.0	Commissioning with High Voltage	
	5.1	Check List	
	5.2	Safety test main circuit breaker	
	5.3	Auxiliary Converter Commissioning	
	5.3.1	Running test of 3 ph. auxiliary equipments	
	5.3.2	Performance of Auxiliary Converters	10.05
	5.3.3	Performance of BURs when one BUR goes out	16-25
	5.4	Auxiliary circuit 415/110	
	5.5	Hotel Load Circuit	
	5.6	Traction Converter Commissioning	
	5.7	Test protective shutdown SR	
	5.8	Test Harmonic Filter	
	5.9	Test important components of the locomotive	25-26
6.	6.0	Running Trial of the locomotive	
7.	7.0	Final Check List to be verified at the time of Loco dispatch	27
8.	8.0	Status of RDSO modifications	28
9.	1-10	Pneumatic Test Parameters	29 - 32
10.		Loco Check Sheet(LRS)	33
11.	-	Component History (LRS,TRS,ABS)	34-36
12.	-	Component History & Testing Parameter (Bogie Shop)	37 - 38
13	-	Warranty Conditions as per Tenders	39 -41

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559 1.0 Continuity Test of the cables Type of Locomotive: WAP-7/WAG-9HC Page: 1 of 27

As per cable list given in Para 1.3 of document no. 3 EHX 410 124, check the continuity with 1.1 Continuity Test of Traction Circuit Cables continuity tester and megger each cable to be connected between following equipment with 500V megger.

ov megger. From	То	Continuity (OK/Not OK)	Prescribed Megger Value (min)	Measured Megger Value
	Transformer	OK	100 ΜΩ	1500
Filter Cubicle	Transfer		100 ΜΩ	
Filter Cubicle	Terminal Box of Harmonic Filter	DL.		1200
	Resistor (Roof)		100 ΜΩ	1500.
Filter Cubicle	Earthing Choke	ong	100 10132	1300
Earthing Choke	Earth Return	DK	100 ΜΩ	5200
	Brushes	-	100 ΜΩ	1500
Transformer	Power Converter 1	200	100 11122	1,00
Transferme	12	22	100 ΜΩ	1500
Transformer	Power Converter 2	OK	100 ΜΩ	1500
Power Converter 1	TM1, TM2, TM3	DR	100 11122	1300
	TO TO TO TO TO TO	ore	100 ΜΩ	1500
Power Converter 2		201	100 ΜΩ	2000
Earth	Power Converter	1 24	100.040	2000
Earth	Power Converter	2 2	100 ΜΩ	

1.2 Continuity Test of Auxiliary Circuit Cables

As per cable list given in Para 1.4 of document no. 3 EHX 410 124, check the continuity with continuity meter and megger each cable to be connected between following equipment with the help of 500V megger.

Effective Date: March 2021

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

Page: 2 of 27

From	То	Continuity(OK/ Not OK)	Prescribed Megger Value (min)	Measured Megger Value
		ox.	100 M Ω	1000
Transformer	BUR1	25	100 ΜΩ	1000
Transformer	BUR2	ne	100 ΜΩ	100
Transformer	BUR3	or.	100 ΜΩ	1000
Earth	BUR1	DK.	100 MΩ	1000
Earth	BUR2	or or	100 ΜΩ	2000
Earth	BUR3		100 ΜΩ	1000
BUR1	HB1	or me	100 ΜΩ	1000
BUR2	HB2	ore_	100 ΜΩ	1000
HB1	HB2	DL	100 ΜΩ	200
HB1	TM Blower 1	DR	100 ΜΩ	200
HB1	TM Scavenge Blower 1	ne		200
	Oil Cooling Unit 1	de	100 ΜΩ	200
HB1	Compressor 1	ne	100 ΜΩ	173
HB1	TFP Oil Pump 1	DL	100 MΩ	
HB1	Converter Coolant	2K	100 MΩ	200
HB1	Pump 1	O IK	100 ΜΩ	150
LID4	MR Blower 1	De	500000001100000000000000000000000000000	
HB1	MR Scavenge Blower 1	2x	100 ΜΩ	150
HB1		de	100 MΩ	100
HB1	Cab1	OV.	100 ΜΩ	100
Cab1	Cab Heater 1	DK	100 MΩ	150
HB2	TM Blower 2	nc nc	100 MΩ	200
HB2	TM Scavenge Blower 2		100 ΜΩ	20
HB2	Oil Cooling Unit 2	ork ork	100 ΜΩ	200
HB2	Compressor 2	De ne	100 MΩ	200
HB2	TFP Oil Pump 2	or or	100 ΜΩ	000
HB2	Converter Coolant Pum	np2 ox	100 MΩ	
HB2	I an Dlawor 2	ou ou	100 MS	
	- In Convenge Blower 2	ne		
HB2	2.12	2K	100 MS	
HB2 Cabi	a Lillintor 2	or	100 MS	2 150

Doc.No.F/TRS/UT (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

Page: 3 of 27

1.3 Continuity Test of Battery Circuit Cables

Check continuity of following cables as per Para 2.3 of document no. 3 EHX 610 299

To	Condition	Continuity (OK/Not OK)
Circuit breakers 110-	By opening and	OK
2, 112.1-1, 310.4-1 Connector 50.X7-1	By opening and	3K
. FO Y7 2		OK
Connector 50.X7-2		SK
	Circuit breakers 110- 2, 112.1-1, 310.4-1 Connector 50.X7-1	Circuit breakers 110- 2, 112.1-1, 310.4-1 Connector 50.X7-1 By opening and closing MCB 112 By opening and closing MCB 110 Connector 50.X7-2

Close the MCB 112, 110, 112.1, and 310.4 and measure the resistance of battery wires 2093, 2052, 2050 with respect to the loco earth. Measure the resistance between 2093 & 2052, 2093 & 2050, 2052 & 2050	Prescribed value Measured Value Value $\square \Omega \cap \Omega$ Measured Nescribed value: Measured Nescribed value: Value $\square \Omega \cap \Omega$
---	---

Commission the indoor lighting of the locomotive as per Sheet No 7A & 7B.

1.4 Continuity Test of Screened Control Circuit Cables

Check the continuity and isolation of the screen cable of the following circuits with the help of sheet no. mentioned against each as per document no. 3 EHX 610 299.

Corresponding Sheet Nos.	Continuity & Isolation (OK/Not OK)
O4B	OK
100	OK
10A	DK
10A	
01A, 12A	δ¥_
	OK
00.7	
	Sheet Nos. 04B 10A 10A

Effective Date: March 2021

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC Page: 4 of 27

otive No.: 9153		4
	08C, 08D	OK
Master controller cab-1 &2	08E, 08F	DK
TE/BE meter bogie-1 & 2		JK.
Terminal fault indication cab-1 & 2	09F	OK.
Brake pipe pressure actual BE electric	06H	OK OK
Brake pipe pressure details	12B, 12F	
Primary current sensors	12B, 12F	OK.
Harmonic filter current sensors	12B, 12F	DK.
Auxiliary current sensors	12E, 12I	JK
Oil circuit transformer bogie 1	12C, 12G	DF.
Magnetization current	12D	JK,
Traction motor speed sensors (2 nos.)		DIC.
tor cheed sensuis (21103)	12D	1
Liberary arature sensors (1110.) of the	12D	OK
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-3		DK
Tartion motor speed sensors (2 1103.)	12H	
1 sonsors (1 no.) 01 11V1-4	12H	PK
- ator chapitalistis		
and temperature sensors (1 no.) of TM-5 Traction motor speed sensors (2nos)	12H	OK
Traction motor speed sensors (1 no.) of TM-6		
Train Rus cah 1 & 2	13A	OR
(Wire U13A& U13B to earthing		
resistance=		0
10KΩ± ± 10%)	13B	OK
UIC line	13A	OK
Connection FLG1-Box TB		

Doc.No.F/1R3/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC Page: 5 of 27

2.0 Low Tension test

Measure the resistances of the load resistors for primary voltage transformer, load resistors for primary current transformer and Resistor harmonic filter as per Para 3.2 of the document no. 3 EHX 610 279.

o. 3 EHX 610 279.	Prescribed value	Measured value
ame of the resistor	3.9K Ω ± 10%	3.920
oad resistor for primary voltage		1-52
ransformer (POS. 74.2).	1 Ω ± 10%	3.32
Resister to maximum current relay.	3.3 Ω ± 10%	,3,300
oad resistor for primary current ransformer (Pos. 6.11).	WAP7	WAP7
Resistance harmonic filter (Pos 8.3). Variation		0.27
allowed ± 10%	0.2 Ω	0.252
Between wire 5 & 6	0.2 Ω	0.452
Between wire 6 & 7	0.4 Ω	
Between wire 5 & 7	10 kΩ± 10%	10,340
For train bus, line U13A to earthing.	10 kΩ ± 10%	10.0kg
in a line III3B to earthing.	200 MΩ	300MJB
- de la	200	*
from the top of the root to the		0.285
(by1000 V megger).	≤0.3 Ω	0.77
Resistance measurement earth return		0.2852
brushes Pos. 10/1. Resistance measurement earth return	≤0.3 Ω	
Resistance measurement cure. brushes Pos. 10/2.		v. 30 v
Resistance measurement earth return	≤0.3 Ω	
hauches Pos 10/3.	≤0.3 Ω	0.2852
Resistance measurement earth return	50.5 12	
	2.2 kΩ± 10%	2.2KS
Farthing resistance (earth Idult detection)		2.7452
· Filtor - I. POS O.U.	100/	2.1
Earthing resistance (earth fault detection)		3.812
Harmonic Filter –II; Pos 8.62.) $3.9 \text{ k}\Omega \pm 10\%$	
Earthing resistance (earth fault detection Aux. Converter; Pos. 90.3.	120/	1.8KS
Earthing resistance (earth fault detection	1.8 kΩ± 10%	
41E/110V: POS. 9U.41.		3905
Earthing resistance (earth fault detection	a) $390\Omega \pm 10\%$	
- atrol circilli PDS. JU.7:	1 - 100/	MA
: tamas (parth fault detection	n) 3.3 K121 10/0	103
11 stal load: POS 3/.1(111 case o)	100/	1001
Resistance for headlight dimmer; Pos. 33	2.3. 1011 1070	ges/

Effective Date: March 2021

Doc.No.F/TRS/01 (Ref: WI/TRS/10) Issue No.02

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC Page: 6 of 27

Make sure that the earthing brush device don't make direct contact with the axle housing, Note: earth connection must go by brushes.

2.2 Check Points

2.2 Check Points	Remarks
Items to be checked	
Check whether all the earthing connection in roof and machine room as mentioned in sheet no. 22A is done properly or not. These earthing connections must be flexible and should be	cheeked or
marked yellow & green Check whether all the earthing connection between loco body and bogie is done properly or not. These cables must be flexible having correct length and cross section	cheeped a

2.3 Low Tension Test Battery Circuits (without control electronics)

These tests are done with the help of the special type test loop boxes as per procedure given in

nese tests are done with the help of the ara 3.6 of the document no. 3 EHX 610	Schematic used.	Remarks
ame of the test		charbedoe
est 24V supply	Sheet 04F and other linked sheets	
Fest 48V supply	Sheet 04F & sheets of group 09	of of
	Sheets of Group 08.	Fan supply to be checked.
Test traction control Test power supply bus stations.	Sheets of Group 09.	Fan supply to be chesical
	Sheets of Group 05.	24
Test control main apparatus Test earth fault detection battery	Sheet 04C	O(C
circuit by making artificial earth fault to test the earth fault detection	Sheets of Group 06	OK
Test control Pneumatic devices	Sheets of Group 07	OK
Test lighting control	Sheets of Group 10	OK
Pretest speedometer Pretest vigilance control and fire	Sheets of Group 11	DK
system Power supply train bus	Sheets of Group 13	occ

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/559 Downloading of Software Type of Locomotive: WAP-7/WAG-9HC Page: 7 of 27

3.0 Downloading of Software	Yes/No
3.1 Check Points. Check that all the cards are physically present in the bus stations and all the plugs are	Yes
connected. Check that all the fibre optic cables are correctly connected to the bus stations.	Yes
tral electronics off relay is not energized i.e. discourse	Tes
Make sure that control electromes 411.LG and loco is set up in simulation mode. 411.LG and loco is set up in simulation mode. Check that battery power is on and all the MCBs (Pos. 127.*) in SB1 &SB2 are on	Yes

The software of Traction converter, Auxiliary converter and VCU should be done by commissioning engineer of the firm in presence of supervisor. Correct software version of the

ommissioning engineer of the firm in presence or ropulsion equipment to be ensured and noted:	26	
Traction converter-1 software version.	26	
Traction converter-2 software version.	3.0	
Auviliary converter-1 software version.	3.0	
Auxiliary converter-2 software version.	3.0	
Auxiliary converter-3 software version.	2008	
Vahisla control unit -1 software version.	2008	
Vehicle control unit -2 software version:		

Check for the following analogue signals with the help of diagnostic tool connected with loco. 3.3 Analogue Signal Checking

Check for the following	analogue signals with the help of diago	Prescribed value	Measured
Description	Signal name		Value
	FLG2;0101XPrAutoBkLn	100% (= 5 Kg/cm2)	OK
Brake pipe pressure	FLG2; AMSB_0201- Wpn BEdem	100% (= 10V)	OK
Actual BE electric		Between 9% and 11 %	10%
TE/BE at 'o' position	FLG1; AMSB_0101- Xang Trans	Between 770 and	
from both cab	FLG2; AMSB_0101- Xang Trans FLG1; AMSB_0101- Xang Trans	Between 99 % and 101 %	100%
TE/BE at 'TE maximal' position from both cab	- T	7.	
	+ MCD 0101- Xang Trans	Between 20 % and 25 %	244
TE/BE at 'TE minimal'	FLG2; AMSB_0101- Xang Trans		

Effective Date: March 2021

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/559

Type of Locomotive: WAP-7/WAG-9HC

Page: 8 of 27

re/BE at 'BE maximal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 99% and 101%	100%
TE/BE at 'BE Minimal' position from both cab	FLG1; AMSB_0101-	Between 20% and 25%	244,
TE/BE at '1/3' position in TE and BE mode in both cab.	TIDDI. AMS 0101-	Between 42 and 44%	444
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>2/3 HBB2; AMS_0101- LT/BDEM>2/3	Between 72 and 74%	74.4
Both temperature sensor of TM1	SLG1; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	37.5°C
Both temperature sensor of TM2	SLG1; AMSB_0106- Xatmp2Mot		
Both temperature sensor of TM3	SLG1; AMSB_0106- Xatmp3Mot		
Both temperature sensor of TM4	SLG2; AMSB_0106 XAtmp1Mot	=	
Both temperature sensor of TM5	SLG2; AMSB_0106 Xatmp2Mot		
Both temperature sensor of TM6	SLG2; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	37°C

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC Page: 9 of 27

Functional test in simulation mode 3.4

Conduct the following functional tests in simulation mode as per Para 5.5 of document no.3EHX 610 281. through the Diagnostic tool/laptop:

Test Function	Result desired in sequence	Result obtained
Emergency shutdown through emergency stop switch 244	VCB must open. Panto must lower.	cheeked or
shut Down through cab activation switch to OFF position	VCB must open. Panto must lower.	cherked on
Converter and filter contactor operation with both Power Converters during Start Up.	FB contactor 8.41 is closed. By moving reverser handle: Converter pre-charging contactor 12.3 must close after few seconds. Converter contactor 12.4 must close. Converter re-charging contactor 12.3 must opens. By increasing TE/BE throttle: FB contactor 8.41 must open. FB contactor 8.2 must close. FB contactor 8.1 must close.	checked or
Converter and filter contact operation with both Pow Converters during Shut Down.	bring TE/BE to O. Bring the cab activation key to "O" VCB must open. Panto must lower. Converter contactor 12.4 must ope FB contactor 8.1 must open. FB contactors 8.41 must close. FB contactor 8.2 must remain close	8

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC Page: 10 of 27

	through bogie ()	1
ontactor filter adaptation by	Isolate any one bogie through bogie cut out switch. Wait for self-test of	
plating any bogie	the loco.	
	• Check that FB contactor 8.1 is open.	
	• Check that FB contactor 8.2 is open. • Check that FB contactor 8.2 is open.	ou
26 (E)	After raising panto, closing VCB, and	
	After raising parito, closing 1 = 7	
	setting TE/BE	
	• FB contactor 8.1 closes.	
	• FB contactor 8.2 remains open.	
hottory.	By connecting wire 2050 to	
est earth fault detection battery	earth, create earth fault	
circuit positive & negative	negative potential.	
	• message for earth fault	10.
	• message for earth fault	थ ज्
· ·	By connecting wife 2000	
	to earth, create earth	
	fault positive potential.	
	message for earth fault	
·	When smoke sensor-1 gets	
Test fire system. Create a smoke in	activated then	
the machine room near the FDU.	1 activated their	
Watch for activation of alarm.	Alarm triggers and fault	
Water for decision	message priority 2	10
	appears on screen.	400
	When both smoke sensor	
	1+2 gets activated then	
	A fault message priority	
	1 appears on screen and	
	Lappears of serees.	
S REF	lamp LSF1 glow.	
	Start/Running interlock occurs and	
	TE/BE becomes to 0.	
a L symbor	France correct date time and Loco	
Time, date & loco number	number	
110	P	

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

Page: 11 of 27

4.0 Sensor Test and Converter Test

4.1 Test wiring main Transformer Circuits

Apply $198V_p/140V_{RMS}$ to the primary winding of the transformer (at 1u; wire no. 2 at surge arrestor and at 1v; wire no. 100 at earthing choke). Measure the output voltage and compare

he phase of the Output Winding nos.	v; wire no. 100 at earthing the following of the transformers. Description of winding.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
2U ₁ & 2V ₁	For line converter bogie 1 between cable 801A- 804A	10.05V _p and same polarity	10.04vp	6K
2U ₄ & 2V ₄	For line converter bogie 1 between cable 811A- 814A	10.05V _p and same polarity	10:0400	8K
2U ₂ & 2V ₂	For line converter bogie 2 between cable 801B-804B	10.05V _p and same polarity	10.05Vp	OK
2U ₃ & 2V ₃	For line converter bogie 2 between cable 811B-814B	10.05V _p and same polarity	10.05VP	,
2U _B & 2V _B	For aux. converter 1 between cable 1103- 1117 (in HB1) For Aux converter 2 between cable 1103-	7.9V _p , 5.6V _{RMS} and same polarity.	5.20/5/bs) ok
2U _F & 2V _F	For harmonic filter between cable 4-12 (in	9.12V _p , 6.45V _{RMS} and same polarity.	9.11/f 6.44/pms	9 04

4.2 Test wiring auxiliary transformer 1000V/415V-110V (pos. 67) Apply $141V_p$ / $100V_{RMS}$ to input of the auxiliary transformer at cable no 1203 –1117 and measure the output at

Description of wire no.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
Cable no. 1218 - 1200	2 = 2 7 / 41 5 / and opposite polarity.	58.5VP 9	OK
Cable no. 1218 – 6500	15.5V _p , 11.0V _{RMS} and opposite polarity.	15-42P 1	OK

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC Page: 12 of 27

4.3 Primary Voltage Transformer

Apply $250V_{eff}/350V_p$ by variac to roof wire 1 and any wire 0 and measure the magnitude and polarity of the output of the primary voltage transformer for both bogies as per the procedure specified and suggested by the traction converter manufacturer. Primary voltage measurement converters (Pos. 224.1/*) & catenary voltmeter (Pos. 74/*)

This test is to be done for each converter.

Activate cab in driving mode and supply $200V_{RMS}$ through variac to wire no 1501 and 1502. Monitor the following parameters through Diagnostic tool and in catenary voltmeter.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
o of MID:	25kV	250%	25KV	2501
SLG1_G 87-XUPrim		250%	25 VV	2504
SLG2 G 87-XUPrim	25 kV	23070		

Decrease the supply voltage below 140 V_{RMS} . VCB must open at this voltage. In this case the readings in Diagnostic Tool and catenary voltmeter will be as follows.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
	14711/	170%	17KV	170%
SLG1 G 87-XUPrim	17kV		17×V	1707.
SLG2 G 87-XUPrim	17 kV	170%	7 (

Reactivate VCB to on by increasing this voltage to 175% (17.5 kV).

Increase the supply to 240 V_{RMS} through variac. VCB must open at this voltage, In this case the readings in diagnostic tool and catenary voltmeter will be as follows:

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
	30kV	300%	30KN	300%
SLG1_G 87-XUPrim		300%	30KV	
SLG2 G 87-XUPrim	30 kV	30070		

Reactivate VCB to on by decreasing this voltage to 290% (29 kV).

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC Page: 13 of 27

4.4 Minimum voltage relay (Pos. 86)

4 Minimum voicage 1014)	
Inctionality test: Minimum voltage relay (Pos. 86) must be adjust	ed to approx 68%
Minimum voltage relay (Pos. 86) must be adjust	L(Yes/No)
the cooling mode Check Power supply 01 48 V to	7 (65)
ninimum voltage relay. Disconnect primary voltage	
ransformer (wire no. 1511 and 1512) from load resistor (Pos.	
ransformer (wire no. 1511 and 1512) Normal and 1502. Supply (4.2) and connect variac to wire no. 1501 and 1502. Supply	
4.2) and connect variac to wife no. 1301 and 1302 and 2007 and 200	
Pos. 86) picks up	
1 03. 00/ \$10.00	2
	(Yes/No)
Try to activate the cab in driving mode:	
Contactor 218 do not close; the control	
electronics is not be working.	L(Yes/No)
- ff the variati	LITESTICO
Contactor 218 closes; the control electronics is be	200
1.	
working Test Under Voltage Protection	<u>n;</u>
1000 011	
li ando Raiso nanto.	(Yes/No)
Activate the cab in cooling mode; Raise panto;	
Supply 200V _{RMS} through variac to wire no. 1501	
& 1502; Close the VCB; Interrupt the supply	
voltage	
The VCB goes off after 2 second time delay.	(Yes/No)
a is supply 200Vases through variac to wire no.	
1501 & 1502; Decrease the supply voltage below	
1.01/.	
$140V_{RMS} \pm 4V$; Fine tune the minimum voltage relay so that VCB opens.	

4.5 Maximum current relay (Pos. 78) Disconnect wire 1521 & 1522 of primary current transference with the second state of primary current transference with the second state of the second	en wire 1521; Tune the drum of the
VCB opens with Priority 1 fault message on	(Yes/No)
display. Keep contact $R_3 - R_4$ of 136.3 closed; Close VCB; Tune the /9.9 A_p at the open wire 1521;	resistor 78.1 for the current of 7.0A _{RMS}
VCB opens with Priority 1 fault message on display.	(Yes/No)

18

Effective Date: March 2021

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41557

Type of Locomotive: WAP-7/WAG-9HC Page: 14 of 27

Test current sensors	Description of the test	Prescribed value	Set/Measured value
mary return current nsor (Test-1,Pos.6.2/1 6.2/2)	Activate cab in driving mode supply 10A. Measure the current through diagnostic tool or measuring print.	(Variation allowed is ± 10%)	
	Supply 90mA _{DC} to the test winding of sensor through connector 415.AA/100 2 pin no. 7(+) & 8(-)		
imary return current ensor (Test-2, Pos.6.2/1 6.2/2)	Supply 297mA _{DC} to the test winding o sensor through connector 415.AA/1o 2 pin no. 7(+) & 8(-)	f r	298mB
Auxiliary winding current sensor (Pos. 42.3/1 & 42.3/2)	Supply 90mA _{DC} to the test winding of sensor through connector 415.AC/16 2 pin no. 7(+) & 8(-) Supply 333mA _{DC} to the test winding of sensor through connector 415.AC/1 or 2 pin no. 7(+) & 8(-)	of	330mp
Harmonic filter current sensors (Pos.8.5/1 &8.5/2)	Supply 90mA _{DC} to the test winding sensor through connector 415.AE/12 pin no. 7(+) & 8(-) Supply 342mA _{DC} to the test winding sensor through connector 415.AE/12 pin no. 7(+) & 8(-)	of	340mm
Hotel load current	Switch on hotel load. Supply 90mA to the test winding of sensor throu connector 415.AG/1or 2 pin no. 7(8(-)	+) &	MA
sensors (Pos. 33/1 & 33/2)	Supply 1242mA _{DC} to the test wind of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)	ding	HA

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

4.7 Test DC Link Voltage Sensors (Pos 15.6/*)

Page: 15 of 27

This test is to be done by the commissioning engineer of the firm if required.

4.8 Verification of Converter Protection Circuits (Hardware limits) -

This test is to be done as per para 6.17 of the document no. 3EHX 610 282 for both the converters.

Protection circuits	Limit on which shutdown should take place	Measured limit
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 1	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1=
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 2	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 8.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=
Fibre optic failure In Power Converter1	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	OK
Fibre optic failure In Power Converter2	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	ek

4.9 Sequence of BUR contactors

The sequence of operation of BUR contactors for 'ALL BUR OK' BUR 1 out BUR 2 out and BUR 3 out condition has to be verified by putting the Loco in driving mode (VCB should not be closed) and isolating the BURs one by one. In these condition following will be the contactor sequence.

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
Al BUR OK	Close	Open	Close	Open	Close	Open	Close	Close	Open
BUR1 off	Close	Open	Close	Close	Open	Close	Open	Open	Close
BUR2 off	Open	Open	Close	Close	Close	Close	Open	Open	Close
BUR3 off	Open	Close	Open	Close	Close	Close	Open	Open	Close

31

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

Page: 16 of 27

Monitored contactor sequence

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	closs	open	clos	open	close	open	clos	Clos	Open
BUR1 off	close	8pen	Close	closs	open	clos	Open	open	elog
BUR2 off	open	open	clos	clos	clos	clas	open	open	clos
BUR3 off	open	close	open	close	close	clos	oper	Open	clos

5.0 Commissioning with High Voltage

5.1 Check List

Items to be checked	Yes/No
Fibre optic cables connected correctly.	Yes
No rubbish in machine room, on the roof, under the loco.	Yes.
All the electronic Sub-D and connectors connected	Yes
All the MCBs of the HB1 & HB2 open.	Yes
All the three fuses 40/* of the auxiliary converters	Tes
The fuse of the 415/110V auxiliary circuit (in HB1) open.	Yaz
Roof to roof earthing and roof to cab earthing done	Yes
Fixing, connection and earthing in the surge arrestor done correctly.	Yes
Connection in all the traction motors done correctly.	Yes
All the bogie body connection and earthing connection done correctly.	les
Pulse generator (Pos. 94.1) connection done correctly.	Tey
All the oil cocks of the gate valve of the transformer in open condition.	reg
All covers on Aux & Power converters, Filter block, HB1, HB2 fitted	Tey
KABA key interlocking system.	rej.

5.2 Safety test main circuit breaker

Prepare to switch off the catenary supply during the first charging of the locomotive in case of any unexpected behavior of the electrical component of the loco. Charge the loco for the first time by closing BLDJ switch. The VCB will trip after certain time as no oil/coolant pumps are running yet.

Perform the following safety test of main circuit breaker through both the cabs of the locomotive.

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC Page : 17 of 27

Name of the test	Description of the test	Expected result	Monitored result
Emergency stop in cooling mode	Raise panto in cooling mode. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	cherked ox
Emergency stop in driving mode	Raise panto in driving mode in. Put the brake controller into RUN position. Close the VCB.	VCB must open. Panto must lower. Emergency	cheekeelog
	Push emergency stop button 244.	brake will be applied.	
Under voltage protection in cooling mode	Raise panto in cooling mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open.	charged or
Under voltage protection in driving mode	Raise panto in driving mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open with diagnostic message that catenary voltage out of limits	chekeelou
Shut down in cooling mode.	Raise panto in cooling mode. Close the VCB. Bring the BL- key in O position.	VCB must open. Panto must lower.	cheekeel or
Shutdown in driving mode	Raise panto in driving mode. Close the VCB. Bring the BL-key in O position.	VCB must open. Panto must lower.	checked ou
Interlocking pantograph- VCB in cooling mode	Raise panto in cooling mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	charked on
Interlocking pantograph- VCB in driving mode	Raise panto in driving mode. Close the VCB. Lower the pantograph by ZPT		Cherkeelog

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/559

Type of Locomotive: WAP-7/WAG-9HC

Page: 18 of 27

5.3 Auxiliary Converter Commissioning

Switch on the high voltage supply and set up the loco in driving mode. Raise the panto. Close the VCB. Check that there is no earth fault in the auxiliary circuit, Switch off the VCB. Lower the panto. Create the earth fault in auxiliary circuit by making connection between wire no 1117(in HB2 cubicle) and earth. After 3 minutes a diagnostic message will come that "Earth fault auxiliary circuit."

5.3.1 Running test of 3 ph. auxiliary equipments

Switch on the 3 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured continuous phase current	Measured starting phase current
Oil pump transformer 1	9.8 amps	8.8	9.5
Oil pump transformer 2	9.8 amps	9.3	1),0
Coolant pump converter 1	19.6 amps	4.8	6.2
Coolant pump converter 2	19.6 amps	5.0	6.3
Oil cooling blower unit 1	40.0 amps	42.0	1150
Oil cooling blower unit 2	40.0 amps	40.0	105.0
Traction motor blower 1	34.0 amps	27.0	112.0
Traction motor blower 2	34.0 amps	26.4	137.0
Sc. Blower to Traction motor blower 1	6.0 amps	5.3	6.4
Sc. Blower to Traction motor blower 1	6.0 amps	5.1	6,6
Compressor 1	25 amps at 0 kg/ cm ² 40 amps at 10 kg/ cm ²	27.0	110,0
Compressor 2	25 amps at 0 kg/ cm ² 40 amps at 10 kg/ cm ²	26.5	125.0

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/559

Type of Locomotive: WAP-7/WAG-9HC

Page: 19 of 27

5.3.2 Performance of Auxiliary Converters

Measure the performance of the auxiliary converters through software and record it. BUR1 (Condition: Switch off all the load of BUR 1)- to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value	Monitored value	Value under Limit (Yes/No)
BURI 7303 XUUN	Input voltage to BUR1	75% (10%=125V)	998	Yey
BUR1 7303 XUUZ1	DC link voltage of BUR1	60% (10%=100V)	563 V	Yes
BURI 7303 XUIZI	DC link current of BUR1	0% (10%=50A)	1 Amp	Yes

BUR2 (Condition: Switch off all the load of BUR 2, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value by the firm	Monitored value	Value under Limit (Yes/No)
BUR2 7303-XUUN	Input voltage to BUR2	75% (10%=125V)	10001	Yey
BUR2 7303-XUUZ1	DC link voltage of BUR2	60% (10%=100V)	500V	tes
BUR2 7303-XUIZ 1	DC link current of BUR2	1% (10%=50A)*	7 Am	Tes
BUR2 7303-XUILG	Current battery charger of BUR2	3% (10%=100A)*	24 Boy	Yes
BUR2 7303-XUIB1	Current battery of BUR2	1.5%(10%=100A)*	12Amp	Yes .
BUR2 7303 -XUUB	Voltage battery of BUR2	110%(10%=10V)	1100	Yen

^{*} Readings are dependent upon charging condition of the battery.

BUR3 (Condition: Switch off all the load of BUR 3, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed set value by the firm	Monitored value	Value under limit (Yes/No)
BUR3 7303-XUUN	Input voltage to BUR3	75% (10%=125V	1005	Yey
BUR3 7303- XUUZI	DC link voltage of BUR3	60% (10%=100V)	499V	Yes
BUR3 7303-XUIZ 1	DC link current of BUR3	1% (10%=50A)*	7 Amp	Yes
BUR3 7303-XUILG	Current battery charger of BUR 3	3% (10%=100A)*	22 pulp	Yes
BUR3 7303-XUIB1	Current battery of BUR 3	1.5%(10%=100A)*	due 11	Yes
BUR3 7303-XUUB	Voltage battery of BUR 3	110%(10%=10V)	110~	Yes

^{*} Readings are dependent upon charging condition of the battery.

Sk

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

Page: 20 of 27

cherred

5.3.3 Performance of BURs when one BUR goes out

When any one BUR goes out then rest of the two BURs should take the load of all the auxiliaries at ventilation level 3 of the locomotive.

Condition of BURs	Loads on BUR1	Loads in BUR2	Loads in BUR3
All BURs OK	Oil Cooling unit 1&2	TM blower1&2, TFP oil pump 1&2, SR coolant pump 1&2.	Compressor 1&2, Battery charger and TM Scavenger blower 1&2
BUR 1 out		Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2,TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 2 out	Oil Cooling unit 1&2, TM blower 1&2, TM Scavenger blower 1&2		Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 3 out	Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.	

5.4 Auxiliary circuit 415/110

For checking earth fault detection, make a connection between wire no. 1218 and vehicle body. On switching on VCB, Earth fault relay 89.5 must pick up and after 3 minutes a message will come in the Diagnostic display that Earth Fault 415/110V Circuit

Switch on the 1 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured phase current	Measured starting current
Machine room blower 1	15.0 amps*	5.8	36.3
Machine room blower 2	15.0 amps*	6. 2	32.0
Sc. Blower to MR blower 1	1.3 amps	1.9	12.0
Sc. Blower to MR blower 2	1.3 amps	1.9	12.6
Ventilator cab heater 1	1.1 amps	1.3	1.5
Ventilator cab heater 2	1.1 amps	1.3	1.5
Cab heater 1	4.8 amps	5.0	5.7
Cab heater 2	4.8 amps	5.0	5.2

^{*} For indigenous MR blowers.

fr

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

Page: 21 of 27

5.5 Hotel load circuit (Not applicable for WAG-9HC)

For WAP-7 locomotive with Hotel load converter refer to Annexure-HLC

5.6 Traction Converter Commissioning

This test is carried out in association with Firm.

Traction converter commissioning is being done one at a time. For testing Converter 1, switch off the traction converter 2 by switch bogie cut out switch 154. For testing Converter 2, switch off the traction converter 2 by switch bogie cut out switch 154. Isolate the harmonic filter also by switch 160. Start up the loco by one converter. Follow the functionality tests.

For Converter 1

Test Function	Results desired	Result obtained
Measurement of charging and pre- charging and charging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	cheeked oil
Measurement of discharging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	cherkedou
Earth fault detection on positive potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	charced on
Earth fault detection on negative potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	checkeel ou
Earth fault detection on AC part of the traction circuit of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	cherked ox
Pulsing of line converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	charkedou
Pulsing of drive converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	checked ou

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

Page: 22 of 27

For Converter 2

Test Function	Results desired in sequence	Result obtained
Measurement of charging and pre- charging and charging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	cholked on
Measurement of discharging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	cherked ou
	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	choused on
	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/v	chereed of
Earth fault detection on AC part of the traction circuit of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	chalced on
of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	chocked on
Pulsing of drive converter of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	cholked ou

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

Page: 23 of 27

5.7 Test protective shutdown SR

Test Function	Results desired in sequence	Result obtained
Measurement of	Start up the loco with both the	
protective shutdown	converter. Raise panto. Close VCB.	\sim
by Converter 1		
electronics.	Move Reverser handle to forward or	
electronics.	reverse. Remove one of the orange	
	fibre optic feedback cable from	& cheeked on
	converter 1Check that converter 1	
	electronics produces a protective shut	
	down.	*=;
	• VCB goes off	
	 Priority 1 fault mesg. on DDU 	
	appears	
	Disturbance in Converter 1	
Measurement of	Start up the loco with both the	Q
protective shutdown	converter. Raise panto. Close VCB.	
by Converter 2	Move Reverser handle to forward or	N = 0
electronics.	reverse. Remove one of the orange	
	fibre optic feedback cable from	o checked or
	converter 2. Check that converter 2	
	electronics produces a protective shut	
	down.	
	 VCB goes off 	
	 Priority 1 fault mesg. on diagnostic 	
	display appears	
	Disturbance in Converter 2	Y

5.8 Test Harmonic Filter

Switch on the filter by switch 160

Test Function	Results desired in sequence	Result obtained
Measurement of filter currents	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Apply a small value of TE/BE by moving the throttle. • FB contactor 8.41 must open.	Cheekoelou

fer

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

Page: 24 of 27

	• FB contactor 8.2 must close.	
	• FB contactor 8.1 must close	* A 45
	• Check the filter current in	
	diagnostic laptop	
	Bring the TE/BE throttle to O	Page 1000 100
4.8 5 10 202	Switch off the VCB	chercelou
	• FB contactor 8.1must open.	
	• FB discharging contactor 8.41	
20.0	must close	
	Check the filter current in	
	diagnostic laptop	
Test earth fault	Make a connection between wire	
detection harmonic	no. 12 and vehicle body. Start up	
filter circuit.	the loco. Close VCB.	A / Aw
	• Earth fault relay 89.6 must pick up.	cheekeelor
4	Diagnostic message comes that -	
	Earth fault in harmonic filter circuit	
	7	
Test traction motor	Traction converter manufacturer 9	
speed sensors for	to declare the successful operation	or
both bogie in both	and demonstrate the same to the	
cabs	supervisor/ DMW	

5.9 Test important components of the locomotive

Items to be tested	Description of the test	Monitored value/remarks
Speedometer	VCU converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ DMW	cheeped ore
Time delay module of MR blower	The time after which the starting capacitor for MR blower should go off the circuit should be set to 10-12 seconds	cheekeelok
Ni-Cd battery voltage	At full charge, the battery voltage should be 110V DC.	checkeelor
Flasher light	From both cab flasher light should blink at least 65 times in one minute.	e helked on
Head light	Head light should glow from both cabs by operating ZLPRD. Dimmer operation of headlight should also occur by operating the switch ZLPRD.	chercel ou

Effective Date: March 2021

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

Page: 25 of 27

Marker light	Both front and tail marker light should glow from both the cabs	cheeked ar
Cab Light	Cab light should glow in both the cabs by operating the switch ZLC	charced or
Spot lights	Both Drivers and Asst. Drivers Spot light should glow in both cabs by operating ZLDD	cheekeel ou
Instrument lights	Instrument light should glow from both cab by operating the switch ZLI	charceel on
Illuminated Push button	All illuminated push buttons should glow during the operation	chelled al
Contact pressure of the high rating contactors	The contact pressure of FB contactors (8.1, 8.2) is to be measured Criteria: The minimum contact pressure is 54 to 66 Newton.	For contactor 8.1: 9 For contactor 8.2:
rew Fan	All crew fans should work properly when VCB of the loco is switched on. The airflow from each cab fan is to be measured. Criteria: The minimum flow of air of cab fan should be 25 m ³ /minute	Cab 1 LHS: Cab 1 RHS: Cab 2 LHS: Cab 2 RHS:

6.0 Running Trial of the locomotive

SN	Description of the items to be seen during trail run	Action which should take place	Remarks
1	Cab activation in driving mode	No fault message should appear on the diagnostic panel of the loco.	Clerkedoy
	Loco charging	Loco to be charged and all auxiliaries should run. No fault message to appear on the diagnostic panel of the loco. Raise MR pressure to 10 Kg/cm ² , BP to 5 Kg/cm ² , FP to 6 Kg/cm ² .	cheekeelou
3.	Check function of Emergency push stop.	This switch is active only in activated cab. By pushing this switch VCB should open & pantograph should be lowered.	charkedox
4.	Check function of BPCS.	 Beyond 5 kmph, press BPCS, the speed of loco should be constant. BPCS action should be cancelled by moving TE/BE throttle, by dropping BP below 4.75 Kg/cm², by pressing BPCS again. 	cheercolon
5.	Check train parting operation of the Locomotive.	Operate the emergency cock to drop the BP Pressure LSAF should glow.	chelkedop

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

Page: 26 of 27

6.	Check vigilance	Set the speed more than 1.5 kmph and ensure that
	operation of the	brakes are released i.e. BC < 1 Kg/cm ² .
200"	locomotive	For 60 seconds do not press vigilance foot switch or
		sanding foots switch or TE/BE throttle or BPVG
- 100		switch then
		Buzzer should start buzzing.
- B		• LSVW should glow continuously.
1000	11 881 2 ,	Do not acknowledge the alarm through BPVG or
		vigilance foot switch further for 8 seconds then:-
		Emergency brake should be applied
		automatically.
		VCB should be switched off.
	8 8 8	Resetting of this penalty brake is possible only after
		180 seconds by bringing TE/BE throttle to 0 and
		acknowledge BPVR and press & release vigilance
		foot switch.
7.	Check start/run interlock	• At low pressure of MR (< 5.6 Kg/cm ²).
		At low pressure of MR (< 5.6 Kg/cm²). With park brake in applied condition. NA
17		• With direct loco brake applied (BP< 4.75Kg/cm ²).
		• With automatic train brake applied (BP<4.75Kg/cm ²).
		• With emergency cock (BP < 4.75 Kg/cm ²).
8.	Check traction interlock	Switch of the brake electronics. The
		Tractive / Braking effort should ramp down, VCB
		Tractive / Braking effort should ramp down, VCB should open and BP reduces rapidly.
9.	Check regenerative	Bring the TE/BE throttle to BE side. Loco speed ? Leckgelou
	braking.	should start reducing.
10.	Check for BUR	In the event of failure of one BUR, rest of the two
	redundancy test at	BURs can take the load of all the auxiliaries. For this
	ventilation level 1 & 3 of	switch off one BUR.
	loco operation	Auxiliaries should be catered by rest of two BURs.
		Switch off the 2 BURs; loco should trip in this case.
11.	Check the power	Create disturbance in power converter by switching
	converter	off the electronics. VCB should open and converter
	isolation test	should get isolated and traction is possible with
		another power converter.

Se

Issue No.02

Effective Date: March 2021

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41559

Type of Locomotive: WAP-7/WAG-9HC

Page: 27 of 27

7.0 Final check list to be verified at the time of Loco dispatch

Condition /Operations of the following items are to be checked:

SN	Item	Cab-1	Cab-2	Remarks
1	Head lights	OK	OK C	
2	Marker Red	OK	OK	
3	Marker White	01	OK	
4	Cab Lights	012	OK	
5	Dr Spot Light	OK	DK.	cheesed worther
6	Asst Dr Spot Light	04	OK) ok
7	Flasher Light	OK	OK	
8	Instrument Lights	DV	OK	
9	Corridor Light	OK	OK	
10	Cab Fans	D&	OK	
11	Cab Heater/Blowers	OV	OK	
12	All Cab Signal Lamps Panel 'A'	Oa	OR	

Status of RDSO modifications



LOCO NO: 4/589

	n Modification No.	Description	Remarks
1		7 Modification in control size it s	Kemarks
	Rev.'0' Dt 20.02.08	7 Modification in control circuit of Flasher Light and Head Light of three phase electric locametics	/
2	DD00/000	prises electric locornotives.	Ok/Not Ok
2.			
	Rev.'0' Dt 22.04.09	locomotives.	6
3.	RDSO/2010/EL/MS/039		Ok/Not Ok
	Rev.'0' Dt 31.12.10	· signified of filleringing of ED contact-	1
4.	RDSO/2011/EL/MS/0399	three phase locomotives to improve reliability.	6k/Not Ok
	Rev.'0' Dt 08.08.11	removal of interlocks of control circuit control	/
5.			6k/Not 0k
	Rev.'0' Dt 10.08.11		
	21 10.00.11	KV, 70 sq mm cables and 2x2.5 sq mm cables housed in lower portion of HB2 panel and are said are said and are said and are said and are said and are said are said are said and are said are s	
			6k/Not 0k
6.	RDSO/2011/EL/MS/0401		/
Ο.	Rev.'0' Dt 10.08.11	modification special to the second of second of the second	
7.			6k/Not 0k
1.	RDSO/2011/EL/MS/0403 Rev.'0' Dt 30.11.11	Auto Switchillo Of Machine room/service is	/ OK
0	PD00/0015		Qk/Not Ok
8.	RDSO/2012/EL/MS/0408 Rev.'0'	The second of th	QIVIVOL OK
_			Øk/Not Ok
9.	RDSO/2012/EL/MS/0411	Modification sheet to avoid simultaneous switching ON of White and Red marker light in the switching ON of	GK/NOLOK
	Rev.'1' dated 02.11.12	White and Red marker light in the Switching ON of	
	*	White and Red marker light in three phase electric locomotives.	Ok/Not Ok
10	RDSO/2012/EL/MS/0413	Paralleling of interlooks of ED	/
	Rev.'1' Dt 25.04.16	Paralleling of interlocks of EP contactors and auxiliary	dini
11	RDSO/2012/EL/MS/0419		Ok/Not Ok
	Rev.'0' Dt 20.12.12		du
2	RDSO/2013/EL/MS/0420	Modification	Øk/Not Ok
	Rev.'0' Dt 23.01.13	Modification sheet to provide mechanical locking	/
100000			Ok/Not Ok
3	RDSO/2013/EL/MS/0425		- Into OK
	Rev.'0' Dt 22.05.13	Modification sheet for improving illumination of head light in	
4	DDCC		Øk/Not Ok
	ROW'N' D+ 10 07 10	Woodincation sheet of Bogie isolation rotary switch in three	
5			Ok/Not Ok
	Pau'n' D+ 22 40 40	Modification sheet for MCP control in three phase electric	/
6			ok/Not Ok
		Woldfication sheet for relocation of and the control of the contro	/
			L
7			ok/Not Ok
	David Di 10 22	Removal of shorting link provided at a literature	/
			k/Not Ok
,	D- 101 D = -	TOVISION OF AUXILIARY INTERIORIS for many the	10.01
		10.1//quobility (8/) Contactor in OTO//on-	
+	DDOO		k/Not Ok
)	RDSO/2017/EL/MS/0467	Modification in blocking diodes to increase and in the	
	Rev.'0' Dt 07.12.17	Modification in blocking diodes to improve reliability in three phase electric locomotives.	N/Not O
			k/Not Ok
	201	Modification in existing Control Electronics (CE) resetting	
I	2000/00/10		k/Not Ok
F	Rev.'0' Dt 18.09.19	implementation of push pull scheme.	
1	Parameter State St	//	k/Not Ok

Signature of JE/SSE/TRS

DMW/PATIALA

Loco No.: 41559



PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

S.N	Parameters	Reference	Value	Result
1.0	Auxillary Air supply system (Pantograph & VCB)		ets.	
1.1	Ensure, Air is completely vented from pantograph		0	0
	Reservoir (Ensure Panto gauge reading is Zero)			
1.2	Turn On BL Key. Now MCPA starts.		60 sec. (Max.)	57 Sec
	Record pressure Build up time (8.5kg/cm2)			
1.3	Auxillary compressor safety Valve 23F setting	Faiveley Doc. No. DMTS-014-1, 8	8.5±0.25kg/cm2 -	8.5 Kg/cm2
		CLW's check sheet no. F60.812 Version 2	*	at a
1.4	Check VCB Pressure Switch Setting	CLW's check sheet no. F60.812 Version 2	Opens 4.5±0.15 kg/cm2 closes 5.5±0.15 kg/cm2	4.5 Kg /cm2
1.5	Set pantograph Selector Switch is in Auto, Open pan-1&2 Iso	lating Cocks & KABA co		
1.6	Set Cab-1 Pan UP in Panel A.		Observed Pan-2 Rises.	ОК
1.7	Close Pan-2 isolating Cock		Panto-2 Falls Down	ОК
	Open Pan -2 isolating Cock		Panto-2 Rises	0.5
1.8	Record Pantograph Rise time		06 to 10 seconds	8 Sec
1.9	Record Pantograph Lowering Time		06 to 10 seconds	8 Sec
1.10	Panto line air leakage		0.7 kg/cm2 in 5 Min.	0.5 kg/cm2 in 5 Min.
2.0	Main Air Supply System			
2.1	Ensure, Air is completely vented from locomotive. Drain	Theoretical		
	out all the reservoirs by opening the drain cocks and then	calculation and test		
	closed drain cocks. MR air pressure build up time by each	performed by		
	compressor from 0 to 10 kg/cm2.	Railways.		
	i) with 1750 LPM compressor		i) 7 Mts. Max.	6.8 Mts
	ii) with 1450 LPM compressor		ii) 8.5 Mts. Max.	
2.2	Drain air below MR 8 kg/cm2 to start both the		Check Starting of	1
	compressors		both compressors	
2.3	Drain air from main reservoir up to 7 kg/cm2. Start		30 Sec. (Max)	CP1-28 Sec
	compressors, Check pressure build time of individual	10		The state of the s
	compressor from 8 kg/cm2 to 9 kg/cm2	=		CP2-28 Sec
2.4	Check Low MR Pressure Switch Setting (37)	D&M test spec.	Closes at 6.40±0.15	6.5 Kg/cm2
		MM3882 &	kg/cm2 Opens at	At 8
		MM3946	5.60±0.15kg/cm2	5.5 Kg/cm2
2.5	Check compressor Pressure Switch RGCP setting (35)	D&M test spec.	Closes at 10±0.20	10.0 Kg/cm ²
		MM3882 &	kg/cm2 Opens at	7758
		MM3946	8±0.20 kg/cm2	8.0 Kg/cm2
2.6	Run both the compressors Record Pressure build up time	Trial results	3.5 Minutes Max.	3.4 minute

Page 2 of 4 Loco No.:41559



				Approx. 12 Sec.	11 sec
Direct by BLCP. 2.10 Check CP-2 delivery safety valve setting (10/2) direct by BLCP 2.11 Switch 'OFF' the compressors and ensure that valve to reset at pressure 12 kg/cm2 less than pressure. 2.12 BP Pressure: Switch 'OFF' compressor, Drain M by drain cock of 1" Main Reservoir, Start Compreheck setting pressure of Duplex Check Valve 9 2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open is 136F. Check pressure in Gauge. 3.0 Air Dryer Operation 3.1 Open Drain Cock 90 of 2" MR to start Compreopen for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to Check Open In Full Service, Check MR I leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cock open for Test (Automatic Brake Operation) 5.0 Brake Test (Automatic Brake Operation) Record Brake Pipe & Brake Cylinder pressure a Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2)			Operates when	
Direct by BLCP. 2.10 Check CP-2 delivery safety valve setting (10/2) direct by BLCP 2.11 Switch 'OFF' the compressors and ensure that valve to reset at pressure 12 kg/cm2 less than pressure. 2.12 BP Pressure: Switch 'OFF' compressor, Drain M by drain cock of 1" Main Reservoir, Start Compreheck setting pressure of Duplex Check Valve 9 2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open is 136F. Check pressure in Gauge. 3.0 Air Dryer Operation 3.1 Open Drain Cock 90 of 2" MR to start Compreopen for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to Check Office to Check Condition of humidity indicator 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR I leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cock of Brake Test (Automatic Brake Operation) 5.1 Record Brake Pipe & Brake Cylinder pressure a Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2				Compressor starts	
direct by BLCP 2.11 Switch 'OFF' the compressors and ensure that valve to reset at pressure 12 kg/cm2 less than pressure. 2.12 BP Pressure: Switch 'OFF' compressor, Drain M by drain cock of 1" Main Reservoir, Start Compressor, Check setting pressure of Duplex Check Valve 9 2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open is 136F. Check pressure in Gauge. 3.0 Air Dryer Operation 3.1 Open Drain Cock 90 of 2nd MR to start Compresopen for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change the compression of th	. Run CP		est spec. & MM3946	11.50±0.35kg/cm2	11.6 Kg/cm2
2.11 Switch 'OFF' the compressors and ensure that valve to reset at pressure 12 kg/cm2 less than pressure. 2.12 BP Pressure: Switch 'OFF' compressor, Drain M by drain cock of 1" Main Reservoir, Start Compressor setting pressure of Duplex Check Valve 9 check setting pressure of Duplex Check Valve 9 check setting pressure in Gauge. 2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open in 136F. Check pressure in Gauge. 3.0 Air Dryer Operation 3.1 Open Drain Cock 90 of 2nd MR to start Compressore open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer at Compressore and the compressore open for Test Check Air Stops from Air Dryer at Compressore 1 check condition of humidity indicator 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cock) 5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure a Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2 Run 5±0.1 5.0 I). Run CP		est spec.	11.50±0.35kg/cm2	11.6 Kg/cm2
valve to reset at pressure 12 kg/cm2 less than pressure. 2.12 BP Pressure: Switch 'OFF' compressor, Drain M by drain cock of 1" Main Reservoir, Start Compressor check setting pressure of Duplex Check Valve 9 2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open is 136F. Check pressure in Gauge. 3.0 Air Dryer Operation 3.1 Open Drain Cock 90 of 2 nd MR to start Compre open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Stops from Air Dryer at Compre open for Test Check Air Stops from Air Dryer at Compre open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to Check Open In Indiana Indian			& MM3946		
by drain cock of 1" Main Reservoir, Start Compense Check setting pressure of Duplex Check Valve Start Compense Start Compense Start Compense Start Compense Start Compense Start Compense Start Check pressure in Gauge. 3.0 Air Dryer Operation 3.1 Open Drain Cock 90 of 2nd MR to start Compression open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change Check Condition of humidity indicator 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cocks) 5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure and Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2 Run 5±0.1 5.01			est spec. & MM3946	Si S	
2.13 FP pressure: Fit Test Gauge in Test point 107F FPTP. Open is 136F. Check pressure in Gauge. 3.0 Air Dryer Operation 3.1 Open Drain Cock 90 of 2 nd MR to start Compre open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Towers to change open for Test Check Air Dryer Air Dryer at Compress. 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR I leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cock) 5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure a Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2 Run 5±0.1 5.0 II	pressor,	CLW's che no. F60.81	ck sheet .2 Version 2	5.0±0.10kg/cm2	5.0 Kg/cm2
3.1 Open Drain Cock 90 of 2 nd MR to start Compre open for Test Check Air Dryer Towers to change 3.2 Check Purge Air Stops from Air Dryer at Compress. 3.3 Check condition of humidity indicator 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cocks) 5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure a Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2 Run 5±0.1 5.0 II		CLW's che no. F60.81	ck sheet 2 Version 2	6.0±0.20kg/cm2	6.0 Kg/cm2
3.2 Check Purge Air Stops from Air Dryer at Compr. 3.3 Check condition of humidity indicator 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR I leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cock.) 5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure a Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2 Run 5±0.1 5.0 I					L
3.3 Check condition of humidity indicator 4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR I leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cocks) 5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure a Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2 Run 5±0.1 5.0 I	ge.			Tower to change i) Every minute (FTIL & SIL) ii)every two minute (KBIL)	OK
4.0 Main Reservoir Leakage Test 4.1 Put Auto Brake (A-9) in full service, Check MR I leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cock.) 5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure a Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2 Run 5±0.1 5.0 I	ressor stops				
 4.1 Put Auto Brake (A-9) in full service, Check MR I leakage from both cabs. 4.2 Check BP Air leakage (isolate BP charging cock.) 5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure a Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2 Run 5±0.1 5.0 I 	Main Reservoir Leakage Test		Blue		Blue
Leakage from both cabs.					
5.0 Brake Test (Automatic Brake operation) 5.1 Record Brake Pipe & Brake Cylinder pressure a Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2 Run 5±0.1 5.0 I	Pressure air		est spec. & MM3946	Should be less than 1 kg/cm2 in 15 minutes	0.5 Kg/cm2 in 15 minutes
S.1 Record Brake Pipe & Brake Cylinder pressure a Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2 Run 5±0.1 5.0 I	-70)	A STATE OF THE STA	est spec. & MM3946	0.15 kg/cm2 in 5 minutes	0.07 Kg/cm2 in 5 minutes
Check proportionality of Auto Brake system Auto controller position BP Pressure kg/cm2 Run 5±0.1 5.0 I		-			1
Auto controller position BP Pressure kg/cm2 Run 5±0.1 5.0 I	it Each Step				
BP Pressure kg/cm2 Run 5±0.1 5.0 I		SCOULDSOND SHOULDEST	eck sheet 2 Version 2		
Run 5±0.1 5.0 I		BC (WAG-9 Kg/cm2	9 & WAG-7)	BC (WAP-5) Kg/cm2	
		Value	Result	Value	Result
Initial 4.60±0.1 4.5 k	Kg/cm2	0.00	0.00 Kg/ cm2	0.00	
	Kg/cm2	0.40±0.1	0.40Kg/ cm2	0.75±0.15	
Full service 3.35±0.2 3.5 F	Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	
Emergency Less than 0.3 0.1	Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	



Loco No.:41559

5.2	Record time to BP pressure drop to 3.5 kg/cm2 Ensure Automatic Brake Controller handle is Full Service from Run	D&M test spec. MM3882 & MM3946	8±2 sec.	9 Sec
5.3	Operate Asst. Driver Emergency Cock,	D&M test spec. MM3882 & MM3946	BP pressure falls to Below 25 kg/cm2	ОК
5.4	Check brake Pipe Pressure Switch 69F operates	CLW's check sheet no. F60.812 Version 2	Closes at BP 4.05- 4.35	4.1 Kg/cm2
			kg/cm2 Opens at BP 2.85-3.15 kg/cm2	3 Kg/cm2
5.5	Move Auto Brake Controller handle from Running to Emergency BC filling time from 0.4 kg/cm2 i.e. 95% of Max. BC developed WAP5 – BC 5.15 ± 0.3 kg/cm2 apply time	D&M test spec. MM3882 & MM3946	4±1 sec.	
	WAP7 - BC 2.50 ± 0.1 kg/cm2 WAG9 - BC 2.50 ± 0.1 kg/cm2	9) 	7.5±1.5 sec. 21±3 sec.	24 Sec
5.6	Move Auto Brake Controller handle to full service and BP pressure 3.5 kg/cm2. Move Brake controller to Running position BC Release time to fall BC Pressure up to 0.4 kg/cm2 i.e. 95% of Max. BC developed BC release Time	D&M test spec. MM3882 & MM3946	47.5125	
	WAG9 / WAP7 WAP5 WAGG		17.5±25 sec. 52±7.5 sec.	49 Sec
5.7	Move Auto Brake Controller handle to Release, Check BP Pressure Steady at 5.5 0.2 kg/cm2 time.	CLW's check sheet no. F60.812 Version 2	60 to 80 Sec.	75 Sec
5.8	Auto Brake capacity test: The capacity of the A9 valve in released condition must conform to certain limit in order to ensure compensation for air leakage in the train without interfering with the automatic functioning of brake. * Allow The MR pressure to build up to maximum stipulated limit. * Close brake pipe angle cock and charge brake pipe to 5 kg/cm2 by A (Automatic brake controlling) at run position. * Couple 7.5 dia leak hole to the brake hose pipe of locomotive. Open the angle cock for brake pipe. The test shall be carried out with all the compressors in working condition.	RDSO Motive power Directorate report no. MP Guide No. 11 July, 1999 Rev.1	BP pressure should not fall below 4.0 kg/cm2 with in 60 Sec.	4.2 Kg/cm2
5.9	Keep Auto Brake Controller (A-9) in Full Service. Press Driver End paddle Switch (PVEF)		BC comes to '0'	0
6.0	Direct Brake (SA-9)		1	
6.1	Apply Direct Brake in Full Check BC pressure WAG9/WAP7 WAP5	CLW's check sheet no. F60.812 Version 2	3.5±0.20 kg/cm2 5.15±0.3 kg/cm2	3.5Kg/cm2
6.2	Apply Direct Brake, Record Brake Cylinder charging time	D&M test spec. MM3882 & MM3946	8 sec. (Max.)	6 Sec

DMW/PATIALA

Loco No.:41559

6.3	Check Direct Brake Pressure switch 59 (F)	D&M test spec. MM3882 & MM3946	0.2.±0.1 kg/cm2	0.1 kg/cm2
6.4	Release direct brake & BC Release time to fall BC pressure up to 0.4 kg/cm2		10 -15 Sec.	11 Sec
7.0	Sanding Equipment			
7.1	Check Isolating Cock-134F is in open position. Press sander paddle Switch. (To confirm EP valves Operates)		Sand on Rail	ОК
8.0	Test Vigilance equipment : As per D&M test specification		M 30 40 40 40 40 40 40 40 40 40 40 40 40 40	ОК

Signature of Loco testing staff

Signature of SSE/Shop

Issue No.: 03

Effective Date: Oct-2021

DOC NO: F/LAS/Electric Loco CHECK SHEET (Ref: WI/LAS/Elect/01, 02, 03 & 04 & QPL/LAS/Elect. Loco) Page 1 of 1

डीजल रेळइंजन आधुनिकीकरण कारखाना पटियाला। DIESEL LOCO MODERNISATION WORKS, PATIALA

ELECTRIC LOCO CHECK SHEET

	NO: 41559 Rly: W(R		Shed:	ET	
S. No.	ITEM TO BE CHECKED	Specified Value		served V	alue
1.1	Check proper Fitment of Hotel Load Converter & its output contactor.	-0K-		ok NA	_
1.2	Check proper Fitment of MR Blower 1 & 2, MR Scavenging Blower 1 & 2, TM Blower 1 & 2.	ОК		sk	
1.3	Check proper of Fitment of oil cooling unit (OCU).	OK	1	ok	
1.4	Check proper Fitment of HB 1 & 2 and its respected lower part on its	ОК		ok	
1.5	Check proper Fitment of FB panel on its position.	ОК		K	
1.6	Check proper Fitment of assembled SB1 & SB2 with VCU1 & VCU2.	OK		K	
7	Check proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3).	ОК		ok.	
8	Check proper Fitment of Traction converter 1 & 2 (SR-1 & 2).	ОК		12	
1.10	Check proper fitment, torquing & Locking of Main transformer bolt.	OK		K	
1.12	Check proper fitment of compressor both side with the compressor safety wire rope.	ОК		3K	
1.13	Proper setting of the dampers as required.	ОК	(ok	
1.14	Check proper position of Secondary Helical Springs between Bogie & Shell	ОК	1	ok	0
1.15	Check proper fitment of Body Bogie Safety Chains fitted properly.	ОК		k	
1.16	Check proper fitment of Cow catcher.	ОК		K	
1.17	Check coolant level in SR 1 & 2 Expansion Tank	ОК		k	
1.18	Check Transformer Oil Level in both conservators Tank (Breather Tank).	ОК		K	
1.19	Check proper fitment of both battery box.	ОК		ilc	
1.20	Check proper fitment of Push Pull rod its bolt torquing and safety slings.	ок		k	
1.21	Buffer height: Range (1085 mm to 1105 mm) Drg No IB031-02002.	1090-1105		L/S	R/S
		mm	FRONT	1097	1101
			REAR	1 ' 1	1095
1.22	Buffer Length: Range (641 mm + 3 to 10 mm with buffer face) Drg No-	641 mm		1090 L/S	R/S
	SK.DL-3430.		FRONT	642	643
			REAR	647	645
1.23	Height of Rail Guard. (114 mm + 5 mm,-12 mm).	114 mm +		L/S	R/S
		5 mm,-12	FRONT	119	119
		mm	REAR	118	119
1.24	CBC Height: Range (1085 mm to 1105 mm) Drg No- IB031-02002 .	1085-1105	FRONT:	109	
		mm	REAR:	1090	

NAME SANTAY KUMAR DATE 29 11/2/

	N. Descrition of component	Pt No.	Make	Mfg. date & Serial no.	
1		29171064	Trident	10/00 10/0	
2	i de la constante	29731057		19/49 ,10/21	
3	TOURSELL TOUR DIENTHER		YOGYA ENTERPRISES	ABB-65-09-21-2XYT000000-ABY-036 ,2021	
4	Compressor normatice	29511008		21-5342, 21-4649	
5	Battery Box both side			EUFS927015(09/21) ,EUFS927009(09/21)	-
6	Traction Bar Cab-1	29100069	TEW	,BM 4621/67(09/21) , 65/1449(10/21)	
7	Traction Bar Cab-2	29100069	IILVV	3133,09/21	4
8	Side Buffer Assly Both Side	11803587		3138 ,09/21	7
9	Oil Cooling Pump both Side			LP357-06-21, 363-06-21,LP21 ,368-06-21	7
10	Transformer oil Steel pipes	20330027	SAMAL HARAND OF INDIA PVT.LTD.	D2693 & D 2466	1
11	Soft Draft Gear (CBC)	29230044	RANSAL PVT.LTD		-
12	Secondry Helical Spring on Bogin	20045024	SN	08-21 ,08-21	4
13	ELASTIC RING (Center pivot Ring	29045034	G.B. SPRING PVT. LTD.		-
14	Center Pivot Housing		AMADH		and and
1000	T	29100057		3527(08/21) ,3221(04/21)	-
1	Hotel Load Contactor	29741087	Machine room Component cab 1		1_
	Hotel Load Converter	29741087	70.00 AV	**************************************	
	TM-Blower		AIR CONTROL & CUCANO	7 6 mm m	-
4	TM- Scavenging Blower Motor	29440117	G.T.R CO (P) LTD.	D & 09/21 & AC-47144, CGLUIAM-1337	
5	Axillary Control Cubical (HB-1)		STINCO (F) LID.	ST-21-07-165	
6	Filter Cubical (FB-1)		HIND RECTIFIER PVT LTD.	05/21 & HB1/2021/J/0052/381	
	Complete Control Cubicle SB-1		AUTOMETER ALLIANCE LTD. HIND RECTIFIER PVT LTD.	10/21 & AALN/10/2021/5/FB/042	
8	Vehicle Control Unit (VCU)	29741075	***************************************	05/21 & SB-1/2021/J/0069/655	
9	Aux. Converter (BUR) 1	29741075	C.G.L.	10/21 & T2110627-P265	
10	Oil Cooling Unit (OCU)		C.G.L. SAINI ELECTRICALS	10/21 & CGAI00121A638-P264	
11	OCU RADIATOR		STANDARD RADIATORS	10/21 & 321092005 FAN-32109AF2005	
12	M/C Room Blower	29440105	AIR CONTROL & CUSANGA TORS	08/21 & 018-SRPL	
13	M/C Room Scavenging Blower	29//0120	AIR CONTROL & CHEMICAL ENGG. LTD	08/21 & 018-3RPL 08/09/21 & AC-47055, CGLUHAM-10360	
14	Traction Convertor	29741075	AIR CONTROL & CHEMICAL ENGG. LTD	805/21 & AC-45705, CGLUDBM-16705	
15	Hotel load convertor I.V. Coupler	29741087	C.G.L.	10/21 & CGPI21A0664, P265	
		1 25741007	MACHINE ROOM COMPONENT Cab-	A. A	
1 1	Hotel Load Contactor	29741087	KOOM COMPONENT CAB-,	2	
2 1	Hotel Load Converter	29741087	At 4 m at 2 is		
	TM-Blower	29440075	AIR CONTROL & CHEMICAL ENGG LTD	8-09/21 & AC-47122, CGLUIAM-0207	
4 7	M- Scavenging Blower Motor	29440117	S.T.R CO (P) LTD.	ST-21-07-212	
5 4	Axillary Control Cubical HB-2	29171192 A	UTOMETER ALLIANCE LTD.	06/21 & AALN/06/2021/10/H62G9/052	
6 C	Complete Control Cubicle S8-2	29171210 T	ROLEX	09/21 & 21933	
8 A	/ehicle Control Unit (VCU) Aux. Converter (BUR) 2&3	29741075	C.G.L.	10/21 & T2110628-P265	
9 (Oil Cooling Unit (OCU)	29741075	C.G.L.	10/21 & CGAI00221A639-P265	
	OCU RADIATOR	29470043 S	AINI ELECTICALS	10/21 & 321092008, , FAN-:32109AF2008	
	1/C Room blower	29470031 S	TANDARD RADIATORS	08/21 & 021 CDDI	
2 N	M/C Room Scav. blower	29440105 A	IR CONTROL & CHEMICAL ENGG. LTD	8/09/21 & AC-47064 CCULINAM 14505	
3 T	raction Convertor		IN CONTROL & CHEMICAL ENGG, LID	805/21 & AC-45706, CGLUDBM-16718	
	otel load convertor I.V. Coupler	23771073	C.G.L.	10/21 & CGPI21A0663, P265	
	and territor i.v. Couplet	29741087	Diversity		
1 H	and Brake	29140050 M	Driver Cabin lechwell Mod. Hand brake com fitt.		
	ir Conditioner	29811028	KKI POWER DRIVES PVT. LTD.	12647	(
	ab Heater	29170011 ES	CORTS	08/21 KKI/HVAC/CLW/682, & 683 95, 101	Ĉ.
	rew Fans	29470080 RA	ANJAN	561, 531, 480, 521	4
	river Seats		ASTERN EQUIPMENT		CO soo ov
	GN STORY			20-56, 20-80, 20-05, 20-40	-

D.M.W.

DMW/PTA

ELECTRIC LOCO HISTORY SHEET (TRS)

ELECTRIC LOCO NO: 41559 LIST OF ITEMS FITTED BY TRS

RLY: WCR

SHED: ET

PROPULSION SYSTEM: CGL

WARRANTY	COVERED								AS PER IRS / P.O						
QPL		04 Nos.	02 Set	04 Set	04 Nos.	02 Set	04 Nos.	02 Nos.	02 Set	02 Nos.	02 Nos.	02 Nos.	01 Set	01 Set	01 Set
MAKE/SUPPLIER		M/s PCE	M/s SCS	M/s POWER TECH	M/s EIC	M/s ESCORT	M/s. VENTWELL	M/s AUTOMETER	M/s. KONTACT	M/s. CROMPTON	M/s PATRA & CHANDA	Ms. TROLEX	M/s MEDHA	AMCO	PPS DMW
ITEM SR. NO.	CAB-2	5/2021	FLE03651	3805,3827	2741,2650	101	537,561	3205	KT-111	CG/CF/21090918	PCE/166/7/2021	7681	4386	ery Set No 260 Battery maintenance kit)	MW
LEM	CAB-1	5/2021	FLE03682	3837,3873	2552,2703	96	480,527	3209	KT-137	CG/CF/21090915	PCE/187/7/2021	7699	3704	Battery Set No (Along with Battery mair	. 1
TEM PL	Ö Z	29610023	25984962	25984860	29610461	29170011	29470080	29860015	29178204	29178162	29700012	29500059	29200040	29680025	29600418
DESCRIPTION OF ITEM		HEAD LIGHT LAMP	LED BASED FL LIGHT	LED MARKER LIGHT	DRIVER CAB LIGHT	CAB HEATER	CREW FAN	MASTER CONTROLLER	COMPLETE PANEL A,C,D	COMPLETE CUBICLE- F PANEL	HEATER ROTERY SWITCH	DIFFRENCIAL AMPLIFIRE	SPEED IND. & REC. SYSTEM	BATTERY (Ni- Cd)	HARNESSED CABLE COMPLETE
20		~	2	m	4	2	9	7	00	o	10	-	7	13	4





	Warranty												As per IRS/PO conditions			158				8308			
		Sr. no.	10820-10/21,10798-10/21	10356-07/21,10357-07/21		08/20,07/20		8/21/2552	2020/51460468	223634324/41	5/21,5/21	448182/28-07/2021	AALN/07/21/007/ES/241	858671, 858670		EUFS 927009A &EUFS 927015B	LD2-06-6257-21	BULS104355	21-08-CO-2013	21-03-EO-1830A,21-03-EO-1830B			
41559	ROOF COMPONENT CAB 1 & 2	Supplier	Contransys Private Ltd. Kolkata	Contransys Private Ltd. Kolkata	VIKRANT	BHEL	MIDDLE ROOF COMPONENT	EIPL	RITZ	SCHNEIDER	IEC ·	RSI Switchgear	AUTOMETER ALLIANCE	CG POWER	Air Brake Components	Elgi	TRIDENT	ELGI	KNORR	KNORR	KNORR	Elgi	
		QPL /Nos.	2	2	2	8		1	1	Н	6	1	1	2		2	1	1	1	2	2	4	
		Description	Pantograph	Servo motor	Air Intake filter Assly	Insulator Panto Mtg.		High Voltage Bushing	Voltage Transformer	Vacuum Circuit Breaker	Insulator Roof line	Harmonic Filter	Earth Switch	Surge Arrester		Air Compressor	Air Dryer	Auxillary Compresssor	Air Brake Panel	Contoller	Breakup Valve	wiper motor	
		S.No.	1	2	3	4		5	9	7	8	6	10	11		12 /	13 /	14 /	15 /	16 (17 E	18	

SSE/Testing

37

DIESEL LOCO MODERNISATION WORKS

Loco No. 41559

1. BOGIE FRAME:

BOGIE	FRAME NO	Make	PL No.	PO No. & dt.	Warranty Period
FRONT	SL-1174	ECBT	20405440	100074	As per PO/IRS
REAR	SL-80	VED	29105146	100075	conditions

2. Hydraulic Dampers (Axle, Vertical, Yaw and Horizontal) Make: ESCORT

3. AXLES:

AXLE POSITION NO	1	2	3	4	5	6
MAKE/	DMW	DMW	DMW	DMW	DMW	DMW
S.NO	21886	21895	21859	21830	21829	21855
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

4. WHEEL DISCS NO. AND TYPE

AXLE POSITION NO	1	2	3	4	5	6
GEAR END	CNC/21- 1425	CNC/21- 1450	CNC/21- 1438	CNC/21- 1415	CNC/21- 1416	CNC/21- 1407
Ultrasonic Testing	OK	OK	OK	OK	OK	OK
FREE END	CNC/21- 1427	CNC/21- 1511	CNC/21- 1439	CNC/21- 1419	CNC/21- 1420	CNC/21- 1406
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

5. AXLE ROLLER BEARING (CRU) (PL No. 29010020, Warranty: As per PO/IRS conditions)

AX	XLE POSITION NO	1	2	3	4	5	6
Gear	MAKE	NBC	NBC	NBC	NBC	NBC	NBC
End	PO NO. & dt	771567	771567	771567	771567	771567	771567
Free	MAKE	NBC	NBC	NBC	NBC	NBC	NBC
End	PO NO. & dt	771567	771567	771567	771567	771567	771567

6. WHEEL DISC PRESSING (PRESSURE IN KN): SPECIFIED 80-105 T

AXLE POSITION NO	1	2	3	4	5	6
BULL GEAR END	864	98 T	876	931	890	903
FREE END	838	81 T	883	940	822	912



Loco No. 41559

7. DIAMETER AFTER PROFILE TURNING: SPECIFIED 1092 + 5 mm - 0 mm

AXLE POSITION NO	1	2	3	4	5	6
DIA IN mm GE.	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
DIA IN mm FE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
WHEEL PROFILE GAUGE (1596±0.5mm)	OK	ОК	ОК	ОК	OK	OK

8. SUSPENSION TUBE & ITS TAPER ROLLER BEARING:

AXLE POSITIO	ON V	1	2	3	4	5	6
S.T.	MAKE	KM	KPE	KPE	KM	KM	KM
G.E. BEARING	MAKE	FAG	FAG	FAG	FAG	FAG	FAG
F.E. BEARING	MAKE	FAG	FAG	FAG	FAG	FAG	FAG

9. GEAR CASE & BACKLASH:

AXLE POSITION NO	1	2	3	4	5	-6
MAKE	KP	KP	KP	KM	KM	KM
BACKLASH (0.254 – 0.458mm)	0.320	0.310	0.350	0.350	0.340	0.330

10 A/BOX TO BOGIE FRAME LATERAL CLEARANCES (SPECIFIED 15.0 to 19.0mm):

AXLE POSITION NO	1	2	3	4	5	6
RIGHT SIDE	18.81	15.50	16.50	18.40	16.45	18.69
LEFT SIDE	16.30	16.70	17.93	16	16.83	15.64

11. TRACTION MOTOR: (PL No. 29942007, Warranty: As per PO/IRS conditions)

AXLE POSITION NO	MAKE	PO No. & date	S. NO.
1	DMW	-	DMW-902
2	DMW	-	DMW-910
3	DMW	-	DMW-763
4	DMW	= 1	DMW-874
5	DMW	-	DMW-881
6	DMW	=	DMW-897

SSE/ Bogie Shop

	TOP 12 (COSTLIEST ITEMS OF WAG9HC LOCO WITH	TOP 12 COSTLIEST ITEMS OF WAG9HC LOCO WITH WARRANTY CONDITIONS AS PER TENDERS
S No	PL No	DESCRIPTION	Warranty Period
Н	29741075	IGBT BASED 3-PHASE DRIVE PROPULSION EQUIPMENT	60 months after commissioning or 72 months from date of supply whichever earlier as per special conditions given by CLW
2	29731057	MAIN TRANSFORMER 7775 KVA TYPE LOT 7500 FOR WAP7 3- PHASE ELECTRIC LOCOMOTIVE TO CLW SPECN NO.CLW/ES/3/0660/C	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
es .	29171064	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT-8	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR AS PER IRS CONDITIONS-30 MONTHS FROM THE DATE OF WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT-SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER.
	8		
4	29600418	SET OF HARNESSED CABLE FOR 3-PHASE ELECTRIC LOCOMOTIVES TO CLW SPECN. NO. CLW/ES/03/646 ALT-NIL WITH DMW REQUIREMENT OF HARNESSED CABLE FOR WAP-7, ALT-A1 DATED 27/11/2018.	As per clause no.9 of CLW Specn. CLW/ES/3/0458 & Clause No.10 of CLW SpecnCLW/ES/3/0459. [18 months after commissioning or 20 months from date of supply for single core & 18 months after commissioning or 24 months from date of supply for multi core]

		W et	81
As per specification no. CLW/MS/3/001 Alt. 16 i.e. the manufacturer is required to guarantee that the brakevalves/equipment work satisfactorily for a period of five (5) years after commissioning. Any equipment/part which failsduring the guarantee period shall be replaced free of cost by the manufacturer. The replaced components shallfurther be under warranty for five (5) years from the date of their fitment and should the replaced components proveunsatisfactory in service, they shall be replaced by modified and improved components by the supplier free of cost.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.	
BRAKE CONTROL SYSTEM INCLUDING DRIVER'S VIGILANCE CONTROL DEVICE TO SET LIST NO.EL29180016.	COMPLETE FILTER CUBICLE ALONG WITH ALL EQUIPMENTS AND CABLING TO DRG./SPEC NO. [1] CLW/ES/3/0193 ALT-F OR LATEST AND CLW DRG. NO. 1209-15-143-004 ALT-10 AND PART DRG./SPEC NO AS PER ANNEXURE-A ATTACHED.	3-PHASE ASYNCHRONOUS TRACTION MOTOR (RESISTANCE RING MECHANICALLY INTERLOCKED TO END PLATE DESIGN ROTOR, SCHEME-II), TYPE 6FRA-6068 FOR WAP-7 ELECTRIC LOCO WITHOUT ACTIVE SPEED SENSOR TO SPECIFICATION NO. 4TMS.096.081 ALT-2 AND STR NO. CLW/2008/3PHTM/STR/0001.	
29180016	29480140	29942007	
rv	σ	7	4

	3
-	1
٦	1)
	4

∞	29105146	Bogie Frame Complete for WAP-7 for 3 Phase Co Co Locomotive to CLW specification No. CLW/MS/3/Bogie/003 alt-1 and CLW Drg.No.1209.01.112-202 Alt-Nil	As per clause 16 of Spec.No.CLW/MS/3/Bogie/003 Alt-1. [60 months after commissioning or 72 months from date of supply]
O	29171192	COMPLETE AUXILIARY CUBICLE HB2 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0192 ALT-E OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
10	29171210	COMPLETE CONTROL CUBICLE SB2 ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0195/A ALT-H OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
11	29171209	COMPLETE CONTROL CUBICLE SB1 (PUSH PULL SCHEME COMPLIANT) ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0194 ALT-G OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
.1			
12	29171180	COMPLETE AUXILIARY CUBICLE HB1 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0191 ALT-D OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
The second secon	-		