

भारतीय रेल Indian Railways

डीजल रेलइंजिन आधुनिकीकरण कारख़ाना, पटियाला Diesel Loco Modernation Works, Patiala



LOCO TESTING & DISPATCH REPORT OF IGBT BASED WAG9HC ELECTRIC LOCOMOTIVE

LOCO NO.:

41570

TYPE:

WAG9HC

RAILWAY SHED:

ECOR/WAT

PROPULSION SYSTEM:

BT

DATE OF DISPATCH:

24.12.2021

लोको निर्माण रिकार्ड



डीजल रेलइंजिन आधुनिकीकरण कारख़ाना, पटियाला Diesel Loco Modernisation

LOCO NO.: 41570

RAILWAY/SHED: ECoR/WAT DOD: DECEMBER 2021

INDEX

SN	PARA	ACTIVITIES	PAGE NO.
		Testing & Commissioning (TRS)	
1.	1.0	Continuity Test of the cables	-
	1.1	Continuity Test of Traction Circuit Cables	
	1.2	Continuity Test of Auxiliary Circuit Cables	1-4
	1.3	Continuity Test of Battery Circuit Cables	91
	1.4	Continuity Test of Screened Control Circuit Cables	
2.	2.0	Low Tension test	
	2.1	Measurement of resistor in OHMS (Ω)	5-6
	2.2	Check Points	
	2.3	Low Tension Test Battery Circuits (without control electronics)	<u> </u>
3	3.0	Downloading of Software	
	3.1	Check Points	
	3.2	Download Software	7-10
	3.3	Analogue Signal Checking	
	3.4	Functional test in simulation mode	
4	4.0	Sensor test & convertor test	
	4.1	Test wiring Transformer Circuits – Polarity Test	
	4.2	Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)	
	4.3	Primary Voltage Transformer	
4	4.4	Minimum voltage relay (Pos. 86)	11-16
	4.5	Maximum current relay (Pos. 78)	11-10
	4.6	Test current sensors	17
	4.7	Test DC Link Voltage Sensors (Pos 15.6/*)	
	4.8	Verification of Converter Protection Circuits (Hardware limits)	
	4.9	Sequence of BUR contactors	
5.	5.0	Commissioning with High Voltage	20
	5.1	Check List	
	5.2	Safety test main circuit breaker	
	5.3	Auxiliary Converter Commissioning	
	5.3.1	Running test of 3 ph. auxiliary equipments	
	5.3.2	Performance of Auxiliary Converters	
	5.3.3	Performance of BURs when one BUR goes out	16-25
	5.4	Auxiliary circuit 415/110	
	5.5	Hotel Load Circuit	
	5.6	Traction Converter Commissioning	
	5.7	Test protective shutdown SR	
	5.8	Test Harmonic Filter	
	5.9	Test important components of the locomotive	05.00
6.	6.0	Running Trial of the locomotive	25-26
7.	7.0	Final Check List to be verified at the time of Loco dispatch	27
8.	8.0	Status of RDSO modifications	28
9.	1-10	Pneumatic Test Parameters	29 - 32
10.		Loco Check Sheet(LRS)	33
11.	-	Component History (LRS,TRS,ABS)	34-36
12.	-	Component History & Testing Parameter (Bogie Shop)	37 - 38
13		Warranty Conditions as per Tenders	39 -41

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

1.0 Continuity Test of the cables

Type of Locomotive: WAP-7/WAG-9HC

Page: 1 of 27

1.1 Continuity Test of Traction Circuit Cables

As per cable list given in Para 1.3 of document no. 3 EHX 410 124, check the continuity with continuity tester and megger each cable to be connected between following equipment with 500V megger.

From	То	Continuity (OK/Not OK)	Prescribed Megger Value (min)	Measured Megger Yalue
Filter Cubicle	Transformer	ne	100 ΜΩ	500
Filter Cubicle	Terminal Box of Harmonic Filter Resistor (Roof)	ne	100 ΜΩ	200
Filter Cubicle	Earthing Choke	on	100 ΜΩ	500
Earthing Choke	Earth Return Brushes	OK	100 ΜΩ	500
Transformer	Power Converter 1	ne	100 ΜΩ	500
Transformer	Power Converter 2	or	100 ΜΩ	500
Power Converter 1	TM1, TM2, TM3	ore	100 ΜΩ	500
Power Converter 2	TM4, TM5, TM6	8U	100 ΜΩ	500
Earth	Power Converter 1	on	100 ΜΩ	500
Earth	Power Converter 2	on	100 ΜΩ	500

1.2 Continuity Test of Auxiliary Circuit Cables

As per cable list given in Para 1.4 of document no. 3 EHX 410 124, check the continuity with continuity meter and megger each cable to be connected between following equipment with the help of 500V megger.

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 2 of 27

From	То	Continuity(OK/ Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Transformer	BUR1	org	100 ΜΩ	1600
Transformer	BUR2	ne	100 MΩ ·	1000
Transformer	BUR3	ne	100 ΜΩ	1000
Earth	BUR1	ore	100 ΜΩ	1000
Earth	BUR2	ore	100 ΜΩ	1000
Earth	BUR3	ne	100 ΜΩ	1000
BUR1	HB1	De	100 MΩ	1000
BUR2	HB2	De .	100 ΜΩ	1000
HB1	HB2	OK	100 ΜΩ	1 000
HB1	TM Blower 1	or	100 MΩ	200
HB1	TM Scavenge Blower 1	or .	100 ΜΩ	150
HB1	Oil Cooling Unit 1	ou	100 MΩ	200
HB1	Compressor 1	OK	100 ΜΩ	200
HB1	TFP Oil Pump 1	ou	100 ΜΩ	200
HB1	Converter Coolant Pump 1	n	100 ΜΩ	150
HB1	MR Blower 1	ou.	100 ΜΩ	200
HB1	MR Scavenge Blower 1	ou	100 ΜΩ	150
HB1	Cab1	ou.	100 ΜΩ	200
Cab1	Cab Heater 1	ne	100 MΩ	200
HB2	TM Blower 2	820	100 ΜΩ	150
HB2	TM Scavenge Blower 2	ne	100 ΜΩ	200
HB2	Oil Cooling Unit 2	De	100 ΜΩ	200
HB2	Compressor 2	ore	100 ΜΩ	150
HB2	TFP Oil Pump 2	6K	100 ΜΩ	200
HB2	Converter Coolant Pump 2	Ol	100 ΜΩ	200
HB2	MR Blower 2	02	100 ΜΩ	200
HB2	MR Scavenge Blower 2	OL	100 ΜΩ	158
HB2	Cab2	ore	100 ΜΩ	100
Cab2	Cab Heater 2	on	100 ΜΩ	150

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 415 70

Type of Locomotive: WAP-7/WAG-9HC

1.3 Continuity Test of Battery Circuit Cables

Page: 3 of 27

Check continuity of following cables as per Para 2.3 of document no. 3 EHX 610 299

From	То	Condition	Continuity (OK/Not OK)
Battery (wire no 2093)	Circuit breakers 110- 2, 112.1-1, 310.4-1	By opening and closing MCB 112	ÐK.
MCB 110	Connector 50.X7-1	By opening and closing MCB 110	8K
Battery (Wire no. 2052)	Connector 50.X7-2		OK
SB2 (Wire no 2050)	Connector 50.X7-3		on

Close the MCB 112, 110, 112.1, and 310.4 and	Prescribed value	Measured
measure the resistance of battery wires 2093, 2052, 2050 with respect to the loco earth.	> 0.5 MΩ	Value MΩ
Measure the resistance between 2093 & 2052, 2093 & 2050, 2052 &	Prescribed value:	Measured .
2050	> 50 MΩ	Value &SMΩ

Commission the indoor lighting of the locomotive as per Sheet No 7A & 7B.

1.4 Continuity Test of Screened Control Circuit Cables

Check the continuity and isolation of the screen cable of the following circuits with the help of sheet no. mentioned against each as per document no. 3 EHX 610 299.

Corresponding Sheet Nos.	Continuity & Isolation (OK/Not OK)
04B	OK
10A	OK
10A	OK
01A, 12A	DK.
06F, 06G	ou
	Sheet Nos. 04B 10A 10A 01A, 12A

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 4 of 27

Master controller cab-1 &2	08C, 08D	OK
TE/BE meter bogie-1 & 2	08E, 08F	OK
Terminal fault indication cab-1 & 2	09F	OK
Brake pipe pressure actual BE electric	06H	OK
Primary current sensors	12B, 12F	OK
Harmonic filter current sensors	12B, 12F	∂I(
Auxiliary current sensors	12B, 12F	OK
Oil circuit transformer bogie 1	12E, 12I	OK
Magnetization current	12C, 12G	OK
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-1	12D	ÐΚ.
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-2	12D	ĐΚ
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-3	12D	OK
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-4	12H	OK
Traction motor speed sensors (2 nos) and temperature sensors (1 no.) of TM-5	12H	OK
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-6	12H	OK
Train Bus cab 1 & 2 (Wire U13A& U13B to earthing resistance= $10K\Omega \pm \pm 10\%$)	13A	O _I K
UIC line	13B	OK
Connection FLG1-Box TB	13A	0 K

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 415 70

Type of Locomotive: WAP-7/WAG-9HC

Page: 5 of 27

2.0 Low Tension test

2.1 Measurement of resistor in OHMS (Ω)

Measure the resistances of the load resistors for primary voltage transformer, load resistors for primary current transformer and Resistor harmonic filter as per Para 3.2 of the document no. 3 EHX 610 279.

Name of the resistor	Prescribed value	Measured value
Load resistor for primary voltage transformer (Pos. 74.2).	3.9K Ω ± 10%	3.9KN
Resister to maximum current relay.	1Ω ± 10%	152
Load resistor for primary current transformer (Pos. 6.11).	3.3 Ω ± 10%	3.352
Resistance harmonic filter (Pos 8.3). Variation allowed \pm 10%	WAP7	WAP7
Between wire 5 & 6	0.2 Ω	022
Between wire 6 & 7	0.2 Ω	0.2.12
Between wire 5 & 7	0.4 Ω	0.452
For train bus, line U13A to earthing.	10 kΩ± 10%	10.01 KZ
For train bus, line U13B to earthing.	10 kΩ ± 10%	10.0Kg
Insulation resistance of High Voltage Cable from the top of the roof to the earth (by1000 V megger).	200 ΜΩ	HOOMS
Resistance measurement earth return brushes Pos. 10/1.	≤0.3 Ω	0.2852
Resistance measurement earth return brushes Pos. 10/2.	≤0.3 Ω	0.2-8-52
Resistance measurement earth return brushes Pos. 10/3.	≤0.3 Ω	0.30 S
Resistance measurement earth return brushes Pos. 10/4.	≤0.3 Ω	0.285
Earthing resistance (earth fault detection) Harmonic Filter –I; Pos. 8.61.	2.2 kΩ± 10%	2.240
Earthing resistance (earth fault detection) Harmonic Filter –II; Pos 8.62.	2.7 kΩ± 10%	2.745
Earthing resistance (earth fault detection) Aux. Converter; Pos. 90.3.	3.9 k Ω ± 10%	3.95
Earthing resistance (earth fault detection) 415/110V; Pos. 90.41.	1.8 kΩ± 10%	1.8 KS
Earthing resistance (earth fault detection) control circuit; Pos. 90.7.	390Ω ± 10%	3905
Earthing resistance (earth fault detection) Hotel load; Pos. 37.1(in case of WAP5).	3.3 k Ω ± 10%	HA
Resistance for headlight dimmer; Pos. 332.3.	10Ω ± 10%	1052

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 6 of 27

Make sure that the earthing brush device don't make direct contact with the axle housing, earth connection must go by brushes.

2.2 Check Points

Note:

Items to be checked	Remarks
Check whether all the earthing connection in roof and machine room as mentioned in sheet no. 22A is done properly or not. These earthing connections must be flexible and should be marked yellow & green	cherked or
Check whether all the earthing connection between loco body and bogie is done properly or not. These cables must be flexible having correct length and cross section	cheeped ou

2.3 Low Tension Test Battery Circuits (without control electronics)

These tests are done with the help of the special type test loop boxes as per procedure given in Para 3.6 of the document no. 3 EHX 610 279

Name of the test	Schematic used.	Remarks
Test 24V supply	Sheet 04F and other linked sheets	Cherped 04
Test 48V supply	Sheet 04F & sheets of group 09	Fan supply to be checked.
Test traction control	Sheets of Group 08.	OK
Test power supply bus stations.	Sheets of Group 09.	Fan supply to be checked.
Test control main apparatus	Sheets of Group 05.	OK
Test earth fault detection battery circuit by making artificial earth fault to test the earth fault detection	Sheet 04C	OLL
Test control Pneumatic devices	Sheets of Group 06	OK
Test lighting control	Sheets of Group 07	OK
Pretest speedometer	Sheets of Group 10	OK
Pretest vigilance control and fire system	Sheets of Group 11	OK
Power supply train bus	Sheets of Group 13	04

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570
3.0 Downloading of Software

Type of Locomotive: WAP-7/WAG-9HC

Page: 7 of 27

3.1 Check Points.	Yes/No
Check that all the cards are physically present in the bus stations and all the plugs are connected.	Yes
Check that all the fibre optic cables are correctly connected to the bus stations.	Yes
Make sure that control electronics off relay is not energized i.e. disconnect Sub-D 411.LG and loco is set up in simulation mode.	yes
Check that battery power is on and all the MCBs (Pos. 127.*) in SB1 &SB2 are on	rej

3.2 Download Software

The software of Traction converter, Auxiliary converter and VCU should be done by commissioning engineer of the firm in presence of supervisor. Correct software version of the propulsion equipment to be ensured and noted:

Traction converter-1 software version:	1.0.3.6
Traction converter-2 software version:	1.0.3.6
Auxiliary converter-1 software version:	1.8.2.2
Auxiliary converter-2 software version:	2.8.2.2
Auxiliary converter-3 software version:	3.8.2.2
Vehicle control unit -1 software version:	1.6.8.7
Vehicle control unit -2 software version:	1.6.8.7

3.3 Analogue Signal Checking

Check for the following analogue signals with the help of diagnostic tool connected with loco.

Description	Signal name	Prescribed value	Measured Value
Brake pipe pressure	FLG2;0101XPrAutoBkLn	100% (= 5 Kg/cm2)	OK
Actual BE electric	FLG2; AMSB_0201- Wpn BEdem	100% (= 10V)	OK
TE/BE at 'o' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 9%, and 11 %	101.
TE/BE at 'TE maximal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 99 % and 101 %	100./_
TE/BE at 'TE minimal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 20 % and 25 %	221,

Se

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 415 70

Type of Locomotive: WAP-7/WAG-9HC

Page: 8 of 27

TE/BE at 'BE Minimal'	FLG2; AMSB_0101- XangTrans FLG1; AMSB_0101-	Between 20% and 25%	241.1
position from both cab	XangTrans FLG2; AMSB_0101- XangTrans	between 20% and 23%	241,
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS 0101- LT/BDEM>1/3 HBB2; AMS_0101- LT/BDEM>1/3	Between 42 and 44%	444,
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>2/3 HBB2; AMS_0101- LT/BDEM>2/3	Between 72 and 74%	734,
Both temperature sensor of TM1	SLG1; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature 0° C to 40° C	16°C
Both temperature sensor of TM2	SLG1; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	16°C
Both temperature sensor of TM3	SLG1; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	16°C
Both temperature sensor of TM4	SLG2; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	15°C
Both temperature sensor of TM5	SLG2; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	15°C
Both temperature sensor of TM6	SLG2; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	1600

Sr.

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 9 of 27

3.4 Functional test in simulation mode

Conduct the following functional tests in simulation mode as per Para 5.5 of document no.3EHX 610 281. through the Diagnostic tool/laptop:

Test Function	Result desired in sequence	Result obtained
Emergency shutdown through emergency stop switch 244	VCB must open. Panto must lower.	charged ou
Shut Down through cab activation switch to OFF position	VCB must open. Panto must lower.	choexeelou
Converter and filter contactor operation with both Power Converters during Start Up.	FB contactor 8.41 is closed. By moving reverser handle: Converter pre-charging contactor 12.3 must close after few seconds. Converter contactor 12.4 must close. Converter re-charging contactor 12.3 must opens. By increasing TE/BE throttle: FB contactor 8.41 must open. FB contactor 8.2 must close. FB contactor 8.1 must close.	o cheeked ou
Converter and filter contactor operation with both Power Converters during Shut Down.	Bring TE/BE to O. Bring the cab activation key to "O" VCB must open. Panto must lower. Converter contactor 12.4 must open. FB contactor 8.1 must open. FB contactors 8.41 must close. FB contactor 8.2 must remain closed.	chalked on

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC Page: 10 of 27

Contactor filter adaptation by isolating any bogie	Isolate any one bogie through bogie cut out switch. Wait for self-test of the loco.	
	• Check that FB contactor 8.1 is open.	
	• Check that FB contactor 8.2 is open.	peresedou
	After raising panto, closing VCB, and	PERCENT
	setting TE/BE	
	• FB contactor 8.1 closes.	
	• FB contactor 8.2 remains open.	
Test earth fault detection battery	By connecting wire 2050 to	4
circuit positive & negative	earth, create earth fault	Y
	negative potential.	
	 message for earth fault 	ochleted ou
	By connecting wire 2095	pc
	to earth, create earth	
	fault positive potential.	
	• message for earth fault	
Test fire system. Create a smoke in	When smoke sensor-1 gets	
the machine room near the FDU.	activated then	1
Watch for activation of alarm.	Alarm triggers and fault	
	message priority 2	1
	appears on screen.	cheekedou
	When both smoke sensor	
	1+2 gets activated then	
	 A fault message priority 	
	1 appears on screen and	
	lamp LSF1 glow.	
	• Start/Running interlock occurs and	
	TE/BE becomes to 0.	7
Time, date & loco number	Ensure correct date time and Loco	for
	number	Con
· ·		7)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4)570

Type of Locomotive: WAP-7/WAG-9HC

Page: 11 of 27

4.0 Sensor Test and Converter Test

4.1 Test wiring main Transformer Circuits

Apply $198V_p/140V_{RMS}$ to the primary winding of the transformer (at 1u; wire no. 2 at surge arrestor and at 1v; wire no. 100 at earthing choke). Measure the output voltage and compare the phase of the following of the transformers.

Output Winding nos.	Description of winding.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
2U ₁ & 2V ₁	For line converter bogie 1 between cable 801A- 804A	10.05V _p and same polarity	10,03/0	OK
2U ₄ & 2V ₄	For line converter bogie 1 between cable 811A- 814A	10.05V _p and same polarity	10.03 Up	OK
2U ₂ & 2V ₂	For line converter bogie 2 between cable 801B- 804B	10.05V _p and same polarity	10.05/1	DK
2U ₃ & 2V ₃	For line converter bogie 2 between cable 811B- 814B	10.05V _p and same polarity	10.0549	OK
2U _B & 2V _B	For aux. converter 1 between cable 1103- 1117 (in HB1) For Aux converter 2 between cable 1103- 1117 (in HB2)	7.9V _p , 5.6V _{RMS} and same polarity.	7.7VP 2 5-5VPMS	OK
2U _F & 2V _F	For harmonic filter between cable 4-12 (in FB)	9.12V _p , 6.45V _{RMS} and same polarity.	9.10 NP 1 6.42 NRMS	0 v

4.2 Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)

Apply $141V_p$ / $100V_{RMS}$ to input of the auxiliary transformer at cable no 1203 –1117 and measure the output at

Description of wire no.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
Cable no. 1218 - 1200	$58.7V_p$, $41.5V_{RMS}$ and opposite polarity.	58-511 41:44pms	OK
Cable no. 1218 – 6500	15.5V _p , 11.0V _{RMS} and opposite polarity.	15.4281	OK

11 . OVEM

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 12 of 27

4.3 Primary Voltage Transformer

Apply $250V_{eff}/350V_p$ by variac to roof wire 1 and any wire 0 and measure the magnitude and polarity of the output of the primary voltage transformer for both bogies as per the procedure specified and suggested by the traction converter manufacturer. Primary voltage measurement converters (Pos. 224.1/*) & catenary voltmeter (Pos. 74/*)

This test is to be done for each converter.

Activate cab in driving mode and supply $200V_{RMS}$ through variac to wire no 1501 and 1502. Monitor the following parameters through Diagnostic tool and in catenary voltmeter.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	25kV	250%	25KV	2501
SLG2_G 87-XUPrim	25 kV	250%	25 XV	250%

Decrease the supply voltage below 140 V_{RMS} . VCB must open at this voltage. In this case the readings in Diagnostic Tool and catenary voltmeter will be as follows.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLGI_G 87-XUPrim	17kV	170%	17KY	170%
SLG2_G 87-XUPrim	17 kV	170%	17KV	170.1

Reactivate VCB to on by increasing this voltage to 175% (17.5 kV).

Increase the supply to $240~V_{RMS}$ through variac. VCB must open at this voltage, In this case the readings in diagnostic tool and catenary voltmeter will be as follows:

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	30kV	300%	30KA	300/
SLG2_G 87-XUPrim	30 kV	300%	BOKV	300%

Reactivate VCB to on by decreasing this voltage to 290% (29 kV).

Effective Date: March 2021

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 13 of 27

Minimum voltage relay (Pos. 86)

ansformer (wire no. 1511 and 1512) from load resistor (ros. 4.2) and connect variac to wire no. 1501 and 1502. Supply 200V _{RMS} through variac. In this case; <i>Minimum voltage relay</i> 20s. 86) picks up Try to activate the cab in driving mode: 20s. 86) picks up 20s. 86) picks up 20s. 86) picks up Try to activate the cab in driving mode: 20s. 86) picks up 20s. 86) picks	Functionality test:	tod to approx 68%
inimum voltage relay. Disconnect primary voltage ansformer (wire no. 1511 and 1512) from load resistor (Pos. 4.2) and connect variac to wire no. 1501 and 1502. Supply 200V _{RMS} through variac. In this case; Minimum voltage relay 200S. 86) picks up Try to activate the cab in driving mode: In this case; Minimum voltage relay 200S. 86) picks up Try to activate the cab in driving mode: In this case; Minimum voltage relay 200S. 86) picks up Try to activate the cab in driving mode: In this case; Minimum voltage relay 200S. 86) picks up Try to activate the cab in driving mode: In this case; Minimum voltage relay 200S. 86) picks up In this case; Minimum voltage relay 200S. 86) picks up Test Under Voltage Protection; Test Under Voltage Protection; Activate the cab in cooling mode; Raise panto; In this case; The VCB goes off after 2 second time delay. Again supply 200V _{RMS} through variac to wire no. 1501 & 1501 & 1502; Decrease the supply voltage below 140V _{PMS} + 4V:	Minimum voltage relay (Pos. 86) must be adjus	ted to approx 6876
ry to activate the cab in driving mode: ontactor 218 do not close; the control lectronics is not be working. urn off the variac: Contactor 218 closes; the control electronics is be working Test Under Voltage Protection; Activate the cab in cooling mode; Raise panto; Supply 200V _{RMS} through variac to wire no. 1501 & 1502; Close the VCB; Interrupt the supply woltage The VCB goes off after 2 second time delay. Again supply 200V _{RMS} through variac to wire no. 1501 & 1502; Decrease the supply voltage below 140V _{RMS} + 4V:	Activate loco in cooling mode. Check Power supply of 48V to minimum voltage relay. Disconnect primary voltage transformer (wire no. 1511 and 1512) from load resistor (Pos. 74.2) and connect variac to wire no. 1501 and 1502. Supply 200V _{RMS} through variac. In this case; <i>Minimum voltage relay (Pos. 86) picks up</i>	L(res/No)
ry to activate the cab in driving mode: ontactor 218 do not close; the control lectronics is not be working. urn off the variac: Contactor 218 closes; the control electronics is be working Test Under Voltage Protection; Activate the cab in cooling mode; Raise panto; Supply 200V _{RMS} through variac to wire no. 1501 & 1502; Close the VCB; Interrupt the supply woltage The VCB goes off after 2 second time delay. Again supply 200V _{RMS} through variac to wire no. 1501 & 1502; Decrease the supply voltage below 140V _{RMS} + 4V:		
Test Under Voltage Protection; Activate the cab in cooling mode; Raise panto; Supply 200V _{RMS} through variac to wire no. 1501 & 1502; Close the VCB; Interrupt the supply voltage The VCB goes off after 2 second time delay. Again supply 200V _{RMS} through variac to wire no. 1501 & 1502; Decrease the supply voltage below 140V _{RMS} + 4V:	Try to activate the cab in driving mode: Contactor 218 do not close; the control closetronics is not be working.	
Test Under Voltage Protection; Test Under Voltage Protection; Activate the cab in cooling mode; Raise panto; Supply 200V _{RMS} through variac to wire no. 1501 & 1502; Close the VCB; Interrupt the supply voltage The VCB goes off after 2 second time delay. Again supply 200V _{RMS} through variac to wire no. 1501 & 1502; Decrease the supply voltage below 140V _{RMS} + 4V:		(Yes/No)
Test Under Voltage Protection; Activate the cab in cooling mode; Raise panto; Supply 200V _{RMS} through variac to wire no. 1501 & 1502; Close the VCB; Interrupt the supply voltage The VCB goes off after 2 second time delay. Again supply 200V _{RMS} through variac to wire no. 1501 & 1502; Decrease the supply voltage below 140V _{RMS} + 4V:	Contactor 218 closes; the control electronics is be	
Test Under Voltage Protection; Activate the cab in cooling mode; Raise panto; Supply 200V _{RMS} through variac to wire no. 1501 & 1502; Close the VCB; Interrupt the supply voltage The VCB goes off after 2 second time delay. Again supply 200V _{RMS} through variac to wire no. 1501 & 1502; Decrease the supply voltage below 140V _{RMS} + 4V:	working	
Activate the cab in cooling mode, Naise parts, Supply 200V _{RMS} through variac to wire no. 1501 & 1502; Close the VCB; Interrupt the supply voltage The VCB goes off after 2 second time delay. Again supply 200V _{RMS} through variac to wire no. 1501 & 1502; Decrease the supply voltage below 140V _{RMS} + 4V:	Test Under Voltage Protection	<u>1;</u>
Activate the cab in cooling mode, Naise parts, Supply 200V _{RMS} through variac to wire no. 1501 & 1502; Close the VCB; Interrupt the supply voltage The VCB goes off after 2 second time delay. Again supply 200V _{RMS} through variac to wire no. 1501 & 1502; Decrease the supply voltage below 140V _{RMS} + 4V:		()(, -(0)-)
The VCB goes off after 2 second time delay. Again supply 200V _{RMS} through variac to wire no. 1501 & 1502; Decrease the supply voltage below 140V _{RMS} + 4V:	Activate the cab in cooling mode; Raise panto; Supply 200V _{RMS} through variac to wire no. 1501 & 1502; Close the VCB; Interrupt the supply voltage	LYes/NO)
Again supply 200V _{RMS} through variac to wire no. 1501 & 1502; Decrease the supply voltage below 140V _{RMS} + 4V:	The VCB goes off after 2 second time delay.	
140Vpags + 4V:	Again supply 200V pMs through variac to wire no.	(Yes/No)
	$140V_{RMS} \pm 4V$; Fine tune the minimum voltage relay so that VCB opens.	

4.5 Maximum current relay (Pos. 78)

Disconnect wire 1521 & 1522 of primary current trans &1522 (including the resistor at Pos. 6.11); Put loco in sim on contact 136.3; Close VCB; supply 3.6A _{RMS} at the op maximum current relay Pos. 78 for correct over current variables.	en wire 1521; Tune the drum of the
VCB opens with Priority 1 fault message on display.	(Yes/No)
Keep contact $R_3 - R_4$ of 136.3 closed; Close VCB; Tune the /9.9 A_p at the open wire 1521;	resistor 78.1 for the current of 7.0A _{RMS}
VCB opens with Priority 1 fault message on	(Yes/No)

DOC.NO.TITOIVI (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 14 of 27

.6 Test current sensors Name of the sensor	Description of the test	Prescribed value	Set/Measured value
Primary return current ensor (Test-1,Pos.6.2/1 & 6.2/2)	Activate cab in driving mode supply 10A. Measure the current through diagnostic tool or measuring print.	(Variation allowed is ± 10%)	
Primary return current	Supply 90mA _{DC} to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		
sensor (Test-2, Pos.6.2/1 & 6.2/2)	Supply 297mA _{DC} to the test winding of sensor through connector 415.AA/1012 pin no. 7(+) & 8(-)		298mB
Auxiliary winding current sensor (Pos. 42.3/1 & 42.3/2)	Supply 90mA _{DC} to the test winding of sensor through connector 415.AC/10 2 pin no. 7(+) & 8(-) Supply 333mA _{DC} to the test winding of sensor through connector 415.AC/1 or 2 pin no. 7(+) & 8(-)		3328mB
Harmonic filter current sensors (Pos.8.5/1 &8.5/2)	Supply 90mA _{DC} to the test winding of sensor through connector 415.AE/10 2 pin no. 7(+) & 8(-) Supply 342mA _{DC} to the test winding of sensor through connector 415.AE/10 2 pin no. 7(+) & 8(-)	f	240тв
Hotel load current sensors (Pos. 33/1 &	Switch on hotel load. Supply 90mA _D to the test winding of sensor throug connector 415.AG/1or 2 pin no. 7(+) 8(-)	% &	
33/2)	Supply 1242mA _{DC} to the test windir of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)	ng	

Doc.No.F/IKS/UI

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

41570 Locomotive No.:

Type of Locomotive: WAP-7/WAG-9HC

Page: 15 of 27

4.7 Test DC Link Voltage Sensors (Pos 15.6/*)

This test is to be done by the commissioning engineer of the firm if required.

4.8 Verification of Converter Protection Circuits (Hardware limits) -

This test is to be done as per para 6.17 of the document no. 3EHX 610 282 for both the converters.

Protection circuits	Limit on which shutdown should take place	Measured limit
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 1	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 18.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 2	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 8.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=
Fibre optic failure In Power Converter1	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	DK
Fibre optic failure In Power Converter2	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	Och,

4.9 Sequence of BUR contactors

The sequence of operation of BUR contactors for 'ALL BUR OK' BUR' 1 out BUR 2 out and BUR 3 out condition has to be verified by putting the Loco in driving mode (VCB should not be closed) and isolating the BURs one by one. In these condition following will be the contactor sequence.

Chabus	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
Al BUR OK	Close	Open	Close	Open	Close	Open	Close	Close	Open
BUR1 off	Close	Open	Close	Close	Open	Close	Open	Open	Close
BUR2 off	Open	Open	Close	Close	Close	Close	Open	Open	Close
BUR3 off	Open	Close	Open	Close	Close	Close	Open	Open	Close

Effective Date: March 2021

Doc.No.F/TRS/01

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 16 of 27

Monitored contactor sequence

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	close	open	clesp	open	closp	open	close	close	open
BUR1 off	, lose	oben	close	class	Open	clos	Open	open	clos
BUR2 off	oben	oben	clos	cles	clos	close	Open	معطو	close
BUR3 off	open	close	open	close	close	clos.	oper	oper	clos

5.0 Commissioning with High Voltage

5.1 Check List

Items to be checked	Yes/No
Fibre optic cables connected correctly.	tes
No rubbish in machine room, on the roof, under the loco.	Yey
All the electronic Sub-D and connectors connected	Yes
All the MCBs of the HB1 & HB2 open.	Yes
All the three fuses 40/* of the auxiliary converters	Yey
The fuse of the 415/110V auxiliary circuit (in HB1) open.	Yes
Roof to roof earthing and roof to cab earthing done	You
Fixing, connection and earthing in the surge arrestor done correctly.	Yes
Connection in all the traction motors done correctly.	Yes
All the bogie body connection and earthing connection done correctly.	Yes
Pulse generator (Pos. 94.1) connection done correctly.	180g
All the oil cocks of the gate valve of the transformer in open condition.	Yes
All covers on Aux & Power converters, Filter block, HB1, HB2 fitted	Yey
KABA key interlocking system.	ites

5.2 Safety test main circuit breaker

Prepare to switch off the catenary supply during the first charging of the locomotive in case of any unexpected behavior of the electrical component of the loco. Charge the loco for the first time by closing BLDJ switch. The VCB will trip after certain time as no oil/coolant pumps are running yet.

Perform the following safety test of main circuit breaker through both the cabs of the locomotive.

Doc.No.H/IKS/UT

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 17 of 27

lame of the test	Description of the test	Expected result	Monitored result
mergency stop n cooling mode	Raise panto in cooling mode. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	cheeked ou
Emergency stop n driving mode	Raise panto in driving mode in. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	cheeped on
Under voltage protection in cooling mode	Raise panto in cooling mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open.	choesed on
Under voltage protection in driving mode	Raise panto in driving mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open with diagnostic message that catenary voltage out of limits	chocked on
Shut down in cooling mode.	Raise panto in cooling mode. Close the VCB. Bring the BL- key in O position.	VCB must open. Panto must lower.	charbeel ok
Shutdown in driving mode	Raise panto in driving mode. Close the VCB. Bring the BL-key in O position.	VCB must open. Panto must lower.	c folled on
Interlocking pantograph- VCB in cooling mode	Raise panto in cooling mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	cheekeel ou
Interlocking pantograph- VCB in driving mode	Raise panto in driving mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	cheeked on

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 18 of 27

5.3 Auxiliary Converter Commissioning

Switch on the high voltage supply and set up the loco in driving mode. Raise the panto. Close the VCB. Check that there is no earth fault in the auxiliary circuit, Switch off the VCB. Lower the panto. Create the earth fault in auxiliary circuit by making connection between wire no 1117(in HB2 cubicle) and earth. After 3 minutes a diagnostic message will come that "Earth fault auxiliary circuit."

5.3.1 Running test of 3 ph. auxiliary equipments

Switch on the 3 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured continuous phase current	Measured starting phase current
Oil pump transformer 1	9.8 amps	10.6	11.3
Oil pump transformer 2	9.8 amps	10.8	11.6
Coolant pump converter 1	19.6 amps	5.5	6.3
Coolant pump	19.6 amps	6.5	6-7
Oil cooling blower unit 1	40.0 amps	43.0	148.0
Oil cooling blower unit 2	40.0 amps	43.0	160.0
Traction motor blower 1	34.0 amps	5,3	6.5
Traction motor blower 2	34.0 amps	5.1	6.1
Sc. Blower to Traction motor blower 1	6.0 amps	35.0	168-0
Sc. Blower to Traction motor blower 1	6.0 amps	33.7	160.0
Compressor 1	25 amps at 0 kg/ cm ² 40 amps at 10 kg/ cm ²	28.5	1500
Compressor 2	25 amps at 0 kg/ cm ² 40 amps at 10 kg/ cm ²	29.9	109.0

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 19 of 27

5.3.2 Performance of Auxiliary Converters

Measure the performance of the auxiliary converters through software and record it. BUR1 (Condition: Switch off all the load of BUR 1)- to be filled by commissioning engineer

of the firm.

Signal name	Description of the signal	Prescribed value	Monitored value	Value under Limit (Yes/No)
BURI 7303 XUUN	Input voltage to BUR1	75% (10%=125V)	1050V	Yes
	DC link voltage of BUR1	60% (10%=100V)	625V	Tes
	DC link current of BUR1	0% (10%=50A)	1 Amb	Yes

BUR2 (Condition: Switch off all the load of BUR 2, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value by the firm	Monitored value	Value under Limit (Yes/No)
BUR2 7303-XUUN	Input voltage to BUR2	75% (10%=125V)	1055 V	Yes
BUR2 7303-XUUZ1	DC link voltage of BUR2	60% (10%=100V)	636V	Yes
BUR2 7303-XUIZ 1	DC link current of BUR2	1% (10%=50A)*	6 Arup	Yes
BUR2 7303-XUILG	Current battery charger of BUR2	3% (10%=100A)*	8 Amp	Yes
BUR2 7303-XUIB1	Current battery of BUR2	1.5%(10%=100A)*	14 Amb	Yes
BUR2 7303 -XUUB	Voltage battery of BUR2	110%(10%=10V)	1100	Yey

^{*} Readings are dependent upon charging condition of the battery.

BUR3 (Condition: Switch off all the load of BUR 3, Battery Charger on) to be filled by

commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed set value by the firm	Monitored value	Value under limit (Yes/No)
BUR3 7303-XUUN	Input voltage to BUR3	75% (10%=125V	10551	Yey
BUR3 7303- XUUZI	DC link voltage of BUR3	60% (10%=100V)	636 N	res
BUR3 7303-XUIZ 1	DC link current of BUR3	1% (10%=50A)*	2 Amp	Yes
BUR3-7303-XUILG	Current battery charger of BUR 3	3% (10%=100A)*	7 Amp	Yes
BUR3 7303-XUIB1	Current battery of BUR 3	1.5%(10%=100A)*	13 Am)	Tes
BUR3 7303-XUUB	Voltage battery of BUR 3	110%(10%=10V)	110 ✓	Tes

^{*} Readings are dependent upon charging condition of the battery.

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 20 of 27

5.3.3 Performance of BURs when one BUR goes out

Oil Cooling unit 1&2,

TM blower 1&2, TM

Scavenger blower 1&2

Oil Cooling unit 1&2,

TM blower1&2, TM

Scavenger blower 1&2

When any one BUR goes out then rest of the two BURs should take the load of all the auxiliaries at ventilation level 3 of the locomotive.

Loads in BUR3 Loads in BUR2 Loads on BUR1 Condition of BURS Compressor 1&2, Battery TM blower1&2, TFP oil Oil Cooling unit All BURs OK charger and TM Scavenger pump 1&2, SR coolant 1&2 blower 1&2 pump 1&2. Compressor 1&2,TFP oil Oil Cooling unit 1&2, TM BUR 1 out pump 1&2, SR coolant blower1&2, TM pump 1&2 and Battery Scavenger blower 1&2 charger.

Compressor 1&2, TFP oil

pump 1&2, SR coolant

pump 1&2 and Battery

pump 1&2, SR coolant pump 1&2 and Battery charger.

Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.

5.4 Auxiliary circuit 415/110

BUR 2 out

BUR 3 out

For checking earth fault detection, make a connection between wire no. 1218 and vehicle body. On switching on VCB, Earth fault relay 89.5 must pick up and after 3 minutes a message will come in the Diagnostic display that Earth Fault 415/110V Circuit

charger.

Switch on the 1 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

auxiliary machine and measure Name of the auxiliary machine	Typical phase current	Measured phase current	Measured starting current
Machine room blower 1	15.0 amps*	6.5	33.0
Machine room blower 2	15.0 amps*	6.3	280
Sc. Blower to MR blower 1	1.3 amps	0.9	12.0
Sc. Blower to MR blower 2	1.3 amps	1.0	130
Ventilator cab heater 1	1.1 amps	1.2	1-4
Ventilator cab heater 2	1.1 amps	1.2	1.4
Cab heater 1	4.8 amps	5.0	512
Cab heater 2	4.8 amps	5.0	5.2

^{*} For indigenous MR blowers.

gr

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 415 70

Type of Locomotive: WAP-7/WAG-9HC

Page: 21 of 27

5.5 Hotel load circuit (Not applicable for WAG-9HC)

For WAP-7 locomotive with Hotel load converter refer to Annexure-HLC

5.6 Traction Converter Commissioning

This test is carried out in association with Firm.

Traction converter commissioning is being done one at a time. For testing Converter 1, switch off the traction converter 2 by switch bogie cut out switch 154. For testing Converter 2, switch off the traction converter 2 by switch bogie cut out switch 154. Isolate the harmonic filter also by switch 160. Start up the loco by one converter. Follow the functionality tests.

For Converter 1 Test Function	Results desired	Result obtained
Measurement of charging and pre-	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	cheeted on
of DC Link of Converter 1 Measurement of discharging of DC Lin of Converter 1	Traction converter manufacturer to	cholbed ou
Earth fault detection on positive potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	chelked ou
Earth fault detection on negative potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	chelteel ou
Earth fault detection on part of the traction circuit of Converter 1	declare the successful operation and demonstrate the same to the DMW supervisor.	chockeel ou
Pulsing of line converter of Converter 1	declare the successful operation and demonstrate the same to the DMW supervisor.	cherted on
Pulsing of drive converter of Converter	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	CRURKED OO

Issue No.02

Effective Date: March 2021

Doc.No.F/TRS/01 (Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 22 of 27

For Converter 2

For Converter 2		Result obtained
Test Function	Results desired in sequence	Result obtained
Measurement of charging and pre- charging and charging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	chocked ox
Measurement of discharging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	chaekeel ou
positive potential of DC Link of Converter 2.	demonstrate the same to the DMW supervisor.	cheeped ou
Earth fault detection on negative potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/v	chelked ou
Earth fault detection or AC part of the traction circuit of Converter 2.	declare the successful operation and demonstrate the same to the DMW supervisor.	cheeked be
Pulsing of line converte of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	chared on
Pulsing of drive converter of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the DMW supervisor.	cheeped ou

(Ref: WI/TRS/10)

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 23 of 27

5.7 Test protective shutdown SR

Test Function	Results desired in sequence	Result obtained
Measurement of protective shutdown by Converter 1 electronics.	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 1Check that converter 1 electronics produces a protective shut down. • VCB goes off • Priority 1 fault mesg. on DDU	cheeked on
	appears Disturbance in Converter 1	
Measurement of protective shutdown by Converter 2 electronics.	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 2. Check that converter 2 electronics produces a protective shudown. • VCB goes off • Priority 1 fault mesg. on diagnostic display appears Disturbance in Converter 2	choexad qu

5.8 Test Harmonic Filter

Switch on the filter by switch 160

Test Function	Results desired in sequence	Result obtained
Measurement of filter currents	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Apply a small value of TE/BE by moving the throttle. • FB contactor 8.41 must open.	Charked ou

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 24 of 27

	• FB contactor 8.2 must close.	
	FB contactor 8.1 must close	
	• Check the filter current in	
	diagnostic laptop	
	Bring the TE/BE throttle to O	
	Switch off the VCB cheeked or	
	• FB contactor 8.1must open.	
	• FB discharging contactor 8.41	
	must close	
	Check the filter current in	
	diagnostic laptop	
Test earth fault	Make a connection between wire	
detection harmonic	no. 12 and vehicle body. Start up	
filter circuit.	the loco. Close VCB.	
	• Earth fault relay 89.6 must pick up. Chested ou	
	Diagnostic message comes that -	
	Earth fault in harmonic filter circuit	
Test traction motor	Traction converter manufacturer	
speed sensors for	to declare the successful operation cheekedou	
both bogie in both	and demonstrate the same to the	
cabs	supervisor/ DMW	

5.9 Test important components of the locomotive

Items to be tested	Description of the test	Monitored value/remarks
Speedometer	VCU converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ DMW	cheeked od
Time delay module of MR blower	The time after which the starting capacitor for MR blower should go off the circuit should be set to 10-12 seconds	Chalted on
Ni-Cd battery voltage	At full charge, the battery voltage should be 110V DC.	cheeked on
Flasher light	From both cab flasher light should blink at least 65 times in one minute.	chekoelon
Head light	Head light should glow from both cabs by operating ZLPRD. Dimmer operation of headlight should also occur by operating the switch ZLPRD.	choel ob

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41579

Type of Locomotive: WAP-7/WAG-9HC

Page: 25 of 27

Marker light	Both front and tail marker light should glow from both the cabs	chocked on
Cab Light	Cab light should glow in both the cabs by operating the switch ZLC	choekalou
Spot lights	Both Drivers and Asst. Drivers Spot light should glow in both cabs by operating ZLDD	cholloel on
Instrument lights	Instrument light should glow from both cab by operating the switch ZLI	cheked ou
Illuminated Push button	All illuminated push buttons should glow during the operation	eholped on
Contact pressure of the high rating contactors	The contact pressure of FB contactors (8.1, 8.2) is to be measured Criteria: The minimum contact pressure is 54 to 66 Newton.	For contactor 8.1: For contactor 8.2:
Crew Fan	All crew fans should work properly when VCB of the loco is switched on. The airflow from each cab fan is to be measured. Criteria: The minimum flow of air of cab fan should be 25 m ³ /minute	Cab 1 LHS: Cab 1 RHS: Cab 2 LHS: Cab 2 RHS:

6.0 Running Trial of the locomotive

SN	Description of the items to be seen during trail run	and during trail run	
1	Cab activation in driving mode	No fault message should appear on the diagnostic panel of the loco.	
	Loco charging	Loco to be charged and all auxiliaries should run. No fault message to appear on the diagnostic panel of the loco. Raise MR pressure to 10 Kg/cm ² , BP to 5 Kg/cm ² , FP to 6 Kg/cm ² .	cfeekalou
3.	Check function of Emergency push stop.	This switch is active only in activated cab. By pushing this switch VCB should open & pantograph should be lowered.	Schekodon
4.	Check function of BPCS.	 Beyond 5 kmph, press BPCS, the speed of loco should be constant. BPCS action should be cancelled by moving TE/BE throttle, by dropping BP below 4.75 Kg/cm², by pressing BPCS again. 	Chelka)
5.	Check train parting operation of the Locomotive.	Operate the emergency cock to drop the BP Pressure LSAF should glow.	S on

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 26 of 27

	Check vigilance	Set the speed more than 1.5 kmph and ensure that	9)
	operation of the	brakes are released i.e. BC < 1 Kg/cm ² .	
	locomotive	For 60 seconds do not press vigilance foot switch or	
		sanding foots switch or TE/BE throttle or BPVG	
		switch then	
		 Buzzer should start buzzing. 	
		 LSVW should glow continuously. 	eheckedo
		Do not acknowledge the alarm through BPVG or	
		vigilance foot switch further for 8 seconds then:-	
	3 8	 Emergency brake should be applied 	
		automatically.	
		 VCB should be switched off. 	
		Resetting of this penalty brake is possible only after	
		180 seconds by bringing TE/BE throttle to 0 and	
		acknowledge BPVR and press & release vigilance	\ <u>\</u>
	z z	foot switch.	
7.	Check start/run interlock	• At low pressure of MR (< 5.6 Kg/cm ²).	cheekeelou
	-	• With park brake in applied condition. —————	NA
	* * * * * * * * * * * * * * * * * * *	• With direct loco brake applied (BP< 4.75Kg/cm ²).	9
		• With automatic train brake applied (BP<4.75Kg/cm²).	Scholteelde
		With emergency cock (BP < 4.75 Kg/cm²).	5
8.	Check traction interlock	Switch of the brake electronics. The	
	3	Tractive /Braking effort should ramp down, VCB	(checked og
		should open and BP reduces rapidly.	8
9.	Check regenerative	Bring the TE/BE throttle to BE side. Loco speed	Scheeked by
	braking.	should start reducing.	5
10.	Check for BUR	In the event of failure of one BUR, rest of the two	9
	redundancy test at	BURs can take the load of all the auxiliaries. For this	cheered
	ventilation level 1 & 3 of	switch off one BUR.	Oce
	loco operation	Auxiliaries should be catered by rest of two BURs.	
		Switch off the 2 BURs; loco should trip in this case.	7
11.	Check the power	Create disturbance in power converter by switching	Total 1
	converter	off the electronics. VCB should open and converter	chelked
	isolation test	should get isolated and traction is possible with	
		another power converter.	

DIESEL LOCO MODERNISATION WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41570

Type of Locomotive: WAP-7/WAG-9HC

Page: 27 of 27

7.0 Final check list to be verified at the time of Loco dispatch

Condition /Operations of the following items are to be checked:

N	Item	Cab-1	Cab-2	Remarks
1	Head lights	OF	010	
2	Marker Red	DV	OK	
3	Marker White	00	or .	
4	Cab Lights	OK	OK	
5	Dr Spot Light	OK	Oe	except worksey
6	Asst Dr Spot Light	8K	By	>
7	Flasher Light	OK	DK	
8	Instrument Lights	OK	OK	
9	Corridor Light	on	ore	
10	Cab Fans	ou	ax .	
11	Cab Heater/Blowers	21	OK.	
12	All Cab Signal Lamps Panel 'A'	90	ov	

Status of RDSO modifications



LOCO NO: 41570

Sn	Modification No.	Description	Remarks
1.	1	Modification in control circuit of Flasher Light and Head Light of three phase electric locomotives.	Øk/Not Ok
	RDSO/2009/EL/MS/0377 Rev.'0' Dt 22.04.09	Modification to voltage sensing circuit in electric locomotives.	OK/Not Ok
3.	RDSO/2010/EL/MS/0390 Rev.'0' Dt 31.12.10		ØK/Not Ok
4.	RDSO/2011/EL/MS/0399 Rev.'0' Dt 08.08.11	i i i i i i i i i i i i i i i i i i i	OK/Not Ok
5.	RDSO/2011/EL/MS/0400 Rev.'0' Dt 10.08.11	11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	OK/Not Ok
6.	RDSO/2011/EL/MS/0401 Rev.'0' Dt 10.08.11	Modification sheet for relaying of cables in HB-2 panel of three phase locomotives to avoid fire hazards.	Øk/Not Ok
7.	RDSO/2011/EL/MS/0403 Rev.'0' Dt 30.11.11	Auto switching of machine room/corridor lights to avoid draining of hatteries in three phase electric locomotives.	Ok/Not Ok
8.	RDSO/2012/EL/MS/0408 Rev.'0'		Ok/Not Ok
9.	RDSO/2012/EL/MS/0411 Rev.'1' dated 02.11.12	Modification sheet to avoid simultaneous switching ON of White and Red marker light in three phase electric	Ok/Not Ok
10	RDSO/2012/EL/MS/0413 Rev.'1' Dt 25.04.16	locomotives. Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives to improve reliability.	Øk/Not Ok
11	RDSO/2012/EL/MS/0419 Rev.'0' Dt 20.12.12		Ok/Not Ok
12	RDSO/2013/EL/MS/0420 Rev.'0' Dt 23.01.13	Modification sheet to provide mechanical locking arrangement in Primary Over Current Relay of three phase	Øk/Not Ok
13	RDSO/2013/EL/MS/0429 Rev.'0' Dt 22.05.13	5 Modification sheet for improving illumination of head light in	ØK/Not Ok
14	RDSO/2013/EL/MS/042 Rev.'0' Dt 18.07.13	6 Modification sheet of Bogie isolation rotary switch in three	Øk/Not Ok
15		7 Modification sheet for MCP control in three phase electric	•
16		Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.	OK/140t OK
17	RDSO/2014/EL/MS/043 Rev.'0' Dt 12.03.14	Removal of shorting link provided at c-d terminal of over	
18		Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT	SWINDLOK
19	RDSO/2017/EL/MS/046 Rev.'0' Dt 07.12.17	Modification in blocking diodes to improve reliability in three phase electric locomotives.	· .
20		(CE) recetting	QK/Not Ok
2			Ok/Not Ok



DMW/PATIALA

Loco No.: 41570



PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

S.N	Parameters	Reference	Value	Result
1.0	Auxillary Air supply system (Pantograph & VCB)		- unuc	Result
1.1	Ensure, Air is completely vented from pantograph		0	
	Reservoir (Ensure Panto gauge reading is Zero)		0	0
1.2	Turn On BL Key. Now MCPA starts.		CO (DA)	
	Record pressure Build up time (8.5kg/cm2)		60 sec. (Max.)	52 Sec
1.3	Auxillary compressor safety Valve 23F setting	Faiveley Doc. No.	0.510.351. / 3	_
		DMTS-014-1, 8	8.5±0.25kg/cm2	8.5 Kg/cm2
		CLW's check sheet	-	m _{ess}
		no. F60.812 Version		
		2		
1.4	Check VCB Pressure Switch Setting	CLW's check sheet	Onone 4 5 10 45	
	· ·	no. F60.812 Version	Opens 4.5±0.15	4.55 Kg
		2	kg/cm2 closes	/cm2
1.5	Set pantograph Selector Switch is in Auto, Open pan-1&2 Is	Solating Cocks & KARA of	5.5±0.15 kg/cm2	
1.6	Set Cab-1 Pan UP in Panel A.	COCKS & KABA CO		
			Observed Pan-2	OK
1.7	Close Pan-2 isolating Cock		Rises.	
	Open Pan -2 isolating Cock		Panto-2 Falls Down	OK
1.8	Record Pantograph Rise time		Panto-2 Rises	
1.9	Record Pantograph Lowering Time		06 to 10 seconds	9 Sec
1.10	Panto line air leakage		06 to 10 seconds	9 Sec
	r anto inic dii leakage		0.7 kg/cm2 in 5	0.35 kg/cm2
2.0	Main Air Supply Sustains		Min.	in 5 Min.
2.1	Main Air Supply System			
2.1	Ensure, Air is completely vented from locomotive. Drain	Theoretical		
	out all the reservoirs by opening the drain cocks and then	calculation and test		
	closed drain cocks. MR air pressure build up time by each	performed by		
	compressor from 0 to 10 kg/cm2.	Railways.		
1	i) with 1750 LPM compressor		i) 7 Mts. Max.	6.75 Mts
	ii) with 1450 LPM compressor		ii) 8.5 Mts. Max.	
2.2	D			-
2.2	Drain air below MR 8 kg/cm2 to start both the		Check Starting of	
2.2	compressors	_	both compressors	
2.3	Drain air from main reservoir up to 7 kg/cm2. Start		30 Sec. (Max)	CP1-26.5 Sec
	compressors, Check pressure build time of individual			
	compressor from 8 kg/cm2 to 9 kg/cm2			CP2-26.5 Sec
2.4	Check Low MR Pressure Switch Setting (37)	D&M test spec.	Closes at 6.40±0.15	6.4 Kg/cm2
		MM3882 &	kg/cm2 Opens at	,
		MM3946	5.60±0.15kg/cm2	5.5 Kg/cm2
2.5	Check compressor Pressure Switch RGCP setting (35)	D&M test spec.	Closes at 10±0.20	10.1 Kg/cm2
		MM3882 &	kg/cm2 Opens at	
		MM3946	8±0.20 kg/cm2	8.1 Kg/cm2
2.6	Run both the compressors Record Pressure build up time	Trial results	3.5 Minutes Max.	3.3 minute



2.7	Check unloade	r valve operation time				Approx. 12 Sec.	11 sec
2.8	Check Auto Dra	ain Valve functioning (124 & 87)			Operates when	
		900 A CO	*			Compressor starts	
2.9		very safety valve settir	ng (10/1). Run CP	D&M t	est spec.	11.50±0.35kg/cm2	11.8 Kg/cm
	Direct by BLCP.			MM3882	& MM3946		, and
2.10		ivery safety valve setti	ng (10/2). Run CP	D&M t	est spec.	11.50±0.35kg/cm2	11.8 Kg/cm
0.11	direct by BLCP			MM3882 & MM3946		1	
2.11	Switch 'OFF' the compressors and ensure that the safety valve to reset at pressure 12 kg/cm2 less than opening			D&M t	est spec.		
6		it pressure 12 kg/cm2	less than opening	MM3882	& MM3946		
2.12	pressure.	/					
2.12	BP Pressure: Sv	vitch 'OFF' compresso	r, Drain MR Pressure	CLW's che		5.0±0.10kg/cm2	5.0 Kg/cm2
	by drain cock o	f 1" Main Reservoir, S	tart Compressor, and	no. F60.81	L2 Version 2		
2.13		ressure of Duplex Che	ck Valve 92F.				
2.15	FP pressure:	in Tool :- 1075 50T	5.0	CLW's che		6.0±0.20kg/cm2	6.0 Kg/cm2
	136E Chock pre	in Test point 107F FPT essure in Gauge.	P. Open isolate cock	no. F60.81	L2 Version 2	=	
3.0	20.000						
3.1	Air Dryer Ope						
5.1	open Drain Coc	ck 90 of 2 nd MR to star	t Compressor, leave			Tower to change	
	openior rest c	heck Air Dryer Towers	to change.			i) Every minute	OK
1	3 9					(FTIL & SIL) ii)every	
3.2	Check Purge Air	r Stops from Air Dryer	at Compressor stone			two minute (KBIL)	
3.3		of humidity indicator					
4.0	Main Reservoir					Blue	Blue
4.1			anck MD Drossura air	DOMA		61 111 1	
	leakage from ho	Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.			est spec.	Should be less than	0.45
	leakage from both cabs.			1011013882	& MM3946	1 kg/cm2 in 15	Kg/cm2 in
4.2	Check BP Air leakage (isolate BP charging cock-70)		DOMAtest		minutes	15 minutes	
	check by All leakage (Isolate By charging cock-70)			D&M test spec. MM3882 & MM3946		0.15 kg/cm2 in 5 minutes	0.11
				1011013002	Q 1011013340	minutes	Kg/cm2 in 5 minutes
5.0	Brake Test (Au	utomatic Brake ope	ration)				3 minutes
5.1		ipe & Brake Cylinder p					
		i jagaines e	- ac ac acon step				
	Check proportionality of Auto Brake system			CLW's ch	eck sheet		
				no. F60.812 Version 2			
	Auto controller position				9 & WAG-7)	BC (WAP-5)	
				Kg/cm2		Kg/cm2	
					T		
		BP Pressure kg/cr	n2	Value	Result	Value	Result
		ar i ressure kg/ cr	2	value	Result	value	Result
				(6			
						9	
	Run	5±0.1	5.0 Kg/cm2	0.00	0.00 Kg/ cm2	0.00	
	Initial	4.60±0.1	4.6 Kg/cm2	0.40±0.1	0.40Kg/ cm2	0.75±0.15	
	Full service	3.35±0.2	3.5 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	
	Emergency	Less than 0.3	0.2 Kg/cm2	2.50±0.1	200	5.15±0.30	
	J,		0.2 1.0/ 01112	2.50±0.1	2.5Kg/ cm2	J.1J±0.30	

Loco No.:41570

5.2	Record time to BP pressure drop to 3.5 kg/cm2 Ensure Automatic Brake Controller handle is Full Service from Run	D&M test spec.	8±2 sec.	9 Sec
5.3	Operate Asst. Driver Emergency Cock,	MM3882 & MM3946		
	operate Asst. Driver Emergency Cock,	D&M test spec.	BP pressure falls	7
	A.	MM3882 & MM3946	to Below 2.5	OK
5.4	Check brake Pipe Pressure Switch 69F operates	CINA L	kg/cm2	
	shear prace ripe rressure switch 69F operates	CLW's check sheet no.	Closes at BP	4.2 Kg/cm2
	*	F60.812 Version 2	4.05- 4.35	is .
			kg/cm2	
			Opens at BP	3 Kg/cm2
	*		2.85- 3.15	
5.5	Move Auto Proba Carla III I I II I		kg/cm2	
5.5	Move Auto Brake Controller handle from Running to	D&M test spec.		
	Emergency BC filling time from 0.4 kg/cm2 i.e. 95% of	MM3882 & MM3946		
	Max. BC developed			14
	WAP7 - BC 2.50 ± 0.1 kg/cm2		7.5±1.5 sec.	
_	WAG9 - BC 2.50 ± 0.1 kg/cm2		21±3 sec.	20 Sec
٥.6	Move Auto Brake Controller handle to full service and	D&M test spec.		
	BP pressure 3.5 kg/cm2. Move Brake controller to	MM3882 & MM3946		=
	Running position BC Release time to fall BC Pressure			
	up to 0.4 kg/cm2 i.e. 95% of Max. BC developed			
	BC release Time			25
	WAP7		17.5±25 sec.	
	WAP9	8	52±7.5 sec.	54 Sec
5.7	Move Auto Brake Controller handle to Release, Check	CLW's check sheet no.	60 to 80 Sec.	73 Sec
	BP Pressure Steady at 5.5 0.2 kg/cm2 time.	F60.812 Version 2	V 2022	
5.8	Auto Brake capacity test: The capacity of the A9 valve	RDSO Motive power	BP pressure	
	in released condition must conform to certain limit in	Directorate report no.	should not fall	
	order to ensure compensation for air leakage in the	MP Guide No. 11 July,	below 4.0	
	train without interfering with the automatic	1999 Rev.1	kg/cm2 with in	4.25 Kg/cm2
	functioning of brake.		60 Sec.	4.23 (8) (11)
	* Allow The MR pressure to build up to maximum		00000	,
	stipulated limit.			
,	* Close brake pipe angle cock and charge brake pipe to			
	5 kg/cm2 by A (Automatic brake controlling) at run			
	position.		8	
	* Couple 7.5 dia leak hole to the brake hose pipe of		*	
	locomotive. Open the angle cock for brake pipe.			
	The test shall be carried out with all the compressors			
	in working condition.		9	
5.9	Keep Auto Brake Controller (A-9) in Full Service. Press		DC 00m0- t- (0)	0
	Driver End paddle Switch (PVEF)		BC comes to '0'	0
5.0	Direct Brake (SA-9)			
5.1	Apply Direct Brake in Full Check BC pressure			
	WAG9/WAP7	CIWA	25/25-1	
	WAP5	CLW's check sheet no.	3.5±0.20 kg/cm2	3.5Kg/cm2
5.2		F60.812 Version 2	5.15±0.3 kg/cm2	
1.2	Apply Direct Brake, Record Brake Cylinder charging	D&M test spec.	8 sec. (Max.)	7 Sec
	time	MM3882 & MM3946		

DMW/PATIALA

Loco No.:41570

6.3	Check Direct Brake Pressure switch 59 (F)	D&M test spec. MM3882 & MM3946	0.2.±0.1 kg/cm2	0.2 kg/cm2
6.4	Release direct brake & BC Release time to fall BC pressure up to 0.4 kg/cm2		10 -15 Sec.	12.5 Sec
7.0	Dynamic Brake (Brake Blending)			
7.1	This test is to be done by forcing signal by laptop 06H Actual BE E1 = 100%	D&M test spec. MM3882 & MM3946	WAP7 & WAG9 - 2.5 kg/cm2. WAP5-5.15kg/cm2	
7.2	This test is to be done by forcing signal by laptop 06H Actual BE E1 = 50%	D&M test spec. MM3882 & MM3946	WAP7 & WAG9 - 1.25 kg/cm2. WAP5-2.55kg/cm2	
8.0	Parking Brake		7771 3 2.33Rg/CIIIZ	
8.1	Press BPPB to Release brake	D&M test spec. MM3882 & MM3946	PB released Lamp off in Panel pressure in parking Brake gauge	
8.2	Press BPPB to apply parking brake		60kg/cm2 PB applied, Lamp On in panel Pressure in parking Brake gauge 0.0 kg/cm2	
8.3	Manually release and apply Parking Brake by pressing solenoid valve 30F		Verify release and application of parking Brake.	
8.4	Check Pressure in PB Gauge		6.0.±0.15 kg/cm2	
8.5	Check Brake Block clearance	D&M test spec. MM3882 & MM3946	10 mm in TBU 3 mm in Disc. Brake (WAP5)	
9.0	Sanding Equipment		(17,113)	
9.1	Check Isolating Cock-134F is in open position. Press sander paddle Switch. (To confirm EP valves Operates)		Sand on Rail	ОК
10.0	Test Vigilance equipment : As per D&M test specification			ОК

Signature of loco testing staff

Signature of SSE/Shop



Issue No.: 03

Effective Date: Oct-2021

DOC NO: F/LAS/Electric Loco CHECK SHEET (Ref: WI/LAS/Elect/01, 02, 03 & 04 & OPL/LAS/Elect. Loco) Page 1 of 1

डीजल रेळइंजन आधुनिकीकरण कारखाना पटियाला। DIESEL LOCO MODERNISATION WORKS, PATIALA

ELECTRIC LOCO CHECK SHEET

S. No	O NO: 4/570 ELECTRIC LOCO CHECK SHEET Rly: ECOR		Shed:	WAT	
1.1	a 1980	Specified Value		bserved	
1.2	Check proper Fitment of Hotel Load Converter & its output contactor.	OK		NA -	
	Check proper Fitment of MR Blower 1 & 2, MR Scavenging Blower 1 & 2, TM Blower 1 & 2.	ОК	_		
1.3				OR	
1.4	Check proper of Fitment of oil cooling unit (OCU).	ОК		B 15	
1.5	Check proper Fitment of HB 1 & 2 and its respected lower part on its Check proper Fitment of FB panel on its position.	ОК		35	
1.6	Check proper Fitment of assembled SB1 & SB2 with VCU1 & VCU2.	OK	-	K	
1.7	Check proper Fig. 6.1	OK		K	
1.8	Check proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3).	ОК	-	3 K	
1.10	officer proper ritinent of Traction convertor 1 8 2 (cp. 1 0 2)	ОК		15	
1.12	Glicek proper fittinent, forguing & Locking of Maintain	OK OK		25	Α.
	Check proper fitment of compressor both side with the compressor safety wire rope.	OK	+		
1.13	Proper setting of the dampers as required.			310	
1.14	Check proper position of Secondary 1997	OK	6	115	
1.15	Check proper position of Secondary Helical Springs between Bogie & Shell	OK		15	
1.16	Check proper fitment of Body Bogie Safety Chains fitted properly. Check proper fitment of Cow catcher.	ОК	-	X	
.17	Check goods at the land of Cow catcher.	OK		7	
.18	Check coolant level in SR 1 & 2 Expansion Tank	ОК			
0 -	Check Transformer Oil Level in both conservators Tank (Breather Tank).	OK		1K	
.19	Check proper fitment of both battery hox	CORNACA	θ	1	
.20	Check proper fitment of Push Pull rod its holt torquing and as fit it	ОК	0		100
.21	Buffer height: Range (1085 mm to 1105 mm) Drg No IB031-02002.	OK	6		
	o (103 mm) big No iB031-02002.	1090-1105		L/S	R/S
		mm	FRONT	1098	109
22	Buffer Length: Range (641 mm + 3 to 10 mm with buffer face) Drg No- SK.DL-3430		REAR	1098	109
	SK.DL-3430.	641 mm		L/S	R/S
			FRONT		
23	Height of Pail County (444)		REAR	645	646
23	Height of Rail Guard. (114 mm + 5 mm,-12 mm).	114 mm +	KLAIK	645	645
	8	5 mm,-12	FRONT	L/S	R/S
24	CDC H-1-1 P	mm	REAR	119	119
4	CBC Height: Range (1085 mm to 1105 mm) Drg No- IB031-02002.	1085-1105	100	119	118
		mm	FRONT: REAR:	1095)

(Signature of JE/Elect Loco)

(Signature of JE/UF)

		SEL LOCO MODERNISATIO LOCO NO -:41	570 /	A	
141		Under frame com	ponent		
ition of component	PL No.	Make		Mfg day o	Warra
	29171027	Taid		Mfg. date & Serial no.	cover
Transformer	20721057	Trident	21/49,11	/2021	upto
ervator Tank BREATHE	D 20-	BHEL	65-10-21	2052050	
ressor both side	23/3105/	YOGYA ENTERPRISES	2052056	2053859 ,2021	
y Box both side	29511008	ELGI	EUC5036	, 2053855	
on Bar Cab-1	29680013	BBSS	4621/12/	61(06/21) ,EUDS926516(07/21)
on Bar Cab-2	29100069	KMRI	+021/4/	09/21),4621/36/09/21/	6
uffer Assly Both Side		KMRI	7047-09-	21	di ij
oling Pump both Side		KMRI	7061-09-2		—— <u>6</u>
Ormer oil Start :	29530027	SAMAL HARAND OF INDIA	LP329-06-2	1,364-06-21,LP276-06-21,312-06	21 0
ormer oil Steel pipes raft Gear (CBC)	29230044 F	RANSAL PVT.LTD	D2703 & [02455	21 0
arr gear (CBC)		ASP			— Ge
dry Helical Spring on B	Ogie 20045024	G.B. SPRING PVT. LTD.	10-21 & 09	9-21	As per PO condition
- RING (Center pivot I	Ring) 29100010 S	SDI SPRING PVI. LTD.			
Pivot Housing	29100057 A	SPL.			
	A		444-07.21	440.07.5	
.oad Contactor	29741087	Machine room Componer	444-07-21 nt cab 1	,448-07-21	
oad Converter	29741087				
wer					
ivenging Blower Motor	1 00	ELECTRICALS COMPANY (P) 10/21 &		
Control Cubical (HB-1)	2017	T.R.CO (P) LTD.	ST-21-06-	ICTMB211019	
ubical (FB-1)	20400140	G.L.		//Z	
te Control Cubicle SB-1	29480140 AL	TOMETER ALLIANCE LTD.	10/21 & CG	HB1G21A127	no
Control Unit (VCU)	231/12U9 HI	ND RECTIFIERS LIMITED	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	ALN/11/2021/02/FB/045	一 第
nverter (BUR) 1	23/410/3 BO	MBARDIFR	103/21 & SB	1/2021/H/0060/C40	Jug
DLING BLOWER(OCB)	29741075 BO	MBARDIER	D11L/11/202	1/U8/PRPIJISION A/1074	- 5
LING RADIATOR (OCR)	29470043 AIR	CONTROL & CHENNEY	11/21 & 202	21L/10142/68A/0131	PO condition
om Blower	29470031 STA	NDARD RADIATORS	1.00. 010/21 AC-46	048, & CGILLIAM-5006	ber
om Scavenging Blower	_ 29440105 G T	RCO(D) ITD	10/21 & 06	55-SRPI	- a
Convertor	29440129 AIR	CONTROL & CHEMICAL EN MBARDIER	MF-21-()7-134	As
	29741075 BON	ABARDIER	NGG. 406/21 AC-46	536, & CGLUDBM-16702	\dashv 1
d convertor I.V. Coupler	29/4108/		0.12/11/2021	/08/PRPULSION_A/1972	-
d Contactor	MA	CHINE ROOM COMPONEN	17.0	- 120.01V_A/1972	- 1
d Converter			II Cab-2		
er	29741087				$\overline{}$
nging Blower Motor	29440075 IC EL	ECTRICALS COMPANY (P)			\dashv \vdash
ontrol Cubical HB-2	0.1.	TOTAL TIP		ICTMB211022	
Control Cubicle SB-2	291/1192 AUT(OMETER ALLIANCE LTD	ST-21-07-1	95	
ontrol Unit (VCU)	TESTITETO LIKUL	EX INDIA DIT ITO	07/21 & AALN	/07/2021/05/HB2G9/063	- iº
erter (BUR) 2&3	1 23/410/2 IBOM	BARDIER	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	27	- i i i
NG PLOWERS	29/41075 BOM	BARDIER	BTIL/11/2021/	08/PRPULSION_A/1972	PO condition
NG BLOWER(OCB)	29470043 SAINI	FLECTRICALS	11/21 Q 2021	/10147/688/0121	1 0 1
NG RADIATOR (OCR)	29470031 STAN	DARD RADIATORS	03/21 & 32108:	1963, FAN- 32109AF10C2	1 ă
	1 23440103 G.I.K	CO (P) ITD	10/21 & U66	-SRPL	per
Scav. blower	29440129 AIR CO	ONTROL & CHENNICAL FILE			Asp
	29741075 BOME	ONTROL & CHEMICAL ENG BARDIER	G. 106/21 & AC-4	6531, CGLUDRM-15441	10
onvertor I.V. Coupler	29741087		BTIL/11/2021/0	6/PRPULSION_A/1967	
		Driver Cabin		5.1_7/1307	1 1
oner	29140050 Modif.	Machinellan	Loa		
mer	-53011058 (VKI b()	WER DRIVES DUT LTD	12655		
	29170011 ESCOR	15	KKI/HVAC/CLW/	783 & 785	PO
61	29470080 RANIA	V	38, 87		As per PC condition
7	29171131 MODE	RN RAILTECH & EASTERN E	822, 753, 813, 7	73	As per l
		- LOUI & LASTEKIN E	49, 66, 79		As CO
OPINDER SING	74		SIGN	< A	
SSE/LAS			NAMI	SPT754 KumpR JE/LAS	
				washing I work	

डी.एम.डब्स्यु

DWW/PTA

ELECTRIC LOCO HISTORY SHEET (TRS)

RLY ECOR ELECTRIC LCO NO: 41570

SHED: WAT

PROPULSION SYSTEM: BT

ULSION SYS	
	מו מ
	M SR NO
	ITEN
RS	ITEM PL
SFITTED BY T	F ITEM
LIST OF ITEMSFIT	CRIPTIO 0
LIST OF	DESC
	SN
	n.

WARRANTY	COVERED			57						CONDITIONS					H	
OPL	į	04 Nos	02 Set	04 Set	04 Nos.	02 Set	04 Nos.	02 Nos		02 Set	02 Nos.	02 Nos.	O2 Nos	01 Set	01 Set	01 Set
MAKE/SUPPLIER		M/s PCE	M/s SCS	-	M/s EIC	M/s ESBEE	M/s. RANJAN		M/s AUTOMETER	M/s. KEPCO	M/s. CROMPTON	M/s PATRA & CHANDA	Ms. TROLEX	M/s TELPRO	AMCO	PPS DMW
ITEM SR. NO.	CAB-2	5/2021	FLEO3680	3880,3885	1223,1398	2163	773,818	AALN/06/2021/	055/MCT/115	KEPCO/A1/1782	CG/CF/21090940	PCE/182/7/2021	7746	MTELS2108171	Battery Set No 271	DMW
ITEM	CAB-1	5/2021	FLE03591	3896,3763	1339,1234	2185	622,753	AALN/06/2021/	052/MCT/117	KEPCO/A1/1786	CG/G=/21090939	PCE/185/7/2021	7924	MTB_M2108171	Battery Set No 271	PPS DMW
ITEM PL	O Z	29610023	25984962	25984860	29610461	29170011	29470080	29860015		29178204	29178162	29700012	29500059	29200040	29680025	29600418
DESCRIPTION OF ITEM		HEAD LIGHT LAP	LED BASED FLIGHT	LED MARKER LEHT	DRIVER CAB LIBHT	CAB HEATER	CREW FAN	MASTER CONTROLLER		COMPLETE PAIEL A,C,D	COMPLETE CUBCLE- F PANEL	HEATER ROTER SWITCH	DIFFRENCIAL MPLIFIRE	SPEED IND. & R.C. SYSTEM	BATTERY (Ni- C)	HARNESSED CÆLE COMPLETE
S S		~	7	m	4	ro.	9			∞	o	10		12	13	4



			ROOF COMPONENT CAB 1 & 2		W. tacaat.
S.No.	Description	QPL /Nos.	Supplier	200	Wallanty
1	Pantograph	2	General Store	2011.10	1-
1		-	द्यादावा उत्पाद्य स्नाविष्ठः	2181-11/21,2182-11/21	
7	servo motor	2	General Stores & Engg.	2084-09/21,2086-09/21	1
80	Air Intake filter Assly	2	VIKRANT		
4	Insulator Panto Mtg.	8	IEC	05/21,06/21	
			MIDDLE ROOF COMPONENT		
	High Voltage Bushing	1	ABB	IZCD12986380	
9	Voltage Transformer	7	Sadtem	2021-N,625385	
7	Vacuum Circuit Breaker	1	Schneider	223171153/03	
∞	Insulator Roof line	6	IEC	5/21.5/21	
6	Harmonic Filter	1	Rsi Switchgear	448182/10	91
10	Earth Switch	1	Autometer Alliance	AALN/07/2021/015/ES/259	As per IRS/PO conditions
11	Surge Arrester	2	CG POWER	9851167 9851166	
			Air Brake Components		
	Air Compressor	2	Elgi	EUCS 926516 A. EUCS 926461 B	190
	Air Dryer	1	PRAG	2479-08-21	
	Auxillary Compresssor	1	ELGI	BUPS 104465	
15	Air Brake Panel	П	Knorr	21-08-CO-2008	
16 (Contoller	2	Knorr	21-08-EO-2032A. 21-08-FO-2032B	
17	Breakup Valve	2	Knorr		
18 \	wiper motor	-	Elgi		

SSE/Resting

DIESEL LOCO MODERNISATION WORKS

Loco No. 41570

1. BOGIE FRAME:

В	OGIE	FRAME NO	Make	PL No.	PO No. & dt.	Warranty Period
F	RONT	TACPL-01/04	TRIDENT	20105146	771831	As per PO/IRS conditions
F	REAR	TACPL-04/04	TRIDENT	29105146	771831	Conditions

2. Hydraulic Dampers (Axle, Vertical, Yaw and Horizontal) Make: ESCORT

3. AXLES:

AXLE POSITION NO	1	2	3	4	5	6
MAKE/	DMW	DMW	DMW	DMW	DMW	DMW
S.NO	21893	21959	21974	21898	21860	21965
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

4. WHEEL DISCS NO. AND TYPE

AXLE POSITION NO	1	2	3	4	5	6
GEAR END	CNC/21- 1569	CNC/21- 1570	CNC/21- 1598	CNC/21- 1596	CNC/21- 1588	CNC/21- 1617
Ultrasonic Testing	OK	OK	OK	OK	OK	OK
FREE END	CNC/21- 1604	CNC/21- 1594	CNC/21- 1605	CNC/21- 1599	CNC/21- 1601	CNC/21- 1589
Ultrasonic Testing	OK	ОК	OK	OK	OK	OK

5. AXLE ROLLER BEARING (CRU) (PL No. 29010020, Warranty: As per PO/IRS conditions)

	AXLE POSITION NO	1	2	3	4	5	6
Gear	MAKE	NBC	NBC	NBC	NBC	NBC	NBC
End	PO NO. & dt	771567	771567	771567	771567	771567	771567
Free	MAKE	NBC	NBC	NBC	NBC	NBC	NBC
End	PO NO. & dt	771567	771567	771567	771567	771567	771567

6. WHEEL DISC PRESSING (PRESSURE IN KN): SPECIFIED 80-105 T

AXLE POSITION NO	1	2	3	4	5	6
BULL GEAR END	835	873	843	869	818	987
FREE END	838	878	852	875	827	846



Loco No. 41570

7. DIAMETER AFTER PROFILE TURNING: SPECIFIED 1092 + 5 mm - 0 mm

AXLE POSITION NO	1	2	3	4	5	6
DIA IN mm GE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
DIA IN mm FE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
WHEEL PROFILE GAUGE (1596±0.5mm)	OK	OK	OK	OK	OK	OK

8. SUSPENSION TUBE & ITS TAPER ROLLER BEARING:

AXLE POSITION	NO NO	1	2	3	4	5	6
S.T.	MAKE	KP	KPE	KPE	KPE	KPE	KPE
G.E. BEARING	MAKE	FAG	FAG	FAG	FAG	FAG	FAG
F.E. BEARING	MAKE	FAG	FAG	FAG	FAG	FAG	FAG

9. GEAR CASE & BACKLASH:

AXLE POSITION NO	1	2	3	4	5	6
MAKE	TRIDENT	TRIDENT	TRIDENT	TRIDENT	TRIDENT	TRIDENT
BACKLASH (0.254 – 0.458mm)	0.340	0.330	0.340	0.350	0.310	0.330

10 A/BOX TO BOGIE FRAME LATERAL CLEARANCES (SPECIFIED 15.0 to 19.0mm):

AXLE POSITION NO	1	2	3	4	5	6
RIGHT SIDE	16.04	17.29	18.87	19	17.90	17.52
LEFT SIDE	16.10	19	17.25	18.16	16.14	16.20

11. TRACTION MOTOR: (PL No. 29942007, Warranty: As per PO/IRS conditions)

AXLE POSITION NO MAKE PO I		PO No. & date	S. NO.
1	SAINI	566630 dt 19.01.19	221083304
2	SAINI	566630 dt 19.01.19	221083305
3	SAINI	566630 dt 19.01.19	221083261
4	SAINI	566630 dt 19.01.19	221083299
5	SAINI	566630 dt 19.01.19	221083309
6	SAINI	566630 dt 19.01.19	221083308

Rogie

	TOP 12	COSTLIEST ITEMS OF WAG9HC LOCO WITH	TOP 12 COSTLIEST ITEMS OF WAG9HC LOCO WITH WARRANTY CONDITIONS AS PER TENDERS
S No	PL No	DESCRIPTION	Warranty Period
М	29741075	IGBT BASED 3-PHASE DRIVE PROPULSION EQUIPMENT	60 months after commissioning or 72 months from date of supply whichever earlier as per special conditions given by CLW
7	29731057	MAIN TRANSFORMER 7775 KVA TYPE LOT 7500 FOR WAP7 3- PHASE ELECTRIC LOCOMOTIVE TO CLW SPECN NO.CLW/ES/3/0660/C	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
, co	29171064	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT 8	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR AS PER IRS CONDITIONS-30 MONTHS FROM THE DATE OF WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT-SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER.
4	29600418	SET OF HARNESSED CABLE FOR 3-PHASE ELECTRIC LOCOMOTIVES TO CLW SPECN. NO. CLW/ES/03/646 ALT-NIL WITH DMW REQUIREMENT OF HARNESSED CABLE FOR WAP-7, ALT-A1 DATED 27/11/2018.	As per clause no.9 of CLW Specn. CLW/ES/3/0458 & Clause No.10 of CLW SpecnCLW/ES/3/0459. [18 months after commissioning or 20 months from date of supply for single core & 18 months after commissioning or 24 months from date of supply for multi core]

-	
1	
	10
	(

S	29180016	BRAKE CONTROL SYSTEM INCLUDING DRIVER'S VIGILANCE CONTROL DEVICE TO SET LIST NO.EL29180016.	As per specification no. CLW/MS/3/001 Alt. 16 i.e. the manufacturer is required to guarantee that the brakevalves/equipment work satisfactorily for a period of five (5) years after commissioning. Any equipment/part which failsduring the guarantee period shall be replaced free of cost by the manufacturer. The replaced components shallfurther be under warranty for five (5) years from the date of their fitment and should the replaced components proveunsatisfactory in service, they shall be replaced by modified and improved components by the supplier free of cost.
9	29480140	COMPLETE FILTER CUBICLE ALONG WITH ALL EQUIPMENTS AND CABLING TO DRG./SPEC NO. [1] CLW/ES/3/0193 ALT-F OR LATEST AND CLW DRG. NO. 1209-15-143-004 ALT-10 AND PART DRG./SPEC NO AS PER ANNEXURE-A ATTACHED.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
7	29942007	3-PHASE ASYNCHRONOUS TRACTION MOTOR (RESISTANCE RING MECHANICALLY INTERLOCKED TO END PLATE DESIGN ROTOR, SCHEME-II), TYPE 6FRA-6068 FOR WAP-7 ELECTRIC LOCO WITHOUT ACTIVE SPEED SENSOR TO SPECIFICATION NO. 4TMS.096.081 ALT-2 AND STR NO. CLW/2008/3PHTM/STR/0001.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.

09	SOM	Σ	Σ	5
As per clause 16 of Spec.No.CLW/MS/3/Bogie/003 Alt-1. [60 months after commissioning or 72 months from date of supply]	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMIMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
Boge FrameComplete for WAP-7 for 3 Phase Co Co Loginotive to CLW specification No. CLM/MS/3/fbgie/003 alt-1 and CLW DrgNo.120901.112-202 Alt-Nil	COMPLETE ALXILIARY CUBICLE HB2 ALONG WITH ALLEQUIPMENTS AND CABLING TO CLW SPELNO.CLW/ES/3/0192 ALT-E OR LATEST FOR WA?7 LOCOWITH HOTEL LOAD WITH BARE CUBICLE AS FER CLW \$PEC.NO.CLW/MS/3/155 ALT-NIL.	COMPLETE CONTROL CUBICLE SB2 ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELETTRONICS) TO CLW SPECN. NO. CLW/ES/3/0295/A ALT-H OR LATEST FOR WAP7 LOC WITH #OTEL LOAD	COMPLETE CENTROL CUBICLE SB1 (PUSH PULL SCHEME COMPLIANT) ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL TELETRONICS) TO CLW SPECN. NO. CLW/ES/3/0194 CALTG OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	COMPLETE ALXILIARY CUBICLE HB1 ALONG WITH ALLEQUIPMENTS AND CABLING TO CLW SPELNO.CLW/ES/3/0191 ALT-D OR LATEST FOR WA?7 LOCOW/ITH HOTEL LOAD WITH BARE CUBICLE AS FER CLW \$PEC.NO.CLW/MS/3/155 ALT-NIL.
29105146	29171192	29171210	29171209	29171180 S
∞	σ,	10	11	12