# भारतीय रेल Indian Railways

पटियाला रेलइंजन कारख़ाना, पटियाला

# PATIALA LOCOMOTIVE WORKS, PATIALA



# LOCO TESTING & DISPATCH REPORT OF IGBT BASED WAG9HC ELECTRIC LOCOMOTIVE

LOCO NO.: 41799

TYPE: WAG9HC

RAILWAY SHED: ER/ASN

PROPULSION SYSTEM: BTIL

**DATE OF DISPATCH:** 27.06.2023

लोको निर्माण रिकार्ड



# पटियाला रेलइंजन कारख़ाना, पटियाला PATIALA LOCOMOTIVE WORKS, PATIALA

LOCO NO.: 41799

**RAILWAY/SHED: ER/ASN** 

DOD: June-2023

#### **INDEX**

SN	PARA	ACTIVITIES	PAGE NO.
		Testing & Commissioning (ECS)	
1.	1.0	Continuity Test of the cables	
	1.1	Continuity Test of Traction Circuit Cables	
	1.2	Continuity Test of Auxiliary Circuit Cables	1-4
	1.3	Continuity Test of Battery Circuit Cables	
	1.4	Continuity Test of Screened Control Circuit Cables	
2.	2.0	Low Tension test	
	2.1	Measurement of resistor in OHMS $(\Omega)$	5-6
	2.2	Check Points	3-0
	2.3	Low Tension Test Battery Circuits (without control electronics)	
3	3.0	Downloading of Software	
	3.1	Check Points	
	3.2	Download Software	7-10
	3.3	Analogue Signal Checking	
	3.4	Functional test in simulation mode	
4	4.0	Sensor test & convertor test	
	4.1	Test wiring Transformer Circuits – Polarity Test	
	4.2	Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)	
	4.3	Primary Voltage Transformer	
	4.4	Minimum voltage relay (Pos. 86)	11-16
	4.5	Maximum current relay (Pos. 78)	11-10
	4.6	Test current sensors	
	4.7	Test DC Link Voltage Sensors (Pos 15.6/*)	
	4.8	Verification of Converter Protection Circuits (Hardware limits)	
	4.9	Sequence of BUR contactors	
5.	5.0	Commissioning with High Voltage	
	5.1	Check List	
	5.2	Safety test main circuit breaker	
	5.3	Auxiliary Converter Commissioning	
	5.3.1	Running test of 3 ph. auxiliary equipments	
	5.3.2	Performance of Auxiliary Converters	
	5.3.3	Performance of BURs when one BUR goes out	16-25
	5.4	Auxiliary circuit 415/110	
	5.5	Hotel Load Circuit	
	5.6	Traction Converter Commissioning	
	5.7	Test protective shutdown SR	
	5.8	Test Harmonic Filter	
	5.9	Test important components of the locomotive	25.00
6.	6.0	Running Trial of the locomotive	25-26
7.	7.0	Final Check List to be verified at the time of Loco dispatch	27
8.	8.0	Status of RDSO modifications	28
9.	1-10	Pneumatic Test Parameters	29 - 32
10.		Loco Check Sheet(LAS)	33
11.	-	Component History (LAS,ECS,ABS)	34-36
12.	-	Component History & Testing Parameter (Bogie Shop)	37 - 38
13	-	Warranty Conditions as per Tenders	39 -41

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4,799
1.0 Continuity Test of the cables

Type of Locomotive: WAP-7/WAG-9HC

Page: 1 of 27

#### 1.1 Continuity Test of Traction Circuit Cables

As per cable list given in Para 1.3 of document no. 3 EHX 410 124, check the continuity with continuity tester and megger each cable to be connected between following equipment with 500V megger.

From	То	Continuity (OK/Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Filter Cubicle	Transformer	ok	100 ΜΩ	700 MIL
Filter Cubicle	Terminal Box of Harmonic Filter Resistor (Roof)	OK	100 ΜΩ	800 MJZ
Filter Cubicle	Earthing Choke	0K	100 ΜΩ	600 M7L
Earthing Choke	Earth Return Brushes	OK	100 ΜΩ	700 MJL
Transformer	Power Converter 1	0K	100 ΜΩ	800 MJZ
Transformer	Power Converter 2	OK	100 ΜΩ	700 M D
Power Converter 1	TM1, TM2, TM3	OK	100 ΜΩ	600 MJZ
Power Converter 2	TM4, TM5, TM6	OK	100 ΜΩ	700 MR
Earth	Power Converter 1	OK	100 ΜΩ	700 MJ
Earth	Power Converter 2	OK	100 ΜΩ	800 MJ

#### 1.2 Continuity Test of Auxiliary Circuit Cables

As per cable list given in Para 1.4 of document no. 3 EHX 410 124, check the continuity with continuity meter and megger each cable to be connected between following equipment with the help of 500V megger.

CADA

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 2 of 27

From	То	Continuity(OK/ Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Transformer	BUR1	01	100 MΩ	1000
Transformer	BUR2	y none	100 MΩ	1000
Transformer	BUR3	Die_	100 MΩ	1000
Earth	BUR1	50	100 ΜΩ	1000
Earth	BUR2	De	100 MΩ	1000
Earth	BUR3	De	100 MΩ	1000
BUR1	HB1	2000	100 MΩ	[000
BUR2	HB2	216	100 MΩ	1000
HB1	HB2	ne	100 MΩ	1000
HB1	TM Blower 1	100	100 MΩ	200
HB1	TM Scavenge Blower 1	×10 00	100 ΜΩ	200
HB1	Oil Cooling Unit 1	me	100 MΩ	100
HB1	Compressor 1	00	100 MΩ	200
HB1	TFP Oil Pump 1	no_	100 MΩ	1,50
HB1	Converter Coolant Pump 1	012	100 ΜΩ	100
HB1	MR Blower 1	De	100 MΩ	200
HB1	MR Scavenge Blower 1	DK.	100 MΩ	200
HB1	Cab1	Ne	100 MΩ	100
Cab1	Cab Heater 1	OL	100 MΩ	100
HB2	TM Blower 2	no	100 MΩ	150
HB2	TM Scavenge Blower 2	2010	100 MΩ	100
HB2	Oil Cooling Unit 2	200	100 MΩ	200
HB2	Compressor 2	20-	100 MΩ	100
HB2	TFP Oil Pump 2	80	100 MΩ	200
HB2	Converter Coolant Pump 2	no	100 MΩ	100
HB2	MR Blower 2	82	100 MΩ	100
HB2	MR Scavenge Blower 2	no	100 MΩ	150
HB2	Cab2	no	100 M $\Omega$	100
Cab2	Cab Heater 2	84	$100~{ m M}\Omega$	200

पी.एल.डब्ल्यू P. L. W

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 3 of 27

1.3 Continuity Test of Battery Circuit Cables

Check continuity of following cables as per Para 2.3 of document no. 3 EHX 610 299

From	То	Condition	Continuity (OK/Not OK)
Battery (wire no 2093)	Circuit breakers 110- 2, 112.1-1, 310.4-1	By opening and closing MCB 112	OK
MCB 110	Connector 50.X7-1	By opening and closing MCB 110	OK
Battery (Wire no. 2052)	Connector 50.X7-2		OK
SB2 (Wire no 2050)	Connector 50.X7-3		OK

Close the MCB 112, 110, 112.1, and 310.4 and measure the resistance of battery wires 2093, 2052, 2050 with respect to the loco earth.	Prescribed value $> 0.5 \ M\Omega$	Measured Value MΩ
Measure the resistance between 2093 & 2052, 2093 & 2050, 2052 &	Prescribed value:	Measured .
2050	> 50 MΩ	Value <u>72</u> MΩ

Commission the indoor lighting of the locomotive as per Sheet No 7A & 7B.

#### 1.4 Continuity Test of Screened Control Circuit Cables

Check the continuity and isolation of the screen cable of the following circuits with the help of sheet no. mentioned against each as per document no. 3 EHX 610 299.

Corresponding Sheet Nos.	Continuity & Isolation (OK/Not OK)
04B	DK
10A	OK
10A	OK
01A, 12A	OK
06F, 06G	OK
	Sheet Nos.  04B  10A  10A  01A, 12A

Se

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC Page : 4 of 27

Master controller cab-1 &2	08C, 08D	OK
ΓΕ/ΒΕ meter bogie-1 & 2	08E, 08F	ak
Terminal fault indication cab-1 & 2	09F	SK-
Brake pipe pressure actual BE electric	06H	OK
Primary current sensors	12B, 12F	2K
Harmonic filter current sensors	12B, 12F	OK
Auxiliary current sensors	12B, 12F	94
Oil circuit transformer bogie 1	12E, 12I	OK
Magnetization current	12C, 12G	OK
Fraction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-1	12D	OK
Fraction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-2	12D	OK,
Fraction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-3	12D	9K
Fraction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-4	12H	0K
Fraction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-5	12H	OK
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-6	12H	OK
Train Bus cab 1 & 2 (Wire U13A& U13B to earthing resistance=	13A	OK
10K <b>Ω</b> ± ± 10%) UIC line	13B	OK
		JK.
Connection FLG1-Box TB	13A	DK.



(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

# <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 5 of 27

2.0 Low Tension test

#### 2.1 Measurement of resistor in OHMS $(\Omega)$

Measure the resistances of the load resistors for primary voltage transformer, load resistors for primary current transformer and Resistor harmonic filter as per Para 3.2 of the document no. 3 EHX 610 279.

Name of the resistor	Prescribed value	Measured value
Load resistor for primary voltage transformer (Pos. 74.2).	$3.9$ K $\Omega \pm 10\%$	3.952
Resister to maximum current relay.	1 <b>Ω</b> ± 10%	152
Load resistor for primary current transformer (Pos. 6.11).	3.3 <b>Ω</b> ± 10%	3.1.52
Resistance harmonic filter (Pos 8.3). Variation allowed $\pm$ 10%	WAP7	WAP7
Between wire 5 & 6	0.2 Ω	0.25
Between wire 6 & 7	0.2 Ω	0.22
Between wire 5 & 7	0.4 Ω	0.45
For train bus, line U13A to earthing.	10 k <b>Ω</b> ± 10%	999 FR
For train bus, line U13B to earthing.	10 k <b>Ω</b> ± 10%	10.0KR
Insulation resistance of High Voltage Cable from the top of the roof to the earth (by1000 V megger).	200 ΜΩ	300MN
Resistance measurement earth return brushes Pos. 10/1.	≤0.3 Ω	0.2852
Resistance measurement earth return brushes Pos. 10/2.	≤0.3 Ω	0.2852
Resistance measurement earth return brushes Pos. 10/3.	≤0.3 Ω	0:291
Resistance measurement earth return brushes Pos. 10/4.	≤0.3 Ω	0:302
Earthing resistance (earth fault detection) Harmonic Filter –I; Pos. 8.61.	<b>2.2 kΩ</b> ± 10%	2.2KR
Earthing resistance (earth fault detection) Harmonic Filter –II; Pos 8.62.	2.7 k <b>Ω</b> ± 10%	2.7 K.R
Earthing resistance (earth fault detection) Aux. Converter; Pos. 90.3.	3.9 k <b>Ω</b> ± 10%	3.9KN
Earthing resistance (earth fault detection) 415/110V; Pos. 90.41.	1.8 k <b>Ω</b> ± 10%	1.8 KJ
Earthing resistance (earth fault detection) control circuit; Pos. 90.7.	390 <b>Ω</b> ± 10%	39052
Earthing resistance (earth fault detection) Hotel load; Pos. 37.1(in case of WAP5).	3.3 k <b>Ω</b> ± 10%	NA
Resistance for headlight dimmer; Pos. 332.3.	10 <b>Ω</b> ± 10%	1052

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799 Note: Type of Locomotive: WAP-7/WAG-9HC

Par

Page: 6 of 27

Make sure that the earthing brush device don't make direct contact with the axle housing, earth connection must go by brushes.

#### 2.2 Check Points

Items to be checked	Remarks
Check whether all the earthing connection in roof and machine room as mentioned in sheet no. 22A is done properly or not.  These earthing connections must be flexible and should be marked yellow & green	cheeped on
Check whether all the earthing connection between loco body and bogie is done properly or not. These cables must be flexible having correct length and cross section	Cheeked ou

#### 2.3 Low Tension Test Battery Circuits (without control electronics)

These tests are done with the help of the special type test loop boxes as per procedure given in Para 3.6 of the document no. 3 EHX 610 279

Name of the test	Schematic used.	Remarks
Test 24V supply	Sheet 04F and other linked sheets	Charled or
Test 48V supply	Sheet 04F & sheets of group 09	Fan supply to be checked.
Test traction control	Sheets of Group 08.	OK
Test power supply bus stations.	Sheets of Group 09.	Fan supply to be checked.
Test control main apparatus	Sheets of Group 05.	OK.
Test earth fault detection battery circuit by making artificial earth fault to test the earth fault detection	Sheet 04C	OK.
Test control Pneumatic devices	Sheets of Group 06	Q.
Test lighting control	Sheets of Group 07	OK
Pretest speedometer	Sheets of Group 10	3K
Pretest vigilance control and fire system	Sheets of Group 11	9K
Power supply train bus	Sheets of Group 13	DIL

भी.एल.डब्ल्यू P. L. W

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page : 7 of 27

		// / / /
3.0	Downloadin	g of Software

3.1 Check Points.	Yes/No
Check that all the cards are physically present in the bus stations and all the plugs are connected.	Yes
Check that all the fibre optic cables are correctly connected to the bus stations.	Yes
Make sure that <b>control electronics off relay</b> is not energized i.e. disconnect Sub-D 411.LG and loco is set up in simulation mode.	Yes
Check that battery power is on and all the MCBs (Pos. 127.*) in SB1 &SB2 are on	Yes

3.2 Download Software

The software of Traction converter, Auxiliary converter and VCU should be done by commissioning engineer of the firm in presence of supervisor. Correct software version of the propulsion equipment to be ensured and noted:

Traction converter-1 software version:	1.0.4.7
Traction converter-2 software version:	1.0.4.7
Auxiliary converter-1 software version:	1,0.0.6
Auxiliary converter-2 software version:	2.0.0.6
Auxiliary converter-3 software version:	3.0.0.6
Vehicle control unit -1 software version:	1.6.8.25
Vehicle control unit -2 software version:	1.6.8.25

#### 3.3 Analogue Signal Checking

Check for the following analogue signals with the help of diagnostic tool connected with loco.

Description	Signal name	Prescribed value	Measured Value
Brake pipe pressure	FLG2;0101XPrAutoBkLn	100% (= 5 Kg/cm2)	OK
Actual BE electric	FLG2; AMSB_0201- Wpn BEdem	100% (= 10V)	OK
TE/BE at 'o' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 9% and 11 %	114,
TE/BE at 'TE maximal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 99 % and 101 %	1014.
TE/BE at 'TE minimal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 20 % and 25 %	287,

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 8 of 27

TE/BE at 'BE maximal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 99% and 101%	1004.
TE/BE at 'BE Minimal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 20% and 25%	257,
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>1/3 HBB2; AMS_0101- LT/BDEM>1/3	Between 42 and 44%	443,
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>2/3 HBB2; AMS_0101- LT/BDEM>2/3	Between 72 and 74%	741,
Both temperature sensor of TM1	SLG1; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature $0^{\circ}$ C to $40^{\circ}$ C	32°C
Both temperature sensor of TM2	SLG1; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	3200
Both temperature sensor of TM3	SLG1; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	31.500
Both temperature sensor of TM4	SLG2; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	32°-
Both temperature sensor of TM5	SLG2; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	3,00
Both temperature sensor of TM6	SLG2; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	3200



(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4,799

Type of Locomotive: WAP-7/WAG-9HC

Page: 9 of 27

#### 3.4 Functional test in simulation mode

Conduct the following functional tests in simulation mode as per Para 5.5 of document no.3EHX 610 281. through the Diagnostic tool/laptop:

Test Function	Result desired in sequence	Result obtained
Emergency shutdown through emergency stop switch 244	VCB must open. Panto must lower.	chercelus
Shut Down through cab activation switch to OFF position	VCB must open. Panto must lower.	cheetedou
Converter and filter contactor operation with both Power Converters during Start Up.	FB contactor 8.41 is closed.  By moving reverser handle:  Converter pre-charging contactor 12.3 must close after few seconds.  Converter contactor 12.4 must close.  Converter re-charging contactor 12.3 must opens.  By increasing TE/BE throttle:  FB contactor 8.41 must open.  FB contactor 8.2 must close.  FB contactor 8.1 must close.	chekalos
Converter and filter contacto operation with both Powe Converters during Shut Down.		o Cheekeed on

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC Page : 10 of 27

Contactor filter adaptation by isolating any bogie	Isolate any one bogie through bogie cut out switch. Wait for self-test of the loco.  • Check that FB contactor 8.1 is open.  • Check that FB contactor 8.2 is open.	o exercedou
	After raising panto, closing VCB, and setting TE/BE  • FB contactor 8.1 closes.  • FB contactor 8.2 remains open.	CALIF
Test earth fault detection battery circuit positive & negative	By connecting wire 2050 to earth, create earth fault negative potential.  • message for earth fault  • By connecting wire 2095 to earth, create earth fault positive potential.  • message for earth fault	- Eletadou
Test fire system. Create a smoke in the machine room near the FDU. Watch for activation of alarm.	<ul> <li>When smoke sensor-1 gets activated then</li> <li>Alarm triggers and fault message priority 2 appears on screen.</li> <li>When both smoke sensor</li> <li>1+2 gets activated then</li> <li>A fault message priority</li> <li>1 appears on screen and lamp LSF1 glow.</li> <li>Start/Running interlock occurs and TE/BE becomes to 0.</li> </ul>	e Rocked Oi
Γime, date & loco number	Ensure correct date time and Loco number	Ou



(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

4.0 Sensor Test and Converter Test

Page: 11 of 27

#### 4.1 Test wiring main Transformer Circuits

Apply  $198V_p/140V_{RMS}$  to the primary winding of the transformer (at 1u; wire no. 2 at surge arrestor and at 1v; wire no. 100 at earthing choke). Measure the output voltage and compare the phase of the following of the transformers.

Output Winding nos.	Description of winding.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
2U <sub>1</sub> & 2V <sub>1</sub>	For line converter bogie 1 between cable 801A- 804A	10.05V <sub>p</sub> and same polarity	10.0549	OF
2U <sub>4</sub> & 2V <sub>4</sub>	For line converter bogie 1 between cable 811A- 814A	10.05V <sub>p</sub> and same polarity	10.0510	DVL
2U <sub>2</sub> & 2V <sub>2</sub>	For line converter bogie 2 between cable 801B- 804B	10.05V <sub>p</sub> and same polarity	10.0400	OK
2U <sub>3</sub> & 2V <sub>3</sub>	For line converter bogie 2 between cable 811B- 814B	10.05V <sub>p</sub> and same polarity	10.054	OK
2U <sub>B</sub> & 2V <sub>B</sub>	For aux. converter 1 between cable 1103- 1117 (in HB1) For Aux converter 2 between cable 1103- 1117 (in HB2)	7.9V <sub>p</sub> , 5.6V <sub>RMS</sub> and same polarity.	7.900 5.502ms	QL.
2U <sub>F</sub> & 2V <sub>F</sub>	For harmonic filter between cable 4-12 (in FB)	9.12V <sub>p</sub> , 6.45V <sub>RMS</sub> and same polarity.	9-10-19 6.44-2ms	or

#### 4.2 Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)

Apply  $141V_p$  /  $100V_{RMS}$  to input of the auxiliary transformer at cable no 1203 –1117 and measure the output at

Description of wire no.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
Cable no. 1218 - 1200	58.7V <sub>p</sub> , 41.5V <sub>RMS</sub> and opposite polarity.	58.7VP 41.5URAS)	OK
Cable no. 1218 – 6500	15.5V <sub>p</sub> , 11.0V <sub>RMS</sub> and opposite polarity.	15-578	Ne
		11.00000	

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 12 of 27

#### 4.3 Primary Voltage Transformer

Apply  $250V_{eff}/350V_p$  by variac to roof wire 1 and any wire 0 and measure the magnitude and polarity of the output of the primary voltage transformer for both bogies as per the procedure specified and suggested by the traction converter manufacturer. Primary voltage measurement converters (Pos. 224.1/\*) & catenary voltmeter (Pos. 74/\*)

This test is to be done for each converter.

Activate cab in driving mode and supply  $200V_{RMS}$  through variac to wire no 1501 and 1502. Monitor the following parameters through Diagnostic tool and in catenary voltmeter.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	25kV	250%	25XV	2501
SLG2_G 87-XUPrim	25 kV	250%	254V	2507,

Decrease the supply voltage below 140  $V_{RMS}$ . VCB must open at this voltage. In this case the readings in Diagnostic Tool and catenary voltmeter will be as follows.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	17kV	170%	1744	170%
SLG2_G 87-XUPrim	17 kV	170%	17KV	1707.

Reactivate VCB to on by increasing this voltage to 175% (17.5 kV).

Increase the supply to 240  $V_{RMS}$  through variac. VCB must open at this voltage, In this case the readings in **diagnostic tool** and catenary voltmeter will be as follows:

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	30kV	300%	BOKN	300%-
SLG2_G 87-XUPrim	30 kV	300%	BOKN	305%.

Reactivate VCB to on by decreasing this voltage to 290% (29 kV).



(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 13 of 27

#### 4.4 Minimum voltage relay (Pos. 86)

Functionality test:

Minimum voltage relay (Pos. 86) must be adjus	ted to approx 68%
Activate loco in cooling mode. Check Power supply of 48V to minimum voltage relay. Disconnect primary voltage transformer (wire no. 1511 and 1512) from load resistor (Pos. 74.2) and connect variac to wire no. 1501 and 1502. Supply 200V <sub>RMS</sub> through variac. In this case; <i>Minimum voltage relay (Pos. 86) picks up</i>	L(Yes/No)
Try to activate the cab in driving mode: Contactor 218 do not close; the control electronics is not be working.	(Yes/No)
Turn off the variac : Contactor 218 closes; the control electronics is be working	(Yes/No)
Test Under Voltage Protection;	
Activate the cab in cooling mode; Raise panto; Supply 200V <sub>RMS</sub> through variac to wire no. 1501 & 1502; Close the VCB; Interrupt the supply voltage The VCB goes off after 2 second time delay.	(Yes/No)
Again supply $200V_{RMS}$ through variac to wire no. 1501 & 1502; Decrease the supply voltage below $140V_{RMS} \pm 4V$ ; Fine tune the minimum voltage relay so that VCB opens.	(Yes/No)

#### 4.5 Maximum current relay (Pos. 78)

Disconnect wire 1521 & 1522 of primary current transformer; Connect variac to wire 1521
&1522 (including the resistor at Pos. 6.11); Put loco in simulation for driving mode; Open R <sub>3</sub> - R <sub>2</sub>
on contact 136.3; Close VCB; supply 3.6 $A_{RMS}$ at the open wire 1521; Tune the drum of the
maximum current relay Pos. 78 for correct over current value;

maximum current relay Pos. 78 for correct over current value	
VCB opens with Priority 1 fault message on	L(Yes/No)
display.	
Keep contact $R_3 - R_4$ of 136.3 closed; Close VCB; Tune the r	esistor 78.1 for the current of 7.0A <sub>RMS</sub>
/9.9A <sub>p</sub> at the open wire 1521;	
VCB opens with Priority 1 fault message on	(Yes/No)
display.	
and the state of t	

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4,799

Type of Locomotive: WAP-7/WAG-9HC

Page: 14 of 27

#### 4.6 Test current sensors

Name of the sensor	Description of the test	Prescribed value	Set/Measured value
Primary return current sensor (Test-1,Pos.6.2/1 & 6.2/2)	Activate cab in driving mode supply 10A. Measure the current through diagnostic tool or measuring print.	(Variation allowed is ± 10%)	_
Primary return current	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		
sensor (Test-2, Pos.6.2/1 & 6.2/2)	Supply 297mA <sub>DC</sub> to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		2-88mB
Auxiliary winding current sensor (Pos. 42.3/1 & 42.3/2)	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AC/1or 2 pin no. 7(+) & 8(-)		
	Supply 333mA <sub>DC</sub> to the test winding of sensor through connector 415.AC/1 or 2 pin no. 7(+) & 8(-)		33.80mg
Harmonic filter current sensors (Pos.8.5/1 &8.5/2)	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AE/1or 2 pin no. 7(+) & 8(-)		
	Supply 342mA <sub>DC</sub> to the test winding of sensor through connector 415.AE/1or 2 pin no. 7(+) & 8(-)		347 mas
Hotel load current sensors (Pos. 33/1 &	Switch on hotel load. Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)	NA	NA
33/2)	Supply 1242mA <sub>DC</sub> to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)	NA	NA



#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4,799

Type of Locomotive: WAP-7/WAG-9HC

4.7 Test DC Link Voltage Sensors (Pos 15.6/\*)

Page: 15 of 27

This test is to be done by the commissioning engineer of the firm if required.

#### 4.8 Verification of Converter Protection Circuits (Hardware limits) -

This test is to be done as per para 6.17 of the document no. 3EHX 610 282 for both the converters.

Protection circuits	Limit on which shutdown should take place	Measured limit	
Current sensors (Pos 18.2/1, 18.2/2,	Increase the current quickly in	For 18.2/1=	C
18.2/3, 18.4/4, 18.5/1, 18.5/2,	the test winding of the current	For 18.2/2=	
18.5/3)	sensors, VCB will off at 2.52A	For 18.2/3=	
for Power Converter 1	with priority 1 fault for each	For 18.4/4=	
	sensor.	For 18.5/1=	. 3
		For 18.5/2=	
		For 18.5/3=	
Current sensors (Pos 18.2/1, 18.2/2,	Increase the current quickly in	For 18.2/1=	G
18.2/3, 18.4/4, 18.5/1, 18.5/2,	the test winding of the current	For 8.2/2=	- 1
18.5/3)	sensors, VCB will off at 2.52A	For 18.2/3=	
for Power Converter 2	with priority 1 fault for each	For 18.4/4=	1
	sensor.	For 18.5/1=	
		For 18.5/2=	-
		For 18.5/3=	
Films and City I. D.			,
Fibre optic failure In Power Converter1	Remove one of the orange		
Converter	fibre optic plugs on traction	OK	
	converter. VCB should trip		= <u>(4)</u>
Fibre optic failure In Power	Remove one of the orange		
Converter2	fibre optic plugs on traction	OK	
	converter. VCB should trip		

#### 4.9 Sequence of BUR contactors

The sequence of operation of BUR contactors for 'ALL BUR OK' BUR 1 out BUR 2 out and BUR 3 out condition has to be verified by putting the Loco in driving mode (VCB should not be closed) and isolating the BURs one by one. In these condition following will be the contactor sequence.

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	Close	Open	Close	Open	Close	Open	Close	Close	Open
BUR1 off	Close	Open	Close	Close	Open	Close	Open	Open	Close
BUR2 off	Open	Open	Close	Close	Close	Close	Open	Open	Close
BUR3 off	Open	Close	Open	Close	Close	Close	Open	Open	Close

A

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 16 of 27

#### Monitored contactor sequence

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	close	open	close	open	cliss	open	clos	closs	open
BUR1 off	close	open	closer	log	open	cless	open	open	008
BUR2 off	Open	ореч	cl08	clos	clos	class	open	open	608
BUR3 off	o, ben	close	open	cl088	close	Close	Open	open	cl08

#### 5.0 Commissioning with High Voltage

#### 5.1 Check List

Items to be checked	Yes/No
Fibre optic cables connected correctly.	703
No rubbish in machine room, on the roof, under the loco.	(A)
All the electronic Sub-D and connectors connected	Yes
All the MCBs of the HB1 & HB2 open.	Yey
All the three fuses 40/* of the auxiliary converters	Yes
The fuse of the 415/110V auxiliary circuit (in HB1) open.	Yey
Roof to roof earthing and roof to cab earthing done	Yes
Fixing, connection and earthing in the surge arrestor done correctly.	Yes
Connection in all the traction motors done correctly.	Kes .
All the bogie body connection and earthing connection done correctly.	Yey
Pulse generator (Pos. 94.1) connection done correctly.	Yes
All the oil cocks of the gate valve of the transformer in open condition.	Yes
All covers on Aux & Power converters, Filter block, HB1, HB2 fitted	Yes
KABA key interlocking system.	les

#### 5.2 Safety test main circuit breaker

Prepare to switch off the catenary supply during the first charging of the locomotive in case of any unexpected behavior of the electrical component of the loco. Charge the loco for the first time by closing BLDJ switch. The VCB will trip after certain time as no oil/coolant pumps are running yet.

Perform the following safety test of main circuit breaker through both the cabs of the locomotive.

भी.एल.डब्स् P. L. W

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page : 17 of 27

Name of the test	Description of the test	Expected result	Monitored result
Emergency stop in cooling mode	Raise panto in cooling mode. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	choird on
Emergency stop in driving mode	Raise panto in driving mode in. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be	cfocked ou
Under voltage protection in cooling mode	Raise panto in cooling mode. Close the VCB. Switch off the supply of catenary by isolator	applied. VCB must open.	cfoekeda
Under voltage protection in driving mode	Raise panto in driving mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open with diagnostic message that catenary voltage out of limits	chaexadoa
Shut down in cooling mode.	Raise panto in cooling mode. Close the VCB. Bring the BL- key in O position.	VCB must open. Panto must lower.	c flexical a
Shutdown in driving mode	Raise panto in driving mode. Close the VCB. Bring the BL-key in O position.	VCB must open. Panto must lower.	Abeked of
Interlocking pantograph- VCB in cooling mode	Raise panto in cooling mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	efected va
Interlocking pantograph- VCB in driving mode	Raise panto in driving mode. Close the VCB. Lower the pantograph by ZPT		cfoeksela

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 18 of 27

#### 5.3 Auxiliary Converter Commissioning

Switch on the high voltage supply and set up the loco in driving mode. Raise the panto. Close the VCB. Check that there is no earth fault in the auxiliary circuit, Switch off the VCB. Lower the panto. Create the earth fault in auxiliary circuit by making connection between wire no 1117(in HB2 cubicle) and earth. After 3 minutes a diagnostic message will come that "Earth fault auxiliary circuit."

#### 5.3.1 Running test of 3 ph. auxiliary equipments

Switch on the 3 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured continuous phase current	Measured starting phase current
Oil pump transformer 1	9.8 amps	8,2	9-0
Oil pump transformer 2	9.8 amps	7.9	8-4
Coolant pump converter 1	19.6 amps	5.8	6.4
Coolant pump converter 2	19.6 amps	5.8	6.3
Oil cooling blower unit 1	40.0 amps	46.8	83.0
Oil cooling blower unit 2	40.0 amps	47.5	84.0
Traction motor blower 1	34.0 amps	34.9	99.8
Traction motor blower 2	34.0 amps	34.4	116.8
Sc. Blower to Traction motor blower 1	6.0 amps	4.5	5.2
Sc. Blower to Traction motor blower 1	6.0 amps	4.2	5.7
Compressor 1	25 amps at 0 kg/cm <sup>2</sup> 40 amps at 10 kg/cm <sup>2</sup>	26.7	39.1
Compressor 2	25 amps at 0 kg/ cm <sup>2</sup> 40 amps at 10 kg/ cm <sup>2</sup>	26.4	38,5

पी.एल.डब्ल्यू P. I. W

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 19 of 27

#### **5.3.2** Performance of Auxiliary Converters

Measure the performance of the auxiliary converters through software and record it. BUR1 (Condition: Switch off all the load of BUR 1)- to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value	Monitored value	Value under Limit (Yes/No)
BUR1 7303 XUUN	Input voltage to BUR1	75% (10%=125V)	1005V	Yes
BUR1 7303 XUUZ1	DC link voltage of BUR1	60% (10%=100V)	636V	Yes
BUR1 7303 XUIZ1	DC link current of BUR1	0% (10%=50A)	1 Amp	Yey

BUR2 (Condition: Switch off all the load of BUR 2, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value by the firm	Monitored value	Value under Limit (Yes/No)
BUR2 7303-XUUN	Input voltage to BUR2	75% (10%=125V)	10100	Yes
BUR2 7303-XUUZ1	DC link voltage of BUR2	60% (10%=100V)	6374	705
BUR2 7303-XUIZ 1	DC link current of BUR2	1% (10%=50A)*	ducy 2	Yes
BUR2 7303-XUILG	Current battery charger of BUR2	3% (10%=100A)*	21 Amb	Yes
BUR2 7303-XUIB1	Current battery of BUR2	1.5%(10%=100A)*	11 Bod	Yes
BUR2 7303 –XUUB	Voltage battery of BUR2	110%(10%=10V)	110 4	. Y-

<sup>\*</sup> Readings are dependent upon charging condition of the battery.

BUR3 (Condition: Switch off all the load of BUR 3, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed set value by the firm	Monitored value	Value under limit (Yes/No)
BUR3 7303-XUUN	Input voltage to BUR3	75% (10%=125V	1012V	Yey
BUR3 7303- XUUZ1	DC link voltage of BUR3	60% (10%=100V)	637V	Yes
BUR3 7303-XUIZ 1	DC link current of BUR3	1% (10%=50A)*	7Anp	Yes
BUR3 7303-XUILG	Current battery charger of BUR 3	3% (10%=100A)*	2-2 Bort	They
BUR3 7303-XUIB1	Current battery of BUR 3	1.5%(10%=100A)*	12-Bong	Yey
BUR3 7303-XUUB	Voltage battery of BUR 3	110%(10%=10V)	110~	Yey

<sup>\*</sup> Readings are dependent upon charging condition of the battery.

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 20 of 27

#### 5.3.3 Performance of BURs when one BUR goes out

When any one BUR goes out then rest of the two BURs should take the load of all the auxiliaries at ventilation level 3 of the locomotive.

Condition of BURs	Loads on BUR1	Loads in BUR2	Loads in BUR3
All BURs OK	Oil Cooling unit 1&2	TM blower1&2, TFP oil pump 1&2, SR coolant pump 1&2.	Compressor 1&2, Battery charger and TM Scavenger blower 1&2
BUR 1 out		Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2,TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 2 out	Oil Cooling unit 1&2, TM blower 1&2, TM Scavenger blower 1&2		Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 3 out	Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.	

#### 5.4 Auxiliary circuit 415/110

For checking earth fault detection, make a connection between wire no. 1218 and vehicle body. On switching on VCB, Earth fault relay 89.5 must pick up and after 3 minutes a message will come in the Diagnostic display that Earth Fault 415/110V Circuit

Switch on the 1 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them

Name of the auxiliary machine	Typical phase current	Measured phase current	Measured starting current
Machine room blower 1	15.0 amps*	4.2	11.2
Machine room blower 2	15.0 amps*	4.3	9.2
Sc. Blower to MR blower 1	1.3 amps	1.1	1.9
Sc. Blower to MR blower 2	1.3 amps	1.1	2.0
Ventilator cab heater 1	1.1 amps	1.3	1.3
Ventilator cab heater 2	1.1 amps	1.3	1.4
Cab heater 1	4.8 amps	4.7	4.8
Cab heater 2	4.8 amps	4.7	4.6

<sup>\*</sup> For indigenous MR blowers.



Signature of the JE/SSE/Loco Testing

Columb

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 21 of 27

#### 5.5 Hotel load circuit (Not applicable for WAG-9HC)

For WAP-7 locomotive with Hotel load converter refer to Annexure-HLC

#### 5.6 Traction Converter Commissioning

#### This test is carried out in association with Firm.

Traction converter commissioning is being done one at a time. For testing Converter 1, switch off the traction converter 2 by switch bogie cut out switch 154. For testing Converter 2, switch off the traction converter 2 by switch bogie cut out switch 154. Isolate the harmonic filter also by switch 160. Start up the loco by one converter. Follow the functionality tests.

#### For Converter 1

Test Function	Results desired	Result obtained
Measurement of charging and precharging and charging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	choeped se
Measurement of discharging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Charled on
Earth fault detection on positive potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	charged an
Earth fault detection on negative potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	c Rocked on
Earth fault detection on AC part of the traction circuit of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	c Loegoel sa
Pulsing of line converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cloexalon
Pulsing of drive converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chocked "On

(Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 22 of 27

#### For Converter 2

Test Function	Results desired in sequence	Result obtained
charging and pre- charging and charging	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeteel va
discharging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeredon
positive potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chekael va
	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/v	Chekeel ou
Earth fault detection on AC part of the traction circuit of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeted on
Pulsing of line converter of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	C feeked un
Pulsing of drive converter of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	choexad on
2010112-		



Doc.No.F/ECS/01 (Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 23 of 27

#### 5.7 Test protective shutdown SR

Start up the loco with both the converter. Raise panto. Close VCB.  Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 1Check that converter 1 electronics produces a protective shut down.  • VCB goes off • Priority 1 fault mesg. on DDU	p efockael va
appears	
Start up the loco with both the converter. Raise panto. Close VCB.  Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 2. Check that converter 2 electronics produces a protective shut down.  • VCB goes off • Priority 1 fault mesg. on diagnostic display appears	e Rocked on
	converter. Raise panto. Close VCB.  Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 1Check that converter 1 electronics produces a protective shut down.  • VCB goes off  • Priority 1 fault mesg. on DDU appears  Disturbance in Converter 1  Start up the loco with both the converter. Raise panto. Close VCB.  Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 2. Check that converter 2 electronics produces a protective shut down.  • VCB goes off  • Priority 1 fault mesg. on diagnostic

#### 5.8 Test Harmonic Filter

Switch on the filter by switch 160

Test Function	Results desired in sequence	Result obtained
Measurement of filter currents	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Apply a small value of TE/BE by moving the throttle.  • FB contactor 8.41 must open.	o expersed on

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 24 of 27

Test traction motor	Earth fault in harmonic filter circuit  Traction converter manufacturer	entropy of the second
Test earth fault detection harmonic filter circuit.	Make a connection between wire no. 12 and vehicle body. Start up the loco. Close VCB.  • Earth fault relay 89.6 must pick up.  • Diagnostic message comes that -	e cheeked ou
	<ul> <li>FB contactor 8.2 must close.</li> <li>FB contactor 8.1 must close</li> <li>Check the filter current in diagnostic laptop</li> <li>Bring the TE/BE throttle to O</li> <li>Switch off the VCB</li> <li>FB contactor 8.1must open.</li> <li>FB discharging contactor 8.41 must close</li> <li>Check the filter current in diagnostic laptop</li> </ul>	e Locked on

#### 5.9 Test important components of the locomotive

Items to be tested	Description of the test	Monitored value/remarks
Speedometer	VCU converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	choexed re
Time delay module of MR blower	The time after which the starting capacitor for MR blower should go off the circuit should be set to 10-12 seconds	challed on
Ni-Cd battery voltage	At full charge, the battery voltage should be 110V DC.	charked on
Flasher light	From both cab flasher light should blink at least 65 times in one minute.	chekedoa
Head light	Head light should glow from both cabs by operating ZLPRD. Dimmer operation of headlight should also occur by operating the switch ZLPRD.	chaepeel ou



Doc.No.F/ECS/01 (Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 25 of 27

Marker light	Both front and tail marker light should glow from both the cabs	chocked on
Cab Light	Cab light should glow in both the cabs by operating the switch ZLC	chelted on
Spot lights	Both Drivers and Asst. Drivers Spot light should glow in both cabs by operating ZLDD	charten as
Instrument lights	Instrument light should glow from both cab by operating the switch ZLI	choeked &
Illuminated Push button	All illuminated push buttons should glow during the operation	cfackoelou
Contact pressure of the high rating contactors	The contact pressure of FB contactors (8.1, 8.2) is to be measured  Criteria:  The minimum contact pressure is 54 to 66  Newton.	For contactor 8.1: For contactor 8.2:
Crew Fan	All crew fans should work properly when VCB of the loco is switched on. The airflow from each cab fan is to be measured.  Criteria:  The minimum flow of air of cab fan should be 25 m³/minute	Cab 1 LHS: Cab 1 RHS: Cab 2 LHS: Cab 2 RHS:

#### 6.0 Running Trial of the locomotive

SN	Description of the items to be seen during trail run	Action which should take place	Remarks	
1	Cab activation in driving mode	No fault message should appear on the diagnostic panel of the loco.	locadou	
130	Loco charging	Loco to be charged and all auxiliaries should run.  No fault message to appear on the diagnostic panel of the loco. Raise MR pressure to 10 Kg/cm <sup>2</sup> , BP to 5 Kg/cm <sup>2</sup> , FP to 6 Kg/cm <sup>2</sup> .	facted in	
3.	Check function of Emergency push stop.	This switch is active only in activated cab. By pushing this switch VCB should open & pantograph should be lowered.	factalog	
4.	Check function of BPCS.	<ul> <li>Beyond 5 kmph, press BPCS, the speed of loco should be constant.</li> <li>BPCS action should be cancelled by moving TE/BE throttle, by dropping BP below 4.75 Kg/cm², by pressing BPCS again.</li> </ul>	LOCKER VO	
5.	Check train parting operation of the Locomotive.	Operate the emergency cock to drop the BP Pressure LSAF should glow.	facted on	

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 26 of 27

6.	Check vigilance	Set the speed more than 1.5 kmph and ensure that
	operation of the	brakes are released i.e. BC < 1 Kg/cm <sup>2</sup> .
	locomotive	For 60 seconds do not press vigilance foot switch or
A>		sanding foots switch or TE/BE throttle or BPVG
		switch then
		Buzzer should start buzzing.
		LSVW should glow continuously.
	gara" i i	Do not acknowledge the alarm through BPVG or
		vigilance foot switch further for 8 seconds then:-
	a la	Emergency brake should be applied automatically.
		VCB should be switched off.
	in a fi	Resetting of this penalty brake is possible only after
	State of the state	180 seconds by bringing TE/BE throttle to 0 and
	7	acknowledge BPVR and press & release vigilance
		foot switch.
7.	Check start/run interlock	• At low pressure of MR (< 5.6 Kg/cm <sup>2</sup> ).
		• With park brake in applied condition.
		• With direct loco brake applied (BP< 4.75Kg/cm <sup>2</sup> ).
		• With automatic train brake applied (BP<4.75Kg/cm <sup>2</sup> ).
	The state of the s	• With emergency cock (BP < 4.75 Kg/cm <sup>2</sup> ).
8.	Check traction interlock	Switch of the brake electronics. The
	- 12W 112	Tractive /Braking effort should ramp down, VCB
		should open and BP reduces rapidly.
9.	Check regenerative	Bring the TE/BE throttle to BE side. Loco speed
	braking.	should start reducing.
10.	Check for BUR	In the event of failure of one BUR, rest of the two
	redundancy test at	BURs can take the load of all the auxiliaries. For this
	ventilation level 1 & 3 of	switch off one BUR.
	loco operation	Auxiliaries should be catered by rest of two BURs.
		Switch off the 2 BURs; loco should trip in this case.
11.	Check the power	Create disturbance in power converter by switching
	converter	off the electronics. VCB should open and converter
	isolation test	should get isolated and traction is possible with
	5	another power converter.



#### (Ref: WI/ECS/10)

#### PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41799

Type of Locomotive: WAP-7/WAG-9HC

Page: 27 of 27

## 7.0 Final check list to be verified at the time of Loco dispatch

Condition /Operations of the following items are to be checked:

SN	Item	Cab-1	Cab-2	Remarks
1	Head lights	Ox	OK O	\
2	Marker Red	UR	OK	
3	Marker White	OV.	OK	
4	Cab Lights	00	OK	
5	·Dr Spot Light	DIR	OK	Alexal worken
6	Asst Dr Spot Light	DV.	26	o merces accessed
7	Flasher Light	OK	2K	
8	Instrument Lights	OR	OK.	
9	Corridor Light	0 K	ચેડ	
10	Cab Fans	0 K	≥K	. 8
11	Cab Heater/Blowers	OU	DK.	
12	All Cab Signal Lamps Panel 'A'	DIL	2K	

# Status of RDSO modifications

LOCO NO: 41799

Sn	Modification No. Description Remarks					
1		Description	Remarks			
1.	RDSO/2008/EL/MS/0357 Rev.'0' Dt 20.02.08	Modification in control circuit of Flasher Light and Head Light of three phase electric locomotives.	Ok/Not Ok			
2.	RDSO/2009/EL/MS/0377 Rev.'0' Dt 22.04.09	Modification to voltage sensing circuit in electric locomotives.	Ok/Not Ok			
3.	RDSO/2010/EL/MS/0390 Rev.'0' Dt 31.12.10	Paralleling of interlocks of EP contactors and Relays of three phase locomotives to improve reliability.	Øk/Not Ok			
4.	RDSO/2011/EL/MS/0399 Rev.'0' Dt 08.08.11	Removal of interlocks of control circuit contactors no. 126 from MCPA circuit.	OK/Not Ok			
5.	RDSO/2011/EL/MS/0400 Rev.'0' Dt 10.08.11	Modification sheet for shifting the termination of \$GKW, 1.8 KV, 70 sq mm cables and 2x2.5 sq mm cables housed in lower portion of HB2 panel and provision of Synthetic resin bonded glass fiber sheet for three phase locomotives.	Ok/Not Ok			
6.	RDSO/2011/EL/MS/0401 Rev.'0' Dt 10.08.11	Modification sheet for relaying of cables in HB-2 panel of three phase locomotives to avoid fire hazards.	Ok/Not Ok			
7.	RDSO/2011/EL/MS/0403 Rev.'0' Dt 30.11.11	Auto switching of machine room/corridor lights to avoid draining of batteries in three phase electric locomotives.	Øk/Not Ok			
8.	RDSO/2012/EL/MS/0408 Rev.'0'	Modification of terminal connection of heater cum blower assembly.	Qk/Not Ok			
9.	RDSO/2012/EL/MS/0411 Rev.'1' dated 02.11.12	Modification sheet to avoid simultaneous switching ON of White and Red marker light in three phase electric locomotives.	Qk/Not Ok			
10	RDSO/2012/EL/MS/0413 Rev.'1' Dt 25.04.16	Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives to improve reliability.	Ok/Not Ok			
11	RDSO/2012/EL/MS/0419 Rev.'0' Dt 20.12.12	Modification sheet to provide rubber sealing gasket in Master Controller of three phase locomotives.	ØR/Not Ok			
12	RDSO/2013/EL/MS/0420 Rev.'0' Dt 23.01.13	Modification sheet to provide mechanical locking arrangement in Primary Over Current Relay of three phase locomotives.	Ok/Not Ok			
13	RDSO/2013/EL/MS/0425 Rev.'0' Dt 22.05.13	Modification sheet for improving illumination of head light in dimmer mode in three phase electric locomotives.	Øk/Not Ok			
14	RDSO/2013/EL/MS/0426 Rev.'0' Dt 18.07.13	Modification sheet of Bogie isolation rotary switch in three phase electric locomotives.	Ok/Not Ok			
15	RDSO/2013/EL/MS/0427 Rev.'0' Dt 23.10.13	Modification sheet for MCP control in three phase electric locomotives.	Ok/Not Ok			
16	RDSO/2013/EL/MS/0428 Rev.'0' Dt 10.12.13	harmonic filter and hotel load along with its resistors in three phase electric locomotives.	Ok/Not Ok			
17	RDSO/2014/EL/MS/0432 Rev.'0' Dt 12.03.14	Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.	Ok/Not Ok			
18	RDSO/2017/EL/MS/0464 Rev.'0' Dt 25.09.17	Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.	Øk/Not Ok			
19	RDSO/2017/EL/MS/0467 Rev.'0' Dt 07.12.17	Modification in blocking diodes to improve reliability in three phase electric locomotives.	Øt√Not Ok			
20	RDSO/2018/EL/MS/0475 Rev.'0'	Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.	Ok/Not Ok			

Signature of JE/SSE/TRS

's Projec

#### PLW/PATIALA

Loco No.: 41799

#### PNEUMATEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

S.N	Parameters	Reference	Value	Result
1.0	Auxillary Air supply system (Pantograph & VCB)			200
1.1 6.0	Ensure, Air is completely vented from pantograph Reservoir (Ensure Pantograph gauge reading is Zero)		0	0
1.2	Turn On BL Key. Now MCPA starts.  Record pressure Build up time (8.5kg/cm2)		60 sec. (Max.)	58 Sec
1.3	Auxiliary compressor safety Valve 23F setting	CLW's check sheet no. F60.812 Version 2	8.5±0.25kg/cm2	8.5 Kg/cm2
1.4 5.14 1.0	Check VCB Pressure Switch Setting	CLW's check sheet no. F60.812 Version 2	Opens 4.5±0.15 kg/cm2 closes 5.5±0.15 kg/cm2	4.50 Kg/cm2 5.55 kg/cm2
1.5	Set pantograph Selector Switch is in Auto, Open pan-1&2 Iso	olating Cocks & KABA co	ock by Key (KABA Key)	LU TE
1.6	Set Cab-1 Pan UP in Panel A.		Observed Pan-2 Rises.	OK Sec
1.7	Close Pan-2 isolating Cock Open Pan -2 isolating Cock		Panto-2 Falls Down Panto-2 Rises	OK STAGE 2
1.8	Record Pantograph Rise time	District and Mosenie and Artist	06 to 10 seconds	9 Sec
1.9	Record Pantograph Lowering Time		06 to 10 seconds	8 Sec
1.10	Pantograph line air leakage		0.7 kg/cm2 in 5 Min.	0.6 kg/cm2 in 5 Min.
2.0	Main Air Supply System			· HAMING
2,1,	Ensure, Air is completely vented from locomotive. Drain out all the reservoirs by opening the drain cocks and then closed drain cocks. MR air pressure build up time by each compressor from 0 to 10 kg/cm2.  i) with 1750 LPM compressor  ii) with 1450 LPM compressor	Theoretical calculation and test performed by Railways.	i) 7 Min. Max. ii) 8.5 Min. Max.	6 min. & 50 sec.
2.2	Drain air below MR 8 kg/cm2 to start both the compressors.		Check Starting of both compressors	ok <sub>sec</sub>
2.3	Drain air from main reservoir up to 7 kg/cm2. Start compressors, Check pressure build time of individual compressor from 8 kg/cm2 to 9 kg/cm2	100 H. 02 JANE 1102	30 Sec. (Max)	CP1-26 Sec CP2-27 Sec
2.4	Check Low MR Pressure Switch Setting (37)	D&M test spec. MM3882 & MM3946	Closes at 6.40±0.15 kg/cm2 Opens at 5.60±0.15kg/cm2	6.40 Kg/cm2 5.65 Kg/cm2

STATE

#### PLW/PATIALA

120

Loco No.: 41799

#### PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

2.5	Check compressor Pressure Switch RGCP setting (35)	D&M test spec.	Closes at 10±0.20	10.1
		MM3882 & MM3946	kg/cm2	Kg/cm2
9.5		A CONTRACTOR OF THE CONTRACTOR	Opens at 8±0.20	0,
	A Tar		kg/cm2	8 Kg/cm2
2,6	Run both the compressors Record Pressure build up time	Trial results	3.5 Minutes Max	3.30
5,3		Tomas - com		minute
2.7	Check unloader valve operation time		Approx. 12 Sec.	11 sec
2.8	Check Auto Drain Valve functioning (124 & 87)		Operates when Compressor starts	
2.9	Check CP-I delivery safety valve setting (10/1). Run CP Direct by BLCP.	D&M test spec. MM3882 & MM3946	11.50±0.35kg/cm2	11.50 Kg/cm2
2.10	Check CP-2 delivery safety valve setting (10/2). Run CP direct by BLCP	D&M test spec. MM3882 & MM3946	11.50±0.35kg/cm2	11.55 Kg/cm2
2.11	Switch 'OFF' the compressors and ensure that the safety valve to reset at pressure 12 kg/cm2 less than opening pressure.	D&M test spec. MM3882 & MM3946	disertation of a second	: :: m2
2.12	BP Pressure: Switch 'OFF' compressor, Drain MR Pressure	CLW's check sheet	5.0±0.10kg/cm2	5.00
2 <u>560</u>	by drain cock of 1" Main Reservoir, Start Compressor, and check setting pressure of Duplex Check Valve 92F.	no. F60.812 Version 2	2	43.Rg/cm2 minute
2.13	EP pressure:	CLW's check sheet	6.0±0.20kg/cm2	16.05
2:8	Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.	no. F60.812 Version 2		Kg/cm2
3.0	Air Dryer Operation		and the second	11.59 Kg/cm2
3.1	Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave	eroman entre	Tower to change	32.35
	open for Test Check Air Dryer Towers to change.		i) Every minute	%ок 2
212.3 { }			(FTIL & SIL) ii)every two minute (KBIL)	.:m2
3.2	Check Purge Air Stops from Air Dryer at Compressor stops			- Ultra
2,12				- \$/6m2 -3.30/
3.3	Check condition of humidity indicator		Blue	Blue
7.73			4500	18.060
4.0	Main Reservoir Leakage Test			Kg/gm2.
4.1	Put Auto Brake (A-9) in full service, Check MR Pressure air	D&M test spec.	Should be less than	0.5 Kg/cm
2	leakage from both cabs.	MM3882 & MM3946	1 kg/cm2 in 15 minutes	in 15 minutes
4.2	Check BP Air leakage (isolate BP charging cock-70)	D&M test spec.	0.15 kg/cm2 in 5	0.07
2i1)		MM3882 & MM3946	minutes	Kg/cm2 in 5 minutes

V MARCHIC

#### PLW/PATIALA

1.8

Loco No.: 41799

# PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

5.0	Brake Test (Au	tomatic Brake op	ke operation)		5 Agrano	
5.1	Record Brake Pip	oe & Brake Cylinder	pressure at Each Ste	p		26 397.55 26 1.5 Age
	Check proportion	nality of Auto Brake	esystem	CLW's chec	ck sheet no. F60.812	2 Version 2
						YORKS
143	Auto controller p	oosition	A STATE OF THE STA	BC (WA	AG-9 & WAG-7)Kg/c	m2
1.0		1/1/2/2/2/2/2/2/2/2/2/2/2/2/2/2/2/2/2/2				
	- 2 <sup>-2</sup> -20-1 2	BP Pressure kg/c	cm2	Value		Result
5.0						T Treyand
13					d.	The state of the s
		V.		il da suament es mil		
	Run	5±0.1	5.0 Kg/cm2	0.00	0.	.00 Kg/ cm2
	Initial	4.60±0.1	4.60 Kg/cm2	0.40±0.1	0.	40 Kg/ cm2
i,	Full service	5.4 Kg/cm2		2.50±0.1	2	.5 Kg/ cm2
	Emergency Less than 0.3 0.25 Kg/cm2		2.50±0.1	2	.5 Kg/ cm2	
.2	Record time to BF Automatic Brake Co	pressure drop to 3 ontroller handle is Full	3.5 kg/cm2, Ensure Service from Run	D&M test spec. MM3882 & MM3946	8±2 sec.	8 Sec
30	Operate Asst. Driv	ver Emergency Cock	ζ,	D&M test spec.	BP pressure falls	1 44 KET
5.5			ACE ACE OFF OF	MM3882 & MM3946	to Below 2.5 kg/cm2	ОК
4	Check brake Pipe	Pressure Switch 69	Foperates	CLW's check sheet no.	Closes at BP	4.15 Kg/cm2
				F60.812 Version 2	4.05- 4.35	V-9/4/2-
1	Far.		Total In Living	· ·	kg/cm2 Opens at BP	3.00 Kg/cm2
6					2.85- 3.15 kg/cm2	A A
5	Move Auto Brake	Controller handle fi	rom Running to	D&M test spec.	Kg/CIIIZ	
5 2 7		ing time from 0.4 kg		MM3882 & MM3946		4/90
S.0	Widay, be develope	<b>u.</b>				+7
	WAP7 - BC 2.50 ±				7.5±1.5 sec.	24
	WAG9 - BC 2.50 ±	0.1 1/			21±3 sec.	22 sec

A Spec

#### PLW/PATIALA

Loco No.: 41799

# PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

29						,		
5.6	Move Auto Brake Controller handle to full service and kg/cm2. Move Brake controller to Running position BC BC Pressure up to 0.4 kg/cm2 i.e. 95% of Max. BC deve BC release Time WAP7 WAG9	Releas loped	e time to fall	spec	3882 &	17.5±2 sec. 52±7.5	1.1	54 sec.
4-12 4-12 -164 2	Move Auto Brake Controller handle to Release, Check I at 5.5 kg/cm2 time.			sheet F60.8 Versi	12	60 to 8 Sec.	0	76 Sec
5.8	Auto Brake capacity test: The capacity of the A9 valve must confirm to certain limit in order to ensure compeleakage in the train without interfering with the autom brake.  * Allow The MR pressure to build up to maximum stipu * Close brake pipe angle cock and charge brake pipe to (Automatic brake controlling) at run position.  * Couple 7.5mm dia leak hole to the brake hose pipe of the angle cock for brake pipe.  The test shall be carried out with all the compressors in	nsation atic fur lated lin 5 kg/cr	for air actioning of mit. m2 by A otive. Open	RDSC Motiv powe Direct report MP G	ve torate t no. uide 1 July,	BP pressur should fall beld 4.0 kg/d with in Sec.	not ow cm2	4.8 Kg/cm2
5.9	Keep Auto Brake Controller (A-9) in Full Service. Press Driver Switch (PVEF)		nd paddle			BC com to '0'	es	0
6.0	Direct Brake (SA-9)							1
6.1	Apply Direct Brake in Full. Check BC pressure WAG9/WAP7		CLW's check sl no. F60.812 Ve 2		3.5±0	0.20 kg/cr	'v	3.50 Kg/cm2
5.2	Apply Direct Brake, Record Brake Cylinder charging time		D&M test spec. MM3882 & MM3946		8 sec. (Max.): 60		1	6 Sec
5.3	MN		M test spec. 13882 & MM3946		0.2.±0.1 kg/cm2		0.2	0 kg/cm2
.4	Release direct brake & BC Release time to fall BC pressure up to 0.4 kg/cm2				10 -15 Sec.		13	Sec
.0	Sanding Equipment							10.00
7.1	Check Isolating Cock-134F is in open position. Press sander paddle Switch. (To confirm EP valves Operates)			9	Sand on	Rail	ОК	S. Maria
7.2	Test Vigilance equipment : As per D&M test specification						ОК	1,5627 34

Signature of loco testing staff

Signature of SSE/Shop



#### पटियाला रेलइंजन कारखाना, पटियाला PATIALA LOCOMOTIVE WORKS, PATIALA

ELECTRIC LOCO CHECK SHEET

S. No.	NO: 41799 Rly: ER		Shed: _	MZ	<u>V</u>
3. NO.	TIEM TO BE CHECKED	Specified Value	0	bserved	l Value
1.1	Check proper Fitment of Hotel Load Converter & its output contactor.	- OK		-NA	_
1.2	Check proper Fitment of MR Blower 1 & 2, MR Scavenging Blower 1 & 2, TM Blower 1 & 2.	OK		ok	
1.3	Check proper of Fitment of oil cooling unit (OCU).	OK		OK	
1.4	Check proper Fitment of HB 1 & 2 and its respected lower part on	OK		ox	
1.5	Check proper Fitment of FB panel on its position.	OK		OK	
1.6	Check proper Fitment of assembled SB1 & SB2 with VCU1 & VCU2.	OK		OK	
1.7	Check proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 &	OK		OK	
1.8	Check proper Fitment of Traction converter 1 & 2 (SR-1 & 2).	OK		OK	
1.10	Check proper fitment, torquing & Locking of Main transformer bolt.	ОК	1	010	
1.12	Check proper fitment of compressor both side with the compressor safety wire rope.	ОК		OK	
1.13	Proper setting of the dampers as required.	OK		or	
1.14	Check proper position of Secondary Helical Springs between Bogie	OK		OK	
1.15	Check proper fitment of Body Bogie Safety Chains fitted properly.	ОК		OK	
1.16	Check proper fitment of Cow catcher.	ОК	-	OK	
1.17	Check coolant level in SR 1 & 2 Expansion Tank	ОК		ar	
1.18	Check Transformer Oil Level in both conservators Tank (Breather	OK	-	OK	
1.19	Check proper fitment of both battery box.	OK	-	OIC	
1.20	Check proper fitment of Push Pull rod its bolt torquing and safety	OK		OR	
1.21	Secondary Vertical and Lateral Clearance on leveled track at the	OIK .	CAE		C 13 2
	time of Loco Dispatch.		LP		CAB-2 LP AL
		W 10.10-11	Lii	ALI	LI
		Vertical-Std :35-60 mm	60	58 -	57 56
		Lateral Std- 45-50 mm	52	39	62 3
1.21	Buffer height: Range (1090, +15,-5) Drg No IB031-02002.	1090-1105 mm	1	L/S	R/S
			FRONT	1092	1
			REAR		
1.22	Buffer Length: Range (641 mm + 3 to 10 mm with buffer face) Drg	641 mm	100000	1095 L/S	R/S
201	No-SK.DL-3430.		PELONIE		
			FRONT	649	646
1.23	Height of Rail Guard. (114 mm + 5 mm,-12 mm).	1114	REAR	650	
	g or man duard. (114 mm + 3 mm,-12 mm).	114 mm + 5 mm,-12		L/S	R/S
		mm	FRONT	113	111
1.24	CRC Height: Pange (1005 mm to 1105 ) P. N. 1900		REAR	110	110
	CBC Height: Range (1085 mm to 1105 mm) Drg No- IB031-02002.	1085-1105 mm	FRONT:		
			REAR:	1095	5

(Signature of SSE/Elect Loco)

NAME SIN BYAM SHARMA

DATE 27/06/23

(Signature of JE/Elect Loco)

NAME SATISY CUMPR

(Signature of JE/UF)

NAME TANDISH PRAJAD DATE 27/08/2023

		PATIA	LA LOCOMOTIVE WO			
S.No.	Equipment	0.80	LOCO NO-417	A STATE OF THE STA		The second second
1	Complete Shell Assembly with piping	PL No.		nt Serial No.		1ake
2	Side Buffer Assly Both Side Cab I	29171027	The second secon	44 , 05/2023	CHAND	RA UDYOG
3	Side Buffer Assly Both Side Cab II	29130050	125- 05/23	147- 05/23	FASP	FASP
4	CBC Cab I & II	A CONTROL ADDRESS OF THE	48- 05/23	221- 04/23	FASP	FASP
5		29130037	0084- 02/23	0115- 03/23	FAS	FAS
-	Hand Brake		04/23	- 15465	MODIFIED	MECHWELL
	Set of Secondry Helical Spring	29045034 29041041	100 100 100 100 100 100 100 100 100 100	#E0:20	GB SPRIN	GS PVT LTD
7	Battery Boxes (both side)	29680013	79- 05/23	71- 05/23	BHARTI	A BRIGHT
8	Traction Bar Bogie I	100	8078	- 07/22		M
9	Traction Bar Bogie II		8051	- 07/22	/ L	(M
10	Centre Pivot Housing in Shell Bogie I side	29100057	5755	04/23	T	EW
11	Centre Pivot Housing in Shell Bogie II side	29100057	5757-	04/23		EW
12	Elastic Ring in Front in Shell Bogie I side		317-	02/23	The second second second	ADH
13	Elastic Ring in Front in Shell Bogie II side	29100010	Liste Colonia	02/23	The second of	ADH
14	Main Transformer	29731008 for WAG 9	HVE/65/05/2	3/2796 , 2023	HIGH	VOLT
15	Oil Cooling Radiator I	752. Fr. 455	2/23/2023	P0223RC0754		
16	Oil Cooling Radiator II	29470031		P0223RC0768		MOTIVE LTD
	Main Compressor I with Motor					MOTIVE LTD
	Main Compressor II with Motor	29511008	The state of the s	- 02/23	THE STATE OF THE S	IWATA
	Transformer Oil Cooling Pump I			- 02/23	ANEST	IWATA
				2,01/23	FLOW	/WELL
	Transformer Oil Cooling Pump II			7,01/23	FLOW	/WELL
	Oil Cooling Blower OCB I	29470043		AF2700, 323022700	SAINI ELECTRICAL AND ENGG WORKS	
	Oil Cooling Blower OCB II		03/23, 32303AF2		SAINI ELECTRICAL AND ENGG WORK	
	TM Blower I	29440075	02/23, AC-54230.	, CGLVLAM23208	ACC	CEL
-	TM Blower II	1 7	03/23, AC-54261	, CGLWBAM23092	ACC	CEL
	Machine Room Blower I	29440105	04/23 & AC-54433	, CGLVLAM13563	ACC	CEL
26 1	Machine Room Blower II	25 110105	04/23 & AC-54452,	CGLWBAM11069	ACC	CEL
27 N	Machine Room Scavenging Blower I	29440129	03/23, SM-23.03.45		G.T.R CO	PVT LTD
28 1	Machine Room Scavenging Blower II	25440125	03/23, SN	03/23, SM-23.03.42		PVT LTD
29 T	M Scavenging Blower Motor I	1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	05/23, ST-	23.05.107	G.T.R CO	
30 T	M Scavenging Blower Motor II	29440117	05/23, ST-	23.05.117	G.T.R CO	
31 T	raction Convertor I		ARTIPL/04/2023/17/	DESCRIPTION OF THE PROPERTY OF	- GITIN CO	, VI EID
2 T	raction Convertor II					
3 V	ehicle Control Unit I		RTIPL/04/2023/18/PROPULSIONA/2977 ATIL/03/2023/18/PROPULSIONA/2889			
	ehicle Control Unit II	29741075			BTIL	
	aux. Converter Box I (BUR 1)		ATIL/03/2023/18/PROPULSIONA/2890 2023D/10333/52A/0586, 04/23 2023D/10333/57B/0591, 04/23			
	aux. Converter Box 2 (BUR 2 + 3)					
-	xillary Control Cubical HB-1	204-1-1-		THE RESERVE OF THE PARTY OF THE	La La Adriana de la Calendaria de la Cal	
-	xillary Control Cubical HB-2	29171180 29171192		05/23, CGHB1G2350540		Light and and
			05/23 &. AALN/05/20		AUTOMETERS A	ALLIANCE LTD
_	omplete Control Cubicle SB-1	29171209	CG/SB1/23		C.G	Lapazietharsz
1 Fi	omplete Control Cubicle SB-2 · lter Cubical (FB) (COMPLETE FILTER	29171210	SB2/2023/D,		HIND RECTI	
CI	UBICLES)	29480140	FB/2023/B/	0206/481	HIND RECTII	FIERS LTD
2 Di	river Seats	29171131	03/23- 374, 40	5, 373, 333	\ \ \ \ EEE	0

NAME SHURHAM SHARMA

ROC		
QPL	T	ription P. NO.
29880014(HR), 2		
29880026 2		
2 29480103 2		29480103
29810127 8		
MIDDLE R	MIDDL	MIDDL
29731021		
2965028	2965028	Voltage Transformer 2965028
25712202		Vacuum Circuit Breaker 25712202
29810139	29810139	Insulator Roof line 29810139
29650033 1		
29700073 E		
29750052 2		
Air Brake Components	Ai	Ai
29511008 2		
29162051 1		
25513000 1		
29180016		
29180016		
29180016		
29162026		

ABS ...

SSE/ABS

## PATIALA LOCOMOTIVE WORKS, PATIALA

#### **Loco No.** 41799

#### 1. BOGIE FRAME:

BOGIE	FRAME NO	Make	PL No.	PO No. & dt.	Warranty Period
FRONT	SL-1565	ECBT	20105146	100189	As per PO/IRS conditions
REAR	SL-1550	ECBT 29105146		100189	Conditions

## 2. Hydraulic Dampers (Axle, Vertical, Yaw and Horizontal) Make: GB

#### 3. AXLES:

AXLE POSITION NO	1	2	3	4	5	6
MAKE/	PLW	PLW	PLW	PLW	PLW	PLW
S.NO	24507	24549	24523	24506	24504	24551
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

#### 4. WHEEL DISCS NO. AND TYPE

AXLE POSITION NO	1	2	3	4	5	6
GEAR END	CNC/23- 1687	CNC/23- 1662	CNC/23- 1697	CNC/23- 1695	CNC/23- 1688	CNC/23- 1690
Ultrasonic Testing	OK	OK	OK	OK	OK	OK
FREE END	CNC/23- 1686	CNC/23- 1678	CNC/23- 1699	CNC/23- 1693	CNC/23- 1677	CNC/23- 1689
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

#### 5. AXLE ROLLER BEARING (CRU) (Warranty: As per PO/IRS conditions)

	AXLE POSITION NO	1	2	3	4	5	6
Gear	MAKE	NBC	NBC	NBC	NBC	NBC	NBC
End	PO NO. & dt	02875	02875	02875	02875	02875	02875
Free	MAKE	NBC	NBC	SKF	NBC	NBC	NBC
End	PO NO. & dt	02875	02875	02898	02875	02875	02875

#### 6. WHEEL DISC PRESSING (PRESSURE IN KN): SPECIFIED 80-105 T

AXLE POSITION NO	1	2	3	4	5	6
BULL GEAR END	846	906	94T	101T	846	920
FREE END	961	957	896	97T	896	938

# ELECTRIC LOCO HISTORY SHEET (ECS)

ELECTRIC LOCO NO: 41799 RLY: ER LIST OF ITEMS FITTED BY ECS

SHED: ASN

PROPULSION SYSTEM: BTIL

	SN DESCRIPTION OF ITEM	ITEM PL NO.		ITEM SR. NO CAB-1/CAB-2	MAKE/SUPPLIER
-	LED Based Flasher Light Cab I & II		2963	3086	POWER TECH
7	Led Marker Light Cab I & II	29612925	16800/16752	16800/16752/18370/18396	ALTOS
က	Cab Heater Cab I & II	29170011	411	382	FICOS
4	Crew Fan Cab I & II	29470080	1438/1470	1438/1470/1527/1536	SHIVAM
2	Master Controller Cab I		4	498	
9	Master Controller Cab II	29860015	4	481	AAI
_	Complete Panel A Cab I & II	29178265	281A	281B	
ω	Complete Panel C Cab I & II	29170539			
0	Complete Panel D Cab I & II	29178265	281A	281B	UNIH
9	Complete Cubicle- F Panel Cab I & II	29178162	CF-2023D0590-491B	CF-2023D0590-491A	CNIH
7	11 Speed Ind. & Rec. System	29200040	4368	5040	MEDHA
12	2 12 Battery (Ni- Cd)	29680025	551		SAFTLIPIA
13	13 Set of Harnessed Cable Complete	29600420			יייייייייייייייייייייייייייייייייייייי
4	Transformer Oil Pressure Sensor (Cab-1) (Pressure Sensor Oil Circuit Transformer)	A CONTRACTOR OF THE CONTRACTOR	01/23 & 22/2850	01/23 & 22/2814	JACK ST. SCIENCE
15	15 Transformer Oil Pressure Sensor (Cab-2)	29500047	01/23 & 22/2765	01/23 & 22/2736	IROLEX
16	Transformer Oil Temperature Sensor (Cab-1) (Temperature Sensor Oil Circuit Transformer)		BG/TFP/4400-FEB-23	00-FEB-23	OFIGE OF LONG
17	Transformer Oil Temperature Sensor (Cab-2)	29500035	BG/TFP/4401-FEB-23	01-FEB-23	DG INDOO I KIES
18	Roof mounted Air Conditioner I		2071	71	
19	19 Roof mounted Air Conditioner II	29811028	2069	69	XX



#### **Loco No.** 41799

#### 7. DIAMETER AFTER PROFILE TURNING: SPECIFIED 1092 + 5 mm - 0 mm

AXLE POSITION NO	1	2	3	4	5	6
DIA IN mm GE	1092.3	1092.4	1092.3	1092.4	1092.4	1092.3
DIA IN mm FE	1092.3	1092.4	1092.3	1092.4	1092.4	1092.3
WHEEL PROFILE GAUGE (1596±0.5mm)	OK	OK	OK	OK	OK	OK

#### 8. SUSPENSION TUBE & ITS TAPER ROLLER BEARING:

AXLE POSITION	NO	1	2	3	4	5	6
S.T.	MAKE	IN	IN	IN	KPE	IN	KPE
G.E. BEARING	MAKE	SKF	SKF	SKF	SKF	SKF	SKF
F.E. BEARING	MAKE	SKF	SKF	SKF	SKF	SKF	SKF

#### 9. GEAR CASE & BACKLASH:

AXLE POSITION NO	1	2	3	4	5	6
MAKE	EEE	EEE	EEE	EEE	EEE	EEE
BACKLASH (0.254 – 0.458mm)	0.300	0.360	0.320	0.310	0.310	.380

#### 10 A/BOX TO BOGIE FRAME LATERAL CLEARANCES (SPECIFIED 15.0 to 19.0mm):

AXLE POSITION NO	1	2	3	4	5	6
RIGHT SIDE	16.71	16.48	16.68	15.31	15.71	17.31
LEFT SIDE	16.71	17.34	16.91	18.04	15.98	16.41

#### 11. TRACTION MOTOR: (Warranty: As per PO/IRS conditions)

AXLE POSITION NO	MAKE	PO No. & date	S. NO.
1	SAINI	100508	223045267
2	SAINI	100508	223045263
3	SAINI	100508	223045262
4	SAINI	100508	223045272
5	SAINI	100508	223045266
6	SAINI	100508	223045270

SSE/ Bogie Shop

As per clause no.9 of CLW Specn. CLW/ES/3/0458 & Clause No.10 of CLW SpecnCLW/ES/3/0459. [18 months after commissioning or 20 months from date of supply for single core & 18 months after commissioning or 24 months from date of supply for multi core]	SET OF HARNESSED CABLE FOR 3-PHASE ELECTRIC LOCOMOTIVES TO CLW SPECN. NO. CLW/ES/03/646 ALT-NIL WITH DMW REQUIREMENT OF HARNESSED CABLE FOR WAP-7, ALT-A1 DATED 27/11/2018.	29600418	4
COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR AS PER IRS CONDITIONS-30 MONTHS FROM THE DATE OF WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT-SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER.	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT-9	29171064	ω
AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.	MAIN TRANSFORMER 7775 KVA TYPE LOT 7500 FOR WAP7 3- PHASE ELECTRIC LOCOMOTIVE TO CLW SPECN NO.CLW/ES/3/0660/C	29731057	2
60 months after commissioning or 72 months from date of supply whichever earlier as per special conditions given by CLW	IGBT BASED 3-PHASE DRIVE PROPULSION EQUIPMENT	29741075	1
Warranty Period	DESCRIPTION	PL No	S No
WARRANTY CONDITIONS AS PER TENDERS	TOP 12 COSTLIEST ITEMS OF WAG9HC LOCO WITH WARRANTY CON	TOP 12 (	*

7		6	5
29942007		29480140	29180016
3-PHASE ASYNCHRONOUS TRACTION MOTOR (RESISTANCE RING MECHANICALLY INTERLOCKED TO END PLATE DESIGN ROTOR, SCHEME-II), TYPE 6FRA-6068 FOR WAP-7 ELECTRIC LOCO WITHOUT ACTIVE SPEED SENSOR TO SPECIFICATION NO. 4TMS.096.081 ALT-2 AND STR NO. CLW/2008/3PHTM/STR/0001.		COMPLETE FILTER CUBICLE ALONG WITH ALL EQUIPMENTS AND CABLING TO DRG./SPEC NO. [1] CLW/ES/3/0193 ALT-F OR LATEST AND CLW DRG. NO. 1209-15-143-004 ALT-10 AND PART DRG./SPEC NO AS PER ANNEXURE-A ATTACHED.	BRAKE CONTROL SYSTEM INCLUDING DRIVER'S VIGILANCE CONTROL DEVICE TO SET LIST NO.EL29180016.
AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.	the state of the s	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.	As per specification no. CLW/MS/3/001 Alt. 16 i.e. the manufacturer is required to guarantee that the brakevalves/equipment work satisfactorily for a period of five (5) years after commissioning. Any equipment/part which failsduring the guarantee period shall be replaced free of cost by the manufacturer. The replaced components shallfurther be under warranty for five (5) years from the date of their fitment and should the replaced components proveunsatisfactory in service, they shall be replaced by modified and improved components by the supplier free of cost.

		19 8				
12	11	10		9		&
29171180	29171209	29171210		29171192	+	29105146
COMPLETE AUXILIARY CUBICLE HB1 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0191 ALT-D OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	COMPLETE CONTROL CUBICLE SB1 (PUSH PULL SCHEME COMPLIANT) ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0194 ALT-G OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	COMPLETE CONTROL CUBICLE SB2 ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0195/A ALT-H OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	The same of the sa	COMPLETE AUXILIARY CUBICLE HB2 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0192 ALT-E OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Bogie Frame Complete for WAP-7 for 3 Phase Co Co Locomotive to CLW specification No. CLW/MS/3/Bogie/003 alt-1 and CLW Drg.No.1209.01.112-202 Alt-Nil
AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.		AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.		As per clause 16 of Spec.No.CLW/MS/3/Bogie/003 Alt-1. [60 months after commissioning or 72 months from date of supply]

पी.एल.डब्ल्बू P. L. W