# भारतीय रेल Indian Railways

पटियाला रेलइंजन कारख़ाना, पटियाला

# PATIALA LOCOMOTIVE WORKS, PATIALA



# LOCO TESTING & DISPATCH REPORT OF IGBT BASED WAG9HC ELECTRIC LOCOMOTIVE

LOCO NO.: 41858

TYPE: WAG9HC

RAILWAY SHED: ECR/BJU

PROPULSION SYSTEM: CGL

**DATE OF DISPATCH:** 25.04.2024

लोको निर्माण रिकार्ड



# पटियाला रेलइंजन कारख़ाना, पटियाला PATIALA LOCOMOTIVE WORKS, PATIALA

LOCO NO.: 41858

RAILWAY/SHED: ECR/BJU

DOD: April-2024

### **INDEX**

SN	PARA	ACTIVITIES	PAGE NO.
		Testing & Commissioning (ECS)	
1.	1.0	Continuity Test of the cables	
	1.1	Continuity Test of Traction Circuit Cables	
	1.2	Continuity Test of Auxiliary Circuit Cables	1-4
	1.3	Continuity Test of Battery Circuit Cables	
	1.4	Continuity Test of Screened Control Circuit Cables	
2.	2.0	Low Tension test	
	2.1	Measurement of resistor in OHMS (Ω)	5-6
	2.2	Check Points	3-0
	2.3	Low Tension Test Battery Circuits (without control electronics)	
3	3.0	Downloading of Software	
	3.1	Check Points	
	3.2	Download Software	7-10
	3.3	Analogue Signal Checking	
	3.4	Functional test in simulation mode	
4	4.0	Sensor test & convertor test	
	4.1	Test wiring Transformer Circuits – Polarity Test	
	4.2	Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)	
	4.3	Primary Voltage Transformer	
	4.4	Minimum voltage relay (Pos. 86)	11-16
	4.5	Maximum current relay (Pos. 78)	77.78
	4.6	Test current sensors	
	4.7	Test DC Link Voltage Sensors (Pos 15.6/*)	
	4.8	Verification of Converter Protection Circuits (Hardware limits)	
	4.9	Sequence of BUR contactors	
5.	5.0	Commissioning with High Voltage	
	5.1	Check List	
	5.2	Safety test main circuit breaker	
	5.3	Auxiliary Converter Commissioning	
	5.3.1	Running test of 3 ph. auxiliary equipments	
	5.3.2	Performance of Auxiliary Converters	10.05
	5.3.3	Performance of BURs when one BUR goes out	16-25
	5.4 5.5	Auxiliary circuit 415/110	
	5.5 5.6	Hotel Load Circuit Traction Convertor Commissioning	
	5.6 5.7	Traction Converter Commissioning Test protective shutdown SP	
	5.7 5.8	Test protective shutdown SR Test Harmonic Filter	
	5.8 5.9	Test important components of the locomotive	
6.	6.0	Running Trial of the locomotive	25-26
7.	7.0	Final Check List to be verified at the time of Loco dispatch	27
8.	8.0	Status of RDSO modifications	28
9.	1-10	Pneumatic Test Parameters	29 - 32
10.		Loco Check Sheet(LAS)	33
11.	-	Component History (LAS,ECS,ABS)	34-36
12.	-	Component History & Testing Parameter (Bogie Shop)	37 - 38
13	-	Warranty Conditions as per Tenders	39 -41

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858 - CG 
1.0 Continuity Test of the cables

Type of Locomotive: WAP-7/WAG-9HC

Page: 1 of 27

### 1.1 Continuity Test of Traction Circuit Cables

As per cable list given in Para 1.3 of document no. 3 EHX 410 124, check the continuity with continuity tester and megger each cable to be connected between following equipment with 1000V megger.

From	То	Continuity (OK/Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Filter Cubicle	Transformer	OK	· 100 MΩ	New Mo
Filter Cubicle	Terminal Box of Harmonic Filter Resistor (Roof)	OK	100 ΜΩ	/ cue po
Filter Cubicle	Earthing Choke	OK	100 ΜΩ	8 com
Earthing Choke	Earth Return Brushes	OK	100 ΜΩ	8 cm
Transformer	Power Converter 1	OK	100 ΜΩ	9 wo mg
Transformer	Power Converter 2	ok	100 ΜΩ	9 w m
Power Converter 1	TM1, TM2, TM3	ok	100 ΜΩ	duona
Power Converter 2	TM4, TM5, TM6	OK	100 ΜΩ	1 eno ma
Earth	Power Converter 1	OK	100 ΜΩ	/enome
Earth	Power Converter 2	OK	100 ΜΩ	Jeona Jewona Jewona Jewona

### 1.2 Continuity Test of Auxiliary Circuit Cables

As per cable list given in Para 1.4 of document no. 3 EHX 410 124, check the continuity with continuity meter and megger each cable to be connected between following equipment with the help of 1000V megger.

Signature of the JE/SSE/Harness

Signature of the JE/SSE/Loco Cabling

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

### **PATIALA LOCOMOTIVE WORKS, PATIALA**

# <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 2 of 27

From	То	Continuity(OK/ Not OK)	Prescribed Megger Value (min)	Measured Megger Value ↑ ✓
Transformer	BUR1	ok	100 MΩ	2000
Transformer	BUR2	ok	100 MΩ	2000
Transformer	BUR3	OR	100 M $\Omega$	2000
Earth	BUR1	OR	100 ΜΩ	2010
Earth	BUR2	OB	100 M $\Omega$	1000
Earth	BUR3	OR	100 MΩ	1000
BUR1	HB1	012	100 MΩ	1000
BUR2	HB2	ok	100 MΩ	1000
HB1	HB2	ok	100 ΜΩ	200
HB1	TM Blower 1	OR	100 ΜΩ	200
HB1	TM Scavenge Blower 1	OK	100 MΩ	200
HB1	Oil Cooling Unit 1	ole	100 ΜΩ	ص ر
HB1	Compressor 1	or	100 ΜΩ	200
HB1	TFP Oil Pump 1	ore	100 ΜΩ	200
HB1	Converter Coolant Pump 1	0 k	100 ΜΩ	2.80
HB1	MR Blower 1	610	100 ΜΩ	200
HB1	MR Scavenge Blower 1	012	100 ΜΩ	06/
HB1	Cab1	01/2	100 ΜΩ	100
Cab1	Cab Heater 1	OK	100 ΜΩ	200
HB2	TM Blower 2	01<	100 ΜΩ	200
HB2	TM Scavenge Blower 2	OK	100 ΜΩ	200
HB2	Oil Cooling Unit 2	OK	100 ΜΩ	250
HB2	Compressor 2	010	100 MΩ	200
HB2	TFP Oil Pump 2	110	100 ΜΩ	250
HB2	Converter Coolant Pump 2	010	100 MΩ	200
HB2	MR Blower 2	012	100 ΜΩ	200
HB2	MR Scavenge Blower 2	012	100 ΜΩ	250
HB2	Cab2	07९	100 ΜΩ	200
Cab <sub>2</sub>	Cab Heater 2	010	100 ΜΩ	200

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 3 of 27

1.3 Continuity Test of Battery Circuit Cables

Check continuity of following cables as per Para 2.3 of document no. 3 EHX 610 299

From	То	Condition	Continuity (OK/Not OK)
Battery (wire no 2093)	Circuit breakers 110- 2, 112.1-1, 310.4-1	By opening and closing MCB 112	OK
MCB 110	Connector 50.X7-1	By opening and closing MCB 110	ac ac
Battery (Wire no. 2052)	Connector 50.X7-2		OK
SB2 (Wire no 2050)	Connector 50.X7-3		or.

Close the MCB 112, 110, 112.1, and 310.4 and	Prescribed value	Measured
measure the resistance of battery wires 2093, 2052, 2050 with respect to the loco earth.	> 0.5 MΩ	Value <u>7</u> ΜΩ
Measure the resistance between 2093 & 2052, 2093 & 2050, 2052 &	Prescribed value:	Measured
2050	> 50 MΩ	Value <u>6 S</u> MΩ

Commission the indoor lighting of the locomotive as per Sheet No 7A & 7B.

### 1.4 Continuity Test of Screened Control Circuit Cables

Check the continuity and isolation of the screen cable of the following circuits with the help of sheet no. mentioned against each as per document no. 3 EHX 610 299.

Screened control circuit cables for	Corresponding Sheet Nos.	Continuity & Isolation (OK/Not OK)
Battery voltage measurement	04B	ac
Memotel circuit of cab1 &2	10A	QK.
Memotel speed sensor	10A	92
Primary voltage detection	01A, 12A	OK.
Brake controller cab-1 & 2	06F, 06G	2

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

### **PATIALA LOCOMOTIVE WORKS, PATIALA**

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41858

Type of Locomotive: WAP-7/WAG-9HC

Page: 4 of 27

Master controller cab-1 &2	08C, 08D	OK
TE/BE meter bogie-1 & 2	08E, 08F	3K
Terminal fault indication cab-1 & 2	09F	ar.
Brake pipe pressure actual BE electric	06H	9K
Primary current sensors	12B, 12F	∂K
Harmonic filter current sensors	12B, 12F	QL.
Auxiliary current sensors	12B, 12F	JK.
Oil circuit transformer bogie 1	12E, 12I	ak a
Magnetization current	12C, 12G	OK
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-1	12D	3K
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-2	12D	ak
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-3	12D	OK
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-4	12H	· ok
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-5	12H	ak,
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-6	12H	92
Train Bus cab 1 & 2 (Wire U13A& U13B to earthing resistance=	13A	QL.
10K <b>Ω</b> ± ± 10%)		
UIC line	13B	OK,
Connection FLG1-Box TB	13A	ar.

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

### PATIALA LOCOMOTIVE WORKS, PATIALA

### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

41858 **Locomotive No.:** 

Type of Locomotive: WAP-7/WAG-9HC

Page: 5 of 27

### 2.0 Low Tension test

### Measurement of resistor in OHMS ( $\Omega$ )

Measure the resistances of the load resistors for primary voltage transformer, load resistors for primary current transformer and Resistor harmonic filter as per Para 3.2 of the document no. 3 EHX 610 279.

Name of the resistor	Prescribed value	Measured value
Load resistor for primary voltage transformer (Pos. 74.2).	3.9K <b>Ω</b> ± 10%	3.9KN
Resister to maximum current relay.	1Ω ± 10%	15
Load resistor for primary current transformer (Pos. 6.11).	3.3 <b>Ω</b> ± 10%	3.3.1
Resistance harmonic filter (Pos 8.3). Variation allowed $\pm$ 10%	WAP7	WAP7
Between wire 5 & 6	0.2 Ω	0.21
Between wire 6 & 7	0.2 Ω	0.252
Between wire 5 & 7	0.4 Ω	0.452
For train bus, line U13A to earthing.	10 k <b>Ω</b> ± 10%	999KN
For train bus, line U13B to earthing.	10 k <b>Ω</b> ± 10%	10.0 KD
Insulation resistance of High Voltage Cable from the top of the roof to the earth (by1000 V megger).	200 ΜΩ	400Mr
Resistance measurement earth return brushes Pos. 10/1.	≤0.3 Ω	0.292
Resistance measurement earth return brushes Pos. 10/2.	≤0.3 Ω	0.281
Resistance measurement earth return brushes Pos. 10/3.	≤0.3 Ω	0.2852
Resistance measurement earth return brushes Pos. 10/4.	≤0.3 Ω	0.282
Earthing resistance (earth fault detection) Harmonic Filter –I; Pos. 8.61.	2.2 kΩ± 10%	2.2 KM
Earthing resistance (earth fault detection) Harmonic Filter –II; Pos 8.62.	2.7 k <b>Ω</b> ± 10%	2.722
Earthing resistance (earth fault detection) Aux. Converter; Pos. 90.3.	3.9 k <b>Ω</b> ± 10%	3.9 KZ
Earthing resistance (earth fault detection) 415/110V; Pos. 90.41.	1.8 k <b>Ω</b> ± 10%	1.8452
Earthing resistance (earth fault detection) control circuit; Pos. 90.7.	390 <b>Ω</b> ± 10%	39052
Earthing resistance (earth fault detection) Hotel load; Pos. 37.1(in case of WAP5).	3.3 k <b>Ω</b> ± 10%	NA
Resistance for headlight dimmer; Pos. 332.3.	10 <b>Ω</b> ± 10%	1052

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41858

Type of Locomotive: WAP-7/WAG-9HC

Page : 6 of 27

Note:

Make sure that the earthing brush device don't make direct contact with the axle housing, earth connection must go by brushes.

### 2.2 Check Points

Items to be checked	Remarks
Check whether all the earthing connection in roof and machine room as mentioned in sheet no. 22A is done properly or not.  These earthing connections must be flexible and should be marked yellow & green	Chocked Of
Check whether all the earthing connection between loco body and bogie is done properly or not. These cables must be flexible having correct length and cross section	Cheeked &

## 2.3 Low Tension Test Battery Circuits (without control electronics)

These tests are done with the help of the special type test loop boxes as per procedure given in Para 3.6 of the document no. 3 EHX 610 279

Name of the test	Schematic used.	Remarks
Test 24V supply	Sheet 04F and other linked sheets	Cheeked of
Test 48V supply	Sheet 04F & sheets of group 09	Fan supply to be checked.
Test traction control	Sheets of Group 08.	JK.
Test power supply bus stations.	Sheets of Group 09.	Fan supply to be checked.
Test control main apparatus	Sheets of Group 05.	Sk.
Test earth fault detection battery circuit by making artificial earth fault to test the earth fault detection	Sheet 04C	ac
Test control Pneumatic devices	Sheets of Group 06	QL.
Test lighting control	Sheets of Group 07	OK
Pretest speedometer	Sheets of Group 10	OK
Pretest vigilance control and fire system	Sheets of Group 11	ex.
Power supply train bus	Sheets of Group 13	DIL

### PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: U/8S 83.0 Downloading of Software

Type of Locomotive: WAP-7/WAG-9HC

Page: 7 of 27

3.1 Check Points.	Yes/No
Check that all the cards are physically present in the bus stations and all the plugs are connected.	Yey
Check that all the fibre optic cables are correctly connected to the bus stations.	Yen
Make sure that <b>control electronics off relay</b> is not energized i.e. disconnect Sub-D 411.LG and loco is set up in simulation mode.	Yes
Check that battery power is on and all the MCBs (Pos. 127.*) in SB1 &SB2 are on	Yen

3.2 Download Software

The software of Traction converter, Auxiliary converter and VCU should be done by commissioning engineer of the firm in presence of supervisor. Correct software version of the propulsion equipment to be ensured and noted:

Traction converter-1 software version:	28
Traction converter-2 software version:	28
Auxiliary converter-1 software version:	<u> </u>
Auxiliary converter-2 software version:	4.0
Auxiliary converter-3 software version:	<i>u</i> , 0
Vehicle control unit -1 software version:	1600
Vehicle control unit -2 software version:	1600

### 3.3 Analogue Signal Checking

Check for the following analogue signals with the help of diagnostic tool connected with loco.

Description	Signal name	Prescribed value	Measured
			Value
Brake pipe pressure	FLG2;0101XPrAutoBkLn	100% (= 5 Kg/cm2)	92
Actual BE electric	FLG2; AMSB_0201- Wpn BEdem	100% (= 10V)	Op_
TE/BE at 'o' position	FLG1; AMSB_0101- Xang Trans	Between 9% and 11%	114.
from both cab	FLG2; AMSB_0101- Xang Trans		1 1 1 7 2
TE/BE at 'TE maximal'	FLG1; AMSB_0101- Xang Trans	Between 99 % and 101 %	1011.
position from both cab	FLG2; AMSB_0101- Xang Trans		7 77
TE/BE at 'TE minimal'	FLG1; AMSB_0101- Xang Trans	Between 20 % and 25 %	
position from both cab	FLG2; AMSB_0101- Xang Trans		257,

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 8 of 27

position from both cab	FLG2; AMSB_0101- XangTrans	Between 99% and 101%	1001.
TE/BE at 'BE Minimal' position from both cab	XangTrans FLG2; AMSB_0101- XangTrans	Between 20% and 25%	244.
TE/BE at '1/3' position in TE and BE mode in both cab.	LT/BDEM>1/3 HBB2; AMS_0101- LT/BDEM>1/3	Between 42 and 44%	447
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>2/3 HBB2; AMS_0101- LT/BDEM>2/3	Between 72 and 74%	744.
Both temperature sensor of TM1	SLG1; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature $0^{\circ}$ C to $40^{\circ}$ C	12.500
Both temperature sensor of TM2	SLG1; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	1200
Both temperature sensor of TM3	SLG1; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	1200
Both temperature sensor of TM4	SLG2; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature $0^{\circ}$ C to $40^{\circ}$ C	13°c
Both temperature sensor of TM5	SLG2; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature $0^{\circ}$ C to $40^{\circ}$ C	12.5°C
	Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	13°C

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 9 of 27

#### 3.4 Functional test in simulation mode

Conduct the following functional tests in simulation mode as per Para 5.5 of document no.3EHX 610 281. through the Diagnostic tool/laptop:

Test Function	Posult desired:	
	Result desired in sequence	Result obtained
Emergency shutdown through	VCB must open.	Obtained
emergency stop switch 244	Panto must lower.	cheered ac
Shut Down through cab activation	VCB must open.	· · · · · · · · · · · · · · · · ·
switch to OFF position	Panto must lower.	cheeted a
Converter and filter contactor	FB contactor 8.41 is closed.	
operation with both Power	By moving reverser handle:	7)
Converters during Start Up.	<ul> <li>Converter pre-charging contactor</li> </ul>	
	12.3 must close after few seconds.	·
	<ul> <li>Converter contactor 12.4 must close</li> </ul>	. 1
	<ul> <li>Converter re-charging contactor</li> </ul>	c-Rocked a
	12.3 must opens.	10,000
	By increasing TE/BE throttle:	
	• FB contactor 8.41 must open.	
	• FB contactor 8.2 must close.	
	• FB contactor 8.1 must close.	İ
Converter and filter contacto operation with both Powe		6
operation with both Powe Converters during Shut Down.	a distribution Rey to O	1/
converters during shut bown.	• VCB must open.	V
	Panto must lower.	1
	• Converter contactor 12.4 must open.	choesed of
	<ul><li>FB contactor 8.1 must open.</li><li>FB contactors 8.41 must close.</li></ul>	
	• FB contactors 8.41 must close. • FB contactor 8.2 must remain closed.	
	15 15 contactor 8.2 must remain closed.	
	1	

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC Page: 10 of 27

Contactor City		Page : 10 o
Contactor filter adaptation by isolating any bogie	Isolate any one bogie through bogie cut out switch. Wait for self-test of the loco.	7
	• Check that FB contactor 8.1 is open.	<b>.</b>
	<ul> <li>Check that FB contactor 8.2 is open.</li> <li>After raising panto, closing VCB, and setting TE/BE</li> </ul>	ocheeted on
	• FB contactor 8.1 closes.	
Test earth fault detection battery	FB contactor 8.2 remains open.  By connection  The contact of	<u> </u>
circuit positive & negative	By connecting wire 2050 to earth, create earth fault	
	negative potential.	
	message for earth fault	
	<ul> <li>By connecting wire 2095 to earth, create earth</li> </ul>	o charged s
	fault positive potential.	
	message for earth fault	
Test fire system. Create a smoke in	When smoke sensor-1 gets	
the machine room near the FDU.	activated then	)
Watch for activation of alarm.	Alarm triggers and fault	<i>r</i> .
	message priority 2	
	appears on screen.	
	When both smoke sensor	checkeda
	1+2 gets activated then	•
	<ul> <li>A fault message priority</li> </ul>	
	1 appears on screen and	
	lamp LSF1 glow.	
	Start/Running interlock occurs and	
ime date & loco number	TE/BE becomes to 0.	
ime, date & loco number	Ensure correct date time and Loco	3/_
	humber	~~

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

4.0 Sensor Test and Converter Test

Page: 11 of 27

## 4.1 Test wiring main Transformer Circuits

Apply  $198V_p/140V_{RMS}$  to the primary winding of the transformer (at 1u; wire no. 2 at surge arrestor and at 1v; wire no. 100 at earthing choke). Measure the output voltage and compare the phase of the following of the transformers

Output Winding nos.	Description of winding.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
2U <sub>1</sub> & 2V <sub>1</sub>	For line converter bogie 1 between cable 801A- 804A	10.05V <sub>p</sub> and same polarity	10.0400	3v
2U <sub>4</sub> & 2V <sub>4</sub>	For line converter bogie 1 between cable 811A- 814A	10.05V <sub>p</sub> and same polarity	10.0500	OL
2U <sub>2</sub> & 2V <sub>2</sub>	For line converter bogie 2 between cable 801B- 804B	10.05V <sub>p</sub> and same polarity	10.050	13/
2U <sub>3</sub> & 2V <sub>3</sub>	For line converter bogie 2 between cable 811B- 814B	10.05V <sub>p</sub> and same polarity	.10.0420	One.
2U <sub>B</sub> & 2V <sub>B</sub>	For aux. converter 1 between cable 1103- 1117 (in HB1) For Aux converter 2 between cable 1103- 1117 (in HB2)	7.9V <sub>p</sub> , 5.6V <sub>RMS</sub> and same polarity.	7.9VP 5.5VRMS	¢ K
2U <sub>F</sub> & 2V <sub>F</sub>	For harmonic filter between cable 4-12 (in FB)	9.12V <sub>p</sub> , 6.45V <sub>RMS</sub> and same polarity.	9.12 Vl 6.44 VR131	Q.

## 4.2 Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)

Apply  $141V_p$  /  $100V_{RMS}$  to input of the auxiliary transformer at cable no 1203 –1117 and measure the output at

Description of wire no.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
Cable no. 1218 - 1200	58.7V <sub>p</sub> , 41.5V <sub>RMS</sub> and opposite polarity.	58711	
		41.5 VR1795	OK
Cable no. 1218 – 6500	$15.5V_p$ , $11.0V_{RMS}$ and opposite polarity.	15.51	OR
		2 4 2 42 -2 1	

11.002575

Effective Date: Feb 2022

Doc.No.F/ECS/01

### (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 12 of 27

### 4.3 Primary Voltage Transformer

Apply  $250V_{\rm eff}/350V_{\rm p}$  by variac to roof wire 1 and any wire 0 and measure the magnitude and polarity of the output of the primary voltage transformer for both bogies as per the procedure specified and suggested by the traction converter manufacturer. Primary voltage measurement converters (Pos. 224.1/\*) & catenary voltmeter (Pos. 74/\*)

This test is to be done for each converter.

Activate cab in driving mode and supply  $200V_{RMS}$  through variac to wire no 1501 and 1502. Monitor the following parameters through Diagnostic tool and in catenary voltmeter.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	25kV	250%	25KV	2501-
SLG2_G 87-XUPrim	25 kV	250%	25KV	250/.

Decrease the supply voltage below 140  $V_{RMS}$ . VCB must open at this voltage. In this case the readings in Diagnostic Tool and catenary voltmeter will be as follows.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	17kV	170%	17121	17040
SLG2 G 87-XUPrim	17 kV	170%	1760	1704.

Reactivate VCB to on by increasing this voltage to 175% (17.5 kV).

Increase the supply to 240  $V_{RMS}$  through variac. VCB must open at this voltage, In this case the readings in **diagnostic tool** and catenary voltmeter will be as follows:

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	30kV	300%	BOKV	3004-
SLG2_G 87-XUPrim	30 kV	300%	30KV	300%

Reactivate VCB to on by decreasing this voltage to 290% (29 kV).

Effective Date: Feb 2022

# PATIALA LOCOMOTIVE WORKS, PATIALA

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 13 of 27

## 4.4 Minimum voltage relay (Pos. 86)

**Functionality test:** 

Minimum voltage relay (Pos. 86) must be adju	isted to approv 600/
Activate loco in cooling mode. Check Power supply of 48V to minimum voltage relay. Disconnect primary voltage transformer (wire no. 1511 and 1512) from load resistor (Pos. 74.2) and connect variac to wire no. 1501 and 1502. Supply 200V <sub>RMS</sub> through variac. In this case; <i>Minimum voltage relay (Pos. 86) picks up</i>	(Yes/No)
Try to activate the cab in driving mode: Contactor 218 do not close; the control electronics is not be working.	Yes/No)
Turn off the variac : Contactor 218 closes; the control electronics is be working	(Ares/No)
Test Under Voltage Protection	;
Activate the cab in cooling mode; Raise panto; Supply 200V <sub>RMS</sub> through variac to wire no. 1501 & 1502; Close the VCB; Interrupt the supply voltage	(Yes/No)
The VCB goes off after 2 second time delay.	
Again supply $200V_{RMS}$ through variac to wire no. 1501 & 1502; Decrease the supply voltage below $140V_{RMS} \pm 4V$ ; Fine tune the minimum voltage relay so that VCB opens.	L(Yes/No)

### 4.5 Maximum current relay (Pos. 78)

1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	•
Disconnect wire 1521 & 1522 of primary current transforme &1522 (including the resistor at Pos. 6.11); Put loco in simulatio on contact 136.3; Close VCB; supply 3.6A <sub>RMS</sub> at the open wi maximum current relay Pos. 78 for correct over current value;	n for driving mode: Open R₂ – R₄
VCB opens with Priority 1 fault message on display.	'Yes/No)
Keep contact $R_3 - R_4$ of 136.3 closed; Close VCB; Tune the resist /9.9 $A_p$ at the open wire 1521;	or 78.1 for the current of 7.0A <sub>RMS</sub>
VCB opens with Priority 1 fault message on display.	((Yes/No)

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 14 of 27

### 4.6 Test current sensors

Name of the sensor	Description of the test	Dunnanit I	
		Prescribed value	Set/Measured value
Primary return current sensor (Test-1,Pos.6.2/1	Activate cab in driving mode supply 10A. Measure the current through	(Variation allowed	
& 6.2/2)	diagnostic tool or measuring print.	is   ± 10%)	
	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		
Primary return current sensor (Test-2, Pos.6.2/1			
& 6.2/2)	Supply 297mA <sub>DC</sub> to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)	_	2-96 mg
Auxiliary winding current sensor (Pos. 42.3/1 & 42.3/2)	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AC/1or		
	2 pin no. 7(+) & 8(-) Supply 333mA <sub>DC</sub> to the test winding of sensor through connector 415.AC/1 or 2 pin no. 7(+) & 8(-)	page de marcine	325ma
Harmonic filter current sensors Pos.8.5/1 &8.5/2)	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AE/1or 2 pin no. 7(+) & 8(-)		,
	Supply 342mA <sub>DC</sub> to the test winding of sensor through connector 415.AE/1or 2 pin no. 7(+) & 8(-)		344 mas
Hotel load current ensors (Pos. 33/1 &	Switch on hotel load. Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)	NA	rep
33/2)	Supply 1242mA <sub>DC</sub> to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)	MB	MA

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41858

Type of Locomotive: WAP-7/WAG-9HC

4.7 Test DC Link Voltage Sensors (Pos 15.6/\*)

Page: 15 of 27

This test is to be done by the commissioning engineer of the firm if required.

## 4.8 Verification of Converter Protection Circuits (Hardware limits) -

This test is to be done as per para 6.17 of the document no. 3EHX 610 282 for both the converters.

Protection circuits	Limit on which shutdown should take place	Measured limit
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 1	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 18.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 2	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 8.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=
Fibre optic failure In Power Converter1	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	EX.
Fibre optic failure In Power Converter2	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	OK

### 4.9 Sequence of BUR contactors

The sequence of operation of BUR contactors for 'ALL BUR OK' BUR 1 out BUR 2 out and BUR 3 out condition has to be verified by putting the Loco in driving mode (VCB should not be closed) and isolating the BURs one by one. In these condition following will be the contactor sequence.

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52 5/2
AI BUR OK	Close	Open	Close	Open	Close	Open	Close	Close	Open
BUR1 off	Close	Open	Close	Close	Open	Close	Open	Open	Close
BUR2 off	Open	Open	Close	Close	Close	Close	Open	Open	Close
BUR3 off	Open	Close	Open	Close	Close	Close	Open	Open	Close

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 16 of 27

## Monitored contactor sequence

Status	52/1	52/2	52/3	E2/4	F2/F	T ==			
AI BUR OK	<del></del>	<del></del>	<del> </del>	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
BUR1 off	closs		clos	open	close	open	close	close	open
	clos	open	close	closs	open	close	open .	Oben	closs
BUR2 off	open	open	closs	closs	c los	clos	open	Open	ا
BUR3 off	open	close	open	close					close
		روسي	7	cos	Class	close	Oper	open	close

## 5.0 Commissioning with High Voltage

### 5.1 Check List

Items to be checked	Yes/No
Fibre optic cables connected correctly.	
	<b>)</b> (9)
No rubbish in machine room, on the roof, under the loco.	<del>                                     </del>
All the electronic Sub-D and connectors connected	Yey
	Yey
All the MCBs of the HB1 & HB2 open.	<del>                                     </del>
All the three fuses 40/* of the auxiliary converters	Yes
	1
The fuse of the 415/110V auxiliary circuit (in HB1) open.	7/2)
	Yes
Roof to roof earthing and roof to cab earthing done	3.4
ixing, connection and earthing in the surge arrestor done correctly.	Hes
	Yes
Connection in all the traction motors done correctly.	<del>                                     </del>
All the hogie body connection and combine and in the hogie body connection and combine and in the hogie body connection and combine and co	Yes
All the bogie body connection and earthing connection done correctly.	Yas
ulse generator (Pos. 94.1) connection done correctly.	
	Yes
Il the oil cocks of the gate valve of the transformer in open condition.	1
ll covers on Aux & Power converters, Filter block, HB1, HB2 fitted	Yes
and an indicate converters, Filter block, HB1, HB2 fitted	Ye
ABA key interlocking system.	Yas

## 5.2 Safety test main circuit breaker

Prepare to switch off the catenary supply during the first charging of the locomotive in case of any unexpected behavior of the electrical component of the loco. Charge the loco for the first time by closing BLDJ switch. The VCB will trip after certain time as no oil/coolant pumps are running yet.

Perform the following safety test of main circuit breaker through both the cabs of the locomotive.

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

# <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC Page: 17 of 27

Name of the test	Description of the test	Expected result	Monitored result
Emergency stop in cooling mode	Raise panto in cooling mode. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency	chared an
Emergency stop in driving mode  Under voltage	Raise panto in driving mode in. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.  Raise panto in cooling	VCB must open. Panto must lower. Emergency brake will be applied. VCB must open.	chureda
protection in cooling mode	mode. Close the VCB. Switch off the supply of catenary by isolator	veb must open.	cholted a
Under voltage protection in driving mode	Raise panto in driving mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open with diagnostic message that catenary voltage out of limits	cheeked in
Shut down in cooling mode.	Raise panto in cooling mode. Close the VCB. Bring the BL- key in O position.	VCB must open. Panto must lower.	cheeted on
Shutdown in Iriving mode	Raise panto in driving mode. Close the VCB. Bring the BL-key in O position.	VCB must open. Panto must lower.	choeked on
nterlocking antograph- 'CB in cooling node	Raise panto in cooling mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	choeped ou
nterlocking antograph- CB in driving node	Raise panto in driving mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	Cholkeda

ISSUE No.03

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

# <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 18 of 27

## 5.3 Auxiliary Converter Commissioning

Switch on the high voltage supply and set up the loco in driving mode. Raise the panto. Close the VCB. Check that there is no earth fault in the auxiliary circuit, Switch off the VCB. Lower the panto. Create the earth fault in auxiliary circuit by making connection between wire no 1117(in HB2 cubicle) and earth. After 3 minutes a diagnostic message will come that "Earth fault auxiliary circuit."

## 5.3.1 Running test of 3 ph. auxiliary equipments

Switch on the 3 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine Oil pump transformer 1	Typical phase current	Measured continuous phase current	Measured starting phase current
Oil pump transformer 2	9.8 amps	9.0	10:2
	9.8 amps	9.7	
Coolant pump converter 1	19.6 amps	4.5	5.4
Coolant pump converter 2	19.6 amps	4.3	5.4
Oil cooling blower unit 1	40.0 amps	42,0	/70.0
Oil cooling blower unit 2	40.0 amps	42.0	18013
Traction motor blower 1	34.0 amps	32.0	1650
Traction motor blower 2	34.0 amps	32.0	170.0
Sc. Blower to Traction motor blower 1	6.0 amps	3.6	17.0
Sc. Blower to Traction motor blower 1	6.0 amps	3.8	17.0
Compressor 1	25 amps at 0 kg/ cm <sup>2</sup> 40 amps at 10 kg/ cm <sup>2</sup>	28.0	1450
Compressor 2	25 amps at 0 kg/cm <sup>2</sup> 40 amps at 10	28.0	135 0
	kg/ cm <sup>2</sup>		

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

## Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 19 of 27

## 5.3.2 Performance of Auxiliary Converters

Measure the performance of the auxiliary converters through software and record it. BUR1 (Condition: Switch off all the load of BUR 1)- to be filled by commissioning engineer

Signal name	Description of the signal	Dunca		
Direction		Prescribed value	Monitored value	Value under
70.7	Input voltage to BUR1	75% (10%=125V)	10041	Limit (Yes/No) Ye
	- a milk Adjunge of BOKT	60% (10%=100V)	636 V	401
	DC link current of BUR1 witch off all the load of BU	0% (10%=50A)		40

BUR2 (Condition: Switch off all the load of BUR 2, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value by the firm	Monitored value	Value under Limit (Yes/No
BUR2 7303-XUUN	Input voltage to BUR2	75% (10%=125V)	10.51	
DUD2 7202 VAIV		,	10054	70)
BUR2 7303-XUUZ1	DC link voltage of BUR2	60% (10%=100V)	637V	40)
BUR2 7303-XUIZ 1	DC link current of BUR2	1% (10%=50A)*	7 Amb	Yen
BUR2 7303-XUILG	Current battery	3% (10%=100A)*		
NAME OF THE OWNER OWNER OF THE OWNER O	charger of BUR2	( ) ( )	22 pm	Es
BUR2 7303-XUIB1	Current battery of BUR2	1.5%(10%=100A)*	12 BM	Yes
BUR2 7303 –XUUB	Voltage battery of BUR2 pendent upon charging co	110%(10%=10V)	110	72

<sup>\*</sup> Readings are dependent upon charging condition of the battery.

BUR3 (Condition: Switch off all the load of BUR 3, Battery Charger on) to be filled by commissioning engineer of the firm

Signal name	Description of the signal	Prescribed set value by the firm	Monitored value	Value under limit (Yes/No)
BUR3 7303-XUUN	Input voltage to BUR3	75% (10%=125V	1006V	Yey
BUR3 7303- XUUZ1	DC link voltage of BUR3	60% (10%=100V)	637V	Yes
BUR3 7303-XUIZ 1	DC link current of BUR3	1% (10%=50A)*	7 Amp	Yes
BUR3 7303-XUILG	Current battery charger of BUR 3	3% (10%=100A)*	22 pmp	Yes
BUR3 7303-XUIB1	Current battery of BUR 3	1.5%(10%=100A)*	12- Brop	Yes
BUR3 7303-XUUB	Voltage battery of BUR 3	110%(10%=10V)	1100	Yes

\* Readings are dependent upon charging condition of the battery.

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41858

Type of Locomotive: WAP-7/WAG-9HC Page: 20 of 27

5.3.3 Performance of BURs when one BUR goes out

When any one BUR goes out then rest of the two BURs should take the load of all the

Condition of BURs	Loads on BUR1	Loads in BUR2	Loads in BUR3
All BURs OK BUR 1 out	Oil Cooling unit 1&2	TM blower1&2, TFP oil pump 1&2, SR coolant pump 1&2.	Compressor 1&2, Battery charger and TM Scavenger blower 1&2
BUR 2 out		Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2,TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 3 out	Oil Cooling unit 1&2, TM blower 1&2, TM Scavenger blower 1&2		Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
DON'S OUL	Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.	

## 5.4 Auxiliary circuit 415/110

For checking earth fault detection, make a connection between wire no. 1218 and vehicle body. On switching on VCB, Earth fault relay 89.5 must pick up and after 3 minutes a message will come in the Diagnostic display that Earth Fault 415/110V Circuit

Switch on the 1 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured phase current	Measured starting current
Machine room blower 1	15.0 amps*	4.2	200
Machine room blower 2	15.0 amps*	4.6	21.0
Sc. Blower to MR blower 1	1.3 amps	1.1	4.5
Sc. Blower to MR blower 2	1.3 amps	1.4	4.5
Ventilator cab heater 1	1.1 amps	1.0	1.6
Ventilator cab heater 2	1.1 amps	1, 0	1.6
Cab heater 1	4.8 amps	4.8	4.9
Cab heater 2  For indigenous MR blowers.	4.8 amps	4.8	4.9

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

# <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 21 of 27

# 5.5 Hotel load circuit (Not applicable for WAG-9HC)

For WAP-7 locomotive with Hotel load converter refer to Annexure-HLC

## 5.6 Traction Converter Commissioning

## This test is carried out in association with Firm.

Traction converter commissioning is being done one at a time. For testing Converter 1, switch off the traction converter 2 by switch bogie cut out switch 154. For testing Converter 2, switch off the traction converter 2 by switch bogie cut out switch 154. Isolate the harmonic filter also by switch 160. Start up the loco by one converter. Follow the functionality tests.

### For Converter 1

Test Function	Results desired	Result obtained
Measurement of charging and precharging and charging of DC Link of Converter 1  Measurement of discharging of DC Link of Converter 1  Earth fault detection on	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.  Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	choeted in
oositive potential of DC ink of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Chelted u
arth fault detection on legative potential of DC ink of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeked on
arth fault detection on AC art of the traction ircuit of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Chelked on
ulsing of line converter Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chelted an
	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chelled on

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC Page: 22 of 27

### For Converter 2

Results desired in sequence	Result obtained
idemonstrate the same to the provider	cheered on
Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	charped un
declare the successful operation and demonstrate the same to the PLW	o Rocked on
deciare the successful operation and demonstrate the same to the	chlexed on
declare the successful operation and demonstrate the same to the PLW	Cholted in
declare the successful operation and demonstrate the same to the PLW supervisor.	chalfad a
Traction converter manufacturer to declare the successful operation and demonstrate the same to the	cholked on
	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.  Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.  Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.  Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/v  Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.  Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.  Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 23 of 27

## 5.7 Test protective shutdown SR

Test Function	Results desired in sequence	Result obtained
Measurement of	Start up the least it	
protective shutdown	Start up the loco with both the	
by Converter 1	The state of the s	
electronics.	Move Reverser handle to forward or	
	reverse. Remove one of the orange	
	fibre optic feedback cable from	
	converter 1Check that converter 1	cheeked on
	electronics produces a protective shut	ycraco
	down.	
	VCB goes off	
	Priority 1 fault mesg. on DDU	
	appears	
	Disturbance in Converter 1	
Measurement of	Start up the loco with both the	<i></i>
protective shutdown	converter. Raise panto. Close VCB.	
by Converter 2	Move Reverser handle to forward or	
electronics.	reverse. Remove one of the orange	
	fibre ontic foodback and the	•
	fibre optic feedback cable from	
4.45	converter 2. Check that converter 2	afactace de
	electronics produces a protective shut	
	down.	
	• VCB goes off	
	Priority 1 fault mesg. on diagnostic	
	display appears	
	Disturbance in Converter 2	

### 5.8 Test Harmonic Filter

Switch on the filter by switch 160

Test Function	Results desired in sequence	Result obtained
currents	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Apply a small value of TE/BE by moving the throttle.  • FB contactor 8.41 must open.	cheeted on

ISSUE No.03

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 24 of 27

	<ul> <li>FB contactor 8.2 must close.</li> <li>FB contactor 8.1 must close</li> <li>Check the filter current in diagnostic laptop</li> <li>Bring the TE/BE throttle to O</li> <li>Switch off the VCB</li> <li>FB contactor 8.1 must open.</li> <li>FB discharging contactor 8.41 must close</li> <li>Check the filter</li> </ul>	o cheesed on
Test earth fault detection harmonic filter circuit.	<ul> <li>Check the filter current in diagnostic laptop</li> <li>Make a connection between wire no. 12 and vehicle body. Start up the loco. Close VCB.</li> <li>Earth fault relay 89.6 must pick up.</li> <li>Diagnostic message comes that - Earth fault in harmonic filter circuit</li> </ul>	orected on
Test traction motor speed sensors for both bogie in both cabs	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	Эк

## 5.9 Test important components of the locomotive

Items to be tested	Description of the test	Monitored value/remarks
Speedometer	VCU converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	charted on
Time delay module of MR blower	The time after which the starting capacitor for MR blower should go off the circuit should be set to 10-12 seconds	cheeked ar
Ni-Cd battery voltage	At full charge, the battery voltage should be 110V DC.	cheekeela
Flasher light	From both cab flasher light should blink at least 65 times in one minute.	cheered on
Head light	Head light should glow from both cabs by operating ZLPRD. Dimmer operation of headlight should also occur by operating the switch ZLPRD.	cherred or

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 25 of 27

		Page : 25 of 27
Marker light	Both front and tail marker light should glow from both the cabs	chered of
Cab Light	Cab light should glow in both the cabs by operating the switch ZLC	cheeped on
Spot lights	Both Drivers and Asst. Drivers Spot light should glow in both cabs by operating ZLDD	chalted on
Instrument lights	Instrument light should glow from both cab by operating the switch ZLI	Chelcolon
Illuminated Push button	All illuminated push buttons should glow during the operation	cheeped as
Contact pressure of the high rating contactors	The contact pressure of FB contactors (8.1, 8.2) is to be measured  Criteria:  The minimum contact pressure is 54 to 66  Newton.	For contactor 8.1: For contactor 8.2: 5
Crew Fan	All crew fans should work properly when VCB of the loco is switched on. The airflow from each cab fan is to be measured.  Criteria:  The minimum flow of air of cab fan should be 25 m <sup>3</sup> /minute	Cab 1 LHS: Cab 1 RHS: Cab 2 LHS: Cab 2 RHS:

## 6.0 Running Trial of the locomotive

SN	Description of the items to be seen during trail run	Action which should take place	Remarks
1	Cab activation in driving mode	No fault message should appear on the diagnostic panel of the loco.	Lector
3.	Check function of Emergency push stop.  Check function of BPCS.	should be lowered.	Locker
5.	Check train parting operation of the Locomotive.	<ul> <li>Beyond 5 kmph, press BPCS, the speed of loco should be constant.</li> <li>BPCS action should be cancelled by moving TE/BE throttle, by dropping BP below 4.75 Kg/cm², by pressing BPCS again.</li> <li>Operate the emergency cock to drop the BP Pressure LSAF should glow.</li> </ul>	Rocked on

### Doc.No.F/ECS/01

(Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

## <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 6/858

Type of Locomotive: WAP-7/WAG-9HC

Page : 26 of 27

6.	Ch. I . II	Page: 26 of 27	
	Check vigilance operation of the locomotive	Set the speed more than 1.5 kmph and ensure that brakes are released i.e. BC < 1 Kg/cm <sup>2</sup> .  For 60 seconds do not press vigilance foot switch or	
		sanding foots switch or TE/BE throttle or BPVG switch then	
		Buzzer should start buzzing.      LSVW should glow continuously.	
		Do not acknowledge the alarm through BPVG or	Ked O
		Emergency brake should be applied automatically.	
		VCB should be switched off.	
		Resetting of this penalty brake is possible only after 180 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch.	
7.	Check start/run interlock	• At low pressure of MR (< 5.6 Kg/cm <sup>2</sup> ).	
		With park brake in applied condition.	el ou
		• With direct loco brake applied (BP< 4.75Kg/cm <sup>2</sup> ).	
		<ul> <li>With automatic train brake applied (BP&lt;4.75Kg/cm<sup>2</sup>).</li> <li>With emergency cock (BP &lt; 4.75 Kg/cm<sup>2</sup>).</li> </ul>	feel Or
8.	Check traction interlock	Switch of the brake electronics. The	
			zal ve
	Check regenerative praking.	Tractive /Braking effort should ramp down, VCB should open and BP reduces rapidly.  Bring the TE/BE throttle to BE side. Loco speed should start reducing.	est UK
10. ( r	Check for BUR redundancy test at rentilation level 1 & 3 of	In the event of failure of one BUR, rest of the two BURs can take the load of all the auxiliaries. For this switch off one BUR.	
	oco operation	Auxiliaries should be catered by rest of two BURs.  Switch off the 2 BURs; loco should trip in this case.	
С	check the power onverter solation test	Create disturbance in power converter by switching off the electronics. VCB should open and converter should get isolated and traction is possible with another power converter.	l Ou

Effective Date: Feb 2022

Doc.No.F/ECS/01

### (Ref: WI/ECS/10)

## PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/858

Type of Locomotive: WAP-7/WAG-9HC

Page: 27 of 27

# 7.0 Final check list to be verified at the time of Loco dispatch

Condition /Operations of the following items are to be checked:

SN	Item	Cab-1	Cab-2	Remarks
1	Head lights	Ox	or -	
2	Marker Red	84	OK	
3	Marker White	OR	OK	
4	Cab Lights	Of_	UK	
5	Dr Spot Light	8v	OK	
5	Asst Dr Spot Light	OK_	OK	
,	Flasher Light	8rc		
	Instrument Lights	80	ac	Cheered worken
	Corridor Light	CX	or	
)	Cab Fans	OK	OR	
-	Cab Heater/Blowers	OV	OR	
	All Cab Signal Lamps Panel 'A'	SV.	or	

# Status of RDSO modifications

LOCO NO: 4) 858

Sn	Modification No.	Description	<del></del>
1.	RDSO/2008/EL/MS/035		Remark
	Rev.'0' Dt 20.02.08	Light of three phase electric locomotives.	d Ok/Not Ok
2.	RDSO/2009/EL/MS/037	77 Modification	
3.	Rev.'0' Dt 22.04.09	locomotives schaing circuit in electric	Ok/Not Ok
J.	RDSO/2010/EL/MS/039 Rev.'0' Dt 31.12.10	The state of the contractors and the contractors	of C
4.	RDSO/2011/EL/MS/039	three phase locomotives to improve reliability.  9 Removal of interlocks of	Ok/Not Ok
<u> </u>	Rev.'0' Dt 08.08.11 RDSO/2011/EL/MS/040	9 Removal of interlocks of control circuit contactors no. 126 from MCPA circuit.	% K/Not Ok
J.	Rev.'0' Dt 10.08.11	Wildingation sheet for shifting the termination of a continue	
		KV, 70 sq mm cables and 2x2.5 sq mm cables housed in lower portion of HB2 panel and provision of Synthetic resir bonded glass fiber shoot for these	
3.	RDSO/2011/EL/MS/0401		
	Rev.'0' Dt 10.08.11	three phase leasured three phase leasured three phase leasured to relaying of cables in HB-2 panel of	
· ]	RDSO/2011/EL/MS/0403	Auto switching of machine room/corridor links	
	Rev.'0' Dt 30.11.11 RDSO/2012/EL/MS/0408	draining of batteries in three phase electric locomotives.	Ok/Not Ok
	Rev.'0'	assembly	101/11-10
	RDSO/2012/EL/MS/0411 Rev.'1' dated 02.11.12	Modification sheet to avoid simultaneous switch and	+
	Nev. 1 dated 02.11.12	The same red marker months through the same	Ok/Not Ok
0	RDSO/2012/EL/MS/0413	Paralleling of interlocks of EP contactors and auxiliary	T .
1	Rev.'1' Dt 25.04.16 RDSO/2012/EL/MS/0419	I	Ok/Not Ok
	Rev.'0' Dt 20.12.12 RDSO/2013/EL/MS/0420	Master Controller of three phase locomotives	Ok/Not Ok
	Rev.'0' Dt 23.01.13	arrangement in Primary Over Current Relay of three phase locomotives.	Ok/Not Ok
	RDSO/2013/EL/MS/0425 Rev.'0' Dt 22.05.13	Modification sheet for improving illumination of head light in	
	RDSO/2013/EL/MS/0426	difficition in three phase electric locomotives	Vk/Not Ok
	Rev.'0' Dt 18.07.13	Modification sheet of Bogie isolation rotary switch in three phase electric locomotives.	√ok/Not Ok
	RDSO/2013/EL/MS/0427 Rev.'0' Dt 23.10.13	Modification sheet for MCP control in three phase electric locomotives.	1
T		Modification sheet for relocation of earth fault releva for	Ok/Not Ok
_	-	harmonic filter and hotel load along with its resistors in three phase electric locomotives.	Ok/Not Ok
] F		Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.	Ok/Not Ok
F	2011 101 DE 00 15	Flovision of Auxiliary Interlock for monitoring of Harmonia	STATIOL ON
		filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.	OK/Not Ok
F	RDSO/2017/EL/MS/0467	Modification in blocking diodes to improve reliability in three	
R		phase electric locomotives.  Modification in existing Control Electronics (CE) resetting	Wk/Not Ok
LR	Rev.'0'	scheme of 3 phase electric locomotives.	Øk/Not Ok

Signature of JE/ISSE/ECS

Loco No.: 41858

### PLW/PATIALA

### PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

SN	Parameters	Reference	Value	Result	
	Brake Panel: M/s Knorr				
1.0	Auxiliary Air supply system (Pantograph & VCB)				
1.1	Ensure, Air is completely vented from pantograph			0	
	Reservoir (Ensure Panto gauge reading is Zero)				
1.2	Turn On BL Key. Now MCPA starts.		60 sec. (Max.)		
	Record pressure Build up time (8.0 kg/cm2)		120 sec (knorr)	112 sec	
1.3	Auxiliary compressor safety Valve 23F setting	Faiveley Doc. No.	8.5±0.25kg/cm2	8.4	
		DMTS-014-1, 8 CLW's	-		
		check sheet no.			
		F60.812 Version 2			
1.4	Check VCB Pressure Switch Setting	CLW's check sheet	Opens 4.5±0.15	4.50 Kg/cm2	
		no. F60.812 Version 2	kg/cm2, closes		
			5.5±0.15 kg/cm2	5.50 Kg/cm2	
1.5	Set pantograph Selector Switch is in Auto, Open pan-1&2 Is	solating Cocks & KABA co			
1.6	Set Cab-1 Pan UP in Panel A.		Observed Pan-2	OK	
			Rises.		
1.7	Close Pan-2 isolating Cock		Panto-2 Falls Down	OK	
	Open Pan -2 isolating Cock		Panto-2 Rises		
1.8	Record Pantograph Rise time		06 to 10 seconds	9 Sec	
1.9	Record Pantograph Lowering Time		06 to 10 seconds	9 Sec	
1.10	Panto line air leakage		0.7 kg/cm2 in 5	0.4 kg/cm2	
			Min.	in 5 Min.	
1.11	High Reach Panto emergency test and reset.			ok	
2.0	Main Air Supply System				
2.1	Ensure, Air is completely vented from locomotive. Drain	Theoretical			
	out all the reservoirs by opening the drain cocks and then	calculation and			
	closed drain cocks. MR air pressure build up time by each	test performed by			
	compressor from 0 to 10 kg/cm2.	Railways.			
	i) with 1750 LPM compressor		i) 7 mins Max.	6 min. & 40	
	ii) with 1450 LPM compressor		ii) 8.5 mins Max.	sec.	
2.2	Drain air below MR 8 kg/cm2 to start both the		Check Starting of	ok	
	compressors		both compressors		
2.3	Drain air from main reservoir up to 7 kg/cm2. Start		30 Sec. (Max)	CP1-27 Sec	
	compressors, Check pressure build time of individual		. ,		
	compressor from 8 kg/cm2 to 9 kg/cm2			CP2-29 Sec	
2.4	Check Low MR Pressure Switch Setting (37)	D&M test spec.	Closes at 6.40±0.15	6.4 Kg/cm2	
		MM3882 &	kg/cm2 Opens at		
		MM3946	5.60±0.15kg/cm2	5.6 Kg/cm2	
2.5	Check compressor Pressure Switch RGCP setting (35)	D&M test spec.	Opens at 10±0.20	10 Kg/cm2	
		MM3882 &	kg/cm2, Closes at		
		MM3946	8±0.20 kg/cm2	8 Kg/cm2	
2.6	Run both the compressors Record Pressure build up time	Trial results	3.5 Minutes Max.	3.35 minute	

### PLW/PATIALA

Loco No.: 41858

2.7	Check unloader v	alve operation time				Approx. 12 Sec.	10 sec
2.8	Check Auto Drain	Valve functioning (1	24 & 87)			Operates when Compressor starts	ok
2.9	Direct by BLCP.	ry safety valve settin		D&M test spec. MM3882 & MM3946		11.50±0.35 kg/cm2	11.6 Kg/cm2
2.10	direct by BLCP	ery safety valve settir			test spec. & MM3946	11.50±0.35 kg/cm2	11.55 Kg/cm2
2.11	Switch 'OFF' the compressors and ensure that the safety valve to reset at pressure 1.2 kg/cm2 less than opening pressure.			test spec. & MM3946			
2.12			CLW's chec F60.812 Ve	ck sheet no. ersion 2	5.0±0.10kg/cm2	5.0 Kg/cm2	
2.13	FP pressure: Fit Test Gauge in Test point 107F FPTP. Open isolate cock 136F. Check pressure in Gauge.		CLW's chec F60.812 Ve	ck sheet no. ersion 2	6.0±0.20kg/cm2	6.05 Kg/cm2	
3.0	Air Dryer Opera	ation					
3.1	Open Drain Cock 90 of 2 <sup>nd</sup> MR to start Compressor, leave open for Test Check Air Dryer Towers to change.				Tower to change every minute	ok	
3.2		Stops from Air Dryer					
3.3	Check condition of humidity indicator				Blue	Blue	
4.0	Main Reservoir L						
4.1	Put Auto Brake (A-9) in full service, Check MR Pressure air leakage from both cabs.		D&M test spec. MM3882 & MM3946		Should be less than 1 kg/cm2 in 15 minutes	0.7 Kg/cm2 in 15 minutes	
4.2	Check BP Air leak	age		D&M test spec. MM3882 & MM3946		0.15 kg/cm2 in 5 minutes	0.05 Kg/cm2 in 5 minutes
5.0	Brake Test (Aut	omatic Brake oper	ration)				
5.1	Record Brake Pipe & Brake Cylinder pressure at Each Step						
	Check proportionality of Auto Brake system			eck sheet no. ? Version 2			
	Auto controller position	BP Pressi	ure kg/cm2	BC (WAG-9 Kg/cm2	9 & WAP-7)	BC (WAP-5) Kg/cm2	
		Value	Result	Value	Result	Value	Result
	Run	5±0.1	5.0 Kg/cm2	0.00	0.00 Kg/ cm2	0.00	-
	Intial	4.60±0.1	4.6 Kg/cm2	0.40±0.1	0.40Kg/ cm2	0.75±0.15	-
	Full service	3.35±0.2	3.5 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	-
	Emergency	Less than 0.3	0.25 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	-

### **PLW/PATIALA**

Loco No.: 41858

5.2	Record time to BP pressure drop to 3.5 kg/cm2 Ensure	D&M test spec.	8±2 sec.	9 Sec
0.2	Automatic Brake Controller handle is Full Service from Run	MM3882 & MM3946	0±2 300.	7 300
5.3	Operate Asst. Driver Emergency Cock,	D&M test spec.	BP pressure falls	
0.0	operate 7.55t. Briver Emergency cook,	MM3882 & MM3946	to Below 2.5	OK
		Williams a williams	kg/cm2	
5.4	Check brake Pipe Pressure Switch 69F operates	CLW's check sheet no.	Closes at BP	4.2 Kg/cm2
	·	F60.812 Version 2	4.05- 4.35	
			kg/cm2	
			Opens at BP	3.05
			2.85- 3.15	Kg/cm2
			kg/cm2	
5.5	Move Auto Brake Controller handle from Running to	D&M test spec.		
	Emergency BC filling time from 0.4 kg/cm2 i.e. 95% of	MM3882 & MM3946		
	Max. BC developed			
	WAP5 – BC 5.15 ± 0.3 kg/cm2 apply time		4±1 sec.	
	WAP7 - BC 2.50 ± 0.1 kg/cm2		7.5±1.5 sec.	
	WAG9 - BC 2.50 ± 0.1 kg/cm2		21±3 sec.	22 SEC
5.6	Move Auto Brake Controller handle to full service and	D&M test spec.		
	BP pressure 3.5 kg/cm2. Move Brake controller to	MM3882 & MM3946		
	Running position BC Release time to fall BC Pressure			
	up to 0.4 kg/cm2 i.e. 95% of Max. BC developed			
	BC release Time			
	WAP7		17.5±25 sec.	
	WAG9		52±7.5 sec.	54 sec.
5.7	Move Auto Brake Controller handle to Release, Check	CLW's check sheet no.	60 to 80 Sec.	74 Sec
	BP Pressure Steady at 5.5± 0.2 kg/cm2 time.	F60.812 Version 2		
5.8	Auto Brake capacity test : The capacity of the A9 valve	RDSO Motive power	BP pressure	
	in released condition must conform to certain limit in	Directorate report no.	should not fall	
	order to ensure compensation for air leakage in the	MP Guide No. 11 July,	below 4.0	
	train without interfering with the automatic	1999 Rev.1	kg/cm2 with in	4.7
	functioning of brake.		60 Sec.	Kg/cm2
	* Allow The MR pressure to build up to maximum			
	stipulated limit.			
	* Close brake pipe angle cock and charge brake pipe to			
	5 kg/cm2 by A-9 (Automatic brake controlling) at run			
	position.			
	* Couple 7.5 dia leak hole to the brake hose pipe of			
	locomotive. Open the angle cock for brake pipe.			
	The test shall be carried out with all the compressors			
	in working condition.			
5.9	Keep Auto Brake Controller (A-9) in Full Service. Press		BC comes to '0'	0
	Driver End paddle Switch (PVEF)			
6.0	Direct Brake (SA-9)			
6.1	Apply Direct Brake in Full Check BC pressure			
	WAG9/WAP7	CLW's check sheet no.	3.5±0.20 kg/cm2	3.5Kg/cm2
	WAP5	F60.812 Version 2	5.15±0.3 kg/cm2	
6.2	Apply Direct Brake, Record Brake Cylinder charging	D&M test spec.	8 sec. (Max.)	7 Sec
	time	MM3882 & MM3946		

### PLW/PATIALA

Loco No.: 41858

6.3	Check Direct Brake Pressure switch 59 (F)	D&M test spec. MM3882 & MM3946	0.2.±0.1 kg/cm2	0.20 kg/cm2
6.4	Release direct brake & BC Release time to fall BC pressure up to 0.4 kg/cm2		10 -15 Sec.	14 Sec
7.0	Modified System Software (only for CCB)			
7.1	Bail-off de-activated during emergency by any means			Now de- activated
7.2	DPWCS and Non-DPWCS mode enabled		Multi Loco	
7.3	TCAS and Non-TCAS mode enabled		Not Yet Launched	Presently
7.4	Penalty brake application deactivated for Fault code 113 (FC 113) and CCB health signal will not drop to avoid loco detention/failure. The Brake Electronics Failure "message will not generate on DDS.	DDSO lotter no	Pressure Setting Needed is12 kg/sqcm Causing mismatching with standard Pr Setting	- not happening in PLW
7.5	CCB health signal logic revised (Now will remain high) for penalty condition occurring with FC 108 due to wrong operation/not affecting operation/ Not a CCB Fault (i.e Both controllers selected as LEAD etc) The Brake electronic failure message will not generate on DDS	RDSO letter no. EL/3.2.19/3-phase (CCB), dtd 30.01.2023		Brake electronic failure message not generate on DDS
7.6	CCB health signal logic for FC 102 (In case of BC request from VCU is more than 90 %-above 9V DC) is changed i.e CCB health signal will not drop for FC 102 which will avoid loco detention/failure. The brake electronic failure message will not generate on DDS.		Could not performed by M/s Knorr	Presently not happening in PLW
7.7	Booting time for CCB with TCAS/TPM/PTWS/DPWCS mode 15-20 sec. However, in case of absence of either one or both system booting time subsequently increased to 40-50 sec.			50 sec
8.0	Sanding Equipment			
8.1	Check Isolating Cock-134F is in open position. Press sander paddle Switch. (To confirm EP valves Operates)		Sand on Rail	Ok
9.0	Test Vigilance equipment : As per D&M test specification			Ok

				41858		
		Warranty				
S.No.	Description	PL NO.	QPL /Nos.	Supplier	Sr. no.	warranty
	Pantograph	29880014(HR),	2			
1		29880026		FAIVELEY, GENERAL STORES	L23-1694,OCT-23,3427-08/23	
	Servo motor	29880026	2	GENERAL STORES	3435-08/2023	
	Air Intake filter Assly		2	PARKER	O/C1351P/B/RH/02,O/C	
3		29480103			1355P/B/RH/02 PLW-12/23	
4	Insulator Panto Mtg.	29810127	8	IEC	09/23,09/23	
			MIDDLE RO	OF COMPONENT		
5	High Voltage Bushing	29731021	1	EIPL	5270-12-23	
	Voltage Transformer	2965028	1	SADTEM	2023-N-656493	
7	Vacuum Circuit Breaker	25712202	1	AUTOMETER ALLIANCE	AALN/12/2023/013/VCBA/887	
8	Insulator Roof line	29810139	9	IEC	03-23, 03-23	
9	Harmonic Filter	29650033	1	SUNSHINE	1045-12/23	AS Per PO/IRS Conditions
10	Earth Switch	29700073	E	AUTOMETER ALLIANCE	AALN/06/2023/083/ES/101	
11	Surge Arrester	29750052	2		55023-2023,55024-2023	
			Air Bı	rake Components		
12	Air Compressor (A,B)	29511008	2	ELGI	EXJS 921911 A, EXJS 921906-B	
13	Air Dryer	29162051	1	TRIDENT	LD2-01-9709-24	
14	Babby compressor	25513000	1	CEC	7174-03-23	
15	Air Brake Panel	29180016	1	KNORR	24-03-CO-3378	
16	Contoller (A,B)	29180016	2	KNORR	24-01-FO-3282 A, 24-01-FO-3306 B	
17	Breakup Valve	29180016	2	KNORR	-	
18	wiper motor	29162026	4	ELGI		

SSE/ABS

## PLW/PTA

## ELECTRIC LOCO HISTORY SHEET (ECS)

**RLY: ECR** 

SHED: BJU

PROPULSION SYSTEM: CGL

ELECII	AIC LO	20 NO	+1000
LIST OF	ITEMS	FITTED	BY ECS

SN	DESCRIPTION OF ITEM	ITEM PL NO.	ITEM SR. NO C	MAKE/SUPPLIER	
	LED Based Flasher Light Cab I & II	29612937	22635	22816	ALTOS
2	Led Marker Light Cab I & II	29612925	2636/2587/2	2649/2555	KAYSONS
3	Cab Heater Cab I & II	29170011	835	876	ELECOS
	Crew Fan Cab I & II	29470080	4806/4802/4	1779/4884	SARIA
	Master Controller Cab I	29860015	664	.7	WOAMA
6	Master Controller Cab II	29860013	665	6	
7	Complete Panel A Cab I & II	29178265	2886	3319	
8	Complete Panel C Cab I & II	29170539			KEPCO
	Complete Panel D Cab I & II	29178265	3398	3402	
	Complete Cubicle- F Panel Cab I & II	29178162	CUF/771/08/2023	CUF/774/08/2023	KAYSONS
	Speed Ind.& Rec. System	29200040	MTELS2308287/N	MTELM2308287	AAL
	Battery (Ni- Cd)	29680025	1171-1183 8	1197-1209	SAFT URJA
	Set of Harnessed Cable Complete	29600420			KAYSONS
14	Transformer Oil Pressure Sensor (Cab-1) (Pressure Sensor Oil Circuit Transformer)	29500047	TGIC/CLW/2284-JAN2024	TGIC/CLW/2278-JAN2024	TOPGRIP
15	Transformer Oil Pressure Sensor (Cab-2)		TGIC/CLW/2279-JAN2024	TGIC/CLW/2270-JAN2024	
	Transformer Oil Temperature Sensor (Cab-1) (Temperature Sensor Oil Circuit Transformer)	29500035	BG/TFP/4581-FEB-23		BG INDUSTRIES
17	Transformer Oil Temperature Sensor (Cab-2)		BG/TFP/4546-FEB-23		
18	Roof mounted Air Conditioner I	29811028	CLW2	2429	KKI
19	Roof mounted Air Conditioner II	20011020	CLW2	2432	

Issue No. : 05 Effective Date: July-2023

LOCO NO: 41858

DOC NO: F/LAS/Electric Loco CHECK SHEET (Ref: WI/LAS/Elect/01, 02, 03 & 04 & QPL/LAS/Elect. Loco)
Page 1 of 1

### पटियाला रेलइंजन कारखाना, पटियाला PATIALA LOCOMOTIVE WORKS, PATIALA ELECTRIC LOCO CHECK SHEET

RIY: ECR

Shed: BTUE

S. No.	ITEM TO BE CHECKED	Specified Value	0	bserved	Valu	е
	Check proper Fitment of Hotel Load Converter & its output contactor.	OK		- 1	11-	
1.1	Check proper Fitment of Hotel Load Converter & its output contactor.  Check proper Fitment of MR Blower 1 & 2, MR Scavenging Blower 1 & 2, TM Blower 1 & 2, TMB  Scavenging Blower 1 & 2.  TM scavenging blower 1 & 2 & Oil Cooling unit.	OK			14	
1.3	Check proper of Fitment of oil cooling unit (OCU).	OK		0	1-	
1.4	Check proper Fitment of HB 1 & 2 and its respected lower part on its position.	OK		U	14	
1.5	Check proper Fitment of FB panel on its position.	OK		0		
1.6	Check proper Fitment of assembled SB1 & SB2 panel.	OK		0	11_	
1.7	Check proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3).	OK		0		
1.8	Check proper Fitment of Traction converter 1 & 2 (SR-1 & 2).	OK		Q	1	
1.9	Check proper fitment, torquing & Locking of Main Transformer bolt.	OK		d	14	
1.10	Check proper fitment of Main compressor both side with the compressor safety wire rope.	OK		O	12	-
1.11	Check proper resting of Secondary Helical Springs between Bogie & Shell bcdy.	OK OK		C	12	
1.12	Check proper fitment of Bogie Body Safety Chains.					
.13	Check proper fitment of Cow catcher.	OK			14	
1.14	Check coolant level in SR 1 & 2 Expansion Tank.	OK			12	
1.15	Check Transformer Oil Level in both conservators Tank (Breather Tank).	OK			K.	
1.16	Check proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any damage during online working of Locomotives.	OK			IL	
1.17	Check proper fitment of both battery box.	OK			14	
1.18	Check for any gap between Main Transformer mounting base & Loco Shell.	OK		U	14	
1.19	Check proper fitment of Push Pull rod its bolt torquing and fitment of fixing cable.  As per Drg No 1209-01-113-001	OK			X	
1.20	Secondary Vertical and Lateral Clearance on leveled track at the time of Loco Dispatch.		CA	B-1	(	CAB-2
1.20	ELRS/TC/ 0082 (Rev 1) dated 17.09.2015	Vertical-Std	LP	ALP	LP	ALP
	<u> </u>	:35-60 mm	54.	53	52	53
		Lateral Std- 45-50 mm		52	63	36
4.04	Buffer height: Range (1090, +15,-5)	1085-1105		L/S	S	R/S
1.21	Drg No IB031-02002.	mm	FRONT	100	15	1104
	Dig No 15031-02002.		REAR	109		1191
		641 mm	112/111	LUS		R/S
1.22	Buffer Length: Range (641 mm + 3 to 10 mm with buffer face)	641 mm	FRONT	64	-	644
	Drg No-SK.DL-3430.		REAR	643	-	649
				100		
		444 1.5	1100		2	DIC
1.23	Height of Rail Guard (114 mm + 5 mm12 mm).	114 mm + 5		L/S		R/S
1.23		114 mm + 5 mm,-12 mm	FRONT	110	5	115
1.23	Height of Rail Guard (114 mm + 5 mm12 mm).		FRONT REAR	110	5	
1.23	Height of Rail Guard (114 mm + 5 mm12 mm).		FRONT	110	2	115

(Signature of SSE/Elect. Loco (UE))

NAME SATISM KUMAR

DATE 25/04/24

(Signature of SSE/JE/Elect Loco)

NAME SHUBHAM SHARMA

DATE 25/04/24

(Signature of JE/UF)

NAME ANKIT OPPAL

DATE 25/04/29

## **Loco No.** 41858

### 1. BOGIE FRAME:

BOGIE	FRAME NO	Make	PL No.	PO No. & dt.	Warranty Period
FRONT	SL-0050	ECBT	29100677	100360	As per PO/IRS
REAR	SL-0049	ECBT	29100677	100360	conditions

### 2. Hydraulic Dampers PL No. 29040012, Make: KNORR

### 3. AXLES:

AXLE POSITION NO	1	2	3	4	5	6
MAKE/	PLW	PLW	PLW	PLW	PLW	PLW
S.NO	25878	26023	26342	25866	26100	26248
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

### 4. WHEEL DISCS NO. AND TYPE & BULL GEAR

AXLE POSITION NO	1	2	3	4	5	6
GEAR END	DX92-161	DY23-26	DY19-057	DY19-099	DTC0-014	DY23-140
Make	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
FREE END	DX92-018	DX88-130	DY19-042	DY19-188	DTC0-028	DY92-160
Make	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
Bull Gear No.	23-D-43	23-F-21	23-L-29	23-E-07	23-F-31	23-M-27
Bull Gear Make	LMS	LMS	LMS	LMS	LMS	LMS

### 5. AXLE ROLLER BEARING (CRU) (PL No. 29010020, Warranty: As per PO/IRS conditions)

	AXLE POSITION NO	1	2	3	4	5	6
Gear	MAKE	NBC	NBC	NBC	FAG	FAG	FAG
End	PO NO. & dt	02875	02875	02875	2312	2312	2312
Free	MAKE	NBC	NBC	NBC	FAG	FAG	FAG
End	PO NO. & dt	02875	02875	02875	2312	2312	2312

### 6. WHEEL DISC PRESSING (PRESSURE IN KN): SPECIFIED 80-105 T

AXLE POSITION NO	1	2	3	4	5	6
BULL GEAR END	908	927	892	783	1007	853
FREE END	912	938	825	790	896	790

### **Loco No.** 41858

### 7. DIAMETER AFTER PROFILE TURNING: SPECIFIED 1092 + 5 mm - 0 mm

AXLE POSITION NO	1	2	3	4	5	6
DIA IN mm GE	1092.5	1092.3	1092.5	1092.5	1092.5	1092.5
DIA IN mm FE	1092.5	1092.3	1092.0	1092.5	1092.5	1092.5
WHEEL PROFILE GAUGE (1596±0.5mm)	OK	OK	OK	OK	OK	OK

### 8. SUSPENSION TUBE & ITS TAPER ROLLER BEARING:

AXLE POSITION NO		1	2	3	4	5	6
S.T. (PL 29100288)	MAKE	KPE	IN	KPE	KPE	KPE	KPE
G.E. BRG PL 29030110	MAKE	FAG	FAG	FAG	FAG	FAG	FAG
F.E. BRG PL 29030110	MAKE	FAG	FAG	FAG	FAG	FAG	FAG

### 9. GEAR CASE (PL No. 29030018) & BACKLASH:

AXLE POSITION NO	1	2	3	4	5	6
MAKE	KP	KM	KP	KP	KP	KP
BACKLASH (0.254 – 0.458mm)	0.330	0.390	0.300	0.300	0.300	0.310

### 10 A/BOX TO BOGIE FRAME LATERAL CLEARANCES (SPECIFIED 15.0 to 19.0mm):

AXLE POSITION NO	1	2	3	4	5	6
RIGHT SIDE	16.58	17.66	17.52	15.42	17.06	16.52
LEFT SIDE	15.16	15.08	17.32	18.70	15.18	15.51

### 11. TRACTION MOTOR: (PL No. 29940606, Warranty: As per PO/IRS conditions)

AXLE POSITION NO	MAKE	PO No. & date	S. NO.
1	PLW	-	PLW-2583
2	PLW	-	PLW-2559
3	PLW	-	PLW-2564
4	PLW	-	PLW-2568
5	PLW	-	PLW-2557
6	PLW	-	PLW-2590

Q

### TOP 12 COSTLIEST ITEMS OF WAG9HC LOCO WITH WARRANTY CONDITIONS AS PER TENDERS

S No	PL No	DESCRIPTION	Warranty Period
1	29741075	IGBT BASED 3-PHASE DRIVE PROPULSION EQUIPMENT	60 months after commissioning or 72 months from date of supply whichever earlier as per special conditions given by CLW
2	29731057	MAIN TRANSFORMER 7775 KVA TYPE LOT 7500 FOR WAP7 3- PHASE ELECTRIC LOCOMOTIVE TO CLW SPECN NO.CLW/ES/3/0660/C	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
3	29171064	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT- 8	AS PER IRS CONDITIONS-30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER.
4	29600418	LOCOMOTIVES TO CLW SPECN. NO. CLW/ES/03/646  ALT-NIL WITH DMW REQUIREMENT OF HARNESSED	As per clause no.9 of CLW Specn. CLW/ES/3/0458 & Clause No.10 of CLW SpecnCLW/ES/3/0459. [18 months after commissioning or 20 months from date of supply for single core & 18 months after commissioning or 24 months from date of supply for multi core]

7	29942007	3-PHASE ASYNCHRONOUS TRACTION MOTOR (RESISTANCE RING MECHANICALLY INTERLOCKED TO END PLATE DESIGN ROTOR, SCHEME-II), TYPE 6FRA-6068 FOR WAP-7 ELECTRIC LOCO WITHOUT ACTIVE SPEED SENSOR TO SPECIFICATION NO. 4TMS.096.081 ALT-2 AND STR NO. CLW/2008/3PHTM/STR/0001.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
6	29480140	COMPLETE FILTER CUBICLE ALONG WITH ALL EQUIPMENTS AND CABLING TO DRG./SPEC NO. [1] CLW/ES/3/0193 ALT-F OR LATEST AND CLW DRG. NO. 1209-15-143-004 ALT-10 AND PART DRG./SPEC NO AS PER ANNEXURE-A ATTACHED.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
5	29180016	BRAKE CONTROL SYSTEM INCLUDING DRIVER'S VIGILANCE CONTROL DEVICE TO SET LIST NO.EL29180016.	As per specification no. CLW/MS/3/001 Alt. 16 i.e. the manufacturer is required to guarantee that the brakevalves/equipment work satisfactorily for a period of five (5) years after commissioning. Any equipment/part which failsduring the guarantee period shall be replaced free of cost by the manufacturer. The replaced components shallfurther be under warranty for five (5) years from the date of their fitment and should the replaced components proveunsatisfactory in service, they shall be replaced by modified and improved components by the supplier free of cost.

8	29105146	Bogie Frame Complete for WAP-7 for 3 Phase Co Co Locomotive to CLW specification No. CLW/MS/3/Bogie/003 alt-1 and CLW Drg.No.1209.01.112-202 Alt-Nil	As per clause 16 of Spec.No.CLW/MS/3/Bogie/003 Alt-1. [60 months after commissioning or 72 months from date of supply]
9	29171192	COMPLETE AUXILIARY CUBICLE HB2 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0192 ALT-E OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
10	29171210	COMPLETE CONTROL CUBICLE SB2 ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0195/A ALT-H OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
11	29171209	COMPLETE CONTROL CUBICLE SB1 (PUSH PULL SCHEME COMPLIANT) ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0194 ALT-G OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
12	29171180	COMPLETE AUXILIARY CUBICLE HB1 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0191 ALT-D OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.



#### भारत सरकार **GOVERNMENT OF INDIA**

रेल मंत्राल्य

#### MINISTRY OF RAILWAYS

PATIALA LOCOMOTIVE WORKS

पटियाला रेलइंजन कारखाना

Email: dyceeloco.dmw@gmail.com फैक्स/Fax No.: 0175-2397244

फोन/ Phone: 0175- 2396422 मोबाईल: 9779242310 पटियाला. 147003, भारत PATIALA, 147003, INDIA



(An ISO 9001, ISO 14001, ISO 45001 & ISO 50001, 5S & Green Building certified Organization)

संख्या. PLW/M/ECS/Tech/Kavach

तिथि: 21.05.2024

(Through Mail)

Sr. Div. Electrical Engineer, Electric Loco Shed, Barauni.

Email: srdeetrsbju@gmail.com

विषय:- Fitment of KAVACH in three Phase Electric Loco. No. 41858 WAG9-HC.

संदर्भ:- (i)Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 21.08.2023.

(ii)Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 26.09.2023

In ref. to the above letter's Loco No. 41858 has been dispatched with fittings for implementation of KAVACH system in locomotive at home shed in Zonal Railway. This Loco was dispatched to ELS/BJU/ECR on 25.04.2024. The details of fittings are attached as Annexure-A (pneumatic fittings), Annexure-B (Kavach equipment mounting Brackets) & Annexure-C (Wago with harnessed lay out).

This is for your information & necessary action please.

उप मुख्य विदयुत अभियंता/लोको

#### प्रतिलिपि:-

PCEE: for kind information please CELE/ECR:- for kind information please

CEE/Loco & CEE/D&Q, CMM, CPLE:- for kind information please Dy CME/Planning: for information & necessary action please Dy CEE/Design: for information & necessary action please Dy CME/Design: for information & necessary action please AWM/LAS&ABS: for information & necessary action please

AWM/ECS: to monitor & supply of rest of the items as mentioned above for Kavach to all the concerned Electric Loco Sheds and maintain the record.

Secy. to PCAO for kind information of PCAO please.

AWM/LFS: for information & necessary action please

### Loco No. 41858

List of balance items of KAVACH pneumatic pipes & fitting yet to be supplied later on. These items are currently under procurement process at PLW. The same will be advised to the shed for collection of the material as soon as it will be received at PLW.

3N	PL No.	Description of item	Qty.
		ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITH VENT	04 nos.
1	29163341	ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITHOUT VENT	02 nos.
		TEE UNION 3/8"X3/8"X3/8" BRASS FITTINGS	02 nos.
		MALE CONNECTORS 3/8" TUBE OD X 3/8" BSPT, BRASS FITTINGS	09 nos.
		MALE CONNECTORS 1/2" TUBE OD X 1/2" BSPT, BRASS FITTINGS	06 nos.
		FEMALE CONNECTORS (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	01 no.
		MALE CONNECTOR (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	03 nos.
2	29611994	FEMALE TEE 3/8" BSPP – BRASS	06 nos.
		HEX PLUG -3/8" BSPT – BRASS	02 nos.
		FEMALE TEE 1/2" BSPP – BRASS	04 nos.
		HEX NIPPLE 3/8X3/8" BSPT – BRASS	04 nos.
		RED HEX NIPPLE 3/8X1/2" BSPT - BRASS	02 nos.
		HEX PLUG – 1/2" BSPT – BRASS	04 nos.
		MALE ELBOW CONNECTORS 3/8" TUBE OD X 3/8) BSPT. BRASS FITTINGS	02 nos.
3	29170114	Copper Tube OD 9.52mm (3/8" ) X 1.245 Mm W.T X 6 Mtr	1.2 Mtr

AWMIABS

SSE/G/ABS

SN	PL No.	Description of item	Quantity
1.	29611945	Mounting bracket arrangement provided for RF Antenna on the roof top of both driver cabs.	04 nos.
2.		Mounting bracket arrangement provided for GPS/GSM Antenna on the roof top of both driver cabs.	02 nos.
3.		Protection Guards for RFID reader provided behind the cattle guards of both side.	02 nos.
4.		Inspection door with latch provided on the both driver desk covers (LP side) in each cab to access isolation cock.	02 nos.
5.		Cable Entry Plate fitted for routing of cable with RF Antenna & GPS/GSM Antenna bracket.	06 nos.
6.	-	WAGO bracket fitted in Machine room at back side of SB-1.	01 no.
7.	-	One circular hole of 80 mm dia. provided in each cabs on LP side behind the driver desk toward the wall for routing of OCIP (DMI) cables.	02 nos.
8.	_	80 mm holes provided on TM1 and TM6 Junction box inspection cover hole for drawing of RFID reader cables.	02 nos.
9.		DIN Rail fitted inside the driver desk (LP Side)	02 nos.

pend AWW/LFS

SSE/G/LFS

### Annexure-C

SN	PL No.	Description of item	Quantity
1	42310301	Flexible conduit size 25mm <sup>2</sup> provided for RF-1, 2 & GPS Antenna cable layout from CAB-1&2 to Machine room.	06 nos.
2.	29611982	Wago terminals in CAB-1&2 (25 nos. in each CAB).	50 nos.
3.	29611982	Wago terminal in Machine room at back side of SB-1.	75 nos.
4.	-	Harness provided from KAVACH SB to SB-1	05 wires
5.	-	Harness provided from KAVACH SB to SB-2	05 wires
6.	-	Harness provided from KAVACH SB to Pneumatic Panel	12 wires
7.	_	Harness provided from KAVACH SB to CAB-1	24 wires
8.	<u> </u>	Harness provided from KAVACH SB to CAB-2	16 wires

AWM/ECS

SSE/G/ECS