भारतीय रेल Indian Railways

पटियाला रेलइंजन कारख़ाना, पटियाला

PATIALA LOCOMOTIVE WORKS, PATIALA



LOCO TESTING & DISPATCH REPORT OF IGBT BASED WAG9HC ELECTRIC LOCOMOTIVE

LOCO NO.: 41974

TYPE: WAG9HC

RAILWAY SHED: NR/KJGE

PROPULSION SYSTEM: MEDHA

DATE OF DISPATCH: 29.11.2024

लोको निर्माण रिकार्ड



पटियाला रेलइंजन कारख़ाना, पटियाला PATIALA LOCOMOTIVE WORKS, PATIALA

LOCO NO.: 41974

RAILWAY/SHED: NR/KJGE

DOD: Nov-2024

INDEX

SN	PARA	ACTIVITIES	PAGE NO.
•		Testing & Commissioning (ECS)	<u>.</u>
1.	1.0	Continuity Test of the cables	
	1.1	Continuity Test of Traction Circuit Cables	
	1.2	Continuity Test of Auxiliary Circuit Cables	1-4
	1.3	Continuity Test of Battery Circuit Cables	
	1.4	Continuity Test of Screened Control Circuit Cables	
2.	2.0	Low Tension test	
	2.1	Measurement of resistor in OHMS (Ω)	5-6
	2.2	Check Points	5-6
	2.3	Low Tension Test Battery Circuits (without control electronics)	
3	3.0	Downloading of Software	
	3.1	Check Points	
	3.2	Download Software	7-10
	3.3	Analogue Signal Checking	
	3.4	Functional test in simulation mode	
4	4.0	Sensor test & convertor test	
	4.1	Test wiring Transformer Circuits – Polarity Test	
	4.2	Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)	
	4.3	Primary Voltage Transformer	
	4.4	Minimum voltage relay (Pos. 86)	11-16
	4.5	Maximum current relay (Pos. 78)	11-10
	4.6	Test current sensors	
	4.7	Test DC Link Voltage Sensors (Pos 15.6/*)	
	4.8	Verification of Converter Protection Circuits (Hardware limits)	
	4.9	Sequence of BUR contactors	
5.	5.0	Commissioning with High Voltage	
	5.1	Check List	
	5.2	Safety test main circuit breaker	
	5.3	Auxiliary Converter Commissioning	
	5.3.1	Running test of 3 ph. auxiliary equipments	
	5.3.2	Performance of Auxiliary Converters	
	5.3.3	Performance of BURs when one BUR goes out	16-25
	<i>5.4</i>	Auxiliary circuit 415/110	
	5.5	Hotel Load Circuit	
	5.6	Traction Converter Commissioning	
	5.7	Test protective shutdown SR	
	5.8	Test Harmonic Filter	
	5.9	Test important components of the locomotive	
6.	6.0	Running Trial of the locomotive	25-26
7.	7.0	Final Check List to be verified at the time of Loco dispatch	27
8.	8.0	Status of RDSO modifications	28
9.	1-10	Pneumatic Test Parameters	29 - 32
10.		Loco Check Sheet(LAS)	33
11.	-	Component History (LAS,ECS,ABS)	34-36
12.	-	Component History & Testing Parameter (Bogie Shop)	37 - 38
13	-	Warranty Conditions as per Tenders	39 -41

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41974 - MEDHA

1.0 Continuity Test of the cables

Type of Locomotive: WAP-7/WAG-9HC

Page: 1 of 27

1.1 Continuity Test of Traction Circuit Cables

As per cable list given in Para 1.3 of document no. 3 EHX 410 124, check the continuity with continuity tester and megger each cable to be connected between following equipment with 1000V megger.

From	То	Continuity (OK/Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Filter Cubicle	Transformer	OK	100 ΜΩ	650ma
Filter Cubicle	Terminal Box of Harmonic Filter Resistor (Roof)	Ok	100 ΜΩ	.650MA
Filter Cubicle	Earthing Choke	OK	100 ΜΩ	600 MM.
Earthing Choke	Earth Return Brushes	OK	100 ΜΩ	600 M()
Transformer	Power Converter 1	OK	100 ΜΩ	150MA
Transformer	Power Converter 2	OK	100 ΜΩ	600 M9
Power Converter 1	TM1, TM2, TM3	OK	100 ΜΩ	600 MA
Power Converter 2	TM4, TM5, TM6	OK	100 ΜΩ	650 m1
Earth	Power Converter 1	OK	100 ΜΩ	600MA
Earth	Power Converter 2	OK	100 ΜΩ	bsom

1.2 Continuity Test of Auxiliary Circuit Cables

As per cable list given in Para 1.4 of document no. 3 EHX 410 124, check the continuity with continuity meter and megger each cable to be connected between following equipment with the help of 1000V megger.

Signature of the JE/SSE/Harness

Signature of the JE/SSE/Loco Cabling

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41974

Type of Locomotive: WAP-7/WAG-9HC

Page: 2 of 27

From	То	Continuity(OK/ Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Transformer	BUR1	OK	100 MΩ	700ms
Transformer	BUR2	OK	100 MΩ	600 Mr
Transformer	BUR3	OK	100 MΩ	500 mr
Earth	BUR1	OK	100 MΩ	600 m
Earth	BUR2	. OK	100 ΜΩ	600 mg
Earth	BUR3 .	OK	100 ΜΩ	700 M2
BUR1	HB1	OK	100 M Ω	600 mr
BUR2	HB2	OK	100 MΩ	500 MM
HB1	HB2 •	OK	100 MΩ	SODM
HB1	TM Blower 1	OK	100 ΜΩ	600m
HB1	TM Scavenge Blower 1	OK	100 ΜΩ	700m2
HB1	Oil Cooling Unit 1	OK	100 M Ω	SOO ML
HB1	Compressor 1	OK	100 M Ω	600 mm
HB1	TFP Oil Pump 1	OK	100 MΩ	700 ML
HB1	Converter Coolant Pump 1	OK	100 MΩ	600 ML
HB1	MR Blower 1	OK	100 MΩ	SOOM
HB1	MR Scavenge Blower 1	OK.	100 MΩ	700M2
HB1	Cab1	OK	100 M Ω	SUOMA
Cab1	Cab Heater 1	OK	100 MΩ	700 Ms_
HB2	TM Blower 2	OK	100 MΩ	600 Mr
HB2	TM Scavenge Blower 2	OK	100 MΩ	700 M
HB2	Oil Cooling Unit 2	OK	100 MΩ	600 m
HB2	Compressor 2	OK	100 ΜΩ	600 M
HB2	TFP Oil Pump 2	OK	100 MΩ	commo
HB2	Converter Coolant Pump 2	OK	100 MΩ	Looma
HB2	MR Blower 2	OK.	100 ΜΩ	500 M2
HB2	MR Scavenge Blower 2	OK	100 ΜΩ	600 ML
HB2	Cab2	OK	100 ΜΩ	700 M
Cab2	Cab Heater 2	OK	100 ΜΩ	600 MM

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41874

Type of Locomotive: WAP-7/WAG-9HC

1.3 Continuity Test of Battery Circuit Cables

Page: 3 of 27

Check continuity of following cables as per Para 2.3 of document no. 3 EHX 610 299

From	То	Condition	Continuity (OK/Not OK)
Battery (wire no 2093)	Circuit breakers 110- 2, 112.1-1, 310.4-1	By opening and closing MCB 112	OK
MCB 110	Connector 50.X7-1	By opening and closing MCB 110	°K .
Battery (Wire no. 2052)	Connector 50.X7-2		عد
SB2 (Wire no 2050)	Connector 50.X7-3		2)(

Close the MCB 112, 110, 112.1, and 310.4 and	Prescribed value	Measured
measure the resistance of battery wires 2093, 2052, 2050 with respect to the loco earth.	> 0.5 MΩ	Value <u>7</u> ΜΩ
Measure the resistance between 2093 & 2052, 2093 & 2050, 2052 &	Prescribed value:	Measured
2050	> 50 MΩ	Value <u>70</u> ΜΩ

Commission the indoor lighting of the locomotive as per Sheet No 7A & 7B.

1.4 Continuity Test of Screened Control Circuit Cables

Check the continuity and isolation of the screen cable of the following circuits with the help of sheet no. mentioned against each as per document no. 3 EHX 610 299.

Screened control circuit cables for	Corresponding Sheet Nos.	Continuity & Isolation (OK/Not OK)
Battery voltage measurement	04B	OK
Memotel circuit of cab1 &2	10A	9L
Memotel speed sensor	10A	9K
Primary voltage detection	01A, 12A	2K.
Brake controller cab-1 & 2	06F, 06G	9K

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41874

Type of Locomotive: WAP-7/WAG-9HC

Page: 4 of 27

Master controller cab-1 &2	08C, 08D	OK
TE/BE meter bogie-1 & 2	08E, 08F	. OK
Terminal fault indication cab-1 & 2	09F	٥٢
Brake pipe pressure actual BE electric	06Н	عد
Primary current sensors	12B, 12F	5K
Harmonic filter current sensors	12B, 12F	ο <u>κ</u> .
Auxiliary current sensors	12B, 12F	9K
Oil circuit transformer bogie 1	12E, 12I	3K
Magnetization current	12C, 12G	92
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-1	12D	° X
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-2	12D	οκ.
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-3	12D	a a
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-4	12H	ØK.
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-5	12H	ЭK,
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-6	12H	· &
Train Bus cab 1 & 2 (Wire U13A& U13B to earthing resistance= 10KΩ± ± 10%)	13A	^U K
UIC line	13B	o _K
Connection FLG1-Box TB	13A	O,c.

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/974 2.0 Low Tension test

Type of Locomotive: WAP-7/WAG-9HC

Page: 5 of 27

2.1 Measurement of resistor in OHMS (Ω)

Measure the resistances of the load resistors for primary voltage transformer, load resistors for primary current transformer and Resistor harmonic filter as per Para 3.2 of the document no. 3 EHX 610 279.

Name of the resistor	Prescribed value	Measured value
Load resistor for primary voltage transformer (Pos. 74.2).	3.9K Ω ± 10%	3.9Kn
Resister to maximum current relay.	1 Ω ± 10%	1-2
Load resistor for primary current transformer (Pos. 6.11).	3.3 Ω ± 10%	3.3sl
Resistance harmonic filter (Pos 8.3). Variation allowed \pm 10%	WAP7	WAP7
Between wire 5 & 6	0.2 Ω	0.22
Between wire 6 & 7	0.2 Ω	0.21
Between wire 5 & 7	0.4 Ω	0.42
For train bus, line U13A to earthing.	10 kΩ± 10%	10.00
For train bus, line U13B to earthing.	10 k Ω ± 10%	939 <i>1</i> =2
Insulation resistance of High Voltage Cable from the top of the roof to the earth (by1000 V megger).	200 ΜΩ	BOOMN
Resistance measurement earth return brushes Pos. 10/1.	≤0.3 Ω	0.28-72
Resistance measurement earth return brushes Pos. 10/2.	≤0.3 Ω	0:281
Resistance measurement earth return brushes Pos. 10/3.	≤0.3 Ω	0.30%
Resistance measurement earth return brushes Pos. 10/4.	≤0.3 Ω	0.281
Earthing resistance (earth fault detection) Harmonic Filter –I; Pos. 8.61.	2.2 kΩ± 10%	2.212
Earthing resistance (earth fault detection) Harmonic Filter –II; Pos 8.62.	2.7 k Ω ± 10%	2.7K2
Earthing resistance (earth fault detection) Aux. Converter; Pos. 90.3.	3.9 k Ω ± 10%	3.8 Kr
Earthing resistance (earth fault detection) 415/110V; Pos. 90.41.	1.8 k Ω± 10%	1.8kv
Earthing resistance (earth fault detection) control circuit; Pos. 90.7.	390 Ω ± 10%	3402
Earthing resistance (earth fault detection) Hotel load; Pos. 37.1(in case of WAP5).	3.3 k Ω ± 10%	MA
Resistance for headlight dimmer; Pos. 332.3.	10 Ω ± 10%	10.5

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41974

Type of Locomotive: WAP-7/WAG-9HC

Page: 6 of 27

Make sure that the earthing brush device don't make direct contact with the axle housing,

earth connection must go by brushes.

2.2 Check Points

Items to be checked	Remarks		
Check whether all the earthing connection in roof and machine room as mentioned in sheet no. 22A is done properly or not. These earthing connections must be flexible and should be marked yellow & green	cheked ou		
Check whether all the earthing connection between loco body and bogie is done properly or not. These cables must be flexible having correct length and cross section	Cheeked ox		

2.3 Low Tension Test Battery Circuits (without control electronics)

These tests are done with the help of the special type test loop boxes as per procedure given in Para 3.6 of the document no. 3 EHX 610 279

Name of the test	Schematic used.	Remarks
Test 24V supply	Sheet 04F and other linked sheets	cheeked or
Test 48V supply	Sheet 04F & sheets of group 09	Fan supply to be checked.
Test traction control	Sheets of Group 08.	QC.
Test power supply bus stations.	Sheets of Group 09.	Fan supply to be checked.
Test control main apparatus	Sheets of Group 05.	SK.
Test earth fault detection battery circuit by making artificial earth fault to test the earth fault detection	Sheet 04C	OK
Test control Pneumatic devices	Sheets of Group 06	QK
Test lighting control	Sheets of Group 07	9K
Pretest speedometer	Sheets of Group 10	OK.
Pretest vigilance control and fire system	Sheets of Group 11	OK
Power supply train bus	Sheets of Group 13	0k

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41974

Type of Locomotive: WAP-7/WAG-9HC

Page: 7 of 27

LOCO	monae Mo"	1 '		1
3.0	Downloading	g of	Soj	ftware

3.1 Check Points.	Yes/No
Check that all the cards are physically present in the bus stations and all the plugs are connected.	Yes
Check that all the fibre optic cables are correctly connected to the bus stations.	Yey
Make sure that control electronics off relay is not energized i.e. disconnect Sub-D 411.LG and loco is set up in simulation mode.	Yey
Check that battery power is on and all the MCBs (Pos. 127.*) in SB1 &SB2 are on	Yes

3.2 Download Software

The software of Traction converter, Auxiliary converter and VCU should be done by commissioning engineer of the firm in presence of supervisor. Correct software version of the

propulsion equipment to be ensured and noted:

Traction converter-1 software version:	1.09
Traction converter-2 software version:	1.09
Auxiliary converter-1.software version:	1.04
Auxiliary converter-2 software version:	1.04
Auxiliary converter-3 software version: •	1.04
Vehicle control unit -1 software version:	3.0
Vehicle control unit -2 software version:	3,0

· 3.3 Analogue Signal Checking

Check for the following analogue signals with the help of diagnostic tool connected with loco.

Description	Signal name	Prescribed value	Measured Value
Brake pipe pressure	FLG2;0101XPrAutoBkLn	100% (= 5 Kg/cm2)	OK
Actual BE electric	FLG2; AMSB_0201- Wpn BEdem	100% (= 10V)	QL.
TE/BE at 'o' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 9% and 11%	11.1.
TE/BE at 'TE maximal' position from both cab	1 EG2, Thirisb_0101" Ading Italis	Between 99 % and 101 %	101/
TE/BE at 'TE minimal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 20 % and 25 %	257

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/974

Type of Locomotive: WAP-7/WAG-9HC

Page: 8 of 27

	ELCI ANCE MAN	ı	1
TE/BE at 'BE maximal'	FLG1; AMSB_0101-		_
position from both cab	XangTrans	Between 99% and 101%	100%
1	FLG2; AMSB_0101-		
· -	XangTrans		
TE/BE at 'BE Minimal'	FLG1; AMSB_0101-	·	
position from both cab	XangTrans	Between 20% and 25%	257.
'	FLG2; AMSB_0101-		ĺ
	XangTrans	·	
TE/BE at '1/3' position	HBB1; AMS_0101-		
in TE and BE mode in	LT/BDEM>1/3	Between 42 and 44%	484.
both cab.	HBB2; AMS 0101-		` '
BOTH CUB.	LT/BDEM>1/3		
TE/BE at '1/3' position	LIDD1, AMC 0101		
in TE and BE mode in	HBB1; AMS_0101- LT/BDEM>2/3	Between 72 and 74%	741
both cab.		Detween 72 and 74%	17
Both cas.	HBB2; AMS_0101-		
	LT/BDEM>2/3		
Both temperature	SLG1; AMSB 0106-	Between 10% to 11.7% depending	
sensor of TM1	XAtmp1Mot	upon ambient temperature	ا به د
001.50, 01 1.1.2	1	0°C to 40°C	·
,		Between 10% to 11.7% depending	
		upon ambient temperature 0°C to	140
Both temperature	SLG1; AMSB_0106-	40°C	
sensor of TM2	Xatmp2Mot		·
·			
' .		Between 10% to 11.7% depending	. 90
Both temperature	SLG1; AMSB 0106-	upon ambient temperature 0°C to 40°C	14.5°C
sensor of TM3	Xatmp3Mot	40 0	
SCHSOLOL HAIS	Manipsiviot		
		Between 10% to 11.7% depending	
		upon ambient temperature 0°C to	1400
Both temperature	SLG2; AMSB_0106-	40°C	14
sensor of TM4	XAtmp1Mot	"	
	<u> </u>		
		Between 10% to 11.7% depending	
Dath to as a	OT CO. ANADD OLOC	upon ambient temperature 0°C to	1400
Both temperature	SLG2; AMSB_0106-	40°C	•
sensor of TM5	Xatmp2Mot		
n il i	CL CO. ANGD. 0106	Detugen 100/ to 11 70/ depending	
Both temperature	SLG2; AMSB_0106-	Between 10% to 11.7% depending	1400
sensor of TM6	Xatmp3Mot	upon ambient temperature 0°C	
	<u> </u>	to 40 ^o C	

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41874

Type of Locomotive: WAP-7/WAG-9HC

Page: 9 of 27

3.4 Functional test in simulation mode

Conduct the following functional tests in simulation mode as per Para 5.5 of document no.3EHX 610 281. through the Diagnostic tool/laptop:

Test Function	Result desired in sequence	Result obtained
Emergency shutdown through	VCB must open.	cheeredor
emergency stop switch 244	Panto must lower.	Cheston
Shut Down through cab activation	VCB must open.	٠, ١
switch to OFF position	Panto must lower.	Cheexador
Converter and filter contactor	FB contactor 8.41 is closed.	7
operation with both Power	By moving reverser handle:	V
Converters during Start Up.	Converter pre-charging contactor	1
	12.3 must close after few seconds.	
	• Converter contactor 12.4 must close.	o cheekedor
	Converter re-charging contactor	p
	12.3 must opens.	
	By increasing TE/BE throttle:	
4	• FB contactor 8.41 must open.	
	FB contactor 8.2 must close.	
	• FB contactor 8.1 must close.)
Converter and filter contactor		1
operation with both Power	,	
Converters during Shut Down.	VCB must open.	
	Panto must lower.	1 - energion
	• Converter contactor 12.4 must open.	chord on
	• FB contactor 8.1 must open.	
	• FB contactors 8.41 must close.	
:	• FB contactor 8.2 must remain closed.	
)
	<u> </u>	1

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/874

Type of Locomotive: WAP-7/WAG-9HC

Page: 10 of 27

	·	
Contactor filter adaptation by	Isolate any one bogie through bogie ()
isolating any bogie	cut out switch. Wait for self-test of	1
	the loco.	1
	 Check that FB contactor 8.1 is open. 	2 1 1 27
·	• Check that FB contactor 8.2 is open.	crosped ox
	After raising panto, closing VCB, and	T
	setting TE/BE	
	• FB contactor 8.1 closes.	N.
	• FB contactor 8.2 remains open.	1)
Test earth fault detection battery	By connecting wire 2050 to	{
circuit positive & negative	earth, create earth fault	11
	negative potential.	}
	message for earth fault	cheroda
	By connecting wire 2095	8
	to earth, create earth	1
	·	
	fault positive potential.	
	message for earth fault	
Tost fire quetore Create a smalle in	M/han analya aanan 4	∦
Test fire system. Create a smoke in	When smoke sensor-1 gets	4)
the machine room near the FDU.	activated then	V
Watch for activation of alarm.	Alarm triggers and fault	
	message priority 2	
	appears on screen.	closed or
·	When both smoke sensor	P
	1+2 gets activated then	ľ
	A fault message priority	
	1 appears on screen and	
	lamp LSF1 glow.	đ
	Start/Running interlock occurs and	
	TE/BE becomes to 0.	j
Time, date & loco number	Ensure correct date time and Loco	
	number	ac
		<u> </u>

Effective Date: Feb 2022

Doc.No.F/ECS/01

e: Feb 2022 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/874

Type of Locomotive: WAP-7/WAG-9HC

4.0 Sensor Test and Converter Test

Page: 11 of 27

4.1 Test wiring main Transformer Circuits

Apply $198V_p/140V_{RMS}$ to the primary winding of the transformer (at 1u; wire no. 2 at surge arrestor and at 1v; wire no. 100 at earthing choke). Measure the output voltage and compare the phase of the following of the transformers.

Output Winding nos.	Description of winding.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
2U ₁ & 2V ₁	For line converter bogie 1 between cable 801A- 804A	10.05V _p and same polarity	10.0400	ία.
2U ₄ & 2V ₄	For line converter bogie 1 between cable 811A- 814A	10.05V _p and same polarity	10.0440	ak
2U ₂ & 2V ₂	For line converter bogie 2 between cable 801B- 804B	10.05V _p and same polarity	10.0548	OK
2U ₃ & 2V ₃	For line converter bogie 2 between cable 811B- 814B	10.05V _p and same polarity	10.05/10	٥κ
2U _B & 2V _B	For aux. converter 1 between cable 1103- 1117 (in HB1) For Aux converter 2 between cable 1103- 1117 (in HB2)	7.9V _p , 5.6V _{RMS} and same polarity.	7.88P 5-58Pm3	on
2U _F & 2V _F	For harmonic filter between cable 4-12 (in FB)	$9.12V_{\rm p}$, $6.45V_{\rm RMS}$ and same polarity.	9.11VP 6.44Vens	9K

4.2 Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)

Apply $141V_p$ / $100V_{RMS}$ to input of the auxiliary transformer at cable no 1203 –1117 and measure the output at

Description of wire no.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
Cable no. 1218 - 1200	$58.7V_p$, $41.5V_{RMS}$ and opposite polarity.	58.60P 41.5VRMJ1	OK.
Cable no. 1218 – 6500	15.5V _p , 11.0V _{RMS} and opposite polarity.	15-478	OK
	•	11.03/00	•

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4,874

Type of Locomotive: WAP-7/WAG-9HC

Page: 12 of 27

4.3 Primary Voltage Transformer

Apply $250V_{eff}/350V_p$ by variac to roof wire 1 and any wire 0 and measure the magnitude and polarity of the output of the primary voltage transformer for both bogies as per the procedure specified and suggested by the traction converter manufacturer. Primary voltage measurement converters (Pos. 224.1/*) & catenary voltmeter (Pos. 74/*)

This test is to be done for each converter.

Activate cab in driving mode and supply 200V_{RMS} through variac to wire no 1501 and 1502. Monitor the following parameters through Diagnostic tool and in catenary voltmeter.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	25kV	250%	2542	250/
SLG2_G 87-XUPrim	25 kV	250%	25KV	2504.

Decrease the supply voltage below $140 V_{RMS}$. VCB must open at this voltage. In this case the readings in Diagnostic Tool and catenary voltmeter will be as follows.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	17kV	170%	17KV	1707/
SLG2_G 87-XUPrim	17 kV	170%	17KV	1707

Reactivate VCB to on by increasing this voltage to 175% (17.5 kV).

Increase the supply to 240 V_{RMS} through variac. VCB must open at this voltage, In this case the readings in diagnostic tool and catenary voltmeter will be as follows:

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1_G 87-XUPrim	30kV	300%	30KV	300%
SLG2 G 87-XUPrim	30 kV	300%	30KV	300-/

Reactivate VCB to on by decreasing this voltage to 290% (29 kV).

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41874

Type of Locomotive: WAP-7/WAG-9HC

Page: 13 of 27

4.4 Minimum voltage relay (Pos. 86)

Functionality test:

Minimum voltage relay (Pos. 86) must be adjusted to approx 68%		
Activate loco in cooling mode. Check Power supply of 48V to minimum voltage relay. Disconnect primary voltage transformer (wire no. 1511 and 1512) from load resistor (Pos. 74.2) and connect variac to wire no. 1501 and 1502. Supply 200V _{RMS} through variac. In this case; <i>Minimum voltage relay (Pos. 86) picks up</i>	√(Yes/No)	
Try to activate the cab in driving mode:	(Yes/No)	
Contactor 218 do not close; the control		
electronics is not be working.		
Turn off the variac :	(Yes/No)	
Contactor 218 closes; the control electronics is be		
working . Test Made a Veltage Brets ties		
<u>Test Under Voltage Protection</u>	<u>;</u>	
Activate the cab in cooling mode; Raise panto;	(Yes/No)	
Supply 200V _{RMS} through variac to wire no. 1501		
& 1502; Close the VCB; Interrupt the supply		
voltage	·	
The VCB goes off after 2 second time delay.		
Again supply 200V _{RMS} through variac to wire no.	(Yes/No)	
1501 & 1502; Decrease the supply voltage below		
140V _{RMS} ± 4V;		
Fine tune the minimum voltage relay so that VCB opens.		

4.5 Maximum current relay (Pos. 78)

	· · · · · · · · · · · · · · · · · · ·
Disconnect wire 1521 & 1522 of primary current translated with the session of primary current translated with the session of contact 136.3; Close VCB; supply 3.6A _{RMS} at the maximum current relay Pos. 78 for correct over current	simulation for driving mode; Open $R_3 - R_4$ open wire 1521; Tune the drum of the
VCB opens with Priority 1 fault message on display.	4Yes/No)
Keep contact R_3 – R_4 of 136.3 closed; Close VCB; Tune t /9.9 A_p at the open wire 1521;	the resistor 78.1 for the current of 7.0A _{RMS}
VCB opens with Priority 1 fault message on display.	(Yes/No)

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41974

Type of Locomotive: WAP-7/WAG-9HC

Page: 14 of 27

4.6 Test current sensors

Name of the sensor	Description of the test	Prescribed value	Set/Measured value
Primary return current sensor (Test-1,Pos.6.2/1 & 6.2/2)	Activate cab in driving mode supply 10A. Measure the current through diagnostic tool or measuring print.	(Variation allowed is ± 10%)	1
Primary return current	Supply 90mA _{DC} to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		}
sensor (Test-2, Pos.6.2/1 & 6.2/2)	Supply 297mA _{DC} to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)	· · · <u> · · · · · · · · · · · · · ·</u>	2-99308
Auxiliary winding current sensor (Pos. 42.3/1 & 42.3/2)	Supply 90mA _{DC} to the test winding of sensor through connector 415.AC/1or 2 pin no. 7(+) & 8(-) Supply 333mA _{DC} to the test winding of		
	sensor through connector 415.AC/1 or 2 pin no. 7(+) & 8(-)	_	335mg
Harmonic filter current sensors (Pos.8.5/1 &8.5/2)	Supply 90mA _{DC} to the test winding of sensor through connector 415.AE/1or 2 pin no. 7(+) & 8(-)		
	Supply 342mA _{DC} to the test winding of sensor through connector 415.AE/1or 2 pin no. 7(+) & 8(-)		346mm
Hotel load current sensors (Pos. 33/1 &	Switch on hotel load. Supply 90mA _{DC} to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)	НA	HA
33/2)	Supply 1242mA _{DC} to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)	NA	HA

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/874

Type of Locomotive: WAP-7/WAG-9HC

Page : 15 of 27

4.7 Test DC Link Voltage Sensors (Pos 15.6/*)

This test is to be done by the commissioning engineer of the firm if required.

4.8 Verification of Converter Protection Circuits (Hardware limits) -

This test is to be done as per para 6.17 of the document no. 3EHX 610 282 for both the converters.

Protection circuits	Limit on which shutdown should take place	Measured limit
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 1	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= C For 18.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 2	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 8.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=
Fibre optic failure In Power Converter1	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	QL.
Fibre optic failure In Power Converter2	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	OK

4.9 Sequence of BUR contactors

The sequence of operation of BUR contactors for 'ALL BUR OK' BUR 1 out BUR 2 out and BUR 3 out condition has to be verified by putting the Loco in driving mode (VCB should not be closed) and isolating the BURs one by one. In these condition following will be the contactor sequence.

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	Close	Open	Close	Open	Close	Open	Close	Close	Open
BUR1 off	Close	Open	Close	Close	Open	Close	Open	Open	Close
BUR2 off	Open	Open	Close	Close	Close	Close	Open .	Open	Close
BUR3 off	Open	Close	Open	Close	Close	Close	Open	Open	Close

of the

Effective Date: Feb 2022

Doc.No.F/ECS/01
(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41874

Type of Locomotive: WAP-7/WAG-9HC

Page: 16 of 27

Monitored contactor sequence

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	closs.	open	cless	open	close	den	clos	clos	open
BUR1 off	close	open	clos	cles	Opco	close	Open	Орси	close
BUR2 off	clos	Open	Clos	CD58	Clos	Clos	open	open	Clos
BUR3 off	open	Clos	open	close	Close	closo	open	open	clos-

5.0 Commissioning with High Voltage

5.1 Check List

Items to be checked	Yes/No
Fibre optic cables connected correctly.	Yey
No rubbish in machine room, on the roof, under the loco.	16
All the electronic Sub-D and connectors connected	Yey
All the MCBs of the HB1 & HB2 open.	Yes
All the three fuses 40/* of the auxiliary converters	Yes
The fuse of the 415/110V auxiliary circuit (in HB1) open.	Yoy
Roof to roof earthing and roof to cab earthing done	1
Fixing, connection and earthing in the surge arrestor done correctly.	Yes
Connection in all the traction motors done correctly.	Xay
All the bogie body connection and earthing connection done correctly.	Yey
Pulse generator (Pos. 94.1) connection done correctly.	%
All the oil cocks of the gate valve of the transformer in open condition.) Kij
All covers on Aux & Power converters, Filter block, HB1, HB2 fitted	16,
KABA key interlocking system.	78-5

5.2 Safety test main circuit breaker

Prepare to switch off the catenary supply during the first charging of the locomotive in case of any unexpected behavior of the electrical component of the loco. Charge the loco for the first time by closing BLDJ switch. The VCB will trip after certain time as no oil/coolant pumps are running yet.

Perform the following safety test of main circuit breaker through both the cabs of the locomotive.

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/874

Type of Locomotive: WAP-7/WAG-9HC

Page: 17 of 27

	·		
Name of the test	Description of the test	Expected result	Monitored result
Emergency stop in cooling mode	Raise panto in cooling mode. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	cheeted an
Emergency stop in driving mode	Raise panto in driving mode in. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	checkedox
Under voltage protection in cooling mode	Raise panto in cooling mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open.	Chleked a
Under voltage protection in driving mode	Raise panto in driving mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open with diagnostic message that catenary voltage out of limits	cheeted on
Shut down in cooling mode.	Raise panto in cooling mode. Close the VCB. Bring the BL- key in O position.	VCB must open. Panto must lower.	Charteel
Shutdown in driving mode	Raise panto in driving mode. Close the VCB. Bring the BL-key in O position.	VCB must open. Panto must lower.	cheeredy
Interlocking pantograph- VCB in cooling mode	Raise panto in cooling mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	Charkeil a
Interlocking pantograph- VCB in driving mode	Raise panto in driving mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	Cheeked on

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/874

Type of Locomotive: WAP-7/WAG-9HC

Page: 18 of 27

5.3 Auxiliary Converter Commissioning

Switch on the high voltage supply and set up the loco in driving mode. Raise the panto. Close the VCB. Check that there is no earth fault in the auxiliary circuit, Switch off the VCB. Lower the panto. Create the earth fault in auxiliary circuit by making connection between wire no 1117(in HB2 cubicle) and earth. After 3 minutes a diagnostic message will come that "Earth fault auxiliary circuit."

5.3.1 Running test of 3 ph. auxiliary equipments

Switch on the 3 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured continuous phase current	Measured starting phase current
Oil pump transformer 1	9.8 amps	10.5	180
Oil pump transformer 2	9.8 amps	10.2	11.5
Coolant pump converter 1	19.6 amps	4.6	6.6
Coolant pump converter 2	19.6 amps	4.5	6-0
Oil cooling blower unit 1	40.0 amps	38.3	So is
Oil cooling blower unit 2	40.0 amps	38.1	78,3
Traction motor blower 1	34.0 amps	30.0	125.0
Traction motor blower 2	34.0 amps	29.5	122.0
Sc. Blower to Traction motor blower 1	6.0 amps	4.4	16.0
Sc. Blower to Traction motor blower 1	6.0 amps	4.0	14.0
Compressor 1	25 amps at 0 kg/ cm ² 40 amps at 10 kg/ cm ²	28-1	84.0
Compressor 2	25 amps at 0 kg/ cm ^{2°} 40 amps at 10 kg/ cm ²	28.0	fo.2

Z

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41874

Type of Locomotive: WAP-7/WAG-9HC

Page: 19 of 27

5.3.2 Performance of Auxiliary Converters

Measure the performance of the auxiliary converters through software and record it. **BUR1 (Condition: Switch off all the load of BUR 1)- to be filled by commissioning engineer of the firm.**

Signal name	Description of the signal	Prescribed value	Monitored value	Value under Limit (Yes/No)
BUR1 7303 XUUN	Input voltage to BUR1	75% (10%=125V)	1002V	Ycy
	DC link voltage of BUR1	60% (10%=100V)	636 V	Yes
BURI 7303 XUIZI	DC link current of BUR1	0% (10%=50A)	1 Amp	73

BUR2 (Condition: Switch off all the load of BUR 2, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value by the firm	Monitored value	Value under Limit (Yes/No)
BUR2 7303-XUUN	Input voltage to BUR2	75% (10%=125V)	1001V	Yey
BUR2 7303-XUUZ1	DC link voltage of BUR2	60% (10%=100V)	6370	76,
BUR2 7303-XUIZ 1	DC link current of BUR2	1% (10%=50A)*	7 Bm	Ye,
BUR2 7303-XUILG	Current battery charger of BUR2	3% (10%=100A)*	21 Bong	Yey
BUR2 7303-XUIB1	Current battery of BUR2	1.5%(10%=100A)*	1) Bord	Yey
BUR2 7303 -XUUB	Voltage battery of BUR2	110%(10%=10V)	110~	Yes

^{*} Readings are dependent upon charging condition of the battery.

BUR3 (Condition: Switch off all the load of BUR 3, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed set value by the firm	Monitored value	Value under limit (Yes/No)
BUR3 7303-XUUN	Input voltage to BUR3	75% (10%=125V	1002	.79
BUR3 7303- XUUZ1	DC link voltage of BUR3	60% (10%=100V)	6370	Yey
BUR3 7303-XUIZ 1	DC link current of BUR3	1% (10%=50A)*	7 Amp	Toy
BUR3 7303-XUILG	Current battery charger of BUR 3	3% (10%=100A)*	2/Bm)	Yey
BUR3 7303-XUIB1	Current battery of BUR 3	1.5%(10%=100A)*	1) Any	Yey
BUR3 7303-XUUB	Voltage battery of BUR 3	110%(10%=10V)	7101	Yoy

^{*} Readings are dependent upon charging condition of the battery.

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4 1874

Type of Locomotive: WAP-7/WAG-9HC Page : 20 of 27

5.3.3 Performance of BURs when one BUR goes out

When any one BUR goes out then rest of the two BURs should take the load of all the auxiliaries at ventilation level 3 of the locomotive.

Condition of BURs	Loads on BUR1	Loads in BUR2	Loads in BUR3
All BURS OK	Oil Cooling unit 1&2	TM blower1&2, TFP oil pump 1&2, SR coolant pump 1&2.	Compressor 1&2, Battery charger and TM Scavenger blower 1&2
BUR 1 out		Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2,TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 2 out	Oil Cooling unit 1&2, TM blower 1&2, TM Scavenger blower 1&2		Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 3 out	Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.	

5.4 Auxiliary circuit 415/110

For checking earth fault detection, make a connection between wire no. 1218 and vehicle body. On switching on VCB, Earth fault relay 89.5 must pick up and after 3 minutes a message will come in the Diagnostic display that Earth Fault 415/110V Circuit

Switch on the 1 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary	Typical	Measured phase	Measured
machine	phase	current	starting current
	current	·	
Machine room blower 1	15.0 amps*	4.8	7.0
Machine room blower 2	15.0 amps*	4.6	7.1
Sc. Blower to MR blower 1	1.3 amps	22	4.0
Sc. Blower to MR blower 2	1.3 amps	2.0	3.9
Ventilator cab heater 1	1.1 amps	1.3	1.6
Ventilator cab heater 2	1.1 amps	12	1.6
Cab heater 1	4.8 amps	4.9	5.0
Cab heater 2	4.8 amps	4.9	2.0

^{*} For indigenous MR blowers...

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/974.

Type of Locomotive: WAP-7/WAG-9HC

Page: 21 of 27

5.5 Hotel load circuit (Not applicable for WAG-9HC)

For WAP-7 locomotive with Hotel load converter refer to Annexure-HLC

5.6 Traction Converter Commissioning

This test is carried out in association with Firm.

Traction converter commissioning is being done one at a time. For testing Converter 1, switch off the traction converter 2 by switch bogie cut out switch 154. For testing Converter 2, switch off the traction converter 2 by switch bogie cut out switch 154. Isolate the harmonic filter also by switch 160. Start up the loco by one converter. Follow the functionality tests.

For Converter 1

Test Function	Results desired	Result obtained
Measurement of charging and charging and charging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cleeked on
Measurement of discharging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheered a
Earth fault detection on positive potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeted ac
Earth fault detection on negative potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeted ox
Earth fault detection on AC part of the traction circuit of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chested a
Pulsing of line converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Cheeked &
Pulsing of drive converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheetedon

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

• Locomotive No.: 4/974

Type of Locomotive: WAP-7/WAG-9HC

Page: 22 of 27

For Converter 2

Test Function	Results desired in sequence	Result obtained
Measurement of charging and pre-charging and charging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chelted or
Measurement of discharging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked or
positive potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Chelted &
4	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/v	cheeted or
AC part of the traction circuit of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Cheeted Ox
Pulsing of line converter of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	checked on
Pulsing of drive converter of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeked ok

Effective Date: Feb 2022

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41874

Type of Locomotive: WAP-7/WAG-9HC

Page: 23 of 27

5.7 Test protective shutdown SR

Test Function	Results desired in sequence	Result obtained
Measurement of protective shutdown by Converter 1 electronics.	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 1Check that converter 1 electronics produces a protective shut down. • VCB goes off • Priority 1 fault mesg. on DDU appears Disturbance in Converter 1	chelked ox
Measurement of protective shutdown by Converter 2 electronics.	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 2. Check that converter 2 electronics produces a protective shut down. • VCB goes off • Priority 1 fault mesg. on diagnostic display appears Disturbance in Converter 2	chocked ou

5.8 Test Harmonic Filter

Switch on the filter by switch 160

Test Function	Results desired in sequence	Result obtained
currents	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Apply a small value of TE/BE by moving the throttle. • FB contactor 8.41 must open.	o checkool or

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41874

Type of Locomotive: WAP-7/WAG-9HC

Page: 24 of 27

	FB contactor 8.2 must close. FB contactor 8.1 must close Check the filter current in	
	diagnostic laptop Bring the TE/BE throttle to O Switch off the VCB • FB contactor 8.1must open. • FB discharging contactor 8.41 must close • Check the filter current in diagnostic laptop	checked on
Test earth fault detection harmonic filter circuit.	Make a connection between wire no. 12 and vehicle body. Start up the loco. Close VCB. • Earth fault relay 89.6 must pick up. • Diagnostic message comes that - Earth fault in harmonic filter circuit	effected ox
Test traction motor speed sensors for both bogie in both cabs	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	OK

5.9 Test important components of the locomotive

Items to be tested	Description of the test	Monitored value/remarks	
Speedometer	VCU converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	cheeped on	
Time delay module of MR blower The time after which the starting capacitor for MR blower should go off the circuit should be set to 10-12 seconds		chocked a	
Ni-Cd battery voltage	At full charge, the battery voltage should be 110V DC.	cheeted ox	
Flasher light	From both cab flasher light should blink at least 65 times in one minute.	choeted on	
Head light	Head light should glow from both cabs by operating ZLPRD. Dimmer operation of headlight should also occur by operating the switch ZLPRD.	cheeked on	

Doc.No.F/ECS/01

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41974

Type of Locomotive: WAP-7/WAG-9HC

Page: 25 of 27

· · · · · · · · · · · · · · · · · · ·		· · · · · · · · · · · · · · · · · · ·
Marker light	Both front and tail marker light should glow from both the cabs	Checked ox
Cab Light	Cab light should glow in both the cabs by operating the switch ZLC	cheeked or
Spot lights	Both Drivers and Asst. Drivers Spot light should glow in both cabs by operating ZLDD	Chalkelon
Instrument lights	Instrument light should glow from both cab by operating the switch ZLI	Chelked on Chelked or Chelked or
Illuminated Push button	All illuminated push buttons should glow during the operation	Cheeked ox
Contact pressure of the high rating contactors	The contact pressure of FB contactors (8.1, 8.2) is to be measured Criteria: The minimum contact pressure is 54 to 66 Newton.	For contactor 8.1: () For contactor 8.2:
Crew Fan	All crew fans should work properly when VCB of the loco is switched on. The airflow from each cab fan is to be measured. Criteria: The minimum flow of air of cab fan should be 25 m ³ /minute	Cab 1 LHS: Cab 1 RHS: Cab 2 LHS: Cab 2 RHS:

6.0 Running Trial of the locomotive

SN	Description of the items to be seen during trail run	Action which should take place	Remarks	
1	Cab activation in driving mode	No fault message should appear on the diagnostic panel of the loco.		
	Loco charging	Loco to be charged and all auxiliaries should run. No fault message to appear on the diagnostic panel of the loco. Raise MR pressure to 10 Kg/cm ² , BP to 5 Kg/cm ² , FP to 6 Kg/cm ² .	Locked ox	
3.	Check function of Emergency push stop.	This switch is active only in activated cab. By pushing this switch VCB should open & pantograph should be lowered.	Bared in	
4.	Check function of BPCS.	 Beyond 5 kmph, press BPCS, the speed of loco should be constant. BPCS action should be cancelled by moving TE/BE throttle, by dropping BP below 4.75 Kg/cm², by pressing BPCS again. 	Locked	
5.	Check train parting operation of the Locomotive.	Operate the emergency cock to drop the BP Pressure LSAF should glow.	Rockef	

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/874

Type of Locomotive: WAP-7/WAG-9HC

Page: 26 of 27

Set the speed more than 1.5 kmph and ensure that operation of the locomotive Set the speed more than 1.5 kmph and ensure that brakes are released i.e. BC < 1 kg/cm². For 60 seconds do not press vigilance foot switch or sanding foots switch or TE/BE throttle or BPVG switch then Buzzer should start buzzing. Set the speed more than 1.5 kmph and ensure that brakes are released i.e. BC < 1 kg/cm². Switch then Buzzer should start buzzing. Switch defense the alarm through BPVG or vigilance foot switch further for 8 seconds then: Emergency brake should be applied automatically. VCB should be switched off. Resetting of this penalty brake is possible only after 32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch. At low pressure of MR (< 5.6 kg/cm²). With park brake in applied condition. With direct loco brake applied (BP< 4.75kg/cm²). With automatic train brake applied (BP< 4.75kg/cm²). With emergency cock (BP < 4.75 kg/cm²). With emergency c			~	
locomotive For 60 seconds do not press vigilance foot switch or sanding foots switch or TE/BE throttle or BPVG switch then	6.	Check vigilance	Set the speed more than 1.5 kmph and ensure that	
sanding foots switch or TE/BE throttle or BPVG switch then • Buzzer should start buzzing. • LSVW should glow continuously. Do not acknowledge the alarm through BPVG or vigilance foot switch further for 8 seconds then: • Emergency brake should be applied automatically. • VCB should be switched off. Resetting of this penalty brake is possible only after 32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch. 7. Check start/run interlock • At low pressure of MR (< 5.6 Kg/cm²). • With park brake in applied condition. • With direct loco brake applied (BP< 4.75Kg/cm²). • With automatic train brake applied (BP< 4.75Kg/cm²). • With automatic train brake applied (BP< 4.75Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emer		operation of the	brakes are released i.e. BC < 1 Kg/cm ² .	
switch then Buzzer should start buzzing. LSVW should glow continuously. Do not acknowledge the alarm through BPVG or vigilance foot switch further for 8 seconds then: Emergency brake should be applied automatically. VCB should be switched off. Resetting of this penalty brake is possible only after 32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch. Check start/run interlock At low pressure of MR (< 5.6 Kg/cm²). With park brake in applied condition. With direct loco brake applied (BP<4.75Kg/cm²). With automatic train brake applied (BP<4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With emergency cock (BP < 4.75 Kg/		locomotive	For 60 seconds do not press vigilance foot switch or	
Buzzer should start buzzing. LSVW should glow continuously. Do not acknowledge the alarm through BPVG or vigilance foot switch further for 8 seconds then: Emergency brake should be applied automatically. VCB should be switched off. Resetting of this penalty brake is possible only after 32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch. Check start/run interlock At low pressure of MR (< 5.6 Kg/cm²). With park brake in applied condition. With direct loco brake applied (BP< 4.75Kg/cm²). With automatic train brake applied (BP< 4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With automatic train brake applied (BP< 4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With automatic train brake applied (BP< 4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With emergency coc	,		sanding foots switch or TE/BE throttle or BPVG	
Do not acknowledge the alarm through BPVG or vigilance foot switch further for 8 seconds then: Emergency brake should be applied automatically. VCB should be switched off. Resetting of this penalty brake is possible only after 32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch. Check start/run interlock At low pressure of MR (< 5.6 Kg/cm²). With park brake in applied condition. With direct loco brake applied (BP<4.75Kg/cm²). With automatic train brake applied (BP<4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With automatic train brake applied (BP<4.75Kg/cm²). With automatic train brake applied (BP<4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). Whith emergency cock (BP < 4.75 Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). Whith emergency coc			switch then	
Do not acknowledge the alarm through BPVG or vigilance foot switch further for 8 seconds then: Emergency brake should be applied automatically. VCB should be switched off. Resetting of this penalty brake is possible only after 32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch. Check start/run interlock At low pressure of MR (< 5.6 Kg/cm²). With park brake in applied condition. With direct loco brake applied (BP<4.75Kg/cm²). With automatic train brake applied (BP<4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With automatic train brake applied (BP<4.75Kg/cm²). With automatic train brake applied (BP<4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). Whith emergency cock (BP < 4.75 Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). Whith emergency coc			Buzzer should start buzzing.	chested ox
vigilance foot switch further for 8 seconds then: • Emergency brake should be applied automatically. • VCB should be switched off. Resetting of this penalty brake is possible only after 32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch. 7. Check start/run interlock • At low pressure of MR (< 5.6 Kg/cm²). • With park brake in applied condition. • With direct loco brake applied (BP< 4.75 Kg/cm²). • With automatic train brake applied (BP<4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (B			LSVW should glow continuously.	Y
Emergency brake should be applied automatically. VCB should be switched off. Resetting of this penalty brake is possible only after 32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch. 7. Check start/run interlock At low pressure of MR (< 5.6 Kg/cm²). With park brake in applied condition. With direct loco brake applied (BP< 4.75Kg/cm²). With automatic train brake applied (BP< 4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). With of the brake electronics. The Tractive /Braking effort should ramp down, VCB should open and BP reduces rapidly. 9. Check regenerative braking. Bring the TE/BE throttle to BE side. Loco speed should start reducing. 10. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation Switch off the BURs; loco should trip in this case. 11. Check the power converter lisolation test Create disturbance in power converter by switching off the electronics. VCB should open and converter should get isolated and traction is possible with			Do not acknowledge the alarm through BPVG or	
automatically. • VCB should be switched off. Resetting of this penalty brake is possible only after 32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch. • At low pressure of MR (< 5.6 Kg/cm²). • With park brake in applied condition. • With direct loco brake applied (BP< 4.75Kg/cm²). • With automatic train brake applied (BP< 4.75Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). 8. Check traction interlock With emergency cock (BP < 4.75 Kg/cm²). Switch of the brake electronics. The Tractive /Braking effort should ramp down, VCB should open and BP reduces rapidly. 9. Check regenerative braking. 10. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation BURs can take the load of all the auxiliaries. For this switch off one BUR. Auxiliaries should be catered by rest of two BURs. Switch off one BUR; loco should trip in this case. 11. Check the power converter isolation test Create disturbance in power converter by switching off the electronics. VCB should open and converter should get isolated and traction is possible with			vigilance foot switch further for 8 seconds then:-	
• VCB should be switched off. Resetting of this penalty brake is possible only after 32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch. 7. Check start/run interlock • At low pressure of MR (< 5.6 Kg/cm²). • With park brake in applied condition. • With direct loco brake applied (BP< 4.75Kg/cm²). • With automatic train brake applied (BP< 4.75Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With automatic train brake applied (BP<4.75Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • Wi			 Emergency brake should be applied 	
Resetting of this penalty brake is possible only after 32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch. 7. Check start/run interlock • At low pressure of MR (< 5.6 Kg/cm²). • With park brake in applied condition. • With direct loco brake applied (BP< 4.75Kg/cm²). • With automatic train brake applied (BP< 4.75Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4			automatically.	
32 seconds by bringing TE/BE throttle to 0 and acknowledge BPVR and press & release vigilance foot switch. 7. Check start/run interlock • At low pressure of MR (< 5.6 kg/cm²). • With park brake in applied condition. • With direct loco brake applied (BP< 4.75kg/cm²). • With automatic train brake applied (BP< 4.75kg/cm²). • With emergency cock (BP < 4.75 kg/cm²). • With emergency cock (BP < 4.75 kg/cm²). 8. Check traction interlock Tractive /Braking effort should ramp down, VCB should open and BP reduces rapidly. 9. Check regenerative braking. Bring the TE/BE throttle to BE side. Loco speed should start reducing. 10. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation BURs can take the load of all the auxiliaries. For this switch off one BUR. Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. 11. Check the power converter by switching off the electronics. VCB should open and converter isolation test 32 seconds by release vigilance foot with the call of all the auxiliaries. All the check to a check of the call of all the auxiliaries. For this switch off one BUR. Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. Create disturbance in power converter by switching off the electronics. VCB should open and converter should get isolated and traction is possible with			 VCB should be switched off. 	
acknowledge BPVR and press & release vigilance foot switch. 7. Check start/run interlock • At low pressure of MR (< 5.6 Kg/cm²). • With park brake in applied condition. • With direct loco brake applied (BP< 4.75Kg/cm²). • With automatic train brake applied (BP< 4.75Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). 8. Check traction interlock Switch of the brake electronics. The Tractive /Braking effort should ramp down, VCB should open and BP reduces rapidly. 9. Check regenerative braking. Bring the TE/BE throttle to BE side. Loco speed should start reducing. 10. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation Switch off one BUR. Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. 11. Check the power converter by switching off the electronics. VCB should open and converter should get isolated and traction is possible with			Resetting of this penalty brake is possible only after	
foot switch. 7. Check start/run interlock • At low pressure of MR (< 5.6 Kg/cm²). • With park brake in applied condition. • With direct loco brake applied (BP< 4.75Kg/cm²). • With automatic train brake applied (BP< 4.75Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). • With emergency cock (BP < 4.75 Kg/cm²). Switch of the brake electronics. The Tractive /Braking effort should ramp down, VCB should open and BP reduces rapidly. 9. Check regenerative braking. 10. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation BURs can take the load of all the auxiliaries. For this switch off one BUR. Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. 11. Check the power converter isolation test should get isolated and traction is possible with			32 seconds by bringing TE/BE throttle to 0 and	
7. Check start/run interlock • At low pressure of MR (< 5.6 kg/cm²). • With park brake in applied condition. • With direct loco brake applied (BP< 4.75kg/cm²). • With automatic train brake applied (BP<4.75kg/cm²). • With emergency cock (BP < 4.75 kg/cm²). • With emergency cock (BP < 4.75 kg/cm²). 8. Check traction interlock Switch of the brake electronics. The Tractive /Braking effort should ramp down, VCB should open and BP reduces rapidly. 9. Check regenerative braking. Bring the TE/BE throttle to BE side. Loco speed should start reducing. In the event of failure of one BUR, rest of the two BURs can take the load of all the auxiliaries. For this switch off one BUR. Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. 11. Check the power converter isolation test should get isolated and traction is possible with			acknowledge BPVR and press & release vigilance	
With park brake in applied condition. With direct loco brake applied (BP< 4.75Kg/cm²). With automatic train brake applied (BP<4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). Switch of the brake electronics. The Tractive /Braking effort should ramp down, VCB should open and BP reduces rapidly. P. Check regenerative braking. Bring the TE/BE throttle to BE side. Loco speed should start reducing. In the event of failure of one BUR, rest of the two BURs can take the load of all the auxiliaries. For this switch off one BUR. Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. The Check the power converter by switching off the electronics. VCB should open and converter should get isolated and traction is possible with			foot switch.	
With direct loco brake applied (BP< 4.75Kg/cm²). With automatic train brake applied (BP<4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). Switch of the brake electronics. The Tractive /Braking effort should ramp down, VCB should open and BP reduces rapidly. Proceed on the should ramp down, VCB should open and BP reduces rapidly. Bring the TE/BE throttle to BE side. Loco speed should start reducing. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation BURs can take the load of all the auxiliaries. For this switch off one BUR. Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. Create disturbance in power converter by switching off the electronics. VCB should open and converter isolation test should get isolated and traction is possible with	7.	Check start/run interlock	 At low pressure of MR (< 5.6 Kg/cm²). 	checked
With automatic train brake applied (BP<4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). Switch of the brake electronics. The Tractive /Braking effort should ramp down, VCB should open and BP reduces rapidly. Bring the TE/BE throttle to BE side. Loco speed should start reducing. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation Check the power converter isolation test With automatic train brake applied (BP<4.75Kg/cm²). With emergency cock (BP < 4.75 Kg/cm²). Switch of the brake electronics. The Tractive /Braking effort should ramp down, VCB should ramp down, VCB should open and down, VCB should open and converter should per specific and should get isolated and traction is possible with			With park brake in applied condition.	
With emergency cock (BP < 4.75 Kg/cm²). Switch of the brake electronics. The Tractive /Braking effort should ramp down, VCB should open and BP reduces rapidly. Policy of the Event of Failure of one BUR, rest of the two redundancy test at ventilation level 1 & 3 of loco operation Check the power converter isolation test Create disturbance in power converter isolation test Check for BUR of the brake electronics. The Tractive /Braking effort should ramp down, VCB of the side. Loco speed should start reducing. Check for BUR of the electronics of the two BUR, rest of the two BURs of the switch off one BUR. Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case.			• With direct loco brake applied (BP< 4.75Kg/cm ²).	9
8. Check traction interlock Switch of the brake electronics. The Tractive / Braking effort should ramp down, VCB should open and BP reduces rapidly. 9. Check regenerative braking. 10. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation BURs can take the load of all the auxiliaries. For this switch off one BUR. Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. 11. Check the power converter isolation test Switch of the brake electronics. The Tractive / Braking effort should ramp down, VCB should ramp down rate do			• With automatic train brake applied (BP<4.75Kg/cm ²).	(charted on
Tractive /Braking effort should ramp down, VCB should open and BP reduces rapidly. 9. Check regenerative braking. 10. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation 10. Check the power converter isolation test 11. Check the power should get isolated and traction is possible with Tractive /Braking effort should ramp down, VCB should ramp do		,	• With emergency cock (BP < 4.75 Kg/cm ²).	
braking. 10. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation 11. Check the power converter isolation test 12. Check the power should get isolated and traction is possible with 13. Check regenerative should start reducing. 14. Check the power should be catered by rest of two BURs. 15. Check the power converter by switching off the electronics. VCB should open and converter should get isolated and traction is possible with	8.	Check traction interlock	Switch of the brake electronics. The	9 .
braking. 10. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation 11. Check the power converter isolation test 12. Check the power should get isolated and traction is possible with 13. Check regenerative should start reducing. 14. Check the power should be catered by rest of two BURs. 15. Check the power converter by switching off the electronics. VCB should open and converter should get isolated and traction is possible with		·	Tractive /Braking effort should ramp down, VCB	Leited on
braking. 10. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation 11. Check the power converter isolation test 12. Check the power should get isolated and traction is possible with 13. Check regenerative should start reducing. 14. Check the power should be catered by rest of two BURs. 15. Check the power converter by switching off the electronics. VCB should open and converter should get isolated and traction is possible with			should open and BP reduces rapidly.	<u> </u>
10. Check for BUR redundancy test at ventilation level 1 & 3 of loco operation 11. Check the power converter isolation test 12. Check the power should get isolated and traction is possible with 13. Check for BUR and the event of failure of one BUR, rest of the two BURs. BURs can take the load of all the auxiliaries. For this switch off one BUR. Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. Create disturbance in power converter by switching off the electronics. VCB should open and converter should get isolated and traction is possible with	9.	Check regenerative	Bring the TE/BE throttle to BE side. Loco speed	4 Rocked or
redundancy test at ventilation level 1 & 3 of loco operation Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. Create disturbance in power converter by switching converter isolation test BURs can take the load of all the auxiliaries. For this switch off one BUR. Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. Create disturbance in power converter by switching off the electronics. VCB should open and converter isolation test		braking.	should start reducing.	
ventilation level 1 & 3 of loco operation Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. 11. Check the power converter by switching off the electronics. VCB should open and converter isolation test should get isolated and traction is possible with	10.	Check for BUR	In the event of failure of one BUR, rest of the two	9
ventilation level 1 & 3 of loco operation Auxiliaries should be catered by rest of two BURs. Switch off the 2 BURs; loco should trip in this case. 11. Check the power converter by switching off the electronics. VCB should open and converter isolation test should get isolated and traction is possible with		redundancy test at	BURs can take the load of all the auxiliaries. For this	CROOKER OU
Switch off the 2 BURs; loco should trip in this case. 11. Check the power converter by switching off the electronics. VCB should open and converter isolation test should get isolated and traction is possible with		ventilation level 1 & 3 of	switch off one BUR.	Y ·
11. Check the power Create disturbance in power converter by switching converter off the electronics. VCB should open and converter isolation test should get isolated and traction is possible with		loco operation	Auxiliaries should be catered by rest of two BURs.	
converter off the electronics. VCB should open and converter isolation test should get isolated and traction is possible with			Switch off the 2 BURs; loco should trip in this case.	3
1	11.	Check the power	,	9 ,
1		1		6 charker ou
another power converter.		isolation test		
			another power converter.	

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>iGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41874

Type of Locomotive: WAP-7/WAG-9HC

Page: 27 of 27

7.0 Final check list to be verified at the time of Loco dispatch

Condition /Operations of the following items are to be checked:

SN	Item	Cab-1	Cab-2	Remarks	
1	Head lights	01_	- Q		-
2	Marker Red	00_	OK		
3	Marker White	Due_	مد		
4	Cab Lights	ðv_	ÚK.		
5	Dr Spot Light	·OK	OK	***	
6	Asst Dr Spot Light	DIK	OK	p cheered con	Van & Cyc
7	Flasher Light	0 <u>v</u>	· UK	!	
8	Instrument Lights	Ov.	91		
9	Corridor Light	en .	oe.		
10	Cab Fans	OK.	ax.		
11	Cab Heater/Blowers	04_	æ		
12	All Cab Signal Lamps Panel 'A'	a-	Qu.		

Status of RDSO modifications

LOCO NO: 41974

Sn	Modification No.	Description	Remarks
1.	RDSO/2008/EL/MS/0357 Rev.'0' Dt 20.02.08	Modification in control circuit of Flasher Light and Head Light of three phase electric locomotives.	Ok/Not Ok
2.	RDSO/2009/EL/MS/0377 Rev.'0' Dt 22.04.09	Modification to voltage sensing circuit in electric locomotives.	Ŏk/Not Ok
3.	RDSO/2010/EL/MS/0390 Rev.'0' Dt 31.12.10	Paralleling of interlocks of EP contactors and Relays of three phase locomotives to improve reliability.	Ok/Not Ok
4.	RDSO/2011/EL/MS/0399 Rev.'0' Dt 08.08.11	Removal of interlocks of control circuit contactors no. 126 from MCPA circuit.	Ok/Not Ok
5.	RDSO/2011/EL/MS/0400 Rev.'0' Dt 10.08.11	Modification sheet for shifting the termination of \$GKW, 1.8 KV, 70 sq mm cables and 2x2.5 sq mm cables housed in lower portion of HB2 panel and provision of Synthetic resin bonded glass fiber sheet for three phase locomotives.	Ok/Not Ok
6.	RDSO/2011/EL/MS/0401 Rev.'0' Dt 10.08.11	Modification sheet for relaying of cables in HB-2 panel of three phase locomotives to avoid fire hazards.	Ŏk/Not Ok
7.	RDSO/2011/EL/MS/0403 Rev.'0' Dt 30.11.11	Auto switching of machine room/corridor lights to avoid draining of batteries in three phase electric locomotives.	ởk/Not Ok
8.	RDSO/2012/EL/MS/0408 Rev.'0'	Modification of terminal connection of heater cum blower assembly.	K/Not Ok
9.	RDSO/2012/EL/MS/0411 Rev.'1' dated 02.11.12	Modification sheet to avoid simultaneous switching ON of White and Red marker light in three phase electric locomotives.	Ok/Not Ok
10	RDSO/2012/EL/MS/0413 Rev.'1' Dt 25.04.16	Paralleling of interlocks of EP contactors and auxiliary contactors of three phase locomotives to improve reliability.	Čk/Not Ok
11	RDSO/2012/EL/MS/0419 Rev.'0' Dt 20.12.12		ok/Not Ok
12	RDSO/2013/EL/MS/0420 Rev.'0' Dt 23.01.13	Modification sheet to provide mechanical locking arrangement in Primary Over Current Relay of three phase locomotives.	Ők/Not Ok
13	RDSO/2013/EL/MS/0425 Rev.'0' Dt 22.05.13		Ók/Not Ok
14	RDSO/2013/EL/MS/0426 Rev.'0' Dt 18.07.13		Ŏk/Not Ok
15	RDSO/2013/EL/MS/0427 Rev.'0' Dt 23.10.13		Ŏk/Not Ok
16	RDSO/2013/EL/MS/0428 Rev.'0' Dt 10.12.13	Modification sheet for relocation of earth fault relays for harmonic filter and hotel load along with its resistors in three phase electric locomotives.	Ok/Not Ok
17	RDSO/2014/EL/MS/0432 Rev.'0' Dt 12.03.14	Removal of shorting link provided at c-d terminal of over current relay of three phase electric locomotives.	Ŏk/Not Ok
18	RDSO/2017/EL/MS/0464 Rev.'0' Dt 25.09.17		Ŏk/Not Ok
19	RDSO/2017/EL/MS/0467 Rev.'0' Dt 07.12.17		Ŏk/Not Ok
20			Ŏk/Not Ok

Signature of JE/SSE/ECS

Loco No.: 41974

PLW/PATIALA

PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

SN	Parameters	Reference	Value	Result
	Brake Panel: M/s Faiveley			
1.0	Auxiliary Air supply system (Pantograph & VCB)			
1.1	Ensure, Air is completely vented from pantograph			0
	Reservoir (Ensure Panto gauge reading is Zero)			
1.2	Turn On BL Key. Now MCPA starts.		60 sec. (Max.)	57
	Record pressure Build up time (8.0 kg/cm2)			
1.3	Auxiliary compressor safety Valve 23F setting	Faiveley Doc. No.	8.5±0.25kg/cm2	8.40 Kg/cm2
		DMTS-014-1, 8	-	
		CLW's check sheet		
		no. F60.812 Version		
		2		
1.4	Check VCB Pressure Switch Setting	CLW's check sheet	Opens 4.5±0.15	4.45 Kg/cm2
		no. F60.812 Version	kg/cm2, closes	
		2	5.5±0.15 kg/cm2	5.50 Kg/cm2
1.5	Set pantograph Selector Switch is in Auto, Open pan-1&2 Iso	olating Cocks & KABA co		1
1.6	Set Cab-1 Pan UP in Panel A.		Observed Pan-2	ОК
			Rises.	
1.7	Close Pan-2 isolating Cock		Panto-2 Falls Down	ОК
	Open Pan -2 isolating Cock		Panto-2 Rises	
1.8	Record Pantograph Rise time		06 to 10 seconds	9 Sec
1.9	Record Pantograph Lowering Time		06 to 10 seconds	9 Sec
1.10	Panto line air leakage		0.7 kg/cm2 in 5	0.30 kg/cm2
			Min.	in 5 Min.
1.11	High Reach Panto emergency test and reset.			Ok
2.0	Main Air Supply System			
2.1	Ensure, Air is completely vented from locomotive. Drain	Theoretical		
	out all the reservoirs by opening the drain cocks and then	calculation and		
	closed drain cocks. MR air pressure build up time by each	test performed by		
	compressor from 0 to 10 kg/cm2.	Railways.	.\ ¬	6 . 0 45
	i) with 1750 LPM compressor		i) 7 mins Max.	6 min. & 45
2.2	ii) with 1450 LPM compressor Drain air below MR 8 kg/cm2 to start both the		ii) 8.5 mins Max. Check Starting of	sec.
2.2	compressors		both compressors	Ok
2.3	Drain air from main reservoir up to 7 kg/cm2. Start		30 Sec. (Max)	CP1-29 Sec
2.3	compressors, Check pressure build time of individual		JO Jec. (IVIAX)	CF 1-29 360
	compressor from 8 kg/cm2 to 9 kg/cm2			CP2-29 Sec
2.4	Check Low MR Pressure Switch Setting (37)	D&M test spec.	Closes at 6.40±0.15	6.45 Kg/cm2
۷.٦	Check Low Will I resoure Switch Setting (37)	MM3882 &	kg/cm2 Opens at	0.73 Ng/ CIII2
		MM3946	5.60±0.15kg/cm2	5.65 Kg/cm2
2.5	Check compressor Pressure Switch RGCP setting (35)	D&M test spec.	Opens at 10±0.20	10.0 Kg/cm2
		MM3882 &	kg/cm2 Closes at	15.5
		MM3946	8±0.20 kg/cm2	8.0 Kg/cm2
2.6	Run both the compressors Record Pressure build up time	Trial results	3.5 Minutes Max.	3.40 minute

PLW/PATIALA

Loco No.: 41974

	1					LOCO NO	T13/T
2.7	Check unloader v	alve operation time				Approx. 12 Sec.	10 sec
2.8	Check Auto Drain	Valve functioning (12	24 & 87)			Operates when	Ok
						Compressor	
						starts	
2.9	Check CP-I deliver	y safety valve setting	: (10/1). Run CP	D&M t	est spec.	11.50±0.35	11.50
	Direct by BLCP.	, salet, raire setting	, (10) 1) 11 11 01		& MM3946	kg/cm2	Kg/cm2
2.10		ry safety valve setting	7 /10/2\ Pun CD		est spec.	11.50±0.35	11.50
2.10	direct by BLCP	iy salety valve settili	g (10/2). Null Cr		& MM3946	kg/cm2	
244	•			 		Kg/CIIIZ	Kg/cm2
2.11		ompressors and ensu	•	1	est spec.		
	1	oressure 1.2 kg/cm2 le	ess than opening	IVIIVI3882	& MM3946		
	pressure.						
2.12		ch 'OFF' compressor,			ck sheet no.	5.0±0.10kg/cm2	5.0 Kg/cm2
		" Main Reservoir, Sta	•	F60.812 Ve	ersion 2		
	check setting pres	ssure of Duplex Check	Valve 92F.				
2.13	FP pressure:			CLW's chec	ck sheet no.	6.0±0.20kg/cm2	6.0 Kg/cm2
	Fit Test Gauge in	Test point 107F FPTP.	Open isolate cock	F60.812 Ve	ersion 2		
	136F. Check press	sure in Gauge.					
3.0	Air Dryer Opera	-					
3.1		90 of 2 nd MR to start	Compressor, leave			Tower to change	Ok
0.2		ck Air Dryer Towers t				i) Every minute	"
		on an Diger Towers	0 011411801			(FTIL & SIL)	
						ii)every two	
2.2	Charle Donner Aire C	A: D	+ C			minute (KBIL)	
3.2		tops from Air Dryer a	t Compressor stops			Dloo	Dl
		of humidity indicator				Blue	Blue
4.0	Main Reservoir Lo		LMDD	DOMA		Charlette de la ca	0.45
4.1	· ·	9) in full service, Che	eck wik Pressure air	D&M test spec. MM3882 & MM3946		Should be less	0.45
	leakage from botl	n cabs.		MINI3882	& MM3946	than 1 kg/cm2 in	Kg/cm2 in
						15 minutes	15 minutes
4.2	Check BP Air leak	age (isolate BP chargi	ng cock-/0)		est spec.	0.15 kg/cm2 in 5	0.10
				MM3882	& MM3946	minutes	Kg/cm2 in 5
							minutes
5.0		omatic Brake opera					
5.1	Record Brake Pipe	e & Brake Cylinder pr	essure at Each Step				
	Check proportion	ality of Auto Brake sy	stem		ck sheet no.		
				F60.812	Version 2		
		ı					
	Auto controller	BP Pressure kg/cm2) -	BC (WAG-9) & WAG-7)	BC (WAP-5)	
	position			Kg/cm2		Kg/cm2	
		Value	Result	Value	Result	Value	Result
		value	Nesuit	value	Nesuit	value	Nesuit
	Run	5±0.1	5.0 Kg/cm2	0.00	0.00 Kg/ cm2	0.00	_
					0.00 kg/ till2		
	Intial	4.60±0.1	4.6 Kg/cm2	0.40±0.1	0.40Kg/ cm2	0.75±0.15	-
	Full service	3.35±0.2	3.35 Kg/cm2	2.50±0.1		5.15±0.30	-
	I dii sei vice	J.JJ±0.2	3.33 Ng/ CIIIZ	2.3010.1	2.5Kg/ cm2	J. 1J1U.3U	
	Emergency	Less than 0.3	0.25 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	-
1	1		_				ĺ

PLW/PATIALA

Loco No.: 41974

5.2	Record time to BP pressure drop to 3.5 kg/cm2 Ensure	D&M test spec.	8±2 sec.	9 Sec
	Automatic Brake Controller handle is Full Service from Run	MM3882 & MM3946		
5.3	Operate Asst. Driver Emergency Cock,	D&M test spec.	BP pressure falls	
		MM3882 & MM3946	to Below 2.5	ОК
			kg/cm2	
5.4	Check brake Pipe Pressure Switch 69F operates	CLW's check sheet no.	Closes at BP	
		F60.812 Version 2	4.05- 4.35	4.15
			kg/cm2	Kg/cm2
			Opens at BP	
			2.85- 3.15	2.95
			kg/cm2	Kg/cm2
5.5	Move Auto Brake Controller handle from Running to	D&M test spec.		
	Emergency BC filling time from 0.4 kg/cm2 i.e. 95% of	MM3882 & MM3946		
	Max. BC developed			
	WAP5 – BC 5.15 \pm 0.3 kg/cm2 apply time		4±1 sec.	
	WAP7 - BC 2.50 ± 0.1 kg/cm2		7.5±1.5 sec.	
	WAG9 - BC 2.50 ± 0.1 kg/cm2		21±3 sec.	21 sec
5.6	Move Auto Brake Controller handle to full service and	D&M test spec.		
	BP pressure 3.5 kg/cm2. Move Brake controller to	MM3882 & MM3946		
	Running position BC Release time to fall BC Pressure up			
	to 0.4 kg/cm2 i.e. 95% of Max. BC developed			
	BC release Time			
	WAP7		17.5±2.5 sec.	
	WAG9		52±7.5 sec.	54 sec.
5.7	Move Auto Brake Controller handle to Release, Check	CLW's check sheet no.	60 to 80 Sec.	72 Sec
	BP Pressure Steady at 5.5± 0.2 kg/cm2 time.	F60.812 Version 2		
5.8	Auto Brake capacity test : The capacity of the A9 valve	RDSO Motive power	BP pressure	
	in released condition must conform to certain limit in	Directorate report no.	should not fall	
	order to ensure compensation for air leakage in the	MP Guide No. 11 July,	below 4.0	
	train without interfering with the automatic	1999 Rev.1	kg/cm2 with in	4.60
	functioning of brake.		60 Sec.	Kg/cm2
	* Allow The MR pressure to build up to maximum			
	stipulated limit.			
	* Close brake pipe angle cock and charge brake pipe to			
	5 kg/cm2 by A-9 (Automatic brake controlling) at run			
	position.			
	* Couple 7.5 dia leak hole to the brake hose pipe of			
	locomotive. Open the angle cock for brake pipe.			
	The test shall be carried out with all the compressors in			
	working condition.			
5.9	Keep Auto Brake Controller (A-9) in Full Service. Press		BC comes to '0'	0
	Driver End paddle Switch (PVEF)			
6.0	Direct Brake (SA-9)			
6.1	Apply Direct Brake in Full Check BC pressure			
0.1	WAG9/WAP7	CLW's check sheet no.	3.5±0.20 kg/cm2	3.50
	WAP5	F60.812 Version 2	5.15±0.3 kg/cm2	Kg/cm2
6.2	Apply Direct Brake, Record Brake Cylinder charging	D&M test spec.		7 Sec
0.2		MM3882 & MM3946	8 sec. (Max.)	/ 380
	time	IVIIVI3002 & IVIIVI3946		

PLW/PATIALA

Loco No.: 41974

6.3	Check Direct Brake Pressure switch 59 (F)	D&M test spec. MM3882 & MM3946	0.2.±0.1 kg/cm2	0.20 kg/cm2
6.4	Release direct brake & BC Release time to fall BC pressure up to 0.4 kg/cm2		10 -15 Sec.	12 Sec
7.0	Modified System Software (only for CCB)		-NA-	-NA-
7.1	Bail-off de-activated during emergency by any means			
7.2	DPWCS and Non-DPWCS mode enabled		Multi Loco	
7.3	TCAS and Non-TCAS mode enabled		Not Yet Launched	Presently
7.4	Penalty brake application deactivated for Fault code 113 (FC 113) and CCB health signal will not drop to avoid loco detention/failure. The Brake Electronics Failure "message will not generate on DDS.	RDSO letter no	Pressure Setting Needed is 12 kg/sqcm Causing mismatching with standard Pr Setting	not happening in PLW
7.5	CCB health signal logic revised (Now will remain high) for penalty condition occurring with FC 108 due to wrong operation/not affecting operation/ Not a CCB Fault (i.e Both controllers selected as LEAD etc) The Brake electronic failure message will not generate on DDS	EL/3.2.19/3-phase (CCB), dtd 30.01.2023		
7.6	CCB health signal logic for FC 102 (In case of BC request from VCU is more than 90 %-above 9V DC) is changed i.e CCB health signal will not drop for FC 102 which will avoid loco detention/failure. The brake electronic failure message will not generate on DDS.		Could not performed by M/s Knorr	Presently Not happening in PLW
7.7	Booting time for CCB with TCAS/TPM/PTWS/DPWCS mode 15-20 sec. However, in case of absence of either one or both system booting time subsequently increased to 40-50 sec.			
8.0	Sanding Equipment			
8.1	Check Isolating Cock-134F is in open position. Press sander paddle Switch. (To confirm EP valves Operates)		Sand on Rail	Ok
9.0	Test Vigilance equipment : As per D&M test specification			Ok

SAMSHER SINGH SINGH BIST Date: 2025.01.28

BIST

13:31:18 +05'30'

Signature of SSE/Shop

	41974									
	ROOF COMPONENT CAB 1 & 2									
S.No.	Description	PL NO.	QPL /Nos.	Supplier	Sr. no.					
1	Pantograph	29880014(HR), 29880026	2	FAIVELEY, CONTRANSYS	H24-3703/AUG-2024, 15403-10/24					
2	Servo motor	29880026	2	CONTRANSYS	15397-10/24					
3	Air Intake filter Assly	29480103	2	AFI	AFI/OC/643A-08/24, AFI/OC/662A- 08/24					
4	Insulator Panto Mtg.	29810127	8	BHEL	07-2024, 08-2024					
			MIDDLE RC	OF COMPONENT	•	1				
5	High Voltage Bushing	29731021	1	ELECTRANEX	EIPL-5667-08-24	1				
6	Voltage Transformer	29695028	1	PRAGATI	24/819157-oct/2024	1				
7	Vacuum Circuit Breaker	25712202	1	AUTOMETERS	AALN/09/2024/048/VCBA/645	1				
8	Insulator Roof line	29810139	9	IEC	04-24, 04-24					
9	Harmonic Filter	29650033	1	RESITECH	05/24/232496/62	AS Per PO/IRS Conditions				
10	Earth Switch	29700073	Е	AUTOMETERS	AALN/04/2024/012/ES/012]				
11	Surge Arrester	29750052	2	CG POWER & INDUSTRIAL	57759-2024, 57760-2024					
			Air B	rake Components						
12	Air Compressor (A,B)	29511008	2	ELGI	EXFS -923424 A,EXFS-923411 B	1				
	Air Dryer	29162051	1	TRIDENT	LD2-10-0768-24	1				
	Babby compressor	25513000	1	CEC	RH 3351-08-24	†				
	Air Brake Panel	29180016	1	Faiveley	NOV 23-03-WAG9-3215	†				
16	Contoller (A,B)	29180016	2	Faiveley	G 24 -152 A , K 24 -048 B	1				
17	Breakup Valve	29180016	2	Faiveley						
18	wiper motor	29162026	4	Auto Industry]				

SAMSHE Digitally signed by SAMSHER SINGH SINGH BIST Date: 2025.01.24 15:59:35 +05'30' SSE/ABS

PLW/PTA

ELECTRIC LOCO HISTORY SHEET (ECS)

ELECTRIC LOCO NO: 41974 LIST OF ITEMS FITTED BY ECS

RLY: NR

SHED: KJGE

PROPULSION SYSTEM: MEDHA

S	DESCRIPTION OF ITEM	ITEM PL NO.	ITEM SR. NO C	MAKE/SUPPLIER	
1	LED Based Flasher Light Cab I & II	29612937	4676	4780	POWER TECH
2	T Markor Eight Odb / G II	29612925	143014/143137/14		MATSUSHI P. TECH.
. 3	Tab Heater Cab FA II	29170011	3257	3222	KKI
4	TOTAL TOTAL TOTAL	29470080	5834/5651/5	856/5746	MTI
5	Master Controller Cab I	29860015	7046	3	14/OABAA
6	Middler Controller Cab II	29000015	6982		WOAMA
7	Complete Panel A Cab I & II	29178265	1560	- 1534	KONTACT
8	The state of the s	29170539	010/10	019/10	TOPGRIP/MEDHA
9	Complete Panel D Cab I & II	29178265	1552	1554	KONTACT
	Complete Cubicle- F Panel Cab I & II	29178162	SLFC00012405192 SLFC00012408253		STESALIT
	Speed Ind.& Rec. System	29200040	5280/52		LAXVEN
	Battery (Ni- Cd)	29680025	B-31		HBL
13	Set of Harnessed Cable Complete	29600420		s control of the second of the	QUADRANT
14	Transformer Oil Pressure Sensor (Cab-1) (Pressure Sensor Oil Circuit Transformer)	29500047	BG/PS/1420 Jun-24	BG/PS/1438 Jun-24	BG INDUSTRIES
15	Transformer Oil Pressure Sensor (Cab-2)		BG/PS/1343 Jun-24	BG/PS/1348 Jun-24	
16	Transformer Oil Temperature Sensor (Cab-1) (Temperature Sensor Oil Circuit Transformer)	29500035	BG/TFP/887	7 Aug-24	BG INDUSTRIES
17	Transformer Oil Temperature Sensor (Cab-2)		BG/TFP/8819 Aug-24		
18	Roof mounted Air Conditioner I	20244000	· AE-CLW		
19	Roof mounted Air Conditioner II	29811028	AE-CLW	AMIT ENGG	



JELECS

	PATIALA LOCOMOTIVE WORKS, PATIALA							
	T		1/WAG-9HC/NR/K		1			
S.No.	-	PL No.		ent Serial No.	Mal	ke		
1	Complete Shell Assembly with piping	29171027	Sr. 22/	/27, 11/2024	SELV	ос		
2	Side Buffer Assly Both Side Cab I	29130050	293, 08/24	205, 08/24	FASP	FASP		
3	Side Buffer Assly Both Side Cab II	25130030	46, 08/24	135, 08/24	FASP	FASP		
4	CBC Cab I & II	29130037	56, 07/24	0049, 01/24	FASP	KM		
5	Hand Brake		09/	24- 17736	Modified I	Mechwel		
6	Set of Secondry Helical Spring	29045034 29041041			ABC			
-	Battery Boxes (both side)	29680013	80, 07/24	43, 07/24	D R STEEL	D R STEEL		
	Traction Bar Bogie I	ĺ	86	91, 10/24	KN			
	Traction Bar Bogie II	L	861	86, 10/24	KN			
	Centre Pivot Housing in Shell Bogie I side	29100057	00	04, 11/24	EV	E		
	Centre Pivot Housing in Shell Bogie II side	23100037	00	3, 11/24	EV			
	Elastic Ring in Front in Shell Bogie I side	20100010	0′	1, 07/24	AVA			
13	Elastic Ring in Front in Shell Bogie II side	29100010	19	06, 07/24	AVA			
	Main Transformer	29731008 for WAG 9 29731057 for WAP-7		BHL11500/29, 2024	CC			
	Oil Cooling Radiator I		4775	RPL, 07/24	STANDARD	PADIATORS		
	Oil Cooling Radiator II	29470031		15002/24-25/164	APOLLO HEAT			
	Main Compressor I with Motor	20511000		23411, 09/24	ELGI			
	Main Compressor II with Motor	29511008		23424, 09/24	ELGi			
	Transformer Oil Cooling Pump I			16, 10/24	SAMAL H			
	Transformer Oil Cooling Pump II	1		10, 10/24				
	Oil Cooling Blower OCB I			MT/24-25/386	SAMAL H			
	Oil Cooling Blower OCB II	29470043			FORCE MOTION			
	TM Blower I	·		25/382, 09/24 ICTMB340004	FORCE MOTION			
24 T	TM Blower II	29440075		ICTMB240904	IC ELECTRICA			
_	Machine Room Blower I			ICTMB240902	IC ELECTRICAL PVT LTD			
_	Machine Room Blower II	29440105		, AC-57560	ACC	EL		
	Machine Room Scavenging Blower I			99, CGLXGCM19038	ACC	EL		
	Machine Room Scavenging Blower II	29440129		SM-24.07.52	G.T.R CC	P(P) LTD		
	TM Scavenging Blower Motor I			07.60, 07/24	G.T.R CC			
		29440117	ST-24.0	05.94, 05/24	G.T.R CC			
$\overline{}$	TM Scavenging Blower Motor II			5.111, 05/24	G.T.R CC			
$\overline{}$	Traction Convertor I Traction Convertor II			31, 11/24	5.1	(P) LID		
	Vehicle Control Unit I	, I	583	32, 11/24	1			
	Vehicle Control Unit II	29741075	397	7 3, 10/24	1			
_	Aux. Converter Box I (BUR 1)	,	397	7 3, 10/24	MED	PHA		
	Aux. Converter Box 2 (BUR 2 + 3)	,		2, 11/24	1			
	Axillary Control Cubical HB-1	29171180		92,11/24	1			
	Axillary Control Cubical HB-2	29171180		08/2024, 08/24	KAYSONS ELECT	RICAL PVT LTD		
39 (Complete Control Cubicle SB-1	29171192	HB2/202	24/J/0178/680	HIND RECT			
40 (Complete Control Cubicle SB-2	29171210		05/SB1G9/044, 09/24	AUTOMETERS AL			
41 F	Filter Cubical (FB) (COMPLETE FILTER		24091	.695, 09/24	TROLEX IND			
	CUBICLES) Driver Seats	29480140	SLFBOO	0012407149	STESAL			
_		29171131	10/24- 10/	0, 124, 134, 154				
	Transformer oil steel pipes	29230044		SAL PIPES	TARUI	DEEP		
—	Conservator Tank Breather	29731057		59, 24-8195				
\vdash	Ballast Assembly (only for WAG-9)	29170163		5,61,54	YOGYA ENT			
40 1	Head Light			71, 1055	GF			
	U		1	1, 1000	ENSA	\VE		

NAME SHURMAN MARMA
SSE/LAS

NAME ANKIT UPPAL

NAME Karan Siyh

0



Issue No. : 05 Effective Date: July-2023

DOC NO: F/LAS/Electric Loco CHECK SHEET (Ref: WI/LAS/Elect/01, 02, 03 & 04 & QPL/LAS/Elect. Loco)

Page 1 of 1

पटियाला रेलइंजन कारखाना, पटियाला PATIALA LOCOMOTIVE WORKS, PATIALA ELECTRIC LOCO CHECK SHEET

LOCO NO: 41974

Rly: NR

Shed: KJGF

S. No.	ITEM TO BE CHECKED	Specified Value	C	bserved	Value		
1.1	Check proper Fitment of Hotel Load Converter & its output contactor.	ОК		- 1/	1		
1.2	Check proper Fitment of MR Blower 1 & 2, MR Scavenging Blower 1 & 2, TM Blower 1 & 2, TMB Scavenging Blower 1 & 2. TM scavenging blower 1 & 2 & Oil Cooling unit.	ОК		WL			
1.3	Check proper of Fitment of oil cooling unit (OCU).	OK		OL			
1.4	Check proper Fitment of HB 1 & 2 and its respected lower part on its position	OK		0)2			
1.5	Check proper Fitment of FB panel on its position	OK		CIL			
1.6	Check proper Fitment of assembled SB1 & SB2 panel.	OK		ol2			
1.7	Check proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3).	OK		0/2			
1.8	Check proper Fitment of Traction converter 1 & 2 (SR-1 & 2)	OK		<u>a</u>]2			
1.9	Check proper fitment, torquing & Locking of Main Transformer bolt	OK		(1)	2		
1.10	Check proper fitment of Main compressor both side with the compressor safety wire rope	OK		a)	2		
1.11	Check proper resting of Secondary Helical Springs between Bogie & Shell body	OK		0	2		
1.12	Check proper fitment of Bogie Body Safety Chains.	OK		4)	12		
1.13	Check proper fitment of Cow catcher.	OK		U			
1.14	Check coolant level in SR 1 & 2 Expansion Tank.	OK		a)			
1.15	Check Transformer Oil Level in both conservators Tank (Breather Tank).	OK		u) ²			
1.16	Check proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any damage during online working of Locomotives.	OK	OK.				
1.17	Check proper fitment of both battery box.	OK		0)	12		
1.18	Check for any gap between Main Transformer mounting base & Loco Shell.	OK		O)			
1.19	Check proper fitment of Push Pull rod its bolt torquing and fitment of fixing cable. As per Drg No 1209-01-113-001	OK		<i>0)4</i>			
1.20	Secondary Vertical and Lateral Clearance on leveled track at the time of Loco Dispatch.		CA	B-1	CAB-2		
	ELRS/TC/ 0082 (Rev 1) dated 17.09.2015	Vertical-Std	LP				
		:35-60 mm		ALP	LP ALF		
		Lateral Std-	53	•	53 53 55 41		
1.21	Buffer height: Range (1090, +15,-5)	45-50 mm 1085-1105					
	Drg No IB031-02002.	mm		L/S	R/S	1	
	*	***************************************	FRONT	10 99	5 1100		
			REAR	1092	1100		
1.22	Buffer Length: Range (641 mm + 3 to 10 mm with buffer face)	641 mm		L/S	R/S		
	Drg No-SK.DL-3430.		FRONT				
			REAR	645	646		
1.23	Height of Rail Guard. (114 mm + 5 mm,-12 mm).	444 5	REAR	642			
	As per RDSO Pamphlet Important Bogie Clearances of Electric Locomotives.	114 mm + 5 mm,-12 mm		L/S	R/S		
		111111,-12 mm	FRONT	112	115		
1.24	CBC Height: Range (1090, +15,-5)		REAR	118	115		
1.27	Drg No- IB031-02002.	1090, +15	FRONT:				
	n. 3 110 1200 1 42002.	-5 mm	REAR:	1097			

(Signature of SSE/Elect. Loco)

NAMESHUBHAM SHARMA

DATE 29/11/24

(Signature of /JE/Elect Loco)

NAME KARAN SINGL

DATE 20 11/24

(Signature of JE/UF)

NAME <u>ANKIT C</u>PMAL DATE 29/11/24

Loco No. 41974

1. BOGIE FRAME:

BOGIE	FRAME NO	Make	PL No.	PO No. & dt.	Warranty Period
FRONT	SL-01/733	FRONTIER	29100677	101678	As per PO/IRS
REAR	SL-02/734	FRONTIER	29100677	101678	conditions

2. Hydraulic Dampers (PL No.29040012) Make: ESCORT/ESCORT

3. AXLES:

AXLE POSITION NO	1	2	3	4	5	6
MAKE/	PLW	PLW	PLW	PLW	PLW	PLW
S.NO	27345	27600	27503	27748	27592	27509
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

4. WHEEL DISCS NO. AND TYPE & BULL GEAR

AXLE POSITION NO	1	2	3	4	5	6
GEAR END	PLW24-469	CNC24-3455	CNC24-3231	CNC24-3399	CNC24-3435	CNC24-3296
Make	D.P.	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
FREE END	PLW24-468	PLW24-86	CNC24-3348	CNC24-3401	CNC24-3369	CNC24-3482
Make	D.P.	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
Bull Gear No.	24-E-90	17271	17010	16026	13288	17284
Bull Gear Make	LMS	GGAG	GGAG	GGAG	GGAG	GGAG

5. AXLE ROLLER BEARING (CRU) (PL No. 29010020, Warranty: As per PO/IRS conditions)

AXLE POSITION NO		1	2	3	4	5	6
Gear	MAKE	FAG	FAG	FAG	FAG	FAG	FAG
End	PO NO. & dt	02191	02191	02191	02191	02191	02191
Free	MAKE	FAG	FAG	FAG	FAG	FAG	FAG
End	PO NO. & dt	02191	02191	02191	02191	02191	02191

6. WHEEL DISC PRESSING PRESSURE IN KN: (SPECIFIED 80-105 T)

AXLE POSITION NO	1	2	3	4	5	6
BULL GEAR END	979 KN	963 KN	104 T	881 KN	986 KN	104 T
FREE END	966 KN	96 T	83 T	793 KN	818 KN	105 T

Loco No. 41974

7. DIAMETER AFTER PROFILE TURNING: SPECIFIED 1092 + .5 mm - 0 mm

AXLE POSITION NO	1	2	3	4	5	6
DIA IN mm GE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
DIA IN mm FE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
WHEEL PROFILE GAUGE (1596±0.5mm)	OK	OK	OK	OK	OK	OK

8. SUSPENSION TUBE & ITS TAPER ROLLER BEARING:

AXLE POSITION NO		1	2	3	4	5	6
S.T. PL 29100288 MAKE		KM	BSL	SDI	SDI	SDI	SDI
GE Brg. PL 29030110	MAKE	FAG	NBC	NBC	NBC	NBC	NBC
FE Brg. PL 29030110	MAKE	FAG	NBC	NBC	NBC	NBC	NBC

9. GEAR CASE (PL No. 29030018) & BACKLASH:

AXLE POSITION NO	1	2	3	4	5	6
MAKE	KM	KM	KM	KM	KM	KM
BACKLASH (0.254 – 0.458mm)	0.310	0.330	0.320	0.275	0.260	0.275

10 A/BOX TO BOGIE FRAME LATERAL CLEARANCES (SPECIFIED 15.0 to 19.0mm):

AXLE POSITION NO	1	2	3	4	5	6
RIGHT SIDE	17.35	16.12	17.23	16.92	18.10	15.62
LEFT SIDE	15.73	18.13	18.02	17.70	17.99	16.97

11. TRACTION MOTOR: (PL No.29940606, Warranty: As per PO/IRS conditions)

AXLE POSITION NO	MAKE	PO No. & Date	S. NO.
1	TITAGARH	101650	6FRA24191
2	TITAGARH	101650	6FRA24189
3	TITAGARH	101650	6FRA24227
4	TITAGARH	101650	6FRA24218
5	TITAGARH	101650	6FRA24221
6	TITAGARH	101650	6FRA24217

JE/SSE/ Bogie Shop

TOP 12 COSTLIEST ITEMS OF WAG9HC LOCO WITH WARRANTY CONDITIONS AS PER TENDERS

S No	PL No	DESCRIPTION	Warranty Period
1	29741075	IGBT BASED 3-PHASE DRIVE PROPULSION EQUIPMENT	60 months after commissioning or 72 months from date of supply whichever earlier as per special conditions given by CLW
2	29731057	MAIN TRANSFORMER 7775 KVA TYPE LOT 7500 FOR WAP7 3- PHASE ELECTRIC LOCOMOTIVE TO CLW SPECN NO.CLW/ES/3/0660/C	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
3	29171064	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT- 8	AS PER IRS CONDITIONS-30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER.
4	29600418	LOCOMOTIVES TO CLW SPECN. NO. CLW/ES/03/646 ALT-NIL WITH DMW REQUIREMENT OF HARNESSED	As per clause no.9 of CLW Specn. CLW/ES/3/0458 & Clause No.10 of CLW SpecnCLW/ES/3/0459. [18 months after commissioning or 20 months from date of supply for single core & 18 months after commissioning or 24 months from date of supply for multi core]

7	29942007	3-PHASE ASYNCHRONOUS TRACTION MOTOR (RESISTANCE RING MECHANICALLY INTERLOCKED TO END PLATE DESIGN ROTOR, SCHEME-II), TYPE 6FRA-6068 FOR WAP-7 ELECTRIC LOCO WITHOUT ACTIVE SPEED SENSOR TO SPECIFICATION NO. 4TMS.096.081 ALT-2 AND STR NO. CLW/2008/3PHTM/STR/0001.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
6	29480140	COMPLETE FILTER CUBICLE ALONG WITH ALL EQUIPMENTS AND CABLING TO DRG./SPEC NO. [1] CLW/ES/3/0193 ALT-F OR LATEST AND CLW DRG. NO. 1209-15-143-004 ALT-10 AND PART DRG./SPEC NO AS PER ANNEXURE-A ATTACHED.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
5	29180016	BRAKE CONTROL SYSTEM INCLUDING DRIVER'S VIGILANCE CONTROL DEVICE TO SET LIST NO.EL29180016.	As per specification no. CLW/MS/3/001 Alt. 16 i.e. the manufacturer is required to guarantee that the brakevalves/equipment work satisfactorily for a period of five (5) years after commissioning. Any equipment/part which failsduring the guarantee period shall be replaced free of cost by the manufacturer. The replaced components shallfurther be under warranty for five (5) years from the date of their fitment and should the replaced components proveunsatisfactory in service, they shall be replaced by modified and improved components by the supplier free of cost.

8	29105146	Bogie Frame Complete for WAP-7 for 3 Phase Co Co Locomotive to CLW specification No. CLW/MS/3/Bogie/003 alt-1 and CLW Drg.No.1209.01.112-202 Alt-Nil	As per clause 16 of Spec.No.CLW/MS/3/Bogie/003 Alt-1. [60 months after commissioning or 72 months from date of supply]
9	29171192	COMPLETE AUXILIARY CUBICLE HB2 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0192 ALT-E OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
10	29171210	COMPLETE CONTROL CUBICLE SB2 ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0195/A ALT-H OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
11	29171209	COMPLETE CONTROL CUBICLE SB1 (PUSH PULL SCHEME COMPLIANT) ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0194 ALT-G OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
12	29171180	COMPLETE AUXILIARY CUBICLE HB1 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0191 ALT-D OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.



भारत सरकार **GOVERNMENT OF INDIA**

रेल मंत्राल्य

MINISTRY OF RAILWAYS

पटियाला रेलइंजन कारखाना

PATIALA LOCOMOTIVE WORKS

Email: dyceeloco.dmw@gmail.com

फैक्स/Fax No.: 0175-2397244 फोन/ Phone: 0175- 2396422

मोबाईल: 9779242310 पटियाला, 147003, भारत् PATIALA, 147003, INDIA



(An ISO 9001, ISO 14001, ISO 45001 & ISO 50001, 5S & Green Building certified Organization)

संख्या. PLW/M/ECS/Tech/Kavach

तिथि: As signed

(Through Mail)

Sr. Div. Electrical Engineer, Electric Loco Shed, Khanalampura.

Email: els.kjgy@gmail.com

विषय:- Fitment of KAVACH in three Phase Electric Loco. No. 41974 WAG9-HC.

संदर्भ:- (i)Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 21.08.2023.

(ii)Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 26.09.2023

In ref. to the above letter's Loco No. 41974 has been dispatched with fittings for implementation of KAVACH system in locomotive at home shed in Zonal Railway. This Loco was dispatched to ELS/KJGY/NR on 19.12.2024. The details of fittings are attached as Annexure-A (pneumatic fittings), Annexure-B (Kavach equipment mounting Brackets) & Annexure-C (Wago with harnessed lay out).

This is for your information & necessary action please.

Digitally signed by NISHANT BANSIWAL Date: 2025.01.21 _{18:09:28 +05'30'} (निशांत बसीवाल)

NISHANT BANSIWAL

उप मुख्य विद्युत अभियंता/लोको

प्रतिलिपि:-

CEE/Loco & CEE/D&Q, CMM, CELE/NR:- for kind information please Dy CME/Design, Dy. CMM/Depot: for information & necessary action please WM/LAS, AWM/LFS&ABS, AWM/ECS: for necessary action please

Loco No. 41974

3))		Presentation officia	eiv,
		ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITH VENT	04 nos.
1	29163341	ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITHOUT VENT	02 nos.
		TEE UNION 3/8"X3/8"X3/8" BRASS FITTINGS	02 nos.
		MALE CONNECTORS 3/8" TUBE OD X 3/8" BSPT, BRASS FITTINGS	09 nos.
		MALE CONNECTORS 1/2" TUBE OD X 1/2" BSPT, BRASS FITTINGS	06 nos.
		FEMALE CONNECTORS (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	01 no.
		MALE CONNECTOR (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	03 nos
		FEMALÉ TEE 3/8" BSPP – BRASS	06 nos
2	29611994	HEX PLUG -3/8" BSPT – BRASS	02 nos
		FEMALE TEE 1/2" BSPP - BRASS	04 nos
		HEX NIPPLE 3/8X3/8" BSPT - BRASS	04 nos
		RED HEX NIPPLE 3/8X1/2" BSPT - BRASS	02 nos
		HEX PLUG – 1/2" BSPT – BRASS	04 nos
		MALE ELBOW CONNECTORS 3/8" TUBE OD X 3/8) BSPT. BRASS FITTINGS	02 nos
-3	29170114	Copper Tube OD 9.52mm (3/8") X 1.245 Mm W.T X 6 Mtr	1.2Mtr

AWMARS & LFS

SSE/G/ABS

SN	PL No.	Description of item	Quantity
1.	29611945	Mounting bracket arrangement provided for RF Antenna on the roof top of both driver cabs.	04 nos.
2.		Mounting bracket arrangement provided for GPS/GSM Antenna on the roof top of both driver cabs.	02 nos.
3.		Protection Guards for RFID reader provided behind the cattle guards of both side.	04 nos.
4.		Inspection door with latch provided on the both driver desk covers (LP side) in each cab to access isolation cock.	02 nos.
5.		Cable Entry Plate fitted for routing of cable with RF Antenna & GPS/GSM Antenna bracket.	06 nos.
6.	-	WAGO bracket fitted in Machine room at back side of SB-1.	01 no.
7.	**	One circular hole of 80 mm dia. provided in each cabs on LP side behind the driver desk toward the wall for routing of OCIP (DMI) cables.	02 nos.
8.	-	80 mm holes provided on TM1 and TM6 Junction box inspection cover hole for drawing of RFID reader cables.	02 nos.
9.	-	DIN Rail fitted inside the driver desk (LP Side)	02 nos.

AWM/ABS & LFS

SSE/G/LFS

Annexure-C

SN	PL No.	Description of item	Quantity
1.	42310301	Flexible conduit size 25mm ² provided for RF-1, 2 & GPS Antenna cable layout from CAB-1&2 to Machine room.	06 mts.
2.	29611982	Wago terminals in CAB-1&2 (25 nos. in each CAB).	50 nos.
3.	29611982	Wago terminal in Machine room at back side of SB-1.	75 nos.
4.		Harness provided from KAVACH SB to SB-1	07 wires
5.	· -	Harness provided from KAVACH SB to SB-2	05 wires
6.	-	Harness provided from KAVACH SB to Pneumatic Panel	12 wires
7.	-	Harness provided from KAVACH SB to CAB-1	/6 wires
8.	-	Harness provided from KAVACH SB to CAB-2	16 wires

·AWM/ECS

fr... 88E/G/ECS