# भारतीय रेल Indian Railways

पटियाला रेलइंजन कारख़ाना, पर्टियाला

# PATIALA LOCOMOTIVE WORKS, PATIALA



# LOCO TESTING & DISPATCH REPORT OF IGBT BASED WAG9HC ELECTRIC LOCOMOTIVE

LOCO NO.: 41921

TYPE: WAG9HC

RAILWAY SHED: WCR/ETE

PROPULSION SYSTEM: CGL

**DATE OF DISPATCH:** 31.08.2024

लोको निर्माण रिकार्ड



# पटियाला रेलइंजन कारख़ाना, पटियाला

# PATIALA LOCOMOTIVE WORKS, PATIALA

LOCO NO.: 41921

**RAILWAY/SHED: WCR/ETE** 

**DOD: Aug-2024** 

#### **INDEX**

SN	PARA	ACTIVITIES	PAGE NO.
		Testing & Commissioning (ECS)	
1.	1.0	Continuity Test of the cables	
	1.1	Continuity Test of Traction Circuit Cables	
	1.2	Continuity Test of Auxiliary Circuit Cables	1-4
	1.3	Continuity Test of Battery Circuit Cables	
	1.4	Continuity Test of Screened Control Circuit Cables	
2.	2.0	Low Tension test	
	2.1	Measurement of resistor in OHMS (Ω)	5-6
	2.2	Check Points	3-0
	2.3	Low Tension Test Battery Circuits (without control electronics)	
3	3.0	Downloading of Software	
	3.1	Check Points	
	3.2	Download Software	7-10
	3.3	Analogue Signal Checking	
	3.4	Functional test in simulation mode	
4	4.0	Sensor test & convertor test	
	4.1	Test wiring Transformer Circuits – Polarity Test	
	4.2	Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)	
	4.3	Primary Voltage Transformer	
	4.4	Minimum voltage relay (Pos. 86)	11-16
	4.5	Maximum current relay (Pos. 78)	11-10
	4.6	Test current sensors	
	4.7	Test DC Link Voltage Sensors (Pos 15.6/*)	
	4.8	Verification of Converter Protection Circuits (Hardware limits)	
	4.9	Sequence of BUR contactors	
5.	5.0	Commissioning with High Voltage	
	5.1	Check List	
	5.2	Safety test main circuit breaker	
	5.3	Auxiliary Converter Commissioning	
	5.3.1	Running test of 3 ph. auxiliary equipments	
	5.3.2	Performance of Auxiliary Converters	
	5.3.3	Performance of BURs when one BUR goes out	16-25
	5.4	Auxiliary circuit 415/110	
	5.5	Hotel Load Circuit	
	5.6	Traction Converter Commissioning	
	5.7	Test protective shutdown SR	
	5.8	Test Harmonic Filter	
	5.9	Test important components of the locomotive	05.00
6. 7.	6.0	Running Trial of the locomotive	25-26
	7.0	Final Check List to be verified at the time of Loco dispatch	27
8.	8.0	Status of RDSO modifications	28
9.	1-10	Pneumatic Test Parameters	29 - 32
10.		Loco Check Sheet(LAS)	33
11.	-	Component History (LAS,ECS,ABS)	34-36
12.	-	Component History & Testing Parameter (Bogie Shop)	37 - 38
13	-	Warranty Conditions as per Tenders	39 -41

Effective Date: Feb 2022

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41921 - CG 2

Type of Locomotive: WAP-7/WAG-9HC

Page: 1 of 27

(Ref: WI/ECS/10)

1.0 Continuity Test of the cables

1.1 Continuity Test of Traction Circuit Cables As per cable list given in Para 1.3 of document no. 3 EHX 410 124, check the continuity with continuity tester and megger each cable to be connected between following equipment with 1000V megger.

From	То	Continuity (OK/Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Filter Cubicle	Transformer	ok	100 ΜΩ	100 ome
Filter Cubicle	Terminal Box of Harmonic Filter Resistor (Roof)	ok	100 ΜΩ	1000mg
Filter Cubicle	Earthing Choke	OK	100 ΜΩ	900 ms
Earthing Choke	Earth Return Brushes	ок	100 MΩ	Booms
Transformer	Power Converter 1	ok	100 ΜΩ	900ma
Transformer	Power Converter 2	OK	100 ΜΩ	1000 m
Power Converter 1	TM1, TM2, TM3	ok	100 ΜΩ	Gooma
Power Converter 2	TM4, TM5, TM6	οŁ	100 ΜΩ	900m2
Earth	Power Converter 1	OK	100 ΜΩ	1000 ma
Earth	Power Converter 2		100 ΜΩ	gooms

### 1.2 Continuity Test of Auxiliary Circuit Cables

As per cable list given in Para 1.4 of document no. 3 EHX 410 124, check the continuity with continuity meter and megger each cable to be connected between following equipment with the help of 1000V megger.

Signature of the JE/SSE/Harness

Signature of the JE/SSE/Loco Cabling

# PATIALA LOCOMOTIVE WORKS, PATIALA

# Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.:

Type of Locomotive: WAP-7/WAG-9HC

Page : 2 of 27

From	То	Continuity(OK/ Not OK)	Prescribed Megger Value (min)	Measured Megger Value
		OK	100 ΜΩ	500 M1
Transformer	BUR1	))	100 ΜΩ	700
Transformer	BUR2	21	100 M $\Omega$	600
Transformer	BUR3	1)	100 ΜΩ	700
<u>Earth</u>	BUR1	"	100 ΜΩ	500
<u>Earth</u>	BUR2	n	100 ΜΩ	400
Earth	BUR3	h	100 MΩ	600
BUR1	HB1		100 ΜΩ	700
BUR2	HB2	<u>"</u>	100 ΜΩ	500
HB1	HB2	<u>b</u>	100 ΜΩ	600
HB1	TM Blower 1		100 ΜΩ	600
HB1	TM Scavenge Blower 1	り	<u> </u>	700
HB1	Oil Cooling Unit 1	n	100 ΜΩ	500
HB1	Compressor 1	17	100 ΜΩ	
HB1	TFP Oil Pump 1	1)	100 ΜΩ	600
HB1	Converter Coolant Pump 1	り	100 MΩ	700
HB1	MR Blower 1	12	$100~ extsf{M}\Omega$	1000
HB1	MR Scavenge Blower 1	1)	100 ΜΩ	500
HB1	Cab1	2/	100 ΜΩ	600
Cab1	Cab Heater 1	V	100 ΜΩ	700
HB2	TM Blower 2	1)	100 ΜΩ	800
HB2	TM Scavenge Blower 2	1)	100 ΜΩ	600
HB2	Oil Cooling Unit 2	12	100 ΜΩ	600
	Compressor 2	17	100 ΜΩ	500
HB2 HB2	TFP Oil Pump 2	11	100 ΜΩ	500
HB2	Converter Coolant Pump 2		100 MΩ	600
HB2	MR Blower 2	17	100 ΜΩ	606
			100 ΜΩ	600
HB2	MR Scavenge Blower 2	14	100 ΜΩ	600
HB2	Cab2		100 MΩ	700
Cab2	Cab Heater 2	$\nu$	100 10132	

Effective Date: Feb 2022

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/921

1.3 Continuity Test of Battery Circuit Cables

Type of Locomotive: WAP-7/WAG-9HC

Page: 3 of 27

(Ref: WI/ECS/10)

Check continuity of following cables as per Para 2.3 of document no. 3 EHX 610 299

Continuity of following Car	То	Condition	Continuity (OK/Not OK)
Battery (wire no 2093)	Circuit breakers 110- 2, 112.1-1, 310.4-1	By opening and closing MCB 112	ok
MCB 110	Connector 50.X7-1	By opening and closing MCB 110	BK
Battery (Wire no. 2052)	Connector 50.X7-2		ok.
SB2 (Wire no 2050)	Connector 50.X7-3		ob_

Close the MCB 112, 110, 112.1, and 310.4 and measure the resistance of battery wires 2093, 2052, 2050 with respect to the loco earth.	Prescribed value $> 0.5 \ M\Omega$	Measured  Value MΩ
Measure the resistance between 2093 & 2052, 2093 & 2050, 2052 & 2050	Prescribed value: $> 50 \text{ M}\Omega$	Measured  Value

Commission the indoor lighting of the locomotive as per Sheet No 7A & 7B.

### 1.4 Continuity Test of Screened Control Circuit Cables

Check the continuity and isolation of the screen cable of the following circuits with the help of sheet no. mentioned against each as per document no. 3 EHX 610 299.

Corresponding Sheet Nos.	Continuity & Isolation (OK/Not OK)
04B	ok
10A	OK
10A	ok
01A, 12A	ok
06F, 06G	ok_
	Sheet Nos.  04B  10A  10A  01A, 12A

Effective Date: Feb 2022

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

# Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4152

Type of Locomotive: WAP-7/WAG-9HC Page : 4 of 27

traller eab 1 8.7	08C, 08D	ok
Master controller cab-1 &2	08E, 08F	ok
TE/BE meter bogie-1 & 2	09F	oK
Terminal fault indication cab-1 & 2		ok
Brake pipe pressure actual BE electric	06H	
Primary current sensors	12B, 12F	DK
Harmonic filter current sensors	12B, 12F	8K
Auxiliary current sensors	12B, 12F	ok
Oil circuit transformer bogie 1	12E, 12I	ok
Magnetization current	12C, 12G	ok
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-1	12D	ok
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-2	12D	ok
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-3	12D	ok
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-4	12H	ok
Traction motor speed sensors (2 no.) and temperature sensors (1 no.) of TM-5	12H	ok
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-6	12H	Ok
Train Bus cab 1 & 2 (Wire U13A& U13B to earthing resistance=	13A	ok
10KΩ± ± 10%)	420	OK
UIC line	13B	
Connection FLG1-Box TB	13A	8B-

# PATIALA LOCOMOTIVE WORKS, PATIALA

### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41921

Type of Locomotive: WAP-7/WAG-9HC

Page: 5 of 27

#### 2.0 Low Tension test

Measure the resistances of the load resistors for primary voltage transformer, load resistors for primary current transformer and Resistor harmonic filter as per Para 3.2 of the document no. 3 EHX 610 279.

Call mariator	Prescribed value	Measured value
ame of the resistor oad resistor for primary voltage	3.9K <b>Ω</b> ± 10%	3.9Kr
ransformer (Pos. 74.2).	1Ω ± 10%	10
tesister to maximum current relay.	3.3 Ω ± 10%	3.3-2
oad resistor for primary current	J.5 12 2 2070	WAP7
ransformer (Pos. 6.11).	WAP7	VVAF
Resistance harmonic filter (Pos 8.3). Variation allowed $\pm$ 10%		
	0.2 Ω	0.25
Between wire 5 & 6  Between wire 6 & 7	0.2 Ω	
	0.4 Ω	0.452
Between wire 5 & 7	10 kΩ± 10%	988 KJ
For train bus, line U13A to earthing.	10 k <b>Ω</b> ± 10%	10.0kg
For train bus, line U13B to earthing.	200 MΩ	300 MN
Insulation resistance of High Voltage Cable from the top of the roof to the earth		
(by1000 V megger).		0.282
Resistance measurement earth return	≤0.3 Ω	
brushes Pos. 10/1.	≤0.3 Ω	0.28 2
Resistance measurement earth return	20.3 12	
brushes Pos. 10/2.  Resistance measurement earth return	≤0.3 Ω	0.301
brushes Pos. 10/3.		
Resistance measurement earth return	≤0.3 Ω	0.281
brushes Pos. 10/4. Earthing resistance (earth fault detection)	2.2 kΩ± 10%	2.2 42
Harmonic Filter –I; Pos. 8.61.		0.20
Earthing resistance (earth fault detection)	2.7 k <b>Ω</b> ± 10%	2,742
Harmonic Filter –II; Pos 8.62.	3.9 kΩ ± 10%	3.8K2
Earthing resistance (earth fault detection) Aux. Converter; Pos. 90.3.	J.J ((22 2 20/0	
Earthing resistance (earth fault detection)	1.8 kΩ± 10%	1.8km
415/110V; Pos. 90.41.		3905
Earthing resistance (earth fault detection) control circuit; Pos. 90.7.	390 <b>Ω</b> ± 10%	·
Earthing resistance (earth fault detection) Hotel load; Pos. 37.1(in case of WAP5).	3.3 k <b>Ω</b> ± 10%	NA
Resistance for headlight dimmer; Pos. 332.3.	10Ω ± 10%	10.52

Effective Date: Feb 2022

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/921

Type of Locomotive: WAP-7/WAG-9HC Page: 6 of 27

Make sure that the earthing brush device don't make direct contact with the axle housing,

earth connection must go by brushes.

#### 2.2 Check Points

	Remarks
tems to be checked	
Check whether all the earthing connection in roof and machine room as mentioned in sheet no. 22A is done properly or not.  These earthing connections must be flexible and should be marked yellow & green	checked ok
Check whether all the earthing connection between loco body and bogie is done properly or not. These cables must be flexible having correct length and cross section	Cheshed or

# 2.3 Low Tension Test Battery Circuits (without control electronics)

These tests are done with the help of the special type test loop boxes as per procedure given in Para 3.6 of the document no. 3 EHX 610 279

Para 3.6 of the document no. 3 EHX 6  Name of the test	Schematic used.	Remarks
Test 24V supply	Sheet 04F and other linked sheets	checked ok
Test 48V supply	Sheet 04F & sheets of group 09	Fan supply to be checked.
Test traction control	Sheets of Group 08.	ok
Test power supply bus stations.	Sheets of Group 09.	Fan supply to be checked
Test control main apparatus	Sheets of Group 05.	ok
Test earth fault detection battery circuit by making artificial earth fault to test the earth fault detection	Sheet 04C	øk.
Test control Pneumatic devices	Sheets of Group 06	ok
Test lighting control	Sheets of Group 07	ok
Pretest speedometer	Sheets of Group 10	OK.
Pretest vigilance control and fire	Sheets of Group 11	øk
Power supply train bus	Sheets of Group 13	ok.

# PATIALA LOCOMOTIVE WORKS, PATIALA

#### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 418久1 **Downloading of Software**  Type of Locomotive: WAP-7/WAG-9HC

Page: 7 of 27

	Yes/NO
3.1 Check Points.	
Check that all the cards are physically present in the bus stations and all the plugs are connected.	Yes
Check that all the fibre optic cables are correctly connected to the bus stations.	Yes
Make sure that <b>control electronics off relay</b> is not energized i.e. disconnect Sub-D	Yes
Check that battery power is on and all the MCBs (Pos. 127.*) in SB1 &SB2 are on	Yes

3.2 Download Software

The software of Traction converter, Auxiliary converter and VCU should be done by commissioning engineer of the firm in presence of supervisor. Correct software version of the

propulsion equipment to be ensured and noted:

propulsion equipment to be ensured and noted:	20
Traction converter-1 software version:	28
Traction converter-2 software version:	28
Auxiliary converter-1 software version:	50
Auxiliary converter-2 software version:	4.0
Auxiliary converter-3 software version:	4,0
Vehicle control unit -1 software version:	1600
Vehicle control unit -2 software version:	1600

3.3 Analogue Signal Checking

Check for the following analogue signals with the help of diagnostic tool connected with loco.

Description	g analogue signals with the help of diag Signal name	Prescribed value	Measured Value
Brake pipe pressure	FLG2;0101XPrAutoBkLn	100% (= 5 Kg/cm2)	ON.
Actual BE electric	FLG2; AMSB_0201- Wpn BEdem	100% (= 10V)	92
TE/BE at 'o' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 9% and 11 %	104,
TE/BE at 'TE maximal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB 0101- Xang Trans	Between 99 % and 101 %	100%
TE/BE at 'TE minimal' position from both cab	FLG1; AMSB_0101- Xang Trans	Between 20 % and 25 %	2-57

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

# Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/921

Type of Locomotive: WAP-7/WAG-9HC

Page: 8 of 27

•	e e		1
TE/BE at 'BE maximal' position from both cab	FLG2; AMSB_0101-	Between 99% and 101%	1001,
TE/BE at 'BE Minimal' position from both cab	XangTrans FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101-	Between 20% and 25%	2-57.
TE/BE at '1/3' position in TE and BE mode in both cab.	XangTrans HBB1; AMS_0101- LT/BDEM>1/3 HBB2; AMS_0101- LT/BDEM>1/3	Between 42 and 44%	444,
TE/BE at '1/3' position in TE and BE mode in both cab.		Between 72 and 74%	741,
Both temperature sensor of TM1	SLG1; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	1500
Both temperature sensor of TM2	SLG1; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	
Both temperature sensor of TM3	SLG1; AMSB_0106- Xatmp3Mot		) ( )
Both temperature sensor of TM4	SLG2; AMSB_0106- XAtmp1Mot		) / 4. 2
Both temperature sensor of TM5	SLG2; AMSB_0106- Xatmp2Mot		0 (3
Both temperature sensor of TM6	SLG2; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	1500

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41921

Type of Locomotive: WAP-7/WAG-9HC

Page: 9 of 27

#### Functional test in simulation mode 3.4

Conduct the following functional tests in simulation mode as per Para 5.5 of document no.3EHX 610 281. through the Diagnostic tool/laptop:

Test Function	Result desired in sequence	Result obtained
Emergency shutdown through emergency stop switch 244	VCB must open. Panto must lower.	cheched ok
Shut Down through cab activation switch to OFF position	VCB must open. Panto must lower.	checked ok
Converter and filter contactor operation with both Power Converters during Start Up.	FB contactor 8.41 is closed.  By moving reverser handle:  Converter pre-charging contactor 12.3 must close after few seconds.  Converter contactor 12.4 must close.  Converter re-charging contactor 12.3 must opens.  By increasing TE/BE throttle:  FB contactor 8.41 must open.  FB contactor 8.2 must close.  FB contactor 8.1 must close.	acched ok
Converter and filter contactor operation with both Power Converters during Shut Down.	Bring TE/BE to O. Bring the cab activation key to "O" VCB must open. Panto must lower. Converter contactor 12.4 must open. FB contactor 8.1 must open. FB contactors 8.41 must close. FB contactor 8.2 must remain closed.	chaebel ok

Effective Date: Feb 2022

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

# Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/92/

Type of Locomotive: WAP-7/WAG-9HC Page: 10 of 27

coloting any hogie	Isolate any one bogie through bogie cut out switch. Wait for self-test of the loco.	
	<ul> <li>Check that FB contactor 8.1 is open.</li> <li>Check that FB contactor 8.2 is open.</li> <li>After raising panto, closing VCB, and setting TE/BE</li> <li>FB contactor 8.1 closes.</li> <li>FB contactor 8.2 remains open.</li> </ul>	Checkeelok
Test earth fault detection battery circuit positive & negative	By connecting wire 2050 to earth, create earth fault negative potential.  • message for earth fault  • By connecting wire 2095 to earth, create earth fault positive potential.  • message for earth fault	checked ok
Test fire system. Create a smoke in the machine room near the FDU. Watch for activation of alarm.	<ul> <li>When smoke sensor-1 gets activated then</li> <li>Alarm triggers and fault message priority 2 appears on screen.</li> <li>When both smoke sensor 1+2 gets activated then</li> <li>A fault message priority 1 appears on screen and lamp LSF1 glow.</li> <li>Start/Running interlock occurs and TE/BE becomes to 0.</li> </ul>	Checked of
Time, date & loco number	Ensure correct date time and Loco number	Ok

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

#### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/921

Type of Locomotive: WAP-7/WAG-9HC

Page: 11 of 27

Sensor Test and Converter Test

#### 4.1 Test wiring main Transformer Circuits

Apply  $198V_p/140V_{RMS}$  to the primary winding of the transformer (at 1u; wire no. 2 at surge arrestor and at 1v; wire no. 100 at earthing choke). Measure the output voltage and compare

Output Winding nos.	Description of winding.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
2U <sub>1</sub> & 2V <sub>1</sub>	For line converter bogie 1 between cable 801A- 804A	10.05V <sub>p</sub> and same polarity	10.044	صد_
2U <sub>4</sub> & 2V <sub>4</sub>	For line converter bogie 1 between cable 811A-814A	10.05V <sub>p</sub> and same polarity	10.04 VP	OK.
2U <sub>2</sub> & 2V <sub>2</sub>	For line converter bogie 2 between cable 801B-804B	10.05V <sub>p</sub> and same polarity	10.0211	ar.
2U <sub>3</sub> & 2V <sub>3</sub>	For line converter bogie 2 between cable 811B- 814B	10.05V <sub>p</sub> and same polarity	10.044	OK.
2U <sub>B</sub> & 2V <sub>B</sub>	For aux. converter 1 between cable 1103- 1117 (in HB1) For Aux converter 2 between cable 1103- 1117 (in HB2)	7.9V <sub>p</sub> , 5.6V <sub>RMS</sub> and same polarity.	7.8 VP 5-5 VRM3	G/_
2U <sub>F</sub> & 2V <sub>F</sub>	For harmonic filter between cable 4-12 (in FB)	9.12V <sub>p</sub> , 6.45V <sub>RMS</sub> and same polarity.	9.10vl 6.4uple	ou

#### 4.2 Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)

Apply  $141V_p$  /  $100V_{RMS}$  to input of the auxiliary transformer at cable no 1203 –1117 and measure the output at

Description of wire no.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
Cable no. 1218 - 1200	30.7 VB, 41.3 V KIMIS WILLIAM P. P. S.	41 5VRM	OK
Cable no. 1218 – 6500	15.5V <sub>p</sub> , 11.0V <sub>RMS</sub> and opposite polarity.	15.5 VI	عد

Effective Date: Feb 2022

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

41921 Locomotive No.:

Type of Locomotive: WAP-7/WAG-9HC

Page: 12 of 27

(Ref: WI/ECS/10)

#### **Primary Voltage Transformer** 4.3

Apply  $250V_{eff}/350V_p$  by variac to roof wire 1 and any wire 0 and measure the magnitude and polarity of the output of the primary voltage transformer for both bogies as per the procedure specified and suggested by the traction converter manufacturer. Primary voltage measurement converters (Pos. 224.1/\*) & catenary voltmeter (Pos. 74/\*)

This test is to be done for each converter.

Activate cab in driving mode and supply  $200V_{RMS}$  through variac to wire no 1501 and 1502. Monitor the following parameters through Diagnostic tool and in catenary voltmeter.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	25kV	250%	2544	2501
SLG2 G 87-XUPrim	25 kV	250%	2540	23-1

Decrease the supply voltage below 140  $V_{RMS}$ . VCB must open at this voltage. In this case the readings in Diagnostic Tool and catenary voltmeter will be as follows.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	17kV	170%	17KV	1704
SLG1_G 87-XUPrim	17 kV	170%	17K-V	1704

Reactivate VCB to on by increasing this voltage to 175% (17.5 kV).

Increase the supply to 240  $V_{\mbox{\scriptsize RMS}}$  through variac. VCB must open at this voltage, In this case the readings in diagnostic tool and catenary voltmeter will be as follows:

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	30kV	300%	30KX	3004
SLG2 G 87-XUPrim	30 kV	300%	30KN	300/1

Reactivate VCB to on by decreasing this voltage to 290% (29 kV).

#### (Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/991

**Functionality test:** 

display.

display.

 $/9.9A_p$  at the open wire 1521;

VCB opens with Priority 1 fault message on

Type of Locomotive: WAP-7/WAG-9HC

Page: 13 of 27

#### Minimum voltage relay (Pos. 86) 4.4

<u>Minimum voltage relay (Pos. 86) must be adjust</u>	ted to approx 68%
Minimum voltage relay (Pos. 86) must be dujus	(Yes/No)
Activate loco in cooling mode. Check Power supply of 48V to minimum voltage relay. Disconnect primary voltage transformer (wire no. 1511 and 1512) from load resistor (Pos. 1501 and 1502 Supply	
74.2) and connect variac to wire no. 1501 and 1502. Supply 200V <sub>RMS</sub> through variac. In this case; <i>Minimum voltage relay</i>	
200V <sub>RMS</sub> through variac. In this case, whithin voices	
(Pos. 86) picks up	
Try to activate the cab in driving mode:	(Yes/No)
Contactor 218 do not close; the control	
electronics is not be working.	
Turn off the variac :	Mes/No)
Contactor 218 closes; the control electronics is be	
working	·
Test Under Voltage Protection	1;
	,
Activate the cab in cooling mode; Raise panto;	KYes/No)
Supply 200V <sub>RMS</sub> through variac to wire no. 1501	
& 1502; Close the VCB; Interrupt the supply	
voltage	
The VCB goes off after 2 second time delay.	
	V(Yes/No)
Again supply 200V <sub>RMS</sub> through variac to wire no. 1501 & 1502; Decrease the supply voltage below	
140V <sub>RMS</sub> ± 4V; Fine tune the minimum voltage relay so that VCB opens.	
Fine tune the militaritum voltage relay so that veb opens.	
4 (5 - 70)	•
4.5 Maximum current relay (Pos. 78)	Comment regrice to using 1521
Disconnect wire 1521 & 1522 of primary current transform	mer; Connect Variac to wile 1321
&1522 (including the resistor at Pos. 6.11); Put loco in simulation	tion for driving mode; Open R3 = R4
on contact 136.3; Close VCB; supply 3.6A <sub>RMS</sub> at the open	wire 1521; Tune the druin of the
maximum current relay Pos. 78 for correct over current value	
di Cirili managan an	(Yes/No)
VCB onens with Priority 1 fault message on	(7,00),10)

Signature of the JE/SSE/Loco Testing

Keep contact  $R_3$  –  $R_4$  of 136.3 closed; Close VCB; Tune the resistor 78.1 for the current of 7.0 $A_{RMS}$ 

# PATIALA LOCOMOTIVE WORKS, PATIALA

# Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41921

Type of Locomotive: WAP-7/WAG-9HC

Page: 14 of 27

1.6 Test current sensors Name of the sensor	Description of the test	Prescribed value	Set/Measured value
Primary return current sensor (Test-1,Pos.6.2/1 & 6.2/2)	Activate cab in driving mode supply 10A. Measure the current through diagnostic tool or measuring print.	(Variation allowed is ± 10%)	
	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)	· • • • • • • • • • • • • • • • • • • •	
Primary return current sensor (Test-2, Pos.6.2/1 & 6.2/2)	Supply 297mA <sub>DC</sub> to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		298mB
Auxiliary winding current sensor (Pos. 42.3/1 & 42.3/2)	Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AC/1or 2 pin no. 7(+) & 8(-) Supply 333mA <sub>DC</sub> to the test winding of sensor through connector 415.AC/1		336 mm
Harmonic filter current sensors (Pos.8.5/1 &8.5/2)	or 2 pin no. 7(+) & 8(-)  Supply 90mA <sub>DC</sub> to the test winding of sensor through connector 415.AE/10 2 pin no. 7(+) & 8(-)	f r	
	Supply 342mA <sub>DC</sub> to the test winding of sensor through connector 415.AE/10 2 pin no. 7(+) & 8(-)	r	345mn
Hotel load current sensors (Pos. 33/1 &	Switch on hotel load. Supply 90mA <sub>DO</sub> to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) 8(-)		NA
33/2)	Supply 1242mA <sub>DC</sub> to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)	g NA	MA

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

#### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41921

Type of Locomotive: WAP-7/WAG-9HC

Page: 15 of 27

4.7 Test DC Link Voltage Sensors (Pos 15.6/\*)

This test is to be done by the commissioning engineer of the firm if required.

# 4.8 Verification of Converter Protection Circuits (Hardware limits) -

This test is to be done as per para 6.17 of the document no. 3EHX 610 282 for both the converters.

Protection circuits	Limit on which shutdown should take place	Measured limit	
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 1	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 18.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=	0
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 2	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 8.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=	0
Fibre optic failure In Power Converter1	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	ok	
Fibre optic failure In Power Converter2	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	0K	

#### 4.9 Sequence of BUR contactors

The sequence of operation of BUR contactors for 'ALL BUR OK' BUR 1 out BUR 2 out and BUR 3 out condition has to be verified by putting the Loco in driving mode (VCB should not be closed) and isolating the BURs one by one. In these condition following will be the contactor sequence.

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	Close	Open	Close	Open	Close	Open	Close	Close	Open
BUR1 off	Close	Open	Close	Close	Open	Close	Open	Open	Close
BUR2 off	Open	Open	Close	Close	Close	Close	Open	Open	Close
BUR3 off	Open	Close	Open	Close	Close	Close	Open	Open	Close

# PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41921

Type of Locomotive: WAP-7/WAG-9HC

Page: 16 of 27

#### Monitored contactor sequence

Official contra	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					=2.4/1	52.4/2	52.5/1	52.5/2
Chatus	52/1	52/2	52/3	52/4	52/5	52.4/1			
Status			0.020	open	close	open	clos	محالاك	one,
AI BUR OK	close	open	cles		CEUST _		open	oben	clas
BUR1 off	closs	open	Close	closs	open	clos		1 7 -	
BUR2 off	open	Oben	close	Clos	close	close	Open	open	008
	open		open	close	close	c lex	open	Opera	close
BUR3 off	Jun-	close		1-08-	1				

### 5.0 Commissioning with High Voltage

#### 5.1 Check List

tems to be checked	Yes/No
	Yes
Fibre optic cables connected correctly.	
No rubbish in machine room, on the roof, under the loco.	169
All the electronic Sub-D and connectors connected	Yes
All the MCBs of the HB1 & HB2 open.	Yes
All the three fuses 40/* of the auxiliary converters	(b)
The fuse of the 415/110V auxiliary circuit (in HB1) open.	Yes
Roof to roof earthing and roof to cab earthing done	Yes
Fixing, connection and earthing in the surge arrestor done correctly.	yer
Connection in all the traction motors done correctly.	Yey
All the bogie body connection and earthing connection done correctly.	Yes
Pulse generator (Pos. 94.1) connection done correctly.	Ye,
All the oil cocks of the gate valve of the transformer in open condition.	Yes
All covers on Aux & Power converters, Filter block, HB1, HB2 fitted	Tey
KABA key interlocking system.	Yes

#### 5.2 Safety test main circuit breaker

Prepare to switch off the catenary supply during the first charging of the locomotive in case of any unexpected behavior of the electrical component of the loco. Charge the loco for the first time by closing BLDJ switch. The VCB will trip after certain time as no oil/coolant pumps are running yet.

Perform the following safety test of main circuit breaker through both the cabs of the locomotive.

Effective Date: Feb 2022

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

# Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41921

Type of Locomotive: WAP-7/WAG-9HC Page: 17 of 27

LOCOINOLIVE NO. 41	(0)		<u> </u>
Name of the test	Description of the test	Expected result	Monitored result
Emergency stop in cooling mode	Raise panto in cooling mode. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	cheehed ok
Emergency stop in driving mode	Raise panto in driving mode in. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	created of
Under voltage protection in cooling mode	Raise panto in cooling mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open.	cheehood ok
Under voltage protection in driving mode	Raise panto in driving mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open with diagnostic message that catenary voltage out of limits	checked ok
Shut down in cooling mode.	Raise panto in cooling mode. Close the VCB. Bring the BL- key in O position.	VCB must open. Panto must lower.	checked ok
Shutdown in driving mode	Raise panto in driving mode. Close the VCB. Bring the BL-key in O position.	VCB must open. Panto must lower.	chealsed of
Interlocking pantograph- VCB in cooling mode	Raise panto in cooling mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	Chechad ak
Interlocking pantograph- VCB in driving mode	Raise panto in driving mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	cheehodok

Effective Date: Feb 2022

(Ref: WI/ECS/10)

### PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41981

Type of Locomotive: WAP-7/WAG-9HC

Page: 18 of 27

#### 5.3 Auxiliary Converter Commissioning

Switch on the high voltage supply and set up the loco in driving mode. Raise the panto. Close the VCB. Check that there is no earth fault in the auxiliary circuit, Switch off the VCB. Lower the panto. Create the earth fault in auxiliary circuit by making connection between wire no 1117(in HB2 cubicle) and earth. After 3 minutes a diagnostic message will come that "Earth fault auxiliary circuit."

5.3.1 Running test of 3 ph. auxiliary equipments

Switch on the 3 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured continuous phase current	Measured starting phase current
Oil pump transformer 1	9.8 amps	8.3	9,0
Oil pump transformer 2	9.8 amps	8.9	9.2
Coolant pump converter 1	19.6 amps	5.2	6.0
Coolant pump converter 2	19.6 amps	.55	6.2
Oil cooling blower unit 1	40.0 amps	32.8	59.0
Oil cooling blower unit 2	40.0 amps	37.0	45-6
Traction motor blower 1	34.0 amps	26.0	48-7
Traction motor blower 2	34.0 amps	29.0	49.0
Sc. Blower to Traction motor blower 1	6.0 amps	. 2.3	3.3
Sc. Blower to Traction motor blower 1	6.0 amps	22	2.9
Compressor 1	25 amps at 0 kg/ cm <sup>2</sup> 40 amps at 10 kg/ cm <sup>2</sup>	29.0	59.0
Compressor 2	25 amps at 0 kg/ cm <sup>2</sup> 40 amps at 10 kg/ cm <sup>2</sup>	29.5	5-3-7

### PATIALA LOCOMOTIVE WORKS, PATIALA

#### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/921

Type of Locomotive: WAP-7/WAG-9HC

Page: 19 of 27

5.3.2 Performance of Auxiliary Converters

Measure the performance of the auxiliary converters through software and record it. BUR1 (Condition: Switch off all the load of BUR 1)- to be filled by commissioning engineer

Signal name	Description of the signal	Prescribed value	Monitored value	Value under Limit (Yes/No)
BUR1 7303 XUUN	Input voltage to BUR1	75% (10%=125V)	998 v	Yey
	DC link voltage of BUR1	60% (10%=100V)	636V	Acy .
BUR1 7303 XUIZ1	DC link current of BUR1	0% (10%=50A)	1 Amp	40
2011 / 110 111		<u> </u>	1	<u> </u>

BUR2 (Condition: Switch off all the load of BUR 2, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value by the firm	Monitored value	Value under Limit (Yes/No)
BUR2 7303-XUUN	Input voltage to BUR2	75% (10%=125V)	1002V	Yey
BUR2 7303-XUUZ1	DC link voltage of BUR2	60% (10%=100V)	637¥	les
BUR2 7303-XUIZ 1	DC link current of BUR2	1% (10%=50A)*	7 Amp	<b>b</b>
BUR2 7303-XUILG	Current battery charger of BUR2	3% (10%=100A)*	22 Bm	E
BUR2 7303-XUIB1	Current battery of BUR2	1.5%(10%=100A)*	12 Bonj	B
BUR2 7303 -XUUB	Voltage battery of BUR2	110%(10%=10V)	1102	77

<sup>\*</sup> Readings are dependent upon charging condition of the battery.

BUR3 (Condition: Switch off all the load of BUR 3, Battery Charger on) to be filled by

Signal name	Description of the signal	Prescribed set value by the firm	Monitored value	Value under limit (Yes/No)
BUR3 7303-XUUN	Input voltage to BUR3	75% (10%=125V	1001	Yes
BUR3 7303- XUUZ1	DC link voltage of BUR3	60% (10%=100V)	637V	79
BUR3 7303-XUIZ 1	DC link current of BUR3	1% (10%=50A)*	J Amp	709
BUR3 7303-XUILG	Current battery charger of BUR 3	3% (10%=100A)*	21 Bons	Yey
BUR3 7303-XUIB1	Current battery of BUR 3	1.5%(10%=100A)*	1) Amh	Teg
BUR3 7303-XUUB	Voltage battery of BUR 3	110%(10%=10V)	1)0	Tos

\* Readings are dependent upon charging condition of the battery.

(Ref: WI/ECS/10)

### PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/921

Type of Locomotive: WAP-7/WAG-9HC Page: 20 of 27

5.3.3 Performance of BURs when one BUR goes out

When any one BUR goes out then rest of the two BURs should take the load of all the

at ventilation level 3 of the locomotive.

Condition of	Loads on BUR1	Loads in BUR2	Loads in BUR3
BURs All BURs OK	Oil Cooling unit 1&2	TM blower1&2, TFP oil pump 1&2, SR coolant pump 1&2.	Compressor 1&2, Battery (charger and TM Scavenger blower 1&2
BUR 1 out		Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2,TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 2 out	Oil Cooling unit 1&2, TM blower 1&2, TM Scavenger blower 1&2	<u></u>	Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 3 out	Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.	

5.4 Auxiliary circuit 415/110

For checking earth fault detection, make a connection between wire no. 1218 and vehicle body. On switching on VCB, Earth fault relay 89.5 must pick up and after 3 minutes a message will come in the Diagnostic display that Earth Fault 415/110V Circuit

Switch on the 1 ph. auxiliary equipment one by one. Check the direction of rotation of each

Name of the auxiliary machine	Typical phase current	Measured phase current	Measured starting current
Machine room blower 1	15.0 amps*	4.3	13.0
Machine room blower 2	15.0 amps*	4.2	8-9
Sc. Blower to MR blower 1	1.3 amps	1.3	20
Sc. Blower to MR blower 2	1.3 amps	1.2	1.6
Ventilator cab heater 1	1.1 amps	1.)	1.3
Ventilator cab heater 2	1.1 amps	1.1	1 2
Cab heater 1	4.8 amps	4.7	4.8
Cab heater 2	4.8 amps	4.7	4.8

\* For indigenous MR blowers.

Effective Date: Feb 2022

(Ref: WI/ECS/10)

### PATIALA LOCOMOTIVE WORKS, PATIALA

#### Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41921

Type of Locomotive: WAP-7/WAG-9HC

Page: 21 of 27

### 5.5 Hotel load circuit (Not applicable for WAG-9HC)

For WAP-7 locomotive with Hotel load converter refer to Annexure-HLC

#### 5.6 Traction Converter Commissioning

#### This test is carried out in association with Firm.

Traction converter commissioning is being done one at a time. For testing Converter 1, switch off the traction converter 2 by switch bogie cut out switch 154. For testing Converter 2, switch off the traction converter 2 by switch bogie cut out switch 154. Isolate the harmonic filter also by switch 160. Start up the loco by one converter. Follow the functionality tests.

For Converter 1					
Test Function	Results desired	Result obtained			
Measurement of charging and precharging and charging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheehed ok			
Measurement of discharging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	checked ok			
Earth fault detection on positive potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Cheoland ok			
Earth fault detection on negative potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Cheehed OK			
Earth fault detection on AC part of the traction circuit of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	checked ox			
Pulsing of line converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheehed of			
Pulsing of drive converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked ok			

Effective Date: Feb 2022

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

# <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/921

Type of Locomotive: WAP-7/WAG-9HC Page: 22 of 27

For Converter 2 Result obtained					
Test Function	Results desired in sequence	Meanit opening.			
charging and pre- charging and charging of DC Link of Converter	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	checked ok			
Measurement of discharging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	checked ok			
positive potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Cheebed ok .			
negative potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/v	checked ok			
AC part of the traction circuit of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chechad ok			
Pulsing of line converte of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Checked ok			
Pulsing of drive converter of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Cheehed ok			

Effective Date: Feb 2022

(Ref: WI/ECS/10)

### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4132/

Type of Locomotive: WAP-7/WAG-9HC

Page: 23 of 27

#### 5.7 Test protective shutdown SR

Test Function	Results desired in sequence	Result obtained
Measurement of protective shutdown by Converter 1 electronics.	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 1Check that converter 1 electronics produces a protective shut down.  • VCB goes off • Priority 1 fault mesg. on DDU appears	checked ox
Measurement of protective shutdown by Converter 2 electronics.	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 2. Check that converter 2 electronics produces a protective shuldown.  • VCB goes off • Priority 1 fault mesg. on diagnostic display appears  Disturbance in Converter 2	cheeked ok

#### 5.8 Test Harmonic Filter

Switch on the filter by switch 160

Test Function	Results desired in sequence	Result obtained
Measurement of filter currents	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Apply a small value of TE/BE by moving the throttle.  • FB contactor 8.41 must open.	checkad ok

Effective Date: Feb 2022

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/92

Type of Locomotive: WAP-7/WAG-9HC

Page: 24 of 27

	<ul> <li>FB contactor 8.2 must close.</li> <li>FB contactor 8.1 must close</li> <li>Check the filter current in diagnostic laptop</li> <li>Bring the TE/BE throttle to O</li> <li>Switch off the VCB</li> <li>FB contactor 8.1 must open.</li> <li>FB discharging contactor 8.41 must close</li> <li>Check the filter current in diagnostic laptop</li> </ul>	cheebed ok
Test earth fault detection harmonic filter circuit.	Make a connection between wire no. 12 and vehicle body. Start up the loco. Close VCB.  • Earth fault relay 89.6 must pick up.  • Diagnostic message comes that - Earth fault in harmonic filter circuit	Checked ok
Test traction motor speed sensors for both bogie in both cabs	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	ok

#### 5.9 Test important components of the locomotive

Items to be tested	Description of the test	Monitored value/remarks
Speedometer	VCU converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	Checked ok
Time delay module of MR blower	The time after which the starting capacitor for MR blower should go off the circuit should be set to 10-12 seconds	cheebad ok
Ni-Cd battery voltage	At full charge, the battery voltage should be 110V DC.	cheehed ox
Flasher light	From both cab flasher light should blink at least 65 times in one minute.	Cheched of
Head light	Head light should glow from both cabs by operating ZLPRD. Dimmer operation of headlight should also occur by operating the switch ZLPRD.	cheehed ok

Effective Date: Feb 2022

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

# <u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/531

Type of Locomotive: WAP-7/WAG-9HC Page: 25 of 27

Marker light	Both front and tail marker light should glow from both the cabs	cheebad ok	
Cab Light	Cab light should glow in both the cabs by operating the switch ZLC	cheebed ok	
Spot lights	Both Drivers and Asst. Drivers Spot light should glow in both cabs by operating ZLDD	checked of checked of Checked of	
Instrument lights	Instrument light should glow from both cab by operating the switch ZLI	chechel ot	
Illuminated Push	All illuminated push buttons should glow during the operation	Checked ok	
Contact pressure of the high rating contactors	The contact pressure of FB contactors (8.1, 8.2) is to be measured  Criteria:  The minimum contact pressure is 54 to 66  Newton.	For contactor 8.1: For contactor 8.2:	ok
Crew Fan	All crew fans should work properly when VCB of the loco is switched on. The airflow from each cab fan is to be measured.  Criteria:  The minimum flow of air of cab fan should be 25 m³/minute	Cab 1 LHS: Cab 1 RHS: Cab 2 LHS: Cab 2 RHS:	ok

#### 6.0 Running Trial of the locomotive

		. Altr	<del></del>
SN	Description of the items to Action which should take place be seen during trail run		Remarks
1	Cab activation in driving mode	No fault message should appear on the diagnostic panel of the loco.	cheehedol
	Loco charging	Loco to be charged and all auxiliaries should run.  No fault message to appear on the diagnostic panel of the loco. Raise MR pressure to 10 Kg/cm <sup>2</sup> , BP to 5 Kg/cm <sup>2</sup> , FP to 6 Kg/cm <sup>2</sup> .	checheel
3.	Check function of Emergency push stop.	This switch is active only in activated cab. By pushing this switch VCB should open & pantograph should be lowered.	checked
4.	Check function of BPCS.	<ul> <li>Beyond 5 kmph, press BPCS, the speed of loco should be constant.</li> <li>BPCS action should be cancelled by moving TE/BE throttle, by dropping BP below 4.75 Kg/cm<sup>2</sup>, by pressing BPCS again.</li> </ul>	Cheched
5,	Check train parting operation of the Locomotive.	Operate the emergency cock to drop the BP Pressure LSAF should glow.	cheabed.

Effective Date: Feb 2022

(Ref: WI/ECS/10)

# PATIALA LOCOMOTIVE WORKS, PATIALA

# Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41921

Type of Locomotive: WAP-7/WAG-9HC

Page: 26 of 27

		Set the speed more than 1.5 kmph and ensure that	
5.	Check vigilance	brakes are released i.e. BC < 1 Kg/cm <sup>2</sup> .	
-	operation of the	brakes are released i.e. be in higher foot switch or	
Ì	locomotive	For 60 seconds do not press vigilance foot switch or	
		sanding foots switch or TE/BE throttle or BPVG	
ļ		switch then	-
ļ		Buzzer should start buzzing.	
		LSVW should glow continuously.	
ŧ	•	Do not acknowledge the alarm through BPVG or	checked
		vigilance foot switch further for 8 seconds then:-	
ļ		<ul> <li>Emergency brake should be applied</li> </ul>	
		automatically.	
	;	VCB should be switched off.	
		Resetting of this penalty brake is possible only after	
		32 seconds by bringing TE/BE throttle to 0 and	
		acknowledge BPVR and press & release vigilance	
		foot switch.	
7.	Check start/run interlock	• At low pressure of MR (< 5.6 Kg/cm <sup>2</sup> ).	cheehad?
		With park brake in applied condition.	-NA
		<ul> <li>With direct loco brake applied (BP&lt; 4.75Kg/cm<sup>2</sup>).</li> </ul>	
		<ul> <li>With automatic train brake applied (BP&lt;4.75Kg/cm<sup>2</sup>).</li> </ul>	Checkee
		• With emergency cock (BP < 4.75 Kg/cm <sup>2</sup> ).	- Crasin
8.	Check traction interlock	Switch of the brake electronics. The	
		Tractive /Braking effort should ramp down, VCB	Charles
		should open and BP reduces rapidly.	Creesee
9.	Check regenerative	Bring the TE/BE throttle to BE side. Loco speed	Cheebeel
	braking.	should start reducing.	Cheebee
10.	Check for BUR	In the event of failure of one BUR, rest of the two	
	redundancy test at	BURs can take the load of all the auxiliaries. For this	
	ventilation level 1 & 3 of	switch off one BUR.	
٠	loco operation	Auxiliaries should be catered by rest of two BURs.	Checheel
		Switch off the 2 BURs; loco should trip in this case.	
11.	Check the power	Create disturbance in power converter by switching	
	converter	off the electronics. VCB should open and converter	h
	isolation test	should get isolated and traction is possible with	Checkee
		another power converter.	

Effective Date: Feb 2022

(Ref: WI/ECS/10)

### PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41991

Type of Locomotive: WAP-7/WAG-9HC

Page: 27 of 27

# 7.0 Final check list to be verified at the time of Loco dispatch

Condition /Operations of the following items are to be checked:

SN	item	Cab-1	Cab-2	Remarks	
1	Head lights	ok	ok		
2	Marker Red	ck	ok		
3	Marker White	ok	OK.		
4	Cab Lights	ok	de		
5	Dr Spot Light	ok	ok	Checkeel working	ъŁ
6	Asst Dr Spot Light	ok	. ok	0	
7	Flasher Light	OK	ok .		
8	Instrument Lights	0 K	ok.		
9	Corridor Light	ok	80		
10	Cab Fans	Ok	OK		
11	Cab Heater/Blowers	ók	de		
12	All Cab Signal Lamps Panel 'A'	ok	ok		

# Status of RDSO modifications

LOCO NO: \_\_\_\_\_

	and the Alexander	Description	Remarks
Sn	Modification No.	<u></u> _	
1.	RDSO/2008/EL/MS/0357 Rev.'0' Dt 20.02.08	Modification in control circuit of Flasher Light and Head Light of three phase electric locomotives.	Ok/Not Ok
2.	RDSO/2009/EL/MS/0377 Rev.'0' Dt 22.04.09	Modification to voltage sensing circuit in electric locomotives.	Ok/Not Ok
3.	RDSO/2010/EL/MS/0390 Rev.'0' Dt 31.12.10	Paralleling of interlocks of EP contactors and Relays of three phase locomotives to improve reliability.	Qk/Not Ok
4.	RDSO/2011/EL/MS/0399 Rev.'0' Dt 08.08.11	Removal of interlocks of control circuit contactors no. 126 from MCPA circuit.	Ok/Not Ok
5.	RDSO/2011/EL/MS/0400 Rev.'0' Dt 10.08.11	(40)	Ok/Not Ok
6.	RDSO/2011/EL/MS/0401 Rev.'0' Dt 10.08.11	Modification sheet for relaying of cables in HB-2 panel of three phase locomotives to avoid fire hazards.	Ok/Not Ok
7.	RDSO/2011/EL/MS/0403 Rev.'0' Dt 30.11.11	Auto switching of machine room/corridor lights to avoid draining of batteries in three phase electric locomotives.	OK/Not Ok
8.	RDSO/2012/EL/MS/0408 Rev.'0'	Modification of terminal connection of heater cum blower assembly.	Øk/Not Ok
9.	RDSO/2012/EL/MS/0411 Rev.'1' dated 02.11.12	White and Red marker light in three phase electric locomotives.	Øk/Not Ok
10	RDSO/2012/EL/MS/0413 Rev.'1' Dt 25.04.16	contactors of three phase locomotives to improve reliability.	Øk/Not Ok
11	RDSO/2012/EL/MS/0419 Rev.'0' Dt 20.12.12	Modification sheet to provide rubber sealing gasket in Master Controller of three phase locomotives.	Ok/Not Ok
12	RDSO/2013/EL/MS/0420 Rev.'0' Dt 23.01.13	Modification sheet to provide mechanical locking arrangement in Primary Over Current Relay of three phase locomotives.	Ok/Not Ok
13	RDSO/2013/EL/MS/0425 Rev.'0' Dt 22.05.13	dimmer mode in three phase electric locomotives.	Ok/Not Ok
14	Rev.'0' Dt 18.07.13	phase electric locomotives.	Øk/Not Ok
15	Rev.'0' Dt 23.10.13	locomotives.	Ok/Not Ok
16	Rev.'0' Dt 10.12.13	harmonic filter and hotel load along with its resistors in three phase electric locomotives.	Øk/Not Ok
17	Rev.'0' Dt 12.03.14	current relay of three phase electric locomotives.	OK/NOL OK
18	RDSO/2017/EL/MS/046- Rev.'0' Dt 25.09.17	filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.	Ók/Not Ok
19	Rev.'0' Dt 07.12.17	phase electric locomotives.	OK/140LOK
20	RDSO/2018/EL/MS/047 Rev.'0'	Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.	Ok/Not Ok

Signature of JE/SSE/ECS

Loco No.: 41921

#### PLW/PATIALA

#### PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

SN	Parameters	Reference	Value	Result
	Brake Panel: KNORR BREMSE			
1.0	Auxiliary Air supply system (Pantograph & VCB)			
1.1	Ensure, Air is completely vented from pantograph			0
	Reservoir (Ensure Panto gauge reading is Zero)			
1.2	Turn On BL Key. Now MCPA starts.	For Faiveley	60 sec. (Max.)	
	Record pressure Build up time (8.0 kg/cm2)	For Knorr	120 sec. (Max.)	115 sec.
1.3	Auxiliary compressor safety Valve 23F setting	Faiveley Doc. No.	8.5±0.25kg/cm2	8.5 kg/cm2
		DMTS-014-1, 8 CLW's	-	
		check sheet no.		
		F60.812 Version 2		
1.4	Check VCB Pressure Switch Setting	CLW's check sheet	Opens 4.5±0.15	4.50
		no. F60.812 Version 2	kg/cm2, closes	
			5.5±0.15 kg/cm2	5.50
1.5	Set pantograph Selector Switch is in Auto, Open pan-1&2 Is	solating Cocks & KABA co		
1.6	Set Cab-1 Pan UP in Panel A.		Observed Pan-2	Ok
			Rises.	
1.7	Close Pan-2 isolating Cock		Panto-2 Falls Down	Ok
	Open Pan -2 isolating Cock		Panto-2 Rises	
1.8	Record Pantograph Rise time		06 to 10 seconds	9 sec
1.9	Record Pantograph Lowering Time		06 to 10 seconds	7 sec
1.10	Panto line air leakage		0.7 kg/cm2 in 5	0.25 kg/cm2
4.44			Min.	in 5 min.
1.11	High Reach Panto emergency test and reset.			Ok
2.0	Main Air Supply System			
2.1	Ensure, Air is completely vented from locomotive. Drain	Theoretical		
	out all the reservoirs by opening the drain cocks and then	calculation and		
	closed drain cocks. MR air pressure build up time by each	test performed by		
	compressor from 0 to 10 kg/cm2.	Railways.	:\ 7	6 min.& 40
	i) with 1750 LPM compressor		i) 7 mins Max.	sec.
	ii) with 1450 LPM compressor		ii) 8.5 mins Max.	
2.2	Drain air below MR 8 kg/cm2 to start both the		Check Starting of	Ok
	compressors		both compressors	
2.3	Drain air from main reservoir up to 7 kg/cm2. Start		30 Sec. (Max)	CP1-28 sec
	compressors, Check pressure build time of individual		, ,	CP2-28 sec
	compressor from 8 kg/cm2 to 9 kg/cm2			
2.4	Check Low MR Pressure Switch Setting (37)	D&M test spec.	Closes at 6.40±0.15	6.40 kg/cm2
		MM3882 &	kg/cm2 Opens at	
		MM3946	5.60±0.15kg/cm2	5.6 kg/cm2
2.5	Check compressor Pressure Switch RGCP setting (35)	D&M test spec.	Opens at 10±0.20	10.0 kg/cm2
		MM3882 &	kg/cm2, Closes at	
		MM3946	8±0.20 kg/cm2	8.0 kg/cm2
2.6	Run both the compressors Record Pressure build up time	Trial results	3.5 Minutes Max.	3.3 min

#### PLW/PATIALA

Loco No.: 41921

2.7	Check unloader val	ve operation time				Approx. 12 Sec.	10 sec.
2.8		alve functioning (12	4 & 87)			Operates when	11.5
						Compressor	kg/cm2
						starts	, , , , , , , , , , , , , , , , , , ,
2.9	Check CP-I delivery safety valve setting (10/1). Run CP		D&M t	est spec.	11.50±0.35	11.5	
	Direct by BLCP.			MM3882	& MM3946	kg/cm2	kg/cm2
2.10	Check CP-2 delivery	/ safety valve setting	g (10/2). Run CP	D&M t	est spec.	11.50±0.35	
	direct by BLCP			MM3882	& MM3946	kg/cm2	
2.11		mpressors and ensu			est spec.		
	I	essure 1.2 kg/cm2 le	ess than opening	MM3882	& MM3946		
	pressure.	(					
2.12		'OFF' compressor,			k sheet no.	5.0±0.10kg/cm2	5.0 kg/cm2
	· ·	Main Reservoir, Sta	•	F60.812 Ve	ersion 2		
2.13	FP pressure:	ure of Duplex Check	valve 92F.	CLW/s show	ck sheet no.	6.0±0.20kg/cm2	6.0 kg/cm2
2.13	l ·	est point 107F FPTP.	Onen isolate cock	F60.812 Ve		0.010.20kg/cili2	0.0 kg/ciliz
	136F. Check pressu		open isolate cock	100.012 VC	.131011 2		
3.0	Air Dryer Operati						
3.1		O of 2 <sup>nd</sup> MR to start (	Compressor, leave			Tower to change	Ok
	1 .	k Air Dryer Towers t	•			every minute	
3.2	Check Purge Air Stops from Air Dryer at Compressor stops				-	Ok	
3.3	Check condition of humidity indicator				Blue	Blue	
4.0	Main Reservoir Lea	akage Test					
4.1	· ·	9) in full service, Che	eck MR Pressure air	D&M test spec. MM3882 & MM3946		Should be less	0.25
	leakage from both	cabs.				than 1 kg/cm2 in	kg/cm2 in
						15 minutes	15 min.
4.2	Check BP Air leakag	ge (isolate BP chargii	ng cock-70)		est spec.	0.15 kg/cm2 in 5	0.05
				MM3882 & MM3946		minutes	kg/cm2 in 5
5.0	Brake Test (Auto	matic Brake opera	ntion)				min.
5.1		& Brake Cylinder pre					
J.1	Record Brake Fipe (	& brake Cyllider pre	essure at Lacii Step				
	Check proportional	ity of Auto Brake sy	stem	CLW's che	ck sheet no.		
				F60.812	Version 2		
-	A.,	BP Pressure kg/cm	-2	DC /MAC C	10 M/AD 71	DC (MAD E)	
	Auto controller position	BP Pressure kg/cm	12	Kg/cm2	& WAP-7)	BC (WAP-5) Kg/cm2	
	position		I	_ ·	ı		
		Value	Result	Value	Result	Value	
	Run	5±0.1	5.05 Kg/cm2	0.00	0.00 Kg/ cm2	0.00	-
	Intial	4.60±0.1	4.6 Kg/cm2	0.40±0.1	0.40Kg/ cm2	0.75±0.15	-
	Full service	3.35±0.2	3.4 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	-
	Emergency	Less than 0.3	0.25 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	-
L				1	]		

#### PLW/PATIALA

Loco No.: 41921

5.2	Record time to BP pressure drop to 3.5 kg/cm2 Ensure	D&M test spec.	8±2 sec.	8 sec.
	Automatic Brake Controller handle is Full Service from Run	MM3882 & MM3946		
5.3	Operate Asst. Driver Emergency Cock,	D&M test spec. MM3882 & MM3946	BP pressure falls to Below 2.5 kg/cm2	Ok
5.4	Check brake Pipe Pressure Switch 69F operates	CLW's check sheet no.	Closes at BP	4.20
	·	F60.812 Version 2	4.05- 4.35 kg/cm2 Opens at BP	kg/cm2
			2.85- 3.15	3.0
			kg/cm2	kg/cm2
5.5	Move Auto Brake Controller handle from Running to	D&M test spec.	Kg/CIIIZ	Kg/CIIIZ
5.5	Emergency BC filling time from 0.4 kg/cm2 i.e. 95% of	MM3882 & MM3946		
	Max. BC developed	1011013002 & 1011013940		22 sec.
	WAP5 – BC 5.15 ± 0.3 kg/cm2 apply time		4±1 sec.	22 Sec.
	WAP7 - BC 5.15 ± 0.3 kg/cm2 apply time WAP7 - BC 2.50 ± 0.1 kg/cm2		7.5±1.5 sec.	
			7.5±1.5 sec.	
	WAG9 - BC 2.50 ± 0.1 kg/cm2		ZIIS Sec.	
5.6	Move Auto Brake Controller handle to full service and	D&M test spec.		
	BP pressure 3.5 kg/cm2. Move Brake controller to	MM3882 & MM3946		
	Running position BC Release time to fall BC Pressure up			
	to 0.4 kg/cm2 i.e. 95% of Max. BC developed			
	BC release Time			
	WAP7		17.5±2.5 sec.	
	WAG9		52±7.5 sec.	51 sec.
5.7	Move Auto Brake Controller handle to Release, Check	CLW's check sheet no.	60 to 80 Sec.	72 sec.
	BP Pressure Steady at 5.5± 0.2 kg/cm2 time.	F60.812 Version 2		
5.8	Auto Brake capacity test: The capacity of the A9 valve	RDSO Motive power	BP pressure	
	in released condition must conform to certain limit in	Directorate report no.	should not fall	
	order to ensure compensation for air leakage in the	MP Guide No. 11 July,	below 4.0	
	train without interfering with the automatic	1999 Rev.1	kg/cm2 with in	4.8
	functioning of brake.		60 Sec.	kg/cm2
	* Allow The MR pressure to build up to maximum			
	stipulated limit.			
	* Close brake pipe angle cock and charge brake pipe to			
	5 kg/cm2 by A-9 (Automatic brake controlling) at run			
	position.			
	* Couple 7.5 dia leak hole to the brake hose pipe of			
	locomotive. Open the angle cock for brake pipe.			
	The test shall be carried out with all the compressors in			
	working condition.			
5.9	Keep Auto Brake Controller (A-9) in Full Service. Press		BC comes to '0'	0
	Driver End paddle Switch (PVEF)			
6.0	Direct Brake (SA-9)			
6.1	Apply Direct Brake in Full Check BC pressure			
	WAG9/WAP7	CLW's check sheet no.	3.5±0.20 kg/cm2	3.5
	WAP5	F60.812 Version 2	5.15±0.3 kg/cm2	kg/cm2
6.2	Apply Direct Brake, Record Brake Cylinder charging	D&M test spec.	8 sec. (Max.)	7 sec.
	time	MM3882 & MM3946		

#### **PLW/PATIALA**

Loco No.: 41921

6.3	Check Direct Brake Pressure switch 59 (F)	D&M test spec. MM3882 & MM3946	0.2 ±0.1 kg/cm2	0.20 kg/cm2
6.4	Release direct brake & BC Release time to fall BC pressure up to 0.4 kg/cm2		10 -15 Sec.	12 Sec
7.0	Modified System Software (only for CCB)			
7.1	Bail-off de-activated during emergency by any means			Now De- activated
7.2	DPWCS and Non-DPWCS mode enabled		Multi Loco	
7.3	TCAS and Non-TCAS mode enabled		Not Yet Launched	Presently
7.4	Penalty brake application deactivated for Fault code 113 (FC 113) and CCB health signal will not drop to avoid loco detention/failure. The Brake Electronics Failure "message will not generate on DDS.	DD00 L III	Pressure Setting Needed is12 kg/sqcm Causing mismatching with standard Pr Setting	<ul><li>not</li><li>happening</li><li>in PLW</li></ul>
7.5	CCB health signal logic revised (Now will remain high) for penalty condition occurring with FC 108 due to wrong operation/not affecting operation/ Not a CCB Fault (i.e Both controllers selected as LEAD etc) The Brake electronic failure message will not generate on DDS	RDSO letter no. EL/3.2.19/3-phase (CCB), dtd 30.01.2023		Brake electronic failure message not generate on DDS
7.6	CCB health signal logic for FC 102 (In case of BC request from VCU is more than 90 %-above 9V DC) is changed i.e CCB health signal will not drop for FC 102 which will avoid loco detention/failure. The brake electronic failure message will not generate on DDS.		Could not performed by M/s Knorr	Presently not happening in PLW
7.7	Booting time for CCB with TCAS/TPM/PTWS/DPWCS mode 15-20 sec. However, in case of absence of either one or both system booting time subsequently increased to 40-50 sec.			45 sec
8.0	Sanding Equipment			
8.1	Check Isolating Cock-134F is in open position. Press sander paddle Switch. (To confirm EP valves Operates)		Sand on Rail	Ok
9.0	Test Vigilance equipment : As per D&M test specification			Ok

SAMSHER SINGH BIST Date: 2024.10.21

12:54:28 +05'30'

Signature of SSE/Shop

	41921								
		RC	OF COMP	ONENT CAB 1 & 2		Warranty			
S.No.	Description	Description PL NO. QPI		Supplier	Sr. no.				
1	1 Pantograph 29880014(HR 29880026		2	FAIVELEY, CONTRANSYS	F24-0026-JUN-2024, 14289-04/24				
2	Servo motor	29880026	2	CONTRANSYS	14769-06/24				
3	Air Intake filter Assly	29480103	2	SPECTRUM	O/C 81524/SFPL-0013/July/2024, O/C 81524/SFPL-0017/July/2024,				
4	Insulator Panto Mtg.	29810127	8	BHEL	04/2024,05/2024				
		IV	IIDDLE RO	OF COMPONENT					
5	High Voltage Bushing	29731021	1	RADIANT	RE/08/06/24/HVB-02				
6	Voltage Transformer	2965028	1	SADTEM	2024-N-672481				
7	Vacuum Circuit Breaker	25712202	1	SCHNEIDER	226609873-73N2/JUNE-2024				
8	Insulator Roof line	29810139	9	BHEL	10-2023, 11-2023				
9	Harmonic Filter	29650033	1	ELECOS	EEPL/HF/1562	AS Per PO/IRS Conditions			
10	Earth Switch	29700073	E	PPS	03/24/01015				
11	Surge Arrester	29750052	2	CG POWER & INDUSTRIAL	55063-2023,55064-2023				
			Air Br	ake Components					
12	Air Compressor (A,B)	29511008		ELGI	EXES 923157 -A, EXES 923147 -B				
13	Air Dryer	29162051	1	TRIDENT	LD2-07-0431-24				
14	Babby compressor	25513000	1	ELGI	BXKS 108320				
15	Air Brake Panel	29180016	1	KNORR	23-10-CO-3125				
16	Contoller (A,B)	29180016	2	KNORR	24-07-FO-3705 A, 24-07-FO-3703 B				
17	17 Breakup Valve 29180016 2 KNORR								
18	wiper motor	29162026	4	AUTO INDUSTRY					

SAMSHER Digitally signed by SAMSHER SINGH BIST Date: 2024.10.17 13:23:42 +05'30'

SSE/ABS

#### PLW/PTA

#### ELECTRIC LOCO HISTORY SHEET (ECS)

ELECTRIC LOCO NO: 41921 LIST OF ITEMS FITTED BY ECS **RLY: WCR** 

SHED: ETE

PROPULSION SYSTEM: CGL

SN	DESCRIPTION OF ITEM	ITEM PL NO.	ITEM SR. NO	CAB-1/CAB-2	MAKE/SUPPLIER
1_	LED Based Flasher Light Cab I & II	29612937	26530	26515	MATSUSHI P. TECH.
2	Led Marker Light Cab I & II	29612925	142805/142817/	142772/142804	MATSUSHI P. TECH.
3	Cab Heater Cab I & II	29170011	2401	2388	TOPGRIP
4	Crew Fan Cab I & II	29470080	24070129/24070145/	24070174/24070059	KEPSONS
5	Master Controller Cab I	29860015	01	4	A A I
6	Master Controller Cab II	20000010	06	6	AAL
7	Complete Panel A Cab I & II	29178265	0416A	0414B	HIND
8	Complete Panel C Cab I & II	29170539	KT-1267	KT-1265	KONTACT/CGL
9	Complete Panel D Cab I & II	29178265	0427A	0416B	HIND
10	Complete Cubicle- F Panel Cab I & II	29178162	AALN/05/2024/04/CFP7/019	AALN/05/2024/07/CFP7/022	AAL
11	Speed Ind.& Rec. System	29200040	5028/	5717	MEDHA
12	Battery (Ni- Cd)	29680025	В0	1	HBL
13	Set of Harnessed Cable Complete	29600420		· · · · · · · · · · · · · · · · · · ·	SIECHEM
14	Transformer Oil Pressure Sensor (Cab-1) (Pressure Sensor Oil Circuit Transformer)	29500047	TGIC/CLW/2874 May-24	TGIC/CLW/2873 May-24	TOPGRIP
15	Transformer Oil Pressure Sensor (Cab-2)		TGIC/CLW/2895 May-24	TGIC/CLW/2897 May-24	
16	Transformer Oil Temperature Sensor (Cab-1) (Temperature Sensor Oil Circuit Transformer)	29500035	BG/TFP/7692 Jun-24		BG INDUSTRIES
17	Transformer Oil Temperature Sensor (Cab-2)		BG/TFP/7421 may-24		
18	Roof mounted Air Conditioner I	29811028	24E/RMPU/DC/02/1174		DALII AT DARE
19	Roof mounted Air Conditioner II	23011020	24E/RMPU/D	OC/02/1185	DAULAT RAM

SSE/ECS

JENECS

			OTIVE WORKS, PAT			
CNIC	F		1/WAG-9HC/WCR/I		T NA	ake
S.No.	Equipment	PL No.		ent Serial No.		
	Complete Shell Assembly with piping	29171027		14, 08/24		HILAI
	Side Buffer Assly Both Side Cab I	29130050	196, 07/24	52,07/24	FASP	FASP
3	Side Buffer Assly Both Side Cab II		20, 07/24	100, 07/24	FASP	FASP
4	CBC Cab I & II	29130037	33, 07/24	192, 07/24	FASP	FASP
5	Hand Brake		07/24-	- 17361	Modified	Meckwel
6	Set of Secondry Helical Spring	29045034 29041041			АВ	зок
7	Battery Boxes (both side)	29680013	105, 07/24	108, 07/24	D R STEEL	D R STEEL
8	Traction Bar Bogie I			92, 12/23	F/	AS
-	Traction Bar Bogie II			38, 12/23	F/	AS
	Centre Pivot Housing in Shell Bogie I side	20100057	880	8, 07/24		VE
	Centre Pivot Housing in Shell Bogie II side	29100057		6, 07/24	E/	VE
	Elastic Ring in Front in Shell Bogie I side	20120010	Sr. 40, Batch	ch 01, Mfg 12/23	SSI	SPL
-	Elastic Ring in Front in Shell Bogie II side	29100010		ch 10, Mfg 12/23	SSI	SPL
	Main Transformer	29731008 for WAG 9 29731057 for WAP-7		BHL11500/11, 2024	Co	CG
15	Oil Cooling Radiator I	33.73004	06/24, FG41	15002/24-25/15	APOLLO HEAT	EXCHANGERS
	Oil Cooling Radiator II	29470031		P0524RC2175	FINE AUTOME	TERS INDUSTRY
	Main Compressor I with Motor		-	23147, 08/24		LGi
	Main Compressor II with Motor	29511008		23157, 08/24		LGi
	Transformer Oil Cooling Pump I			0731,06/24		WOIL
				0715, 06/24	FLOV	
	Transformer Oil Cooling Pump II					CEL
	Oil Cooling Blower OCB I	29470043		69, LHP1001541914		
	Oil Cooling Blower OCB II			75, LHP1001541920	ACC	
-	TM Blower I	29440075		6AF30, 24P0846/30	La de la	RICAL PVT LTD
	TM Blower II	20.163.6		2AF13, 24P0942/13		RICAL PVT LTD
25	Machine Room Blower I	29440105		07.39, 07/24	G,T,R CO(P) LTD	
26	Machine Room Blower II	23440103	MF-24.0	7.56,. 07/24	G,T,R CO(P) LTD	
27	Machine Room Scavenging Blower I	29440129	SM-24.0	05.34, 05/24	G,T,R CC	
28	Machine Room Scavenging Blower II	23440123	SM-24.0	05.15, 05/24	G,T,R CC	J(P) LTD
29	TM Scavenging Blower Motor I	30440117	05/24, D3-75	577, CF30/D7852	SAMAL HARA	AND PVT LTD
30	TM Scavenging Blower Motor II	29440117	07/24, D30-77	769,, CF30/D8044	SAMAL HARA	AND PVT LTD
	Traction Convertor I			212492007-P923	The second secon	
	Traction Convertor II			12492008-P923		
33	Vehicle Control Unit I	29741075		9943-P923	CG	GI
	Vehicle Control Unit II	23/410/3		9944-P923		/L
	Aux. Converter Box I (BUR 1)			0012491338- P923		
-	Aux. Converter Box 2 (BUR 2 + 3)			0022491338-P923	4	
	Axillary Control Cubical HB-1	29171180		450764, 05/24	CONTINENTAL	
-	Axillary Control Cubical HB-2	29171192		0192/158	CONTINENTAL	
	Complete Control Cubicle SB-1	29171209		/E/0010/1033	112	TIFIERS LTD
	Complete Control Cubicle SB-2	29171210	SB2/517/05	05/2024, 05/24	KAYSONS ELECT	RICAL PVI LID
41 1	Filter Cubical (FB) (COMPLETE FILTER CUBICLES)	29480140	AALN/05/2024/	/19/FB/043, 05/24	AUTOMETERS A	ALLAINCE LTD
	Driver Seats	29171131				
	Transformer oil steel pipes	29230044	VIKRA	ANT PIPES	VIKRANT	T PIPES
	Conservator Tank Breather			30, 24-0287	YOGYA ENETF	
-		29731057		7,20,17	AKI	
-	Ballast Assembly ( only for WAG-9)	29170163			Matsushi p	
46	Head Light		875	75/868	Watsusinip	owe leci

NAME. ShuBMR SMANA SSE/LAS

NAME AMULT OPPAL JE/LAS

Effective Date: July-2023

LOCO NO: 41921

DOC NO: F/LAS/Electric Loco CHECK SHEET (Ref: WI/LAS/Elect/01, 02, 03 & 04 & QPL/LAS/Elect. Loco)
Page 1 of 1

#### पटियाला रेलइंजन कारखाना, पटियाला PATIALA LOCOMOTIVE WORKS, PATIALA ELECTRIC LOCO CHECK SHEET

RIV: WCR

Shed: ETE

S. No.	ITEM TO BE CHECKED	Specified Value	Ol	bserved	Valu	е
1.1	Check proper Fitment of Hotel Load Converter & its output contactor.	OK		- N	1	
1.2	Check proper Fitment of MR Blower 1 & 2, MR Scavenging Blower 1 & 2, TM Blower 1 & 2, TMB Scavenging Blower 1 & 2.  TM scavenging blower 1 & 2 & Oil Cooling unit.	OK		014		
1.3	Check proper of Fitment of oil cooling unit (OCU).	OK		UZ		
1.4	Check proper Fitment of HB 1 & 2 and its respected lower part on its position.	OK		CUL		
1.5	Check proper Fitment of FB panel on its position.	OK		Ul 4		
1.6	Check proper Fitment of assembled SB1 & SB2 panel.	OK		01		
1.7	Check proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3).	OK		CIL		
1.8	Check proper Fitment of Traction converter 1 & 2 (SR-1 & 2).	OK		C		
1.9	Check proper fitment, torquing & Locking of Main Transformer bolt.	OK		Ol		
10	Check proper fitment of Main compressor both side with the compressor safety wire rope.	OK -		U		
1.11	Check proper resting of Secondary Helical Springs between Bogie & Shell body.	- OK		U		
2	Check proper fitment of Bogie Body Safety Chains.	OK		Ol		
1.13	Check proper fitment of Cow catcher.	OK		01	4	
1.14	Check coolant level in SR 1 & 2 Expansion Tank.	OK		0	14	
1.15	Check Transformer Oil Level in both conservators Tank (Breather Tank).	OK		0	14	(100) T
1.16	Check proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any damage during online working of Locomotives.	ОК		al		
1.17	Check proper fitment of both battery box.	OK	ege of the	d	7	
1.18	Check for any gap between Main Transformer mounting base & Loco Shell.	OK		01	7	
1.19	Check proper fitment of Push Pull rod its bolt torquing and fitment of fixing cable.  As per Drg No 1209-01-113-001	OK			14	
1.20	Secondary Vertical and Lateral Clearance on leveled track at the time of Loco Dispatch.		CA	B-1	C	CAB-2
	ELRS/TC/ 0082 (Rev 1) dated 17.09.2015	Vertical-Std	LP	ALP	LP	ALP
		:35-60 mm	53	48	57	54
		Lateral Std- 45-50 mm	50	50	57	
1.21	Buffer height: Range (1090, +15,-5)	1085-1105		L/8	5	R/S
	Drg No IB031-02002.	mm_	FRONT	100	16	1095
			REAR	100	12	1101
1.22	Buffer Length: Range (641 mm + 3 to 10 mm with buffer face)	641 mm		L		R/S
1.22	Drg No-SK.DL-3430.	041111111	FRONT	647	-	646
-	DIG NO-5K.DE-3430.		REAR	64		
1.23	Height of Rail Guard. (114 mm + 5 mm,-12 mm).	114 mm + 5	TILLY	0 J		648 R/S
1.20	As per RDSO Pamphlet Important Bogie Clearances of Electric Locomotives.	mm,-12 mm	FRONT	11	-	115
			REAR	11:		116
404	CDC	1090, +15	FRONT:			170
1.24	CBC Height: Range (1090, +15,-5)  Drg No- IB031-02002.	-5 mm	REAR:	109		
	DIG 110- 1000 1-02002.	V IIIIII	1 1 1 1 1 1	109	_	W-

(Signature of SSE/Elect. Loco)

NAME Desh Bandhu Gupt

DATE 31/08/24

(Signature of LAE/Elect Loco)

NAME SHUBMA SMAFMA

DATE 31/08/24

(Signature of JE/UF)

NAME ANKIT UPPAL
DATE 31108 24

#### **Loco No.** 41921

#### 1. BOGIE FRAME:

BOGIE	FRAME NO	Make	PL No.	PO No. & dt.	Warranty Period
FRONT	SL-165	ECBT	29100677	100360	As per PO/IRS
REAR	SL-199	ECBT	29101104	102221	conditions

#### 2. Hydraulic Dampers (PL No.29040012 ) Make: ESCORTS/GB

#### 3. AXLES:

AXLE POSITION NO	1	2	3	4	5	6
MAKE/	PLW	PLW	PLW	PLW	PLW	PLW
S.NO	26989	27385	25800	27233	27320	27422
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

#### 4. WHEEL DISCS NO. AND TYPE & BULL GEAR

AXLE POSITION NO	1	2	3	4	5	6
GEAR END	EMC8-67	EM68-10	EMH1-027	EMB6-069	EM68-034	30677
Make	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED	DP
FREE END	EMC8-30	EMC8-169	EMH1-136	EMB6-050	EM68-048	22611
Make	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED	DP
Bull Gear No.	24-E-46	24-E-56	24-D-25	24-C-20	24-E-28	24-E-20
Bull Gear Make	LMS	LMS	LMS	LMS	LMS	LMS

#### 5. AXLE ROLLER BEARING (CRU) (PL No. 29010020, Warranty: As per PO/IRS conditions)

	AXLE POSITION NO	1	2	3	4	5	6
Gear	MAKE	FAG	FAG	NBC	FAG	NBC	FAG
End	PO NO. & dt	02312	02312	02875	02312	02875	02312
Free	MAKE	FAG	FAG	NBC	FAG	NBC	FAG
End	PO NO. & dt	02312	02312	02875	02312	02875	02312

#### 6. WHEEL DISC PRESSING PRESSURE IN KN: (SPECIFIED 80-105 T)

AXLE POSITION NO	1	2	3	4	5	6
BULL GEAR END	934 KN	987 KN	91 T	102 T	979 KN	1001 KN
FREE END	884 KN	922 KN	104 T	98 T	834 KN	891 KN

#### Loco No. 41921

#### 7. DIAMETER AFTER PROFILE TURNING: SPECIFIED 1092 + 5 mm - 0 mm

AXLE POSITION NO	1	2	3	4	5	6
DIA IN mm GE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
DIA IN mm FE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
WHEEL PROFILE GAUGE (1596±0.5mm)	OK	OK	OK	OK	OK	OK

#### 8. SUSPENSION TUBE & ITS TAPER ROLLER BEARING:

AXLE POSITION NO		1	2	3	4	5	6
S.T. PL 29100288	MAKE	IN	IN	PITTI	BSL	IN	KM
GE Brg. PL 29030110	MAKE	FAG	FAG	NBC	NBC	FAG	FAG
FE Brg. PL 29030110	MAKE	FAG	FAG	NBC	NBC	FAG	FAG

#### 9. GEAR CASE (PL No. 29030018) & BACKLASH:

AXLE POSITION NO	1	2	3	4	5	6
MAKE	BSL	KP	KP	BSL	KP	KP
BACKLASH (0.254 – 0.458mm)	0.310	0.300	0.315	0.300	0.300	0.320

#### 10 A/BOX TO BOGIE FRAME LATERAL CLEARANCES (SPECIFIED 15.0 to 19.0mm):

AXLE POSITION NO	1	2	3	4	5	6
RIGHT SIDE	17.90	17.22	15.55	17.43	17.63	15.48
LEFT SIDE	15.90	17.15	16.30	16.70	17.52	17.22

#### 11. TRACTION MOTOR: (PL No.29940606, Warranty: As per PO/IRS conditions)

AXLE POSITION NO	MAKE	PO No. & date	S. NO.
1	GOVIK	101651	G-241274
2	GOVIK	101651	G-241275
3	CGL	101655	2232008-6198
4	CGL	101655	2232008-6196
5	CGL	101655	2232006-6435
6	CGL	101655	2232006-6426

SSE/ Bogie Shop

#### TOP 12 COSTLIEST ITEMS OF WAG9HC LOCO WITH WARRANTY CONDITIONS AS PER TENDERS

S No	PL No	DESCRIPTION	Warranty Period
1	29741075	IGBT BASED 3-PHASE DRIVE PROPULSION EQUIPMENT	60 months after commissioning or 72 months from date of supply whichever earlier as per special conditions given by CLW
2	29731057	MAIN TRANSFORMER 7775 KVA TYPE LOT 7500 FOR WAP7 3- PHASE ELECTRIC LOCOMOTIVE TO CLW SPECN NO.CLW/ES/3/0660/C	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
3	29171064	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT-8	AS PER IRS CONDITIONS-30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER.
4	29600418	LOCOMOTIVES TO CLW SPECN. NO. CLW/ES/03/646  ALT-NIL WITH DMW REQUIREMENT OF HARNESSED	As per clause no.9 of CLW Specn. CLW/ES/3/0458 & Clause No.10 of CLW SpecnCLW/ES/3/0459. [18 months after commissioning or 20 months from date of supply for single core & 18 months after commissioning or 24 months from date of supply for multi core]

7	29942007	3-PHASE ASYNCHRONOUS TRACTION MOTOR (RESISTANCE RING MECHANICALLY INTERLOCKED TO END PLATE DESIGN ROTOR, SCHEME-II), TYPE 6FRA-6068 FOR WAP-7 ELECTRIC LOCO WITHOUT ACTIVE SPEED SENSOR TO SPECIFICATION NO. 4TMS.096.081 ALT-2 AND STR NO. CLW/2008/3PHTM/STR/0001.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
6	29480140	COMPLETE FILTER CUBICLE ALONG WITH ALL EQUIPMENTS AND CABLING TO DRG./SPEC NO. [1] CLW/ES/3/0193 ALT-F OR LATEST AND CLW DRG. NO. 1209-15-143-004 ALT-10 AND PART DRG./SPEC NO AS PER ANNEXURE-A ATTACHED.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
5	29180016	BRAKE CONTROL SYSTEM INCLUDING DRIVER'S VIGILANCE CONTROL DEVICE TO SET LIST NO.EL29180016.	As per specification no. CLW/MS/3/001 Alt. 16 i.e. the manufacturer is required to guarantee that the brakevalves/equipment work satisfactorily for a period of five (5) years after commissioning. Any equipment/part which failsduring the guarantee period shall be replaced free of cost by the manufacturer. The replaced components shallfurther be under warranty for five (5) years from the date of their fitment and should the replaced components proveunsatisfactory in service, they shall be replaced by modified and improved components by the supplier free of cost.

8	29105146	Bogie Frame Complete for WAP-7 for 3 Phase Co Co Locomotive to CLW specification No. CLW/MS/3/Bogie/003 alt-1 and CLW Drg.No.1209.01.112-202 Alt-Nil	As per clause 16 of Spec.No.CLW/MS/3/Bogie/003 Alt-1. [60 months after commissioning or 72 months from date of supply]
9	29171192	COMPLETE AUXILIARY CUBICLE HB2 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0192 ALT-E OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
10	29171210	COMPLETE CONTROL CUBICLE SB2 ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0195/A ALT-H OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
11	29171209	COMPLETE CONTROL CUBICLE SB1 (PUSH PULL SCHEME COMPLIANT) ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0194 ALT-G OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
12	29171180	COMPLETE AUXILIARY CUBICLE HB1 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0191 ALT-D OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.



#### भारत सरकार GOVERNMENT OF INDIA

रेल मंत्राल्य

#### MINISTRY OF RAILWAYS

पटियाला रेलइंजन कारखाना
PATIALA LOCOMOTIVE WORKS

फैक्स/Fax No.: 0175-2397244 फोन/ Phone: 0175-2396422 मोबाईल: 9779242310

Email: dyceeloco.dmw@gmail.com

पटियाला, 147003, भारत् PATIALA, 147003, INDIA



(An ISO 9001, ISO 14001, ISO 45001 & ISO 50001, 5S & Green Building certified Organization)

संख्या. PLW/M/ECS/Tech/Kavach

तिथि: 22.10.2024

(Through Mail)

Sr. Div. Electrical Engineer, Electric Loco Shed, Itarsi.

Email: srdeetrset@gmail.com

विषय:- Fitment of KAVACH in three Phase Electric Loco. No. 41921 WAG9-HC.

संदर्भ:- (i)Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 21.08.2023.

(ii)Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 26.09.2023

In ref. to the above letter's Loco No. 41921 has been dispatched with fittings for implementation of KAVACH system in locomotive at home shed in Zonal Railway. This Loco was dispatched to ELS/ET/WCR on 19.10.2024. The details of fittings are attached as Annexure-A (pneumatic fittings), Annexure-B (Kavach equipment mounting Brackets) & Annexure-C (Wago with harnessed lay out).

This is for your information & necessary action please.

िस्तिवा अ 22.11.24 (निशांत बंसीवाल)

उप मुख्य विद्युत अभियंता/लोको

#### प्रतिलिपि:-

CEE/Loco & CEE/D&Q, CMM, CELE/WCR:- for kind information please Dy CME/Design, Dy. CMM/Depot: for information & necessary action please WM/LAS, AWM/LFS&ABS, AWM/ECS: for necessary action please

#### Loco No. 41921

List of balance items of KAVACH pneumatic pipes & fitting yet to be supplied later on. These items are currently under procurement process at PLW. The same will be advised to the shed for collection of the material as soon as it will be received at PLW.

3	P 2 0	णिकस्वानुमें का विकास	2)jy
		ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITH VENT	04 nos
1	29163341	ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITHOUT VENT	02 nos.
		TEE UNION 3/8"X3/8"X3/8" BRASS FITTINGS	02 nos.
		MALE CONNECTORS 3/8" TUBE OD X 3/8" BSPT, BRASS FITTINGS	09 nos.
		MALE CONNECTORS 1/2" TUBE OD X 1/2" BSPT, BRASS FITTINGS	06 nos.
		FEMALE CONNECTORS (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	01 no.
		MALE CONNECTOR (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	03 nos.
2	29611994	FEMALE TEE 3/8" BSPP – BRASS	06 nos.
		HEX PLUG -3/8" BSPT – BRASS	02 nos.
		FEMALE TEE 1/2" BSPP – BRASS	04 nos.
		HEX NIPPLE 3/8X3/8" BSPT – BRASS	04 nos.
		RED HEX NIPPLE 3/8X1/2" BSPT - BRASS	02 nos.
	•	HEX PLUG – 1/2" BSPT – BRASS	04 nos.
		MALE ELBOW CONNECTORS 3/8" TUBE OD X 3/8) BSPT. BRASS FITTINGS	02 nos.
3	29170114	Copper Tube OD 9.52mm (3/8") X 1.245 Mm W.T X 6 Mtr	1.2 Mtr

AWMABS & LFS ( )

SSE /ABS/ G

SN	PL No.	Description of item	Quantity
1.	29611945	Mounting bracket arrangement provided for RF Antenna on	04 nos.
2.		Mounting bracket arrangement provided for GPS/GSM Antenna on the roof top of both driver cabs.	02 nos.
3.		Protection Guards for RFID reader provided behind the cattle	04 nos.
4.	-	Inspection door with latch provided on the both driver desk covers (LP side) in each cab to access isolation cock.	02 nos.
5.		Cable Entry Plate fitted for routing of cable with RF Antenna & GPS/GSM Antenna bracket.	06 nos.
6.	_	WAGO bracket fitted in Machine room at back side of SB-1.	01 no.
7.	-	One circular hole of 80 mm dia. provided in each cabs on LP side behind the driver desk toward the wall for routing of	02 nos.
8.		OCIP (DMI) cables.  80 mm holes provided on TM1 and TM6 Junction box inspection cover hole for drawing of RFID reader cables.	02 nos.
9.	-	DIN Rail fitted inside the driver desk (LP Side)	02 nos.





#### Annexure-C

		Description of item	Quantity
<b>SN</b> 1.	PL No. 42310301	Flexible conduit size 25mm² provided for RF-1, 2 & GPS Antenna cable layout from CAB-1&2 to Machine room.	06 nos.
2.	29611982	Wago terminals in CAB-1&2 (25 nos. in each CAB).	50 nos.
3.	29611982	Wago terminal in Machine room at back side of SB-1.	75 nos.
4.	-	Harness provided from KAVACH SB to SB-1	05 wires
5.		Harness provided from KAVACH SB to SB-2	05 wires 12 wires
6.	•	Harness provided from KAVACH SB to Pneumatic Panel	24 wires
7.	-	Harness provided from KAVACH SB to CAB-1	16 wires
8.	-	Harness provided from KAVACH SB to CAB-2	10 441100



