भारतीय रेल Indian Railways

पटियाला रेलइंजन कारख़ाना, पटियाला

PATIALA LOCOMOTIVE WORKS, PATIALA



LOCO TESTING & DISPATCH REPORT OF IGBT BASED WAG9HC ELECTRIC LOCOMOTIVE

LOCO NO.: 41950

TYPE: WAG9HC

RAILWAY SHED: WR/SBTD

PROPULSION SYSTEM: MEDHA

DATE OF DISPATCH: 26.10.2024

लोको निर्माण रिकार्ड



पटियाला रेलइंजन कारख़ाना, पटियाला PATIALA LOCOMOTIVE WORKS, PATIALA

LOCO NO.: 41950

RAILWAY/SHED: WR/SBTD

DOD: Oct-2024

INDEX

SN	PARA	ACTIVITIES	PAGE NO.	
Testing & Commissioning (ECS)				
1. 1.0		Continuity Test of the cables		
	1.1	Continuity Test of Traction Circuit Cables		
	1.2	Continuity Test of Auxiliary Circuit Cables	1-4	
	1.3	Continuity Test of Battery Circuit Cables		
	1.4	Continuity Test of Screened Control Circuit Cables		
2.	2.0	Low Tension test		
	2.1	Measurement of resistor in OHMS (Ω)	5.0	
	2.2	Check Points	5-6	
	2.3	Low Tension Test Battery Circuits (without control electronics)		
3	3.0	Downloading of Software		
	3.1	Check Points		
	3.2	Download Software	7-10	
	3.3	Analogue Signal Checking		
	3.4	Functional test in simulation mode		
4	4.0	Sensor test & convertor test		
	4.1	Test wiring Transformer Circuits – Polarity Test		
	4.2	Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)		
	4.3	Primary Voltage Transformer		
	4.4	Minimum voltage relay (Pos. 86)	44.40	
	4.5	Maximum current relay (Pos. 78)	11-16	
	4.6	Test current sensors		
	4.7	Test DC Link Voltage Sensors (Pos 15.6/*)		
	4.8	Verification of Converter Protection Circuits (Hardware limits)		
	4.9	Sequence of BUR contactors		
5.	5.0	Commissioning with High Voltage		
	5.1	Check List		
	5.2	Safety test main circuit breaker		
	5.3	Auxiliary Converter Commissioning		
	5.3.1	Running test of 3 ph. auxiliary equipments		
	5.3.2	Performance of Auxiliary Converters		
	5.3.3	Performance of BURs when one BUR goes out	16-25	
	5.4	Auxiliary circuit 415/110		
	5.5	Hotel Load Circuit		
	5.6	Traction Converter Commissioning		
	5.7	Test protective shutdown SR		
	5.8	Test Harmonic Filter		
	5.9	Test important components of the locomotive		
6.	6.0	Running Trial of the locomotive	25-26	
7.	7.0	Final Check List to be verified at the time of Loco dispatch	27	
8.	8.0	Status of RDSO modifications	28	
9.	1-10	Pneumatic Test Parameters	29 - 32	
10.		Loco Check Sheet(LAS)	33	
11.	-	Component History (LAS,ECS,ABS)	34-36	
12.	-	Component History & Testing Parameter (Bogie Shop)	37 - 38	
13	-	Warranty Conditions as per Tenders	39 -41	

PATIALA LOCOMOTIVE WORKS, PATIALA

(Ref: WI/ECS/10)

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41950 -MEDHA

Type of Locomotive: WAP-7/WAG-9HC

Page: 1 of 27

1.0 Continuity Test of the cables

1.1 Continuity Test of Traction Circuit Cables

As per cable list given in Para 1.3 of document no. 3 EHX 410 124, check the continuity with continuity tester and megger each cable to be connected between following equipment with 1000V megger.

From	То	Continuity (OK/Not OK)	Prescribed Megger Value (min)	Measured Megger Value
Filter Cubicle	Transformer	OK	100 ΜΩ	booma
Filter Cubicle	Terminal Box of Harmonic Filter Resistor (Roof)	οK	100 ΜΩ	600 m()
Filter Cubicle	Earthing Choke	oK	100 ΜΩ	bsoma.
Earthing Choke	Earth Return Brushes	oK	100 ΜΩ	500MA
Transformer	Power Converter 1	oK	100 ΜΩ	SSOMA
Transformer	Power Converter 2	οK	100 ΜΩ	600m()
Power Converter 1	TM1, TM2, TM3	οK	100 ΜΩ	60 omA
Power Converter 2	TM4, TM5, TM6	o K	100 ΜΩ	.650MR
Earth	Power Converter 1	OK	100 ΜΩ	600 m
Earth	Power Converter 2	oK	100 ΜΩ	650ma

1.2 Continuity Test of Auxiliary Circuit Cables

As per cable list given in Para 1.4 of document no. 3 EHX 410 124, check the continuity with continuity meter and megger each cable to be connected between following equipment with the help of 1000V megger.

Signature of the JE/SSE/Harness

Signature of the JE/SSE/Loco Cabling

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/950

Type of Locomotive: WAP-7/WAG-9HC

Page: 2 of 27

From	То	Continuity(OK/ Not OK)	Prescribed Megger Value (min) 100 ΜΩ	Measured Megger Value
	BUR1	OK	100 MΩ	800 0
Transformer Transformer	BUR2	ok	100 MΩ	Comme
Transformer	BUR3	oK	100 MΩ	700 ml
Earth	BUR1	OK	100 MΩ	500 ml
Earth	BUR2	OK	100 ΜΩ	600 ML
Earth	BUR3	OK	100 ΜΩ	500 MA
BUR1	HB1	ok_		600 mr
BUR2	HB2	oK	100 ΜΩ	600 m
	HB2	OK	100 ΜΩ	500 M/L
HB1	TM Blower 1	OK	100 ΜΩ	
HB1	TM Scavenge Blower 1	oK	100 MΩ	500 mr
HB1		ok_	100 ΜΩ	600 MM
HB1	Oil Cooling Unit 1	OK_	100 ΜΩ	600 m
HB1	Compressor 1	OK	100 ΜΩ	700 ml
HB1	TFP Oil Pump 1		100 ΜΩ	600 ma
HB1	Converter Coolant	OK	<u> </u>	
	Pump 1 MR Blower 1	6K	100 ΜΩ	500 mm
HB1		OK	100 MΩ	600 m
HB1	MR Scavenge Blower 1		100 ΜΩ	700 m
HB1	Cab1	oK_	100 ΜΩ	600mA
Cab1	Cab Heater 1	oK_	100 ΜΩ	600m/
HB2	TM Blower 2	ek_	100 MΩ	500 m
HB2	TM Scavenge Blower 2	OK_	100 MΩ	600 mi
HB2	Oil Cooling Unit 2	OK_		
HB2	Compressor 2	OK_	100 MΩ	
HB2	TFP Oil Pump 2	OK	100 ΜΩ	
HB2	Converter Coolant Pump	2 OK	100 ΜΩ	
HB2	MR Blower 2	OK	100 ΜΩ	
HB2	MR Scavenge Blower 2	OK	100 ΜΩ	
HB2	Cab2	OK	100 ΜΩ	
Cab2	Cab Heater 2	OK	100 MΩ	+00 M

Effective Date: Feb 2022

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/950

Type of Locomotive: WAP-7/WAG-9HC Page: 3 of 27

(Ref: WI/ECS/10)

1.3 Continuity Test of Battery Circuit Cables

Check continuity of following cables as per Para 2.3 of document no. 3 EHX 610 299

То	Condition	Continuity (OK/Not OK)
Circuit breakers 110-	By opening and closing MCB 112	عد
2, 112.1-1, 310.4-1 Connector 50.X7-1	By opening and closing MCB 110	OV.
Connector 50.X7-2 Connector 50.X7-3		ev.
	Circuit breakers 110- 2, 112.1-1, 310.4-1 Connector 50.X7-1	Circuit breakers 110- 2, 112.1-1, 310.4-1 Connector 50.X7-1 By opening and closing MCB 112 By opening and closing MCB 110

Close the MCB 112, 110, 112.1, and 310.4 and measure the resistance of battery wires 2093, 2052, 2050 with respect to the loco earth. Measure the resistance between 2093 & 2052,	Prescribed value $> 0.5 \text{ M}\Omega$ Prescribed value:	Measured Value 6 MΩ Measured
2093 & 2050, 2052 & 2050	> 50 MΩ	Value 60 M Ω

Commission the indoor lighting of the locomotive as per Sheet No 7A & 7B.

1.4 Continuity Test of Screened Control Circuit Cables

Check the continuity and isolation of the screen cable of the following circuits with the help of sheet no. mentioned against each as per document no. 3 EHX 610 299.

Screened control circuit cables for	Corresponding Sheet Nos.	Continuity & Isolation (OK/Not OK)
Battery voltage measurement	04B	OK
Memotel circuit of cab1 &2	10A	OR
Memotel speed sensor	10A	91
Primary voltage detection	01A, 12A	^D V_
Brake controller cab-1 & 2	06F, 06G	OL.

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 4 of 27

	·	
Master controller cab-1 &2	08C, 08D	OK
TE/BE meter bogie-1 & 2	08E, 08F	On
Terminal fault indication cab-1 & 2	09F	OK.
Brake pipe pressure actual BE electric	06H	DUL
	12B, 12F	OL
Primary current sensors	12B, 12F	OK
Harmonic filter current sensors	12B, 12F	In the
Auxiliary current sensors	12E, 12I	ac
Oil circuit transformer bogie 1	12C, 12G	ô _k
Magnetization current		
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-1	12D	SV.
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-2	12D	ge
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-3	12D	٩
Traction motor speed sensors (2 nos.) and temperature sensors (1 no.) of TM-4	12H	ac
Traction motor speed sensors (2 nos) and temperature sensors (1 no.) of TM-5	12H	91
Traction motor speed sensors (2nos) and temperature sensors (1 no.) of TM-6	12H	9
Train Bus cab 1 & 2 (Wire U13A& U13B to earthing resistance=	13A	OK
10KΩ± ± 10%)		
UIC line	13B	QL.
Connection FLG1-Box TB	13A	n

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 4/950

Type of Locomotive: WAP-7/WAG-9HC

Page : 5 of 27

2.0 Low Tension test

2.1 Measurement of resistor in OHMS (Ω) Measure the resistances of the load resistors for primary voltage transformer, load resistors for primary current transformer and Resistor harmonic filter as per Para 3.2 of the document

no. 3 EHX 610 279.

Name of the resistor	Prescribed value	Measured value
Load resistor for primary voltage cransformer (Pos. 74.2).	3.9K Ω ± 10%	3.9KL
Resister to maximum current relay.	1Ω ± 10%	150
Load resistor for primary current transformer (Pos. 6.11).	3.3 Ω ± 10%	2.35
Resistance harmonic filter (Pos 8.3). Variation allowed $\pm 10\%$	WAP7	WAP7
Between wire 5 & 6	0.2 Ω	0.21
Between wire 6 & 7	0.2 Ω	0.27
Between wire 5 & 7	0.4 Ω	042
For train bus, line U13A to earthing.	10 kΩ± 10%	998pr
For train bus, line U13B to earthing.	10 kΩ ± 10%	10.041
Insulation resistance of High Voltage Cable from the top of the roof to the earth (by1000 V megger).	200 ΜΩ	300 MM
Resistance measurement earth return brushes Pos. 10/1.	≤0.3 Ω	0.281
Resistance measurement earth return brushes Pos. 10/2.	≤0.3 Ω	0.281
Resistance measurement earth return brushes Pos. 10/3.	≤0.3 Ω	0,281
Resistance measurement earth return brushes Pos. 10/4.	≤0.3 Ω	0.305
Earthing resistance (earth fault detection) Harmonic Filter –I; Pos. 8.61.	2.2 kΩ ± 10%	2.211
Earthing resistance (earth fault detection) Harmonic Filter –II; Pos 8.62.	2.7 k Ω ± 10%	2.7K2
Earthing resistance (earth fault detection) Aux. Converter; Pos. 90.3.	3.9 k Ω ± 10%	3.912
Earthing resistance (earth fault detection) 415/110V; Pos. 90.41.	1.8 k Ω ± 10%	1.8 Kr
Earthing resistance (earth fault detection) control circuit; Pos. 90.7.	390 Ω ± 10%	390A
Earthing resistance (earth fault detection) Hotel load; Pos. 37.1(in case of WAP5).	3.3 k Ω ± 10%	NA
Resistance for headlight dimmer; Pos. 332.3.	- 10Ω ± 10%	1052

Effective Date: Feb 2022

PATIALA LOCOMOTIVE WORKS, PATIALA

(Ref: WI/ECS/10)

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 6 of 27

Make sure that the earthing brush device don't make direct contact with the axle housing, Note: earth connection must go by brushes.

2.2 Check Points

	Remarks
Items to be checked	
Check whether all the earthing connection in roof and machine room as mentioned in sheet no. 22A is done properly or not. These earthing connections must be flexible and should be marked yellow & green	cherteral ar
Check whether all the earthing connection between loco body and bogie is done properly or not. These cables must be flexible having correct length and cross section	cheeped ou

2.3 Low Tension Test Battery Circuits (without control electronics)

These tests are done with the help of the special type test loop boxes as per procedure given in Para 3.6 of the document no. 3 EHX 610 279

Para 3.6 of the document no. 3 EHX 6 Name of the test	Schematic used.	Remarks
Test 24V supply	Sheet 04F and other linked sheets	cheeseel or
Test 48V supply	Sheet 04F & sheets of group 09	Fan supply to be checked.
Test traction control	Sheets of Group 08.	ou
Test power supply bus stations.	Sheets of Group 09.	Fan supply to be checked.
Test control main apparatus	Sheets of Group 05.	^O K
Test earth fault detection battery circuit by making artificial earth fault to test the earth fault detection	Sheet 04C	Sa.
Test control Pneumatic devices	Sheets of Group 06	OK
Test lighting control	Sheets of Group 07	OK.
Pretest speedometer	Sheets of Group 10	9 <u>K</u>
Pretest vigilance control and fire system	Sheets of Group 11	ne
Power supply train bus	Sheets of Group 13	On

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41950 **Downloading of Software** Type of Locomotive: WAP-7/WAG-9HC

Page: 7 of 27

(Ref: WI/ECS/10)

	Yes/No
3.1 Check Points. Check that all the cards are physically present in the bus stations and all the plugs are	Yes
connected. Check that all the fibre optic cables are correctly connected to the bus stations.	Yey
Make sure that control electronics off relay is not energized i.e. disconnect Sub-D 411.LG and loco is set up in simulation mode.	Yay
Check that battery power is on and all the MCBs (Pos. 127.*) in SB1 &SB2 are on	Yes

3.2 Download Software

The software of Traction converter, Auxiliary converter and VCU should be done by commissioning engineer of the firm in presence of supervisor. Correct software version of the

propulsion equipment to be ensured and noted:

propulsion equipment to be ensured and noted:	1.09
Traction converter-1 software version:	
Traction converter-2 software version:	1.09
Auxiliary converter-1 software version:	1,04.
Auxiliary converter-2 software version:	1.04
Auxiliary converter-3 software version:	, 04
Vehicle control unit -1 software version:	3.0
Vehicle control unit -2 software version:	3.0

3.3 Analogue Signal Checking

Check for the following analogue signals with the help of diagnostic tool connected with loco

Description	Signal name	Prescribed value	Measured Value
Brake pipe pressure	FLG2;0101XPrAutoBkLn	100% (= 5 Kg/cm2)	OX
Actual BE electric	FLG2; AMSB_0201- Wpn BEdem	100% (= 10V)	Ou.
TE/BE at 'o' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 9% and 11 %	2041
TE/BE at 'TE maximal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 99 % and 101 %	1000
TE/BE at 'TE minimal' position from both cab	FLG1; AMSB_0101- Xang Trans FLG2; AMSB_0101- Xang Trans	Between 20 % and 25 %	2571

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4195°

Type of Locomotive: WAP-7/WAG-9HC

Page: 8 of 27

TE/BE at 'BE maximal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 99% and 101%	1001,
TE/BE at 'BE Minimal' position from both cab	FLG1; AMSB_0101- XangTrans FLG2; AMSB_0101- XangTrans	Between 20% and 25%	257,
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>1/3 HBB2; AMS_0101- LT/BDEM>1/3	Between 42 and 44%	441,
TE/BE at '1/3' position in TE and BE mode in both cab.	HBB1; AMS_0101- LT/BDEM>2/3 HBB2; AMS_0101- LT/BDEM>2/3	Between 72 and 74%	744
Both temperature sensor of TM1	SLG1; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature 0° C to 40° C	14°C
Both temperature sensor of TM2	SLG1; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	13°C
Both temperature sensor of TM3	SLG1; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	
Both temperature sensor of TM4	SLG2; AMSB_0106- XAtmp1Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	79 3
Both temperature sensor of TM5	SLG2; AMSB_0106- Xatmp2Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	13°C
Both temperature sensor of TM6	SLG2; AMSB_0106- Xatmp3Mot	Between 10% to 11.7% depending upon ambient temperature 0°C to 40°C	14°C

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 9 of 27

(Ref: WI/ECS/10)

Functional test in simulation mode 3.4

Conduct the following functional tests in simulation mode as per Para 5.5 of document no.3EHX 610 281. through the Diagnostic tool/laptop:

Test Function	Result desired in sequence	Result obtained
Emergency shutdown through emergency stop switch 244	VCB must open. Panto must lower.	cheeked on
Shut Down through cab activation switch to OFF position	VCB must open. Panto must lower.	chelteda
Converter and filter contactor operation with both Power Converters during Start Up.	FB contactor 8.41 is closed. By moving reverser handle: Converter pre-charging contactor 12.3 must close after few seconds. Converter contactor 12.4 must close. Converter re-charging contactor 12.3 must opens. By increasing TE/BE throttle: FB contactor 8.41 must open. FB contactor 8.2 must close. FB contactor 8.1 must close.	choesed on
Converter and filter contactor operation with both Power Converters during Shut Down.	 Bring TE/BE to O. Bring the cab activation key to "O" VCB must open. Panto must lower. Converter contactor 12.4 must open. FB contactor 8.1 must open. FB contactors 8.41 must close. FB contactor 8.2 must remain closed. 	

22 PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC Page: 10 of 27

(Ref: WI/ECS/10)

	Liberia (A	
Contactor filter adaptation by solating any bogie	Isolate any one bogie through bogie cut out switch. Wait for self-test of the loco.	•
	• Check that FB contactor 8.1 is open.	charted ou
	 Check that FB contactor 8.2 is open. After raising panto, closing VCB, and 	2
	setting TE/BE	
	 FB contactor 8.1 closes. FB contactor 8.2 remains open. 	
Test earth fault detection battery	By connecting wire 2050 to	
circuit positive & negative	earth, create earth fault	1 -
	negative potential. • message for earth fault	chooked or
	By connecting wire 2095	
	to earth, create earth fault positive potential.	
	message for earth fault	
Test fire system. Create a smoke in	When smoke sensor-1 gets	· ·
the machine room near the FDU.	activated then)
Watch for activation of alarm.	 Alarm triggers and fault message priority 2 	
	appears on screen.	charkedou
	Which poet smoke series	P
	1+2 gets activated then • A fault message priority	
	1 appears on screen and	
•	lamp LSF1 glow.Start/Running interlock occurs and	
	TE/BE becomes to 0.	
Time, date & loco number	Ensure correct date time and Loco	O.L
	number ()	

Effective Date: Feb 2022

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 11 of 27

Sensor Test and Converter Test 4.0

4.1 Test wiring main Transformer Circuits

Apply $198V_p/140V_{RMS}$ to the primary winding of the transformer (at 1u; wire no. 2 at surge arrestor and at 1v; wire no. 100 at earthing choke). Measure the output voltage and compare

hase of the following of the transformers.

the phase of the	the phase of the following of the transformers. Described Measured Mea				
Output Winding nos.	Description of winding.	Prescribed Output Voltage & Polarity with input supply.	output	polarity	
2U ₁ & 2V ₁	For line converter bogie 1 between cable 801A- 804A	10.05V _p and same polarity	10.0400	BIL	
2U ₄ & 2V ₄	For line converter bogie 1 between cable 811A- 814A	10.05V _p and same polarity	10.05Vp	ch.	
2U ₂ & 2V ₂	For line converter bogie 2 between cable 801B- 804B	10.05V _p and same polarity	10.0400	OK	
2U ₃ & 2V ₃	For line converter bogie 2 between cable 811B- 814B	10.05V _p and same polarity	10.0400	ox	
2U _B & 2V _B	For aux. converter 1 between cable 1103- 1117 (in HB1) For Aux converter 2 between cable 1103- 1117 (in HB2)	7.9V _p , 5.6V _{RMS} and same polarity.	7.8 Vpms	ac	
2U _F & 2V _F	For harmonic filter between cable 4-12 (in FB)	9.12V _p , 6.45V _{RMS} and same polarity.	9.10.4p 6.44vams	ou.	

4.2 Test wiring auxiliary transformer 1000V/415V-110V (pos. 67)

Apply $141V_p$ / $100V_{RMS}$ to input of the auxiliary transformer at cable no 1203 –1117 and measure the output at

Description of wire no.	Prescribed Output Voltage & Polarity with input supply.	Measured output	Measured polarity
Cable no. 1218 - 1200	58.7V _p , 41.5V _{RMS} and opposite polarity.	58-641 415 VDMS	OK
Cable no. 1218 – 6500	15.5V _p , 11.0V _{RMS} and opposite polarity.	15-5VB	31
<u> </u>		11.002103	l

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 12 of 27

Primary Voltage Transformer 4.3

Apply $250V_{eff}/350V_p$ by variac to roof wire 1 and any wire 0 and measure the magnitude and polarity of the output of the primary voltage transformer for both bogies as per the procedure specified and suggested by the traction converter manufacturer. Primary voltage measurement converters (Pos. 224.1/*) & catenary voltmeter (Pos. 74/*)

This test is to be done for each converter.

Activate cab in driving mode and supply 200V_{RMS} through variac to wire no 1501 and 1502. Monitor the following parameters through Diagnostic tool and in catenary voltmeter.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	25kV	250%	25XV	250/
SLG2 G 87-XUPrim	25 kV	250%	25KN	2501

Decrease the supply voltage below 140 V_{RMS} . VCB must open at this voltage. In this case the readings in Diagnostic Tool and catenary voltmeter will be as follows.

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	17kV	170%	17KV	170%
SLG2 G 87-XUPrim	17 kV	170%	17KV	1704

Reactivate VCB to on by increasing this voltage to 175% (17.5 kV).

Increase the supply to 240 V_{RMS} through variac. VCB must open at this voltage, In this case the readings in diagnostic tool and catenary voltmeter will be as follows:

Signal name	Prescribed value in catenary voltmeter	Prescribed value in Micview	Monitored value in catenary voltmeter	Monitored value in SR diagnostic tool
SLG1 G 87-XUPrim	30kV	300%	30 KV	3004
SLG2 G 87-XUPrim	30 kV	300%	20KV	300 /

Reactivate VCB to on by decreasing this voltage to 290% (29 kV).

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 13 of 27

(Ref: WI/ECS/10)

Minimum voltage relay (Pos. 86) 4.4

Functionality test:	ted to approx 68%
Functionality test: Minimum voltage relay (Pos. 86) must be adjus	(Yes/No)
Activate loco in cooling mode. Check Power supply of 48V to	1
The state of the s	
HA ON THE ARMOOST VORIOG TO WITE NO. 1501 dilu 1504, 50PP!	
200V _{RMS} through variac. In this case; <i>Minimum voltage relay</i>	
(Pos. 86) picks up	
Try to activate the cab in driving mode:	(Yes/No)
Contactor 218 do not close; the control	
electronics is not be working.	(Yes/No)
Turn off the variac : Contactor 218 closes; the control electronics is be	
working Test Under Voltage Protectio	n:
Test officer voltage i rotestio	
Line works Poiss nants:	(Yes/No)
Activate the cab in cooling mode; Raise panto;	
Supply 200V _{RMS} through variac to wire no. 1501	
& 1502; Close the VCB; Interrupt the supply	·
voltage	
The VCB goes off after 2 second time delay.	1 (YES/NO)
Again supply 200V _{RMS} through variac to wire no.	Lifes/NO)
1501 & 1502; Decrease the supply voltage below	
140V _{RMS} ± 4V;	
Fine tune the minimum voltage relay so that VCB opens.	

4.5 Maximum current relay (Pos. 78)	i
Disconnect wire 1521 & 1522 of primary current transfo &1522 (including the resistor at Pos. 6.11); Put-loco in simul on contact 136.3; Close VCB; supply 3.6A _{RMS} at the oper maximum current relay Pos. 78 for correct over current value.	ation for driving mode; Open $R_3 - R_4$ Note: 1521; Tune the drum of the
VCB opens with Priority 1 fault message on	(Yes/No)
display.	
Keep contact R ₃ – R ₄ of 136.3 closed; Close VCB; Tune the re	esistor 78.1 for the current of 7.0A _{RMS}
/9.9A _p at the open wire 1521;	
VCB opens with Priority 1 fault message on	-(Yes/No)
display.	·

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 14 of 27

4.6 Test current sensors Name of the sensor	Description of the test	Prescribed value	Set/Measured value
Primary return current sensor (Test-1,Pos.6.2/1 & 6.2/2)	Activate cab in driving mode supply 10A. Measure the current through diagnostic tool or measuring print.	(Variation allowed is ± 10%)	
	Supply 90mA _{DC} to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		
Primary return current sensor (Test-2, Pos.6.2/1 & 6.2/2)	Supply 297mA _{DC} to the test winding of sensor through connector 415.AA/1or 2 pin no. 7(+) & 8(-)		298MB
Auxiliary winding current sensor (Pos. 42.3/1 & 42.3/2)	Supply 90mA _{DC} to the test winding of sensor through connector 415.AC/1or 2 pin no. 7(+) & 8(-) Supply 333mA _{DC} to the test winding of sensor through connector 415.AC/1 or 2 pin no. 7(+) & 8(-)		335WA
Harmonic filter current sensors (Pos.8.5/1 &8.5/2)	Supply 90mA _{DC} to the test winding of sensor through connector 415.AE/10 2 pin no. 7(+) & 8(-) Supply 342mA _{DC} to the test winding of	r	21.77.5
	sensor through connector 415.AE/10 2 pin no. 7(+) & 8(-) Switch on hotel load. Supply 90mA _{DO}		347mA
Hotel load current sensors (Pos. 33/1 &	to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) 8(-)	MIT	MA
33/2)	Supply 1242mA _{DC} to the test winding of sensor through connector 415.AG/1or 2 pin no. 7(+) & 8(-)	ain nin	NA

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41850

Type of Locomotive: WAP-7/WAG-9HC

Page: 15 of 27

4.7 Test DC Link Voltage Sensors (Pos 15.6/*)

This test is to be done by the commissioning engineer of the firm if required.

4.8 Verification of Converter Protection Circuits (Hardware limits) -

This test is to be done as per para 6.17 of the document no. 3EHX 610 282 for both the converters.

Protection circuits	Limit on which shutdown should take place	Measured limit	
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 1	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 18.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=	choeked
Current sensors (Pos 18.2/1, 18.2/2, 18.2/3, 18.4/4, 18.5/1, 18.5/2, 18.5/3) for Power Converter 2	Increase the current quickly in the test winding of the current sensors, VCB will off at 2.52A with priority 1 fault for each sensor.	For 18.2/1= For 8.2/2= For 18.2/3= For 18.4/4= For 18.5/1= For 18.5/2= For 18.5/3=	cross
Fibre optic failure in Power Converter1	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	one	
Fibre optic failure In Power Converter2	Remove one of the orange fibre optic plugs on traction converter. VCB should trip	9L	

4.9 Sequence of BUR contactors

The sequence of operation of BUR contactors for 'ALL BUR OK' BUR 1 out BUR 2 out and BUR 3 out condition has to be verified by putting the Loco in driving mode (VCB should not be closed) and isolating the BURs one by one. In these condition following will be the contactor sequence.

Status	52/1	52/2	52/3	52/4	52/5	52.4/1	52.4/2	52.5/1	52.5/2
AI BUR OK	Close	Open	Close	Open	Close	Open	Close	Close	Open
BUR1 off	Close	Open	Close	Close	Open	Close	Open	Open	Close
BUR2 off	Open	Open	Close	Close	Close	Close	Open	Open	Close
BUR3 off	Open	Close	Open	Close	Close	Close	Open	Open	Close

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 16 of 27

Monitored contactor sequence

IOINTOICA JOIN				1 /-	F2/F	52.4/1	52.4/2	52.5/1	52.5/2
Status	52/1	52/2	52/3	52/4	52/5	32.4/1			
		ala a	1000	open	clos	Oben	close	close_	open
AI BUR OK	close	open	clos	 		10.00	open	open	clos
BUR1 off	close	open	clos	clos	Okon	clos	17./		
· · · · · · · · · · · · · · · · · · ·		Oben	Close	clos	clos	clus-	Spag	Often	clos
BUR2 off	ope	<u> </u>	003				open	Dan	closs
BUR3 off	open	close	open	clos	close	close		, ,	1000
		ــــــــــــــــــــــــــــــــــــــ							

5.0 Commissioning with High Voltage

5.1 Check List

Items to be checked	Yes/No
Fibre optic cables connected correctly.	Yey
	49
No rubbish in machine room, on the roof, under the loco.	
All the electronic Sub-D and connectors connected	Ye
All the MCBs of the HB1 & HB2 open.	No.
All the three fuses 40/* of the auxiliary converters	Yes
The fuse of the 415/110V auxiliary circuit (in HB1) open.	Yes
Roof to roof earthing and roof to cab earthing done	Yey
Fixing, connection and earthing in the surge arrestor done correctly.	76)
Connection in all the traction motors done correctly.	Yes
All the bogie body connection and earthing connection done correctly.	Yey
Pulse generator (Pos. 94.1) connection done correctly.	Yes
All the oil cocks of the gate valve of the transformer in open condition.	To
All covers on Aux & Power converters; Filter block, HB1, HB2 fitted	Yes
KABA key interlocking system.	Yes

5.2 Safety test main circuit breaker

Prepare to switch off the catenary supply during the first charging of the locomotive in case of any unexpected behavior of the electrical component of the loco. Charge the loco for the first time by closing BLDJ switch. The VCB will trip after certain time as no oil/coolant pumps are running yet.

Perform the following safety test of main circuit breaker through both the cabs of the locomotive.

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC Page: 17 of 27

Name of the test	Description of the test	Expected result	Monitored result
Emergency stop in cooling mode	Raise panto in cooling mode. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	chooped on
Emergency stop in driving mode	Raise panto in driving mode in. Put the brake controller into RUN position. Close the VCB. Push emergency stop button 244.	VCB must open. Panto must lower. Emergency brake will be applied.	Chalbeel on
Under voltage protection in cooling mode	Raise panto in cooling mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open.	clockedou
Under voltage protection in driving mode	Raise panto in driving mode. Close the VCB. Switch off the supply of catenary by isolator	VCB must open with diagnostic message that catenary voltage out of limits	Cheredon
Shut down in cooling mode.	Raise panto in cooling mode. Close the VCB. Bring the BL- key in O position.	VCB must open. Panto must lower.	choeted an
Shutdown in driving mode	Raise panto in driving mode. Close the VCB. Bring the BL-key in O position.	VCB must open. Panto must lower.	Cheledoe
Interlocking pantograph- VCB in cooling mode	Raise panto in cooling mode. Close the VCB. Lower the pantograph by ZPT	VCB must open.	Cheekedou
Interlocking pantograph- VCB in driving mode	Raise panto in driving mode. Close the VCB. Lower the pantograph by ZPT		Chalkedon

Effective Date: Feb 2022

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 18 of 27

5.3 Auxiliary Converter Commissioning

Switch on the high voltage supply and set up the loco in driving mode. Raise the panto. Close the VCB. Check that there is no earth fault in the auxiliary circuit, Switch off the VCB. Lower the panto. Create the earth fault in auxiliary circuit by making connection between wire no 1117(in HB2 cubicle) and earth. After 3 minutes a diagnostic message will come that "Earth fault auxiliary circuit."

5.3.1 Running test of 3 ph. auxiliary equipments

Switch on the 3 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured continuous phase current	Measured starting phase current
Oil pump transformer 1	9.8 amps	11:1	13.9
Oil pump transformer 2	9.8 amps	11.5	13.3
Coolant pump converter 1	19.6 amps	4.5	5.3
Coolant pump converter 2	19.6 amps	4.3	5-4
Oil cooling blower unit 1	40.0 amps	30.8	66.0
Oil cooling blower unit 2	40.0 amps	31.0	62.0
Traction motor blower 1	34.0 amps	29.8	2010
Traction motor blower 2	34.0 amps	30.3	170.0
Sc. Blower to Traction motor blower 1	6.0 amps	5-1	.6.0
Sc. Blower to Traction motor blower 1	6.0 amps	5.6	6. 3
Compressor 1	25 amps at 0 kg/ cm ² 40 amps at 10 kg/ cm ²	31.3	38.9
Compressor 2	25 amps at 0 kg/ cm ² 40 amps at 10 kg/ cm ²	32.3	42,0

Effective Date: Feb 2022

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.:

Type of Locomotive: WAP-7/WAG-9HC

Page: 19 of 27

5.3.2 Performance of Auxiliary Converters

Measure the performance of the auxiliary converters through software and record it. BUR1 (Condition: Switch off all the load of BUR 1)- to be filled by commissioning engineer

Description of the signal	value	Monitored value	Value under Limit (Yes/No)
Input voltage to BUR1	75% (10%=125V)	1002V	Yey
l	60% (10%=100V)	6374	You
DC link current of BUR1	0% (10%=50A)	1 Amp	19
	Input voltage to BUR1 DC link voltage of BUR1	value Input voltage to BUR1 75% (10%=125V) DC link voltage of BUR1 60% (10%=100V)	value value Input voltage to BUR1 75% (10%=125V) 10 ⊙ 2-V DC link voltage of BUR1 60% (10%=100V) 6 37√

BUR2 (Condition: Switch off all the load of BUR 2, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed value by the firm	Monitored value	Value under Limit (Yes/No)
BUR2 7303-XUUN	Input voltage to BUR2	75% (10%=125V)	10000	709
BUR2 7303-XUUZ1	DC link voltage of BUR2	60% (10%=100V)	6370	leg
BUR2 7303-XUIZ 1	DC link current of BUR2	1% (10%=50A)*	7 Amp	Yey
BUR2 7303-XUILG	Current battery charger of BUR2	3% (10%=100A)*	21 Bm	Yey
BUR2 7303-XUIB1	Current battery of BUR2	1.5%(10%=100A)*	11 Am)	19
BUR2 7303 XUUB	Voltage battery of BUR2	110%(10%=10V)	1104	70

^{*} Readings are dependent upon charging condition of the battery.

BUR3 (Condition: Switch off all the load of BUR 3, Battery Charger on) to be filled by commissioning engineer of the firm.

Signal name	Description of the signal	Prescribed set value by the firm	Monitored value	Value under limit (Yes/No)
BUR3 7303-XUUN	Input voltage to BUR3	75% (10%=125V	100W	Yey
BUR3 7303- XUUZ1	DC link voltage of BUR3	60% (10%=100V)	637	40
BUR3 7303-XUIZ 1	DC link current of BUR3	1% (10%=50A)*	7 Am	Jes
BUR3 7303-XUILG	Current battery charger of BUR 3	3% (10%=100A)*	22 Bm	Tey
BUR3 7303-XUIB1	Current battery of BUR 3	1.5%(10%=100A)*	12/Amp	709
BUR3 7303-XUUB	Voltage battery of BUR 3	110%(10%=10V)	110	Yes

* Readings are dependent upon charging condition of the battery.

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC Page: 20 of 27

5.3.3 Performance of BURs when one BUR goes out

When any one BUR goes out then rest of the two BURs should take the load of all the

tilation level 3 of the locomotive.

Condition of	Loads on BUR1	Loads in BUR2	Loads in BUR3
All BURs OK	Oil Cooling unit	TM blower1&2, TFP oil pump 1&2, SR coolant pump 1&2.	Compressor 1&2, Battery (charger and TM Scavenger blower 1&2
BUR 1 out		Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2,TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 2 out	Oil Cooling unit 1&2, TM blower 1&2, TM Scavenger blower 1&2		Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.
BUR 3 out	Oil Cooling unit 1&2, TM blower1&2, TM Scavenger blower 1&2	Compressor 1&2, TFP oil pump 1&2, SR coolant pump 1&2 and Battery charger.	

5.4 Auxiliary circuit 415/110

For checking earth fault detection, make a connection between wire no. 1218 and vehicle body. On switching on VCB, Earth fault relay 89.5 must pick up and after 3 minutes a message will come in the Diagnostic display that Earth Fault 415/110V Circuit

Switch on the 1 ph. auxiliary equipment one by one. Check the direction of rotation of each auxiliary machine and measure the continuous current and starting current drawn by them.

Name of the auxiliary machine	Typical phase current	Measured phase current	Measured starting current
Machine room blower 1	15.0 amps*	5.3	14.1
Machine room blower 2	15.0 amps*	4.7	10.9
Sc. Blower to MR blower 1	1.3 amps	1,2	1.4
Sc. Blower to MR blower 2	1.3 amps	1.2	1.2
Ventilator cab heater 1	1.1 amps	1.4	1.5
Ventilator cab heater 2	1.1 amps	1.4	1.5
Cab heater 1	4.8 amps	5.8	6.1
Cab heater 2	4.8 amps	5.8	6.1

^{*} For indigenous MR blowers.

Effective Date: Feb 2022

PATIALA LOCOMOTIVE WORKS, PATIALA

(Ref: WI/ECS/10)

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 21 of 27

5.5 Hotel load circuit (Not applicable for WAG-9HC)

For WAP-7 locomotive with Hotel load converter refer to Annexure-HLC

5.6 Traction Converter Commissioning

This test is carried out in association with Firm.

Traction converter commissioning is being done one at a time. For testing Converter 1, switch off the traction converter 2 by switch bogie cut out switch 154. For testing Converter 2, switch off the traction converter 2 by switch bogie cut out switch 154. Isolate the harmonic filter also by switch 160. Start up the loco by one converter. Follow the functionality tests.

For Converter 1		
Test Function	Results desired	Result obtained
Measurement of charging and precharging and charging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	choesed on
Measurement of discharging of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeked ax
Earth fault detection on positive potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	cheeted a
Earth fault detection on negative potential of DC Link of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Cheeked a
Earth fault detection on AC part of the traction circuit of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	charted a
Pulsing of line converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	Charteel &
Pulsing of drive converter of Converter 1	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	choised on

Effective Date: Feb 2022

DOC,NO.F/ECO/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC Page: 22 of 27

For Converter 2		Result obtained
Test Function	Results desired in sequence	Result obtained
charging and pre-	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chelted ou
Measurement of discharging of DC Link of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chocked ou
positive potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chleted ox
Earth fault detection on negative potential of DC Link of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/v	Challed a
AC part of the traction circuit of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chelted a
Pulsing of line converter of Converter 2.	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	charped m
Pulsing of drive converter of Converter 2	Traction converter manufacturer to declare the successful operation and demonstrate the same to the PLW supervisor.	chalked on

Effective Date: Feb 2022

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU

Locomotive No.: $4/95^{\circ}$

Type of Locomotive: WAP-7/WAG-9HC

Page: 23 of 27

5.7 Test protective shutdown SR

Test Function	Results desired in sequence	Result obtained
10301411011011		
Measurement of protective shutdown by Converter 1 electronics.	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 1Check that converter 1 electronics produces a protective shut down. • VCB goes off • Priority 1 fault mesg. on DDU	o charted on
·	appears	
	Disturbance in Converter 1	<u> </u>
Measurement of protective shutdown by Converter 2 electronics.	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Remove one of the orange fibre optic feedback cable from converter 2. Check that converter 2 electronics produces a protective shut down. • VCB goes off • Priority 1 fault mesg. on diagnostic display appears	o charted a
	Disturbance in Converter 2	1

5.8 Test Harmonic Filter

Switch on the filter by switch 160

Test Function	Results desired in sequence	Result obtained
Measurement of filter currents	Start up the loco with both the converter. Raise panto. Close VCB. Move Reverser handle to forward or reverse. Apply a small value of TE/BE by moving the throttle. • FB contactor 8.41 must open.	o charted on

Effective Date: Feb 2022

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 24 of 27

(Ref: WI/ECS/10)

•	·	
	 FB contactor 8.2 must close. FB contactor 8.1 must close Check the filter current in diagnostic laptop Bring the TE/BE throttle to O Switch off the VCB FB contactor 8.1 must open. FB discharging contactor 8.41 must close Check the filter current in diagnostic laptop 	o choesed on
Test earth fault detection harmonic filter circuit.	Make a connection between wire no. 12 and vehicle body. Start up the loco. Close VCB. • Earth fault relay 89.6 must pick up. • Diagnostic message comes that - Earth fault in harmonic filter circuit	o chaeked an
Test traction motor speed sensors for both bogie in both cabs	Traction converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW	or .

5.9 Test important components of the locomotive

Items to be tested	Description of the test	Monitored value/remarks	
Speedometer	VCU converter manufacturer to declare the successful operation and demonstrate the same to the supervisor/ PLW		
Time delay module of MR blower	The time after which the starting capacitor for MR blower should go off the circuit should be set to 10-12 seconds	choesed a	
Ni-Cd battery voltage	At full charge, the battery voltage should be 110V DC.	Cheked on	
Flasher light	From both cab flasher light should blink at least 65 times in one minute.	cheeted as	
Head light	Head light should glow from both cabs by operating ZLPRD. Dimmer operation of headlight should also occur by operating the switch ZLPRD.	Chelted a	

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 4/950

Type of Locomotive: WAP-7/WAG-9HC

Page: 25 of 27

DOC.NO.P/ECS/VI

Marker light	Both front and tail marker light should glow from both the cabs	choeked a
Cab Light	Cab light should glow in both the cabs by operating the switch ZLC	charted
Spot lights	Both Drivers and Asst. Drivers Spot light should glow in both cabs by operating ZLDD	charted of
Instrument lights	Instrument light should glow from both cab by operating the switch ZLI	cheekedou
Illuminated Push	All illuminated push buttons should glow during the operation	cholpelou
Contact pressure of the high rating contactors	The contact pressure of FB contactors (8.1, 8.2) is to be measured Criteria: The minimum contact pressure is 54 to 66 Newton.	For contactor 8.1: For contactor 8.2:
Crew Fan	All crew fans should work properly when VCB of the loco is switched on. The airflow from each cab fan is to be measured. Criteria: The minimum flow of air of cab fan should be 25 m³/minute	Cab 1 LHS: Cab 1 RHS: Cab 2 LHS: Cab 2 RHS:

6.0 Running **Trial of the locomotive**

SN	Description of the items to be seen during trail run	Action which should take place	Remarks
1	Cab activation in driving mode	No fault message should appear on the diagnostic panel of the loco.	Locked o
	Loco charging	Loco to be charged and all auxiliaries should run. No fault message to appear on the diagnostic panel of the loco. Raise MR pressure to 10 Kg/cm ² , BP to 5 Kg/cm ² , FP to 6 Kg/cm ² .	Loekelor
3.	Check function of Emergency push stop.	This switch is active only in activated cab. By pushing this switch VCB should open & pantograph should be lowered.	Lacted
4.	Check function of BPCS.	 Beyond 5 kmph, press BPCS, the speed of loco should be constant. BPCS action should be cancelled by moving TE/BE throttle, by dropping BP below 4.75 Kg/cm², by pressing BPCS again. 	forted on
5.	Check train parting operation of the Locomotive.	Operate the emergency cock to drop the BP Pressure LSAF should glow.	cored

(Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u> <u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 26 of 27

6.	Check vigilance	Set the speed more than 1.5 kmph and ensure that	7
	operation of the	brakes are released i.e. BC < 1 Kg/cm ² .	
Ì	locomotive	For 60 seconds do not press vigilance foot switch or	
		sanding foots switch or TE/BE throttle or BPVG	
		switch then	
	·	 Buzzer should start buzzing. 	
		 LSVW should glow continuously. 	cheepeda
		Do not acknowledge the alarm through BPVG or	
		vigilance foot switch further for 8 seconds then:-	
		 Emergency brake should be applied 	
	,	automatically.	
		 VCB should be switched off. 	
		Resetting of this penalty brake is possible only after	
		32 seconds by bringing TE/BE throttle to 0 and	
		acknowledge BPVR and press & release vigilance	
		foot switch.	
7.	Check start/run interlock	• At low pressure of MR (< 5.6 Kg/cm ²).	cheeked a
		With park brake in applied condition.	- rep
		• With direct loco brake applied (BP< 4.75Kg/cm ²).	9
	٠.	• With automatic train brake applied (BP<4.75Kg/cm ²).	& chocked
		• With emergency cock (BP < 4.75 Kg/cm ²).	
8.	Check traction interlock	Switch of the brake electronics. The	Clare de
		Tractive /Braking effort should ramp down, VCB	CROCCERO
		should open and BP reduces rapidly.	
9.	Check regenerative	Bring the TE/BE throttle to BE side. Loco speed	Charted 6
	braking.	should start reducing.	
10.	Check for BUR	In the event of failure of one BUR, rest of the two	6
	redundancy test at	BURs can take the load of all the auxiliaries. For this	(creetad)
	ventilation level 1 & 3 of	switch off one BUR.	
	loco operation	Auxiliaries should be catered by rest of two BURs.	
4.4		Switch off the 2 BURs; loco should trip in this case.	
11.	Check the power	Create disturbance in power converter by switching	$ \gamma $
	converter	off the electronics. VCB should open and converter	Charged on
,	isolation test	should get isolated and traction is possible with	/
]	another power converter.	\supset

Effective Date: Feb 2022

Doc.No.F/ECS/01 (Ref: WI/ECS/10)

PATIALA LOCOMOTIVE WORKS, PATIALA

<u>Testing & Commissioning Format For 3-Phase Locomotive fitted with</u>
<u>IGBT based Traction Converter, Auxiliary Converter and TCN based VCU</u>

Locomotive No.: 41950

Type of Locomotive: WAP-7/WAG-9HC

Page: 27 of 27

7.0 Final check list to be verified at the time of Loco dispatch

Condition /Operations of the following items are to be checked:

SN	Item	Cab-1	Cab-2	Remarks
1	Head lights	OL	ac O	
2	Marker Red	or_	OX	
3	Marker White	or	OK	
4	Cab Lights	on	OI_	
5	Dr Spot Light	ac	CK	
6	Asst Dr Spot Light	ov_	ac	closted worker
7	Flasher Light	ov	٥	
8	Instrument Lights	Oa	Ch	
9	Corridor Light	Q.	a	
10	Cab Fans	OL .	ay	
11	Cab Heater/Blowers	00_	Ou	
12	All Cab Signal Lamps Panel 'A'	où-	OK_	

Status of RDSO modifications

LOCO NO: 41950

	Manuffication No.	Description	Remarks
Sn	Modification No.		
1.	RDSO/2008/EL/MS/0357 Rev.'0' Dt 20.02.08	Modification in control circuit of Flasher Light and Head Light of three phase electric locomotives.	Ok/Not Ok
2.	RDSO/2009/EL/MS/0377 Rev.'0' Dt 22.04.09	Modification to voltage sensing circuit in electric locomotives.	Ok/Not Ok
3.	RDSO/2010/EL/MS/0390 Rev,'0' Dt 31.12.10	Paralleling of interlocks of EP contactors and Relays of three phase locomotives to improve reliability.	Ök/Not Ok
4.	RDSO/2011/EL/MS/0399 Rev.'0' Dt 08.08.11	Removal of interlocks of control circuit contactors no. 126	Ok/Not Ok
5.	RDSO/2011/EL/MS/0400 Rev.'0' Dt 10.08.11		Ok/Not Ok
6.	RDSO/2011/EL/MS/0401 Rev.'0' Dt 10.08.11		Ok/Not Ok
7.	RDSO/2011/EL/MS/0403 Rev.'0' Dt 30.11.11	Auto switching of machine room/corridor lights to avoid draining of batteries in three phase electric locomotives.	Ok/Not Ok
8.	RDSO/2012/EL/MS/0408 Rev.'0'	Modification of terminal connection of heater cum blower assembly.	Ok/Not Ok
9.	RDSO/2012/EL/MS/0411 Rev.'1' dated 02.11.12	Modification sheet to avoid simultaneous switching ON of White and Red marker light in three phase electric locomotives.	Ok/Not Ok
10	RDSO/2012/EL/MS/0413 Rev.'1' Dt 25.04.16		Ok/Not Ok
11	RDSO/2012/EL/MS/0419 Rev.'0' Dt 20.12.12		Ók/Not Ok
12	RDSO/2013/EL/MS/0420 Rev.'0' Dt 23.01.13	Modification sheet to provide mechanical locking arrangement in Primary Over Current Relay of three phase locomotives.	Ök/Not Ok
13	RDSO/2013/EL/MS/0425 Rev.'0' Dt 22.05.13	· · · · · · · · · · · · · · · · · · ·	Ok/Not Ok
14	RDSO/2013/EL/MS/0426 Rev.'0' Dt 18.07.13		Ok/Not Ok
15	RDSO/2013/EL/MS/0427 Rev. 0' Dt 23.10.13		Ók/Not Ok
16	Rev.'0' Dt 10.12.13	harmonic filter and hotel load along with its resistors in three phase electric locomotives.	Ök/Not Ok
17	Rev.'0' Dt 12.03.14	current relay of three phase electric locomotives.	Ok/Not Ok
18	Rev.'0' Dt 25.09.17	Provision of Auxiliary interlock for monitoring of Harmonic filter ON (8.1)/adoption (8.2) Contactor in GTO/IGBT locomotives.	Ök/Not Ok
19	Rev.'0' Dt 07.12.17	phase electric locomotives.	Ok/Not Ok
20	RDSO/2018/EL/MS/0475 Rev.'0'	Modification in existing Control Electronics (CE) resetting scheme of 3 phase electric locomotives.	Ók/Not Ok

Signature of JE/SSE/ECS

Loco No.: 41950

PLW/PATIALA

PNEUMATIC TEST PARAMETERS OF 3-PHASE ELECTRIC LOCOMOTIVES

(As per DG/RDSO/LKO's letter No.-EL/3.2.19/3phase, dated-29.03.2012)

SN	Parameters	Reference	Value	Result
	Brake Panel: M/s Faiveley			
1.0	Auxiliary Air supply system (Pantograph & VCB)			
1.1	Ensure, Air is completely vented from pantograph			0
	Reservoir (Ensure Panto gauge reading is Zero)			
1.2	Turn On BL Key. Now MCPA starts.		60 sec. (Max.)	58
	Record pressure Build up time (8.0 kg/cm2)			
1.3	Auxiliary compressor safety Valve 23F setting	Faiveley Doc. No.	8.5±0.25kg/cm2	8.6 Kg/cm2
		DMTS-014-1, 8	-	
		CLW's check sheet		
		no. F60.812 Version		
		2		_
1.4	Check VCB Pressure Switch Setting	CLW's check sheet	Opens 4.5±0.15	4.60 Kg/cm2
		no. F60.812 Version	kg/cm2, closes	
		2	5.5±0.15 kg/cm2	5.50 Kg/cm2
1.5	Set pantograph Selector Switch is in Auto, Open pan-1&2 Iso	olating Cocks & KABA co		
1.6	Set Cab-1 Pan UP in Panel A.		Observed Pan-2	ОК
			Rises.	
1.7	Close Pan-2 isolating Cock		Panto-2 Falls Down	ОК
	Open Pan -2 isolating Cock		Panto-2 Rises	
1.8	Record Pantograph Rise time		06 to 10 seconds	8 Sec
1.9	Record Pantograph Lowering Time		06 to 10 seconds	9 Sec
1.10	Panto line air leakage		0.7 kg/cm2 in 5	0.30 kg/cm2
			Min.	in 5 Min.
1.11	High Reach Panto emergency test and reset.			Ok
2.0	Main Air Supply System			
2.1	Ensure, Air is completely vented from locomotive. Drain	Theoretical		
	out all the reservoirs by opening the drain cocks and then	calculation and		
	closed drain cocks. MR air pressure build up time by each	test performed by		
	compressor from 0 to 10 kg/cm2.	Railways.		
	i) with 1750 LPM compressor		i) 7 mins Max.	6 min. & 45
	ii) with 1450 LPM compressor		ii) 8.5 mins Max.	sec.
2.2	Drain air below MR 8 kg/cm2 to start both the		Check Starting of	Ok
2.2	compressors		both compressors	CD1 20 C
2.3	Drain air from main reservoir up to 7 kg/cm2. Start		30 Sec. (Max)	CP1-28 Sec
	compressors, Check pressure build time of individual			CP2-29 Sec
2.4	compressor from 8 kg/cm2 to 9 kg/cm2	DSM tost spec	Classes at 6 4010 15	
2.4	Check Low MR Pressure Switch Setting (37)	D&M test spec. MM3882 &	Closes at 6.40±0.15 kg/cm2 Opens at	6.50 Kg/cm2
		MM3946	5.60±0.15kg/cm2	5.60 Kg/cm2
2.5	Check compressor Pressure Switch RGCP setting (35)	D&M test spec.	Opens at 10±0.20	10.1 Kg/cm2
۷.۵	Check complessor riessure switch rock setting (55)	MM3882 &	kg/cm2 Closes at	10.1 Kg/UII2
		MM3946	8±0.20 kg/cm2	8.1 Kg/cm2
		Trial results	3.5 Minutes Max.	O. I NE/ CITIZ

PLW/PATIALA

Loco No.: 41950

					LOCO NO		
2.7		alve operation time				Approx. 12 Sec.	10 sec
2.8	Check Auto Drain	Valve functioning (12	24 & 87)			Operates when	Ok
						Compressor	
						starts	
2.9	Check CP-I delivery safety valve setting (10/1). Run CP		D&M t	est spec.	11.50±0.35	11.40	
	Direct by BLCP.			& MM3946	kg/cm2	Kg/cm2	
2.10		ry safety valve settin	g (10/2) Run CP	D&M test spec.		11.50±0.35	11.40
2.10	direct by BLCP	if salety valve setting	6 (10/ <i>2)</i> . Null ci		& MM3946	kg/cm2	Kg/cm2
2.11	•	compressors and ensu	ira that the cafety		est spec.	Kg/CIIIZ	Ng/CIII2
2.11		•	•		.est spec. & MM3946		
	1	oressure 1.2 kg/cm2 lo	ess than opening	1011013662	Q 1011013940		
	pressure.	1 /					
2.12		ch 'OFF' compressor,			ck sheet no.	5.0±0.10kg/cm2	5.0 Kg/cm2
		" Main Reservoir, Sta		F60.812 Ve	ersion 2		
		ssure of Duplex Check	Valve 92F.				
2.13	FP pressure:			CLW's chec	ck sheet no.	6.0±0.20kg/cm2	6.0 Kg/cm2
		Test point 107F FPTP.	Open isolate cock	F60.812 Ve	ersion 2		
	136F. Check press	sure in Gauge.					
3.0	Air Dryer Opera	tion					
3.1		90 of 2 nd MR to start	Compressor, leave			Tower to change	Ok
		ck Air Dryer Towers t				i) Every minute	
	'	,	<u> </u>			(FTIL & SIL)	
						ii)every two	
						minute (KBIL)	
3.2	Chack Durge Air S	tops from Air Dryer a	t Compressor stops			minute (RDIL)	
3.3		of humidity indicator	t compressor stops			Blue	Blue
4.0	Main Reservoir Lo	•				Dide	Dide
4.1		د-9) in full service, Che	ack MD Draggura air	D2.M+	ost spec	Should be less	0.30
4.1	· ·	·	eck win Fressure all	D&M test spec. MM3882 & MM3946			
	leakage from botl	n cabs.				than 1 kg/cm2 in	Kg/cm2 in
4.2	CL L DD A: L L	/:	1.70)	50.04.		15 minutes	15 minutes
4.2	Check BP Air leak	age (isolate BP chargi	ng cock-70)		est spec.	0.15 kg/cm2 in 5	0.05
				MM3882 & MM3946		minutes	Kg/cm2 in 5
							minutes
5.0		omatic Brake opera					
5.1	Record Brake Pipe	e & Brake Cylinder pr	essure at Each Step				
	Check proportion	ality of Auto Brake sy	stem		ck sheet no.		
				F60.812	Version 2		
		ı					
	Auto controller	BP Pressure kg/cm2	2		9 & WAG-7)	BC (WAP-5)	
	position		Kg/cm2		Kg/cm2		
		Value	Result	Value	Result	Value	Result
		value	Nesuit	value	Kesuit	value	Nesuit
	Run	5±0.1	5.0 Kg/cm2	0.00	0.00 Kg/ cm2	0.00	_
					0.00 Rg/ CHIZ		
	Intial	4.60±0.1	4.6 Kg/cm2	0.40±0.1	0.40Kg/ cm2	0.75±0.15	-
	Full service	3.35±0.2	3.35 Kg/cm2	2.50±0.1		5.15±0.30	-
	I dii sei vice	J.JJ±0.2		2.5010.1	2.5Kg/ cm2	J. 1J1U.3U	
	Emergency	Less than 0.3	0.25 Kg/cm2	2.50±0.1	2.5Kg/ cm2	5.15±0.30	-
i	1	ĺ	-	1	b/ Ciliz		

PLW/PATIALA

Loco No.: 41950

5.2	Record time to BP pressure drop to 3.5 kg/cm2 Ensure Automatic Brake Controller handle is Full Service from Run	D&M test spec. MM3882 & MM3946	8±2 sec.	8 Sec
5.3	Operate Asst. Driver Emergency Cock,	D&M test spec. MM3882 & MM3946	BP pressure falls to Below 2.5 kg/cm2	ОК
5.4	Check brake Pipe Pressure Switch 69F operates	CLW's check sheet no. F60.812 Version 2	Closes at BP 4.05- 4.35 kg/cm2 Opens at BP 2.85- 3.15 kg/cm2	4.10 Kg/cm2 3.10 Kg/cm2
5.5	Move Auto Brake Controller handle from Running to Emergency BC filling time from 0.4 kg/cm2 i.e. 95% of Max. BC developed WAP5 – BC 5.15 ± 0.3 kg/cm2 apply time WAP7 - BC 2.50 ± 0.1 kg/cm2 WAG9 - BC 2.50 ± 0.1 kg/cm2	D&M test spec. MM3882 & MM3946	4±1 sec. 7.5±1.5 sec. 21±3 sec.	22 sec
5.6	Move Auto Brake Controller handle to full service and BP pressure 3.5 kg/cm2. Move Brake controller to Running position BC Release time to fall BC Pressure up to 0.4 kg/cm2 i.e. 95% of Max. BC developed BC release Time WAP7	D&M test spec. MM3882 & MM3946	17.5±2.5 sec. 52±7.5 sec .	52 sec.
5.7	Move Auto Brake Controller handle to Release, Check BP Pressure Steady at 5.5± 0.2 kg/cm2 time.	CLW's check sheet no. F60.812 Version 2	60 to 80 Sec.	71 Sec
5.8	Auto Brake capacity test: The capacity of the A9 valve in released condition must conform to certain limit in order to ensure compensation for air leakage in the train without interfering with the automatic functioning of brake. * Allow The MR pressure to build up to maximum stipulated limit. * Close brake pipe angle cock and charge brake pipe to 5 kg/cm2 by A-9 (Automatic brake controlling) at run position. * Couple 7.5 dia leak hole to the brake hose pipe of locomotive. Open the angle cock for brake pipe. The test shall be carried out with all the compressors in working condition.	RDSO Motive power Directorate report no. MP Guide No. 11 July, 1999 Rev.1	BP pressure should not fall below 4.0 kg/cm2 with in 60 Sec.	4.50 Kg/cm2
5.9	Keep Auto Brake Controller (A-9) in Full Service. Press Driver End paddle Switch (PVEF)		BC comes to '0'	0
6.0	Direct Brake (SA-9)			
6.1	Apply Direct Brake in Full Check BC pressure WAG9/WAP7 WAP5	CLW's check sheet no. F60.812 Version 2	3.5±0.20 kg/cm2 5.15±0.3 kg/cm2	3.50 Kg/cm2
6.2	Apply Direct Brake, Record Brake Cylinder charging time	D&M test spec. MM3882 & MM3946	8 sec. (Max.)	7 Sec

PLW/PATIALA

Loco No.: 41950

6.3	Check Direct Brake Pressure switch 59 (F)	D&M test spec. MM3882 & MM3946	0.2.±0.1 kg/cm2	0.20 kg/cm2
6.4	Release direct brake & BC Release time to fall BC pressure up to 0.4 kg/cm2		10 -15 Sec.	12 Sec
7.0	Modified System Software (only for CCB)		-NA-	-NA-
7.1	Bail-off de-activated during emergency by any means			
7.2	DPWCS and Non-DPWCS mode enabled	_	Multi Loco	
7.3	TCAS and Non-TCAS mode enabled		Not Yet Launched	Presently
7.4	Penalty brake application deactivated for Fault code 113 (FC 113) and CCB health signal will not drop to avoid loco detention/failure. The Brake Electronics Failure "message will not generate on DDS.	RDSO letter no.	Pressure Setting Needed is 12 kg/sqcm Causing mismatching with standard Pr Setting	not happening in PLW
7.5	CCB health signal logic revised (Now will remain high) for penalty condition occurring with FC 108 due to wrong operation/not affecting operation/ Not a CCB Fault (i.e Both controllers selected as LEAD etc) The Brake electronic failure message will not generate on DDS	EL/3.2.19/3-phase (CCB), dtd 30.01.2023		
7.6	CCB health signal logic for FC 102 (In case of BC request from VCU is more than 90 %-above 9V DC) is changed i.e CCB health signal will not drop for FC 102 which will avoid loco detention/failure. The brake electronic failure message will not generate on DDS.		Could not performed by M/s Knorr	Presently Not happening in PLW
7.7	Booting time for CCB with TCAS/TPM/PTWS/DPWCS mode 15-20 sec. However, in case of absence of either one or both system booting time subsequently increased to 40-50 sec.			
8.0	Sanding Equipment			
8.1	Check Isolating Cock-134F is in open position. Press sander paddle Switch. (To confirm EP valves Operates)		Sand on Rail	Ok
9.0	Test Vigilance equipment : As per D&M test specification			Ok

SAMSHER SINGH BIST Date: 2025.01.28 13:20:46 +05'30'

Digitally signed by SAMSHER SINGH BIST

Signature of SSE/Shop

41950							
		Warranty					
S.No.	Description	PL NO.	QPL /Nos.	Supplier	Sr. no.		
1	Pantograph	29880014(HR), 29880026	2	FAIVELEY, CONTRANSYS	F24-0013/JUN-2024, 14891-07/24		
2	Servo motor	29880026	2	CONTRANSYS	14296-04/24		
3	Air Intake filter Assly	29480103	2	AFI	AFI/OC/646A-08/24, AFI/OC/543B- 06/24		
4	Insulator Panto Mtg.	29810127	8	BHEL	06-2024, 08-2024		
	,	•	MIDDLE RO	OF COMPONENT			
5	High Voltage Bushing	29731021	1	ELECTRANEX	EIPL-5518-06-24		
6	Voltage Transformer	29695028	1	SADTEM	2024-N-669204		
7	7 Vacuum Circuit Breaker 2!		1	SCHNEIDER	226609873-47N2-JUN/24		
8	Insulator Roof line	29810139	9	IEC	04-24, 04-24		
9	Harmonic Filter	29650033	1	RESITECH	05/24/232496/71	AS Per PO/IRS Conditions	
10	Earth Switch	29700073	E	ABSURE Technologies	026 09 24 ES		
11	Surge Arrester	29750052	2	CG POWER & INDUSTRIAL	55136-2023, 56290-2024		
	Γ						
		1		ake Components			
	Air Compressor (A,B)	29511008	2	ELGI	EXFS 923437 -A, EXFS 923431 -B		
	Air Dryer	29162051	1	TRIDENT	LD2-08-0484-24		
14	Babby compressor	25513000	1	CEC	RH 3340-08-24		
15	Air Brake Panel	29180016	1	FAIVELEY	OCT 24-37-WAG9-3688		
16	Contoller (A,B)	29180016	2	FAIVELEY	G24-051 A, G24-059 B		
17	Breakup Valve	29180016	2	FAIVELEY			
18	wiper motor	29162026	4	AUTO INDUSTRY			

SAMSHER Digitally signed by SAMSHER SINGH BIST Date: 2025.01.24 L5:46:34 +05'30' SSE/ABS

PLW/PTA

ELECTRIC LOCO HISTORY SHEET (ECS)

ELECTRIC LOCO NO: 41950 LIST OF ITEMS FITTED BY ECS

RLY: WR

SHED: SBDT

PROPULSION SYSTEM: MEDHA

SN	DESCRIPTION OF ITEM	ITEM PL NO.	ITEM SR. NO	CAB-1/CAB-2	MAKE/SUPPLIER
1	LED Based Flasher Light Cab I & II	29612937	4508	4495	POWER TECH.
2	Led Marker Light Cab I & II	29612925	4240/4267/		KEPCO
3	Cab Heater Cab I & II	29170011	2593	2639	TOPGRIP
4	Crew Fan Cab I & II	29470080	24070189/24070196/	24070186/24070130	KAPSONS
5	Master Controller Cab I	29860015	70:		
6	Master Controller Cab II	29000015	70 ⁻	14	WOAMA
7	Complete Panel A Cab I & II	29178265	1550	1549	KONTACT
3 1	Complete Panel C Cab I & II	29170539	3322	3318	KEPCO/MEDHA
1 1	Complete Panel D Cab I & II	29178265	0569A	0562B	HIND
	Complete Cubicle- F Panel Cab I & II	29178162	AALN/07/2024/12/CFP7/067	AALN/09/2024/03/CFP7/103	AAL
1 1	Speed Ind.& Rec. System	29200040	5267/		LAXVEN
	Battery (Ni- Cd)	29680025	В0	· · · · · · · · · · · · · · · · · · ·	HBL
	Set of Harnessed Cable Complete	29600420			QCPL
14	Transformer Oil Pressure Sensor (Cab-1) (Pressure Sensor Oil Circuit Transformer)	29500047	·		BG INDUSTRIES
15	Transformer Oil Pressure Sensor (Cab-2)				DG INDUSTRIES
16	Transformer Oil Temperature Sensor (Cab-1) (Temperature Sensor Oil Circuit Transformer)	29500035			BG INDUSTRIES
17	Transformer Oil Temperature Sensor (Cab-2)				DO INDOOTTIED
18	Roof mounted Air Conditioner I	20044000	23G3	165	·
19	Roof mounted Air Conditioner II	29811028	24G3		INTEC

SSE/ECS

JE/ECS

		PATIALA LOCOMOTIVE		1/			
		LOCO NO-41950/WA	G-9HC/WR/SBTD		,		
S.No.	Equipment	PL No.	Equipm	ent Serial No.	Mal	ke	
1	Complete Shell Assembly with piping	29171027	Sr. 18,	/27, 09/2024	SELV	ОС	
2	Side Buffer Assly Both Side Cab I	20420050	27, 09/24	Not visible, 08/24	FASP	AEI	
3	Side Buffer Assly Both Side Cab II	29130050	232,08/24	56, 09/24	FASP	FAS	
4	CBC Cab I & II	29130037	112, 07/24	345, 06/23	FASP	FAS	
5	Hand Brake		07/24- 17436		Modified M	Modified Mechwel	
6	Set of Secondry Helical Spring	29045034 29041041				Modified Mechwel	
7	Battery Boxes (both side)	29680013	106, 08/24 87, 08/24		BRITE METALLOY	RITE ME	
8	Traction Bar Bogie I			27, 10/24	КМ	3	
9	Traction Bar Bogie II			08, 10/24	КМ		
10	Centre Pivot Housing in Shell Bogie I side			0, 09/24	ANII	L	
11	Centre Pivot Housing in Shell Bogie II side	29100057		1, 09/24	ANI	L	
12	Elastic Ring in Front in Shell Bogie I side			8, 07/24	AVAD	ЭН	
13	Elastic Ring in Front in Shell Bogie II side	29100010		0, 07/24	AVAD	ЭН	
14	Main Transformer	29731008 for WAG 9 29731057 for WAP-7		BHL11469/19, 2024	cG		
15	Oil Cooling Radiator I		07/2	4, G-24-81	BANCO PRODUCTS PVT L		
16	Oil Cooling Radiator II	29470031		4, G-24-80	BANCO PRODUCTS PVT		
17	Main Compressor I with Motor				EXFS 923431, 09/24 ELG		 ii
1	Main Compressor II with Motor	29511008			EXFS 923437, 09/24 EL		ii .
	Transformer Oil Cooling Pump I				SAMAL HARAND		
	Transformer Oil Cooling Pump II		5607, 05/24		SAMAL HARAND		
	Oil Cooling Blower OCB I		5645, 05/24		PD STEELS		
	Oil Cooling Blower OCB II	29470043	07/24, PDS2407030,				
-	TM Blower I		07/24, PDS2407016, LHP1001496821		PD STEELS		
		29440075		E/TMB/B-028-24	FORCE MOTION TECHNOL		
	TM Blower II			E/TMB/B-034-24	FORCE MOTION TECHNO		
25	Machine Room Blower I	29440105		67, CGLXGCM10921	ACCEL		
	Machine Room Blower II			09.63, 09/24	G.T.R CO(P)LTD		
27	Machine Room Scavenging Blower I	29440129	SM-24.	.07.78, 07/24	G.T.R CO	(P)LTD	
28	Machine Room Scavenging Blower II		SM-24.07.1	5, 07/24(NOT CLR)	G.T.R CC	(P)LTD	
29	TM Scavenging Blower Motor I	29440117	07/24,	ST-24.07.69	G.T.R CO	(P)LTD	
30	TM Scavenging Blower Motor II			, ST-24.07.54	G.T.R CO	(P)LTD	
31	Traction Convertor I			/24, 5633		2	
32	Traction Convertor II		07,	/24, 5634	1		
33	Vehicle Control Unit I	29741075		3872	MED	НА	
34	Vehicle Control Unit II		30	3872 93, 07/24	1		
35	Aux. Converter Box I (BUR 1) Aux. Converter Box 2 (BUR 2 + 3)			93, 07/24	1		
36 37	Axillary Control Cubical HB-1	29171180	08/24, SI	STESALI	TITD		
38	Axillary Control Cubical HB-2	29171192		B2/643/08/2024	KAYSONS ELECTI		
39	Complete Control Cubicle SB-1	29171209		B/23120616	CG		
40	Complete Control Cubicle SB-2	29171210	05/24, SB2/515/05/2024		KAYSONS ELECTI		
41	Filter Cubical (FB) (COMPLETE FILTER CUBICLES)	29480140	KPL/CFC/2407/69		KAPATRONIC		
42	Driver Seats	29171131	PLW B.No-218-10/24-64, 123, 138, 151		AB	ı	
	Transformer oil steel pipes	29230044		ision Spare tools			
43	Conservator Tank Breather	29731057		528, 24-2732	YOGYA ENETR	PRISES	
44	Ballast Assembly (only for WAG-9)	29170163	1 24-00	57,56	AKN		
45		23270203		1027,0737	EVERGREE		
46	Head Light		1	1067,0754	(i)		

NAME SHURMAN SHAP MA SSE/LAS

NAME AND LIT....

NAME Kangu Si JE/LAS

Issue No.: 05 Effective Date: July-2023

DOC NO: F/LAS/Electric Loco CHECK SHEET (Ref: WI/LAS/Elect/01, 02, 03 & 04 & QPL/LAS/Elect. Loco)

Page 1 of 1

पटियाला रेलइंजन कारखाना, पटियाला PATIALA LOCOMOTIVE WORKS, PATIALA **ELECTRIC LOCO CHECK SHEET**

LOCO NO: 41950

Rly: WR

Shed: SBTD

S. No.	ITEM TO BE CHECKED	Specified Value	0	bserved	Valu	е
1.1	Check proper Fitment of Hotel Load Converter & its output contactor.	OK		400		
1.2	Check proper Fitment of MR Blower 1 & 2, MR Scavenging Blower 1 & 2, TM Blower 1 & 2, TMB Scavenging Blower 1 & 2. TM scavenging blower 1 & 2 & Oil Cooling unit.	OK	-	ال	-	
1.3	Check proper of Fitment of oil cooling unit (OCU).	ОК		UZ		
1.4	Check proper Fitment of HB 1 & 2 and its respected lower part on its position.	OK		OAL		
1.5	Check proper Fitment of FB panel on its position	OK		611		
	Check proper Fitment of assembled SB1 & SB2 panel.	OK		01		
1.7	Check proper Fitment of Auxiliary converter 1, 2 & 3-(BUR-1, 2 & 3).	OK		0/		
1.8	Check proper Fitment of Traction converter 1 & 2 (SR-1 & 2).	OK		0	1	
1.9	Check proper fitment, torquing & Locking of Main Transformer bolt.	OK		al	7	
1.10	Check proper fitment of Main compressor both side with the compressor agents with the	OK		Q/		
1.12	Officer proper restrict of Secondary Helical Springs between Posic 9 Chall bank	OK		al.		
1.13	Check proper fitment of Bogie Body Safety Chains.	OK		a)		
	Check proper fitment of Cow catcher.	OK		0/		
1.14	Check coolant level in SR 1 & 2 Expansion Tank.	OK				
1.15	Check Transformer Oil Level in both conservators Tank (Breather Tank).	OK	UL			
1.16	check proper fitment and maintain required gaps from Loco Shell Body of all metallic pipes to avoid any damage during online working of Locomotives	OK	ماد			
1.17	Check proper fitment of both battery box.	OK		ol)	
1.18	Check for any gap between Main Transformer mounting base & Loco Shell.	OK		al-		
1.19	Check proper fitment of Push Pull rod its bolt torquing and fitment of fixing cable. As per Drg No 1209-01-113-001	OK		0/4		
1.20	Secondary Vertical and Lateral Clearance on leveled track at the time of Loco Dispatch. ELRS/TC/ 0082 (Rev 1) dated 17.09.2015	W # 1511	CA	B-1		AB-2
		Vertical-Std :35-60 mm	LP 57	ALP	LP	ALP
1.21	Buffer height: Range (1090, +15,-5)	Lateral Std- 45-50 mm	50	23 28	50 50	20
	Drg No IB031-02002.	1085-1105		L/S		R/S
		mm	FRONT	1100	5	1100
1.22	Buffor Longth: Bongo (644 mm - 24-40 mm - 11 L // - /		REAR	109	7	1090
	Buffer Length: Range (641 mm + 3 to 10 mm with buffer face) Drg No-SK.DL-3430.	641 mm		IJS		R/S
			FRONT	645	_	645
1.23	Height of Rail Guard. (114 mm + 5 mm,-12 mm).		REAR	GY8	$\overline{}$	647
	As per RDSO Pamphlet Important Bogie Clearances of Electric Locomotives.	114 mm + 5		L/S	_	R/S
	Clearances of Electric Locomotives.	mm,-12 mm	FRONT	119		116
1.24	CRC Height: Donne (4000, 145, 5)		REAR	115		111
1.27	CBC Height: Range (1090, +15,-5) Drg No- IB031-02002.	1090, +15	FRONT:	1103		111
	ביא ומסי ו-מבטעב.	-5 mm	REAR:	Ingu		

(Signature of SSE/Elect. Loco)

NAME SHUBMA SMAPA

DATE 26/10/24

(Signature of /JE/Elect Loco)

NAME KARAN SINGL

DATE 26/ 10/24

(Signature of JE/UF)

NAME ANKIT UPPAL

DATE 21)18)24

Loco No. 41950

1. BOGIE FRAME:

BOGIE	FRAME NO	Make	PL No.	PO No. & dt.	Warranty Period
FRONT	SL-164	ECBT	29100677	100360	As per PO/IRS
REAR	SL-28/28	TACPL	29100677	100361	conditions

2. Hydraulic Dampers (PL No.29040012) Make: ESCORT/ESCORT

3. AXLES:

AXLE POSITION NO	1	2	3	4	5	6
MAKE/	PLW	PLW	PLW	PLW	PLW	PLW
S.NO	26732	27029	27174	27660	27378	27568
Ultrasonic Testing	OK	OK	OK	OK	OK	OK

4. WHEEL DISCS NO. AND TYPE & BULL GEAR

AXLE POSITION NO	1	2	3	4	5	6
GEAR END	CNC24-2041	CNC24-2162	CNC24-2093	CNC24-3314	CNC24-3262	CNC24-2989
Make	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
FREE END	CNC24-2047	CNC24-2173	CNC24-2092	CNC24-3315	CNC24-3264	CNC24-2949
Make	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED	IMPORTED
Bull Gear No.	24-B-55	15390	24-B-48	13469	13504	13611
Bull Gear Make	LMS	GGAG	LMS	GGAG	GGAG	GGAG

5. AXLE ROLLER BEARING (CRU) (PL No. 29010020, Warranty: As per PO/IRS conditions)

	AXLE POSITION NO	1	2	3	4	5	6
Gear End	MAKE	NBC	NBC	NBC	NBC	NBC	NBC
	PO NO. & dt	02875	02875	02875	02875	02875	02875
Free	MAKE	NBC	NBC	NBC	NBC	NBC	NBC
End	PO NO. & dt	02875	02875	02875	02875	02875	02875

6. WHEEL DISC PRESSING PRESSURE IN KN: (SPECIFIED 80-105 T)

AXLE POSITION NO	1	2	3	4	5	6
BULL GEAR END	1016 KN	851 KN	842 KN	785 KN	101 T	101 T
FREE END	954 KN	998 KN	1024 KN	885KN	102 T	91 T

Loco No. 41950

7. DIAMETER AFTER PROFILE TURNING: SPECIFIED 1092 + .5 mm - 0 mm

AXLE POSITION NO	1	2	3	4	5	6
DIA IN mm GE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
DIA IN mm FE	1092.5	1092.5	1092.5	1092.5	1092.5	1092.5
WHEEL PROFILE GAUGE (1596±0.5mm)	OK	OK	OK	OK	OK	OK

8. SUSPENSION TUBE & ITS TAPER ROLLER BEARING:

AXLE POSITION NO		1	2	3	4	5	6
S.T. PL 29100288	MAKE	IN	IN	KPE	IN	SDI	SDI
GE Brg. PL 29030110	MAKE	FAG	NBC	NBC	NBC	NBC	NBC
FE Brg. PL 29030110	MAKE	FAG	NBC	NBC	NBC	NBC	NBC

9. GEAR CASE (PL No. 29030018) & BACKLASH:

AXLE POSITION NO	1	2	3	4	5	6
MAKE	TACPL	TACPL	TACPL	KM	TACPL	KM
BACKLASH (0.254 – 0.458mm)	0.300	0.300	0.310	0.300	0.310	0.310

10 A/BOX TO BOGIE FRAME LATERAL CLEARANCES (SPECIFIED 15.0 to 19.0mm):

AXLE POSITION NO	1	2	3	4	5	6
RIGHT SIDE	17.40	18.04	18.52	16.05	15.80	17.40
LEFT SIDE	15.71	18.12	16.42	16.25	16.32	15.68

11. TRACTION MOTOR: (PL No.29940606, Warranty: As per PO/IRS conditions)

AXLE POSITION NO	MAKE	PO No. & Date	S. NO.
1	SAINI	100508	201962403
2	GOVIK	101652	G-241154
3	SAINI	100508	202032403
4	PR	102028	318A24599
5	PR	R 102028	318A24593
6	PR	102028	318A24603

JE/SSE/ Bogie Shop

TOP 12 COSTLIEST ITEMS OF WAG9HC LOCO WITH WARRANTY CONDITIONS AS PER TENDERS

S No	PL No	DESCRIPTION	Warranty Period
1	29741075	IGBT BASED 3-PHASE DRIVE PROPULSION EQUIPMENT	60 months after commissioning or 72 months from date of supply whichever earlier as per special conditions given by CLW
2	29731057	MAIN TRANSFORMER 7775 KVA TYPE LOT 7500 FOR WAP7 3- PHASE ELECTRIC LOCOMOTIVE TO CLW SPECN NO.CLW/ES/3/0660/C	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
3	29171064	COMPLETE SHELL ASSLY (PIPED & PAINTED) FOR WAP-7 LOCO TO CLW SPEC. NO. CLW/MS/3/152 ALT- 8	AS PER IRS CONDITIONS-30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER.
4	29600418	LOCOMOTIVES TO CLW SPECN. NO. CLW/ES/03/646 ALT-NIL WITH DMW REQUIREMENT OF HARNESSED	As per clause no.9 of CLW Specn. CLW/ES/3/0458 & Clause No.10 of CLW SpecnCLW/ES/3/0459. [18 months after commissioning or 20 months from date of supply for single core & 18 months after commissioning or 24 months from date of supply for multi core]

7	29942007	3-PHASE ASYNCHRONOUS TRACTION MOTOR (RESISTANCE RING MECHANICALLY INTERLOCKED TO END PLATE DESIGN ROTOR, SCHEME-II), TYPE 6FRA-6068 FOR WAP-7 ELECTRIC LOCO WITHOUT ACTIVE SPEED SENSOR TO SPECIFICATION NO. 4TMS.096.081 ALT-2 AND STR NO. CLW/2008/3PHTM/STR/0001.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
6	29480140	COMPLETE FILTER CUBICLE ALONG WITH ALL EQUIPMENTS AND CABLING TO DRG./SPEC NO. [1] CLW/ES/3/0193 ALT-F OR LATEST AND CLW DRG. NO. 1209-15-143-004 ALT-10 AND PART DRG./SPEC NO AS PER ANNEXURE-A ATTACHED.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
5	29180016	BRAKE CONTROL SYSTEM INCLUDING DRIVER'S VIGILANCE CONTROL DEVICE TO SET LIST NO.EL29180016.	As per specification no. CLW/MS/3/001 Alt. 16 i.e. the manufacturer is required to guarantee that the brakevalves/equipment work satisfactorily for a period of five (5) years after commissioning. Any equipment/part which failsduring the guarantee period shall be replaced free of cost by the manufacturer. The replaced components shallfurther be under warranty for five (5) years from the date of their fitment and should the replaced components proveunsatisfactory in service, they shall be replaced by modified and improved components by the supplier free of cost.

8	29105146	Bogie Frame Complete for WAP-7 for 3 Phase Co Co Locomotive to CLW specification No. CLW/MS/3/Bogie/003 alt-1 and CLW Drg.No.1209.01.112-202 Alt-Nil	As per clause 16 of Spec.No.CLW/MS/3/Bogie/003 Alt-1. [60 months after commissioning or 72 months from date of supply]
9	29171192	COMPLETE AUXILIARY CUBICLE HB2 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0192 ALT-E OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
10	29171210	COMPLETE CONTROL CUBICLE SB2 ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0195/A ALT-H OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
11	29171209	COMPLETE CONTROL CUBICLE SB1 (PUSH PULL SCHEME COMPLIANT) ALONG WITH ALL EQUIPMENTS AND CABLING (EXCLUDING CONTROL ELECTRONICS) TO CLW SPECN. NO. CLW/ES/3/0194 ALT-G OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.
12	29171180	COMPLETE AUXILIARY CUBICLE HB1 ALONG WITH ALL EQUIPMENTS AND CABLING TO CLW SPEC.NO.CLW/ES/3/0191 ALT-D OR LATEST FOR WAP7 LOCO WITH HOTEL LOAD WITH BARE CUBICLE AS PER CLW SPEC.NO.CLW/MS/3/155 ALT-NIL.	AS PER IRS CONDITIONS OF CONTRACT [i.e. 30 MONTHS FROM THE DATE OF SUPPLY OR 24 MONTHS FROM THE DATE OF COMMISSIONING, WHICHEVER IS EARLIER] WILL BE APPLICABLE.



भारत सरकार GOVERNMENT OF INDIA

रेल मंत्राल्य

PATIALA LOCOMOTIVE WORKS

MINISTRY OF RAILWAYS पटियाला रेलइंजन कारखाना Email: dyceeloco.dmw@gmail.com फैक्स/Fax No.: 0175-2397244

फोर्न/ Phone: 0175- 2396422

मोबाईल: 9779242310 पटियाला, 147003, भारत PATIALA, 147003, INDIA



Date: As signed

(An ISO 9001, ISO 14001, ISO 45001 & ISO 50001, 5S & Green Building certified Organization)

No. PLW/M/ECS/Tech/Kavach

(Through Mail)

Diesel Loco Shed, Sabarmati.

Sr. Div. Mechanical Engineer,

Email: srdmesbi@gmail.com

Sub:- Fitment of KAVACH in three Phase Electric Loco. No. 41950 WAG9-HC.

Ref:- (i). Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 21.08.2023.

(ii).Director General Stds./Electrical/RDSO letter no. EL/0.1.3/3 dated 26.09.2023

In ref. to the above letter's Loco No. 41950 has been dispatched with fittings for implementation of KAVACH system in locomotive at home shed in Zonal Railway. This Loco was dispatched to DLS/SBTD/WR on 13.12.2024. The details of fittings are attached as Annexure-A (pneumatic fittings), Annexure-B (Kavach equipment mounting Brackets) & Annexure-C (Wago with harnessed lay out).

This is for your information & necessary action please.

उप मुख्य विद्युत अभियंता/लोको

प्रतिलिपि:-

CEE/Loco & CEE/D&Q, CMM, CELE/WR:- for kind information please Dy CME/Design, Dy. CMM/Depot: for information & necessary action please WM/LAS, AWM/LFS&ABS, AWM/ECS: for necessary action please

Loco No. 41950

B	1711-1(16)	चित्रसमाव्यक्तिः विभिन्नः	0187
	<u></u>	ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITH VENT	04 nos.
1	29163341	ISOLATING COCK 3/8" (FEMALE) LEGRIS TYPE WITHOUT VENT	02 nos.
		TEE UNION 3/8"X3/8" BRASS FITTINGS	02 nos.
		MALE CONNECTORS 3/8" TUBE OD X 3/8" BSPT, BRASS FITTINGS	09 nos.
		MALE CONNECTORS 1/2" TUBE OD X 1/2" BSPT, BRASS FITTINGS	06 nos.
		FEMALE CONNECTORS (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	01 no.
		MALE CONNECTOR (NYLON TUBE) DIA 6 TUBE X 3/8" BSPP BRASS FITTINGS	03 nos
		FEMALE TEE 3/8" BSPP – BRASS	06 nos
2	29611994	HEX PLUG -3/8" BSPT – BRASS	02 nos
		FEMALE TEE 1/2" BSPP – BRASS	04 nos
		HEX NIPPLE 3/8X3/8" BSPT – BRASS	04 nos
		RED HEX NIPPLE 3/8X1/2" BSPT - BRASS	02 nos
		HEX PLUG – 1/2" BSPT – BRASS	04 nos
		MALE ELBOW CONNECTORS 3/8" TUBE OD X 3/8) BSPT. BRASS FITTINGS	02 nos
3	29170114	Copper Tube OD 9.52mm (3/8") X 1.245 Mm W.T X 6 Mtr	1.2Mtr

AWMABS & LFS

SSE/G/ABS



SN	PL No.	Description of item	Quantity
1.	29611945	Mounting bracket arrangement provided for RF Antenna on the roof top of both driver cabs.	04 nos.
2.		Mounting bracket arrangement provided for GPS/GSM Antenna on the roof top of both driver cabs.	02 nos.
3.		Protection Guards for RFID reader provided behind the cattle guards of both side.	04 nos.
4.		Inspection door with latch provided on the both driver desk covers (LP side) in each cab to access isolation cock.	02 nos.
5.		Cable Entry Plate fitted for routing of cable with RF Antenna & GPS/GSM Antenna bracket.	06 nos.
6.		WAGO bracket fitted in Machine room at back side of SB-1.	01 no.
7.		One circular hole of 80 mm dia. provided in each cabs on LP side behind the driver desk toward the wall for routing of OCIP (DMI) cables.	02 nos.
8.	-	80 mm holes provided on TM1 and TM6 Junction box inspection cover hole for drawing of RFID reader cables.	02 nos.
9.	-	DIN Rail fitted inside the driver desk (LP Side)	02 nos.

AWM/ABS & LFS

SSEIGILFS

Annexure-C

SN	PL No.	Description of item	Quantity
1.	42310301	Flexible conduit size 25mm² provided for RF-1, 2 & GPS Antenna cable layout from CAB-1&2 to Machine room.	06 nos.
2.	29611982	Wago terminals in CAB-1&2 (25 nos. in each CAB).	50 nos.
3.	29611982	Wago terminal in Machine room at back side of SB-1.	75 nos.
4.	-	Harness provided from KAVACH SB to SB-1	07wires
5.	-	Harness provided from KAVACH SB to SB-2	05 wires
6.		Harness provided from KAVACH SB to Pneumatic Panel	12 wires
7.	-	Harness provided from KAVACH SB to CAB-1	16 wires
3.	-	Harness provided from KAVACH SB to CAB-2	16 wires

AWWECS

SSEIGIECS